

# **Avaya Communication Server 1000 Signaling Server IP Line Applications Fundamentals**

© 2011-2016, Avaya, Inc. All Rights Reserved.

#### **Notice**

While reasonable efforts have been made to ensure that the information in this document is complete and accurate at the time of printing, Avaya assumes no liability for any errors. Avaya reserves the right to make changes and corrections to the information in this document without the obligation to notify any person or organization of such changes.

#### **Documentation disclaimer**

"Documentation" means information published in varying mediums which may include product information, operating instructions and performance specifications that are generally made available to users of products. Documentation does not include marketing materials. Avaya shall not be responsible for any modifications, additions, or deletions to the original published version of Documentation unless such modifications, additions, or deletions were performed by or on the express behalf of Avaya. End User agrees to indemnify and hold harmless Avaya, Avaya's agents, servants and employees against all claims, lawsuits, demands and judgments arising out of, or in connection with, subsequent modifications, additions or deletions to this documentation, to the extent made by End User.

#### Link disclaimer

Avaya is not responsible for the contents or reliability of any linked websites referenced within this site or Documentation provided by Avaya. Avaya is not responsible for the accuracy of any information, statement or content provided on these sites and does not necessarily endorse the products, services, or information described or offered within them. Avaya does not guarantee that these links will work all the time and has no control over the availability of the linked pages.

#### Warranty

Avaya provides a limited warranty on Avaya hardware and software. Refer to your sales agreement to establish the terms of the limited warranty. In addition, Avaya's standard warranty language, as well as information regarding support for this product while under warranty is available to Avaya customers and other parties through the Avaya Support website: <a href="https://support.avaya.com/helpcenter/getGenericDetails?detailld=C20091120112456651010">https://support.avaya.com/helpcenter/getGenericDetails?detailld=C20091120112456651010</a> under the link "Warranty & Product Lifecycle" or such successor site as designated by Avaya. Please note that if You acquired the product(s) from an authorized Avaya Channel Partner outside of the United States and Canada, the warranty is provided to You by said Avaya Channel Partner and not by Avaya.

"Hosted Service" means an Avaya hosted service subscription that You acquire from either Avaya or an authorized Avaya Channel Partner (as applicable) and which is described further in Hosted SAS or other service description documentation regarding the applicable hosted service. If You purchase a Hosted Service subscription, the foregoing limited warranty may not apply but You may be entitled to support services in connection with the Hosted Service as described further in your service description documents for the applicable Hosted Service. Contact Avaya or Avaya Channel Partner (as applicable) for more information.

#### **Hosted Service**

THE FOLLOWING APPLIES ONLY IF YOU PURCHASE AN AVAYA HOSTED SERVICE SUBSCRIPTION FROM AVAYA OR AN AVAYA CHANNEL PARTNER (AS APPLICABLE), THE TERMS OF USE FOR HOSTED SERVICES ARE AVAILABLE ON THE AVAYA WEBSITE, HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO UNDER THE LINK "Avaya Terms of Use for Hosted Services" OR SUCH SUCCESSOR SITE AS DESIGNATED BY AVAYA, AND ARE APPLICABLE TO ANYONE WHO ACCESSES OR USES THE HOSTED SERVICE. BY ACCESSING OR USING THE HOSTED SERVICE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE DOING SO (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THE TERMS OF USE. IF YOU ARE ACCEPTING THE TERMS OF USE ON BEHALF A COMPANY OR OTHER LEGAL ENTITY, YOU REPRESENT THAT YOU HAVE THE AUTHORITY TO BIND SUCH ENTITY TO THESE TERMS OF USE. IF YOU DO NOT HAVE SUCH AUTHORITY, OR

IF YOU DO NOT WISH TO ACCEPT THESE TERMS OF USE, YOU MUST NOT ACCESS OR USE THE HOSTED SERVICE OR AUTHORIZE ANYONE TO ACCESS OR USE THE HOSTED SERVICE.

#### Licenses

THE SOFTWARE LICENSE TERMS AVAILABLE ON THE AVAYA WEBSITE, HTTPS://SUPPORT.AVAYA.COM/LICENSEINFO. UNDER THE LINK "AVAYA SOFTWARE LICENSE TERMS (Avaya Products)" OR SUCH SUCCESSOR SITE AS DESIGNATED BY AVAYA, ARE APPLICABLE TO ANYONE WHO DOWNLOADS, USES AND/OR INSTALLS AVAYA SOFTWARE, PURCHASED FROM AVAYA INC., ANY AVAYA AFFILIATE, OR AN AVAYA CHANNEL PARTNER (AS APPLICABLE) UNDER A COMMERCIAL AGREEMENT WITH AVAYA OR AN AVAYA CHANNEL PARTNER. UNLESS OTHERWISE AGREED TO BY AVAYA IN WRITING AVAYA DOES NOT EXTEND THIS LICENSE IF THE SOFTWARE WAS OBTAINED FROM ANYONE OTHER THAN AVAYA, AN AVAYA AFFILIATE OR AN AVAYA CHANNEL PARTNER; AVAYA RESERVES THE RIGHT TO TAKE LEGAL ACTION AGAINST YOU AND ANYONE ELSE USING OR SELLING THE SOFTWARE WITHOUT A LICENSE. BY INSTALLING, DOWNLOADING OR USING THE SOFTWARE, OR AUTHORIZING OTHERS TO DO SO, YOU, ON BEHALF OF YOURSELF AND THE ENTITY FOR WHOM YOU ARE INSTALLING, DOWNLOADING OR USING THE SOFTWARE (HEREINAFTER REFERRED TO INTERCHANGEABLY AS "YOU" AND "END USER"), AGREE TO THESE TERMS AND CONDITIONS AND CREATE A BINDING CONTRACT BETWEEN YOU AND AVAYA INC. OR THE APPLICABLE AVAYA AFFILIATE ("AVAYA").

#### License type(s)

Designated System(s) License (DS). End User may install and use each copy or an Instance of the Software only on a number of Designated Processors up to the number indicated in the order. Avaya may require the Designated Processor(s) to be identified in the order by type, serial number, feature key, Instance, location or other specific designation, or to be provided by End User to Avaya through electronic means established by Avaya specifically for this purpose.

Concurrent User License (CU). End User may install and use the Software on multiple Designated Processors or one or more Servers, so long as only the licensed number of Units are accessing and using the Software at any given time. A "Unit" means the unit on which Avaya, at its sole discretion, bases the pricing of its licenses and can be, without limitation, an agent, port or user, an e-mail or voice mail account in the name of a person or corporate function (e.g., webmaster or helpdesk), or a directory entry in the administrative database utilized by the Software that permits one user to interface with the Software. Units may be linked to a specific, identified Server or an Instance of the Software.

Database License (DL). End User may install and use each copy or an Instance of the Software on one Server or on multiple Servers provided that each of the Servers on which the Software is installed communicates with no more than one Instance of the same database.

CPU License (CP). End User may install and use each copy or Instance of the Software on a number of Servers up to the number indicated in the order provided that the performance capacity of the Server(s) does not exceed the performance capacity specified for the Software. End User may not re-install or operate the Software on Server(s) with a larger performance capacity without Avaya's prior consent and payment of an upgrade fee.

Named User License (NU). You may: (i) install and use each copy or Instance of the Software on a single Designated Processor or Server per authorized Named User (defined below); or (ii) install and use each copy or Instance of the Software on a Server so long as only authorized Named Users access and use the Software. "Named User", means a user or device that has been expressly authorized by Avaya to access and use the Software. At Avaya's sole discretion, a "Named User" may be, without limitation, designated by name, corporate function (e.g., webmaster or helpdesk), an e-mail or voice mail account in the name of a person or corporate function, or a directory entry in the administrative database utilized by the Software that permits one user to interface with the Software.

Shrinkwrap License (SR). You may install and use the Software in accordance with the terms and conditions of the applicable license agreements, such as "shrinkwrap" or "clickthrough" license accompanying or applicable to the Software ("Shrinkwrap License").

#### **Heritage Nortel Software**

"Heritage Nortel Software" means the software that was acquired by Avaya as part of its purchase of the Nortel Enterprise Solutions Business in December 2009. The Heritage Nortel Software is the software contained within the list of Heritage Nortel Products located at <a href="https://support.avaya.com/LicenseInfo">https://support.avaya.com/LicenseInfo</a> under the link "Heritage Nortel Products" or such successor site as designated by Avaya. For Heritage Nortel Software, Avaya grants Customer a license to use Heritage Nortel Software provided hereunder solely to the extent of the authorized activation or authorized usage level, solely for the purpose specified in the Documentation, and solely as embedded in, for execution on, or for communication with Avaya equipment. Charges for Heritage Nortel Software may be based on extent of activation or use authorized as specified in an order or invoice.

#### Copyright

Except where expressly stated otherwise, no use should be made of materials on this site, the Documentation, Software, Hosted Service, or hardware provided by Avaya. All content on this site, the documentation, Hosted Service, and the product provided by Avaya including the selection, arrangement and design of the content is owned either by Avaya or its licensors and is protected by copyright and other intellectual property laws including the sui generis rights relating to the protection of databases. You may not modify, copy, reproduce, republish, upload, post, transmit or distribute in any way any content, in whole or in part, including any code and software unless expressly authorized by Avaya. Unauthorized reproduction, transmission, dissemination, storage, and or use without the express written consent of Avaya can be a criminal, as well as a civil offense under the applicable law.

#### Virtualization

The following applies if the product is deployed on a virtual machine. Each product has its own ordering code and license types. Note that each Instance of a product must be separately licensed and ordered. For example, if the end user customer or Avaya Channel Partner would like to install two Instances of the same type of products, then two products of that type must be ordered.

#### **Third Party Components**

"Third Party Components" mean certain software programs or portions thereof included in the Software or Hosted Service may contain software (including open source software) distributed under third party agreements ("Third Party Components"), which contain terms regarding the rights to use certain portions of the Software ("Third Party Terms"). As required, information regarding distributed Linux OS source code (for those products that have distributed Linux OS source code) and identifying the copyright holders of the Third Party Components and the Third Party Terms that apply is available in the products, Documentation or on Avaya's website at: https:// support.avaya.com/Copyright or such successor site as designated by Avaya. The open source software license terms provided as Third Party Terms are consistent with the license rights granted in these Software License Terms, and may contain additional rights benefiting You, such as modification and distribution of the open source software. The Third Party Terms shall take precedence over these Software License Terms, solely with respect to the applicable Third Party Components to the extent that these Software License Terms impose greater restrictions on You than the applicable Third Party Terms.

The following applies only if the H.264 (AVC) codec is distributed with the product. THIS PRODUCT IS LICENSED UNDER THE AVC PATENT PORTFOLIO LICENSE FOR THE PERSONAL USE OF A CONSUMER OR OTHER USES IN WHICH IT DOES NOT RECEIVE REMUNERATION TO (i) ENCODE VIDEO IN COMPLIANCE WITH THE AVC STANDARD ("AVC VIDEO") AND/OR (ii) DECODE AVC VIDEO THAT WAS ENCODED BY A CONSUMER ENGAGED IN A PERSONAL ACTIVITY AND/OR WAS OBTAINED FROM A VIDEO PROVIDER LICENSED TO PROVIDE AVC VIDEO. NO LICENSE IS GRANTED OR SHALL BE IMPLIED FOR ANY OTHER USE. ADDITIONAL INFORMATION MAY BE OBTAINED FROM MPEG LA, L.L.C. SEE HTTP://WWW.MPEGLA.COM.

#### Service Provider

THE FOLLOWING APPLIES TO AVAYA CHANNEL PARTNER'S HOSTING OF AVAYA PRODUCTS OR SERVICES. THE PRODUCT OR HOSTED SERVICE MAY USE THIRD PARTY COMPONENTS SUBJECT TO THIRD PARTY TERMS AND REQUIRE A SERVICE PROVIDER TO BE INDEPENDENTLY LICENSED DIRECTLY FROM THE THIRD PARTY SUPPLIER. AN AVAYA CHANNEL PARTNER'S HOSTING OF AVAYA PRODUCTS MUST BE AUTHORIZED IN WRITING BY AVAYA AND IF THOSE HOSTED PRODUCTS USE OR EMBED CERTAIN THIRD PARTY SOFTWARE, INCLUDING BUT NOT LIMITED TO MICROSOFT SOFTWARE OR CODECS, THE AVAYA CHANNEL PARTNER IS REQUIRED TO INDEPENDENTLY OBTAIN ANY APPLICABLE LICENSE AGREEMENTS, AT THE AVAYA CHANNEL PARTNER'S EXPENSE, DIRECTLY FROM THE APPLICABLE THIRD PARTY SUPPLIER.

#### Compliance with Laws

You acknowledge and agree that it is Your responsibility for complying with any applicable laws and regulations, including, but not limited to laws and regulations related to call recording, data privacy, intellectual property, trade secret, fraud, and music performance rights, in the country or territory where the Avaya product is used.

#### **Preventing Toll Fraud**

"Toll Fraud" is the unauthorized use of your telecommunications system by an unauthorized party (for example, a person who is not a corporate employee, agent, subcontractor, or is not working on your company's behalf). Be aware that there can be a risk of Toll Fraud associated with your system and that, if Toll Fraud occurs, it can result in substantial additional charges for your telecommunications services

#### Avaya Toll Fraud intervention

If You suspect that You are being victimized by Toll Fraud and You need technical assistance or support, call Technical Service Center Toll Fraud Intervention Hotline at +1-800-643-2353 for the United States and Canada. For additional support telephone numbers, see the Avaya Support website: <a href="https://support.avaya.com">https://support.avaya.com</a> or such successor site as designated by Avaya.

#### Security Vulnerabilities

Information about Avaya's security support policies can be found in the Security Policies and Support section of <a href="https://support.avaya.com/security">https://support.avaya.com/security</a>.

Suspected Avaya product security vulnerabilities are handled per the Avaya Product Security Support Flow (<a href="https://support.avaya.com/css/P8/documents/100161515">https://support.avaya.com/css/P8/documents/100161515</a>).

#### **Downloading Documentation**

For the most current versions of Documentation, see the Avaya Support website: <a href="https://support.avaya.com">https://support.avaya.com</a>, or such successor site as designated by Avaya.

#### **Contact Avaya Support**

See the Avaya Support website: <a href="https://support.avaya.com">https://support.avaya.com</a> for product or Hosted Service notices and articles, or to report a problem with your Avaya product or Hosted Service. For a list of support telephone numbers and contact addresses, go to the Avaya Support website: <a href="https://support.avaya.com">https://support.avaya.com</a> (or such successor site as designated by Avaya), scroll to the bottom of the page, and select Contact Avaya Support.

#### **Trademarks**

The trademarks, logos and service marks ("Marks") displayed in this site, the Documentation, Hosted Service(s), and product(s) provided by Avaya are the registered or unregistered Marks of Avaya, its affiliates, its licensors, its suppliers, or other third parties. Users are not permitted to use such Marks without prior written consent from Avaya or such third party which may own the Mark. Nothing contained in this site, the Documentation, Hosted Service(s) and product(s) should be construed as granting, by implication, estoppel, or otherwise, any license or right in and to the Marks without the express written permission of Avaya or the applicable third party.

Avaya is a registered trademark of Avaya Inc.

All non-Avaya trademarks are the property of their respective owners. Linux $^{\otimes}$  is the registered trademark of Linus Torvalds in the U.S. and other countries.

Chapter 1: New in this release	17
Features	17
Other	17
Revision history	17
Structure	19
Chapter 2: Customer service	22
Navigation	22
Getting technical documentation	22
Getting product training	22
Getting help from a distributor or reseller	22
Getting technical support from the Avaya Web site	23
Chapter 3: Overview	24
Hardware platforms	24
Software installation	
Software delivery	25
Software applications description	25
Line Terminal Proxy Server	26
SIP Line Service	26
SIP and H.323 signaling gateway (Virtual Trunk)	26
Application Server for the Personal Directory, Callers List, and Redial List feature	27
UCM - Common Services	28
System configurations	28
Chapter 4: Description	29
Contents	29
Introduction	29
Digital Signaling Processor resources	29
DHCP server	30
Interworking	31
Required packages	
Fax/Modem pass-through	32
Modem traffic	
Recommendations for Fax configuration in the CS 1000 system	
Typical scenarios	
Recommendations for faxing in a data network	
Configuration for analog line cards connected to faxes	
IP Phone registration on a CS 1000 system	
IP Phone registration	
IP Phone unregistration	
Voice Gateway Media Cards	38

	Media Card 32S	39
	Secure Real-time Transport Protocol	39
	Unsupported products	40
	Signaling and messaging	41
	Signaling protocols	41
	UNIStim	41
	Reliable User Datagram Protocol	41
	ELAN TCP transport	42
	Virtual superloops, Virtual TNs, and physical TNs	42
	Licenses	43
	License limits	44
	Scalability	44
	Redundancy	44
	Administration	45
	Element Manager	45
	Command Line Interface	46
	Overlays	46
Ch	apter 5: Features	47
	Contents	47
	Introduction	48
	Live Dialpad	50
	Diagnostics	50
	Unicode	50
	Language synchronization	51
	Unicode Name Directory	52
	IP Client cookies	55
	e2dsetShow ()	56
	IP Phone Types	56
	Unique TN Types for existing IP Phone models	56
	Automatic IP Phone TN conversion (Flexible Registration)	58
	Manual IP Phone TN conversion	58
	Active Call Failover for IP Phones	59
	Minimum requirements	60
	ACF mode	60
	ACF scenarios	61
	Firmware downloads	
	WLAN Handsets 2210/2211/2212, Avaya 6120/6140 WLAN Handsets	65
	Operating parameters	
	Feature interactions	
	Installation and configuration	72
	Configurable RUDP Time-out and Retries Count	
	Overlay and command modifications	
	Status definitions	73

LD 32 STAT command	. 74
LD 80 TRAC command	. 75
LD 117 STIP ACF command	. 76
Output	. 77
LD 117 STIP ACF in Element Manager	. 77
DSP peg counter for CS 1000E systems	
Enhanced UNIStim Firmware Download for IP Phones	
Operating parameters	. 78
Feature interactions	. 79
System view	. 79
Download maximums	. 82
Immediate and delayed firmware downloads	. 82
Maintenance Mode	. 84
Call Server commands	85
LTPS CLI commands	89
Element Manager	. 92
IP Phone firmware management in Element Manager	. 92
Ethernet Diagnostics in Element Manager	. 92
Maintenance Mode commands in Element Manager	. 96
iset commands in Element Manager	100
Firmware download using UNIStim FTP	
CLI commands	102
NAT Traversal feature	106
Echo Servers	107
Mapping	107
NAT Mapping Keep Alive	108
Mute and Hold considerations	109
NAT and VLAN	110
NAT Traversal and Proactive Voice Quality Management	
Configuring NAT Traversal in Element Manager	
Configuring NAT Traversal in LD 117	112
CLI commands	114
Corporate Directory	118
	118
IP Call Recording	
Enhanced IP Call Recording	119
Feature interactions	121
Identifying the IP Phone	
Administration	122
	123
LD 11	123
LD 20	124
I D 80	124

LD 81	125
LD 83	125
LD 117	125
Examples of STIP output	125
pbxLink connection failure detection	126
Display pbxLink information using Element Manager	127
Display pbxLink information using LD 117 STAT SERV	
IP Phone support	131
Element Manager support	131
Call Statistics collection	132
Counting IP Phones	132
IP Phone Zone Traffic Report 16	134
Programmable line/DN feature keys (self-labeled)	138
Availability	138
Zones	139
Shared Zone	139
Private Zone	139
Resource-sharing for Shared and Private Zones	139
Lack of DSP resources	140
DSP resources and Private Zones	140
Network wide Virtual Office	140
Network Wide Virtual Office and the Network Routing Server	141
Requirements	141
Supported IP Phones	141
Failed password attempt	143
Passwords and IP Phone Registration	143
Virtual Office capabilities	143
Bandwidth Management for Network wide Virtual Office	144
Branch Office and Media Gateway 1000B	144
802.1Q support	145
Configuration of 802.1Q on IP Phones	145
Data Path Capture tool	145
IP Phone firmware	
Default location of firmware files	146
Hardware watchdog timer	
Codecs	147
IP Phone type checking and blocking	147
IP Phone 2002, Avaya 1220 IP Deskphone, and Avaya 1120E IP Dekphone logon	
restrictions	148
IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1210 IP Deskphone, and Avaya	
1110 IP Deskphone logon restrictions	
Enhanced Redundancy for IP Line nodes	
Patch Management	150
Migration from Solid database to MySQI	151

Chapter 6: Personal Directory application	152
Contents	
Introduction	152
Virtual Office	153
Media Gateway 1000B	154
User key for Personal Directory, Callers List, and Redial List	154
Personal Directory	154
Callers List	155
Call log options	156
Redial List	157
IP Phone Application Server configuration and administration	158
Configure the IP Phone Application Server and remote backup	
Personal Directories Server Configuration	
Alarms	163
IP Phone Application Server database maintenance	163
IP Phone Application Server database backup	
Full database recovery	
Selective database recovery for a single user	
Fault clearance	
Password administration	167
Initial password	167
Password guessing protection	168
Forgotten password	
Unicode Name Directory	169
Unicode Name Directory feature restrictions and limitations	169
IP Phones configuration	170
Chapter 7: Codecs	171
Contents	
Introduction	171
Predefined codec table	
Codec selection	172
Codec configuration	
Codec selection in Element Manager	
Codec registration	
Codec registration for IP Phones	
Codec registration for DSPs	
Voice Gateway codec registration	
	177
Codec sorting	177
	179
Codec selection algorithm	179
· · · · · · · · · · · · · · · · · · ·	179
· · · · · · · · · · · · · · · · · · ·	180

Best Bandwidth Codec Selection algorithm	180
Chapter 8: Installation task flow	
Contents	
Introduction	
Before you begin	
Installation summary	
Chapter 9: Signaling Server software installation using Deployment Manager	
Contents	
Introduction	185
Installation Task Flow	
Software Deployment Packages	187
Pre-installation checklist	
Linux Base installation	187
Signaling Server application installation	188
Access UCM	
Element Manager configuration	190
System requirements for Element Manager	190
Configuring the Internet Explorer browser	
Configuring the Mozilla Firefox browser	192
Chapter 10: Signaling Server Software upgrade	193
Contents	
Introduction	
Overview	
Before starting your upgrade	
Signaling Server software upgrade task flow	
Upgrade paths	
Upgrade from Succession 1000 Release 3.0	
Upgrade from CS 1000 Release 4.0	
Upgrade from Communication Server 1000 Release 4.5, 5.0, and 5.5	196
Upgrade from Communication Server 1000 Release 6.0	196
Upgrade procedures	
Chapter 11: Installation and initial configuration of an IP Telephony node	204
Contents	
Introduction	
Installation and configuration procedures	
Equipment considerations	
Required equipment	
Optional equipment	
Install the hardware components	
Voice Gateway Media Card	
Summary of installation steps	
Installing and cabling the Media Card 32-port card	
Voice Gateway Media Card ELAN and TLAN network interfaces	209

	Initial configuration of MC 32S card	211
	Initial configuration of IP Line data	
	Summary of procedures	211
	Configuring IP address for the system active ELNK Ethernet network interface (LD 117)	212
	Configure VoIP bandwidth management zones (LD 117)	212
	Element Manager for Zone Configuration	214
	Configure virtual superloops for IP Phones	215
	Configure IP Phone features in LD 11	216
	Configure the IP Phone Key Expansion Module	218
	Configure the Avaya 1100 Series Expansion Module	
	Configure the Avaya 1200 Series IP Deskphones Expansion Module	222
	Configure the Expansion Module 2050	
	IP Phone dedicated context-sensitive soft keys	
	Node election rules	226
Ch	apter 12: Configuration of IP Telephony nodes using Element Manager	227
	Contents	227
	Introduction	. 227
	Configure IP Line data using Element Manager	228
	Internet Explorer browser configuration	
	Summary of procedures	
	Manually add an IP Telephony node	
	SNMP configuration	
	Configure Voice Gateway Profile data	
	Configure Quality of Service	
	Configure file server access	
	Configure loss and level plan	
	Add card and configure the card properties of the Voice Gateway Media Card	
	Transfer node configuration from Element Manager to the Voice Gateway Media Cards	
	Transmit node properties	
	Upgrade the Voice Gateway Media Card and IP Phone firmware	
	Upgrade procedure steps	
	Upgrade options	
	IP Phone firmware requirements	
	Determine Voice Gateway Media Card software version	
	Download the current loadware and IP Phone firmware	
	Upload the loadware and firmware files to the Signaling Server	
	Upgrade the Voice Gateway Media Card loadware	
	Restart the Voice Gateway Media Card	
	Re-enable the Voice Gateway Media Card	
	Upgrade the IP Phone firmware	
	Assemble and install an IP Phone	
	Change the default IPL CLI Shell password	25 <i>1</i> 257
	Configure the IP Phone Installer Passwords	<b>20</b> /

	Import node configuration from an existing node	257
	Changing the Node ID on an Existing CS 1000 System	258
	Procedure 28: Changing the Node ID on existing CS 1000 system	259
Ch	apter 13: IP Line administration	260
	Contents	260
	Introduction	260
	IP Line feature administration.	261
	Private Zone configuration	262
	Virtual Office	262
	802.1Q	264
	Password security	265
	SNMP community strings	265
	CLI Shell user name and password	265
	Node password synchronization	266
	IP Phone Installer Password	267
	Default user name and password	275
	IP configuration commands	276
	TLAN network interface configuration commands	276
	Display the number of DSPs	
	Display IP Telephony node properties	277
	Display Voice Gateway Media Card parameters	278
	Packet loss monitor	
	Transfer files using the CLI	
	Reset the Operational Measurements file	281
Ch	apter 14: IP Line administration using Element Manager	283
	Contents	283
	Introduction	283
	Element Manager administration procedures	283
	Turn off browser caching	284
	IP Line Operational Measurement report scheduling and generation	284
	Collection period	
	Output	286
	Output example	286
	View Traffic reports	291
	System reports	292
	Customer traffic reports	303
	Backup and restore data	313
	Backup	
	Restore the backed up files	
	Update IP Telephony node properties	
	Add a Voice Gateway Media Card to the node	
	Change the IP addresses of an IP Telephony node in Element Manager	
	Update other node properties	323

	Import or Export an IP Node Configuration File	323
	Telnet to a Voice Gateway Media Card using Virtual Terminal	
	Check the Voice Gateway Channels	326
	Setting the IP Phone Installer Password	326
Ch	apter 15: Numbering Groups	329
	Numbering group attributes	
	Numbering group validation rules	330
	Calling Line Identification Uniform Resource Identifier Generation for Subscriber Telephony	
	Account	330
	CLID/URI Generator	332
	Manage numbering groups	332
	Export numbering groups into a CSV file	333
	Import numbering groups from a CSV file	
	Restore numbering groups	
	Invoke telephony account CLID/URI generation	
	View numbering groups report	335
Ch	apter 16: Corporate Directory	336
	Forming Dialing Prefixes	336
	Corporate Directory prerequisites	338
	Manage Corporate Directory reports	338
	Run the Corporate Directory report	339
	Export Corporate Directory report	341
	Import the Corporate Directory report	342
	View history of the Corporate Directory report	343
	Viewing the history of the Corporate Directory report import	344
	Schedule the Corporate Directory report	344
	Blocking concurrent user operations in Corporate Directory	345
Ch	apter 17: IP Media Services	346
	Contents	346
	Introduction	346
	System architecture	347
	Call Server	348
	Resource selection in mixed deployments	348
	Signaling Server	349
	Resource registration	349
	Avaya Aura® Media Servers	350
	Network Media Services	350
	Service routing	
	Avaya Aura® Session Manager	354
	Bandwidth management	
	System resiliency	355
	Geographic redundancy	355
	Alternate NRS support	356

	High Availability	357
	Security	358
	SIP security	358
	Media Security	
	License requirements for IP Media Services	359
	Configure the license for a dedicated Avaya Aura® MS	360
	Configure the license for an Avaya Aura® MS cluster	
	IP Media Services feature restrictions and limitations	
Ch	apter 18: IP Media Services configuration	364
	Contents.	
	Configure Media Services Routing Number using Element Manager	
	Configure IP Media Services using Element Manager	
	Enable IP Media Services using Element Manager	
	Configure a proxy server using Element Manager	
	Configure a local media server using Element Manager	
	Configure the SIP URI Map using Element Manager	
	Configure the Port Settings using Element Manager	
	Configure IP Attendant Gateway using Element Manager	
	Configure IP Media Services using Avaya Aura ® System Manager	
	Configuring IP Media Services as a SIP entity	
	Configuring the SIP entity link for IP Media Services	
	Configuring Avaya Aura® MS as a SIP entity	
	Configuring the SIP entity link for Avaya Aura® MS	
	Configuring bandwidth management for a Avaya Aura® MS SIP entity	377
	Configuring the Routing Policy and Dial Pattern for Avaya Aura® MS	
	Configuring the Avaya Aura® MS SIP Domain, Trusted Nodes and Routes for IP Media	
	Services	379
	Configure the Avaya Aura® MS media source using Element Manager	382
	Content Store replication	
	Configure Zone and VPNI information using Network Routing Service Manager	385
	Configure support for Avaya Aura® MS clusters	
	Configure survivable IP Tones	388
	Configure the FTC table for IP Tones	
	Configure Music on Hold based on phone type	
Ch	apter 19: Maintenance	
	Contents	
	Introduction	
	IP Line and IP Phone maintenance and diagnostics	
	LD 32	393
	LD 117	394
	TN	396
	Physical TN	396
	Virtual TN	397

	Maintenance commands for the IP Phone	397
	IDU command	. 398
	IP Line CLI commands	. 399
	Protocol trace tool commands for the Network Connection Service	399
	IP Media Services CLI commands	401
	Syslog commands	401
	Maintenance commands	402
	Lamp Audit function	. 403
	Network Signaling Diagnostics	403
	Troubleshoot an IP Phone installation	403
	Maintenance telephone	. 403
	Faceplate maintenance display codes	. 404
	System error messages	406
	Voice Gateway Media Card self-tests	. 410
	Replace the Media Card CompactFlash	410
Ch	apter 20: Voice Gateway Media Card maintenance using Element Manager	411
	Contents	. 411
	Introduction	. 411
	Replace a Voice Gateway Media Card	411
	Verify Voice Gateway Media Card loadware	412
	Add another Voice Gateway Media Card	412
	Access CLI commands from Element Manager	. 413
Αp	pendix A: NAT router requirements for NAT Traversal feature	
•	Contents	
	Description	
	Requirements	
	Cone NAT	
	Time-out configuration	416
	Hairpinning	
	Unidirectional packet flow	
	Firmware versions	418
	Natcheck output	
Αp	pendix B: I/O, maintenance, and extender cable description	
•	Contents	
	Introduction	
	NTMF94EA I/O cable	
	Connector pin assignments	
	Prevent ground loops on connection to external customer LAN equipment	
	NTAG81CA maintenance cable description	
	NTAG81BA maintenance extender cable	
	Replace the NT8D81BA cable	
	Tools list	
	Remove the NT8D81BA cable	427

Install the NT8D81AA cable	428
Appendix C: Product integrity	429
Contents	
Introduction	429
Reliability	429
Mean Time Between Failures (MTBF)	
Voice Gateway Media Card power consumption	430
Environmental specifications	430
Appendix D: Subnet Mask Conversion from CIDR to Dotted Decimal Format	432
Introduction	

## **Chapter 1: New in this release**

The following sections describe what's new for Signaling Server IP Line Applications Fundamentals for Avaya Communication Server 1000 (Avaya CS 1000) Release 7.6.

- Features on page 17
- Other on page 17

## **Features**

There are no new features for Signaling Server in Communication Server CS 1000 Release 7.6.

## **Other**

## **Revision history**

December 2016	Standard 04.11. This document is up-issued for updates to "Run Corporate Directory report section".
June 2016	Standard 04.10. This document is up-issued for updates related to supported web browsers.
September 2015	Standard 04.09. This document is up-issued for updates related to Virtual Office and the Personal Directory application.
December 2014	Standard 04.08. This document is up-issued to include updates to the Run Corporate Directory report section.
September 2014	Standard 04.07. This document is up-issued to include updated procedure for changing the Node ID on existing CS 1000 system.
June 2014	Standard 04.06. This document is up-issued to include content that supports Avaya Aura® Media Server Release 7.6 for IP Media Services feature.
November 2013	Standard 04.05. This document is up-issued to include updates regarding Common Server R2.

Table continues...

	Browser support changes.
October 2013	Standard 04.04. This document is up-issued to include updates to the Corporate Directory chapter. Updated Added Run Corporate Directory report, Schedule Corporate Directory report, and modified other procedures.
June 2013	Standard 04.03. This document is up-issued to include updates to the IP Media Services and IP Media Services configuration chapters.
May 2013	Standard 04.02. This document is up-issued to include updates to the IP Media Services chapter.
March 2013	Standard 04.01. This document is up-issued to support Avaya Communication Server 1000 Release 7.6.
May 2012	Standard 03.12. This document is up-issued to include updated terminology.
April 2012	Standard 03.11. This document is up-issued to include additional information in the IP Network-wide Virtual Office section.
March 2012	Standard 03.10. This document is up-issued to include updates to support Communication Server 1000 Release 7.5.
October 2011	Standard 03.09. This document is up-issued to include an update to the procedure for generating Corporate Directory reports.
August 2011	Standard 03.07 and 03.08. This document is up-issued to support the removal of content for outdated features, hardware, and system types as well as to include an update to the Synchronize IP Nodes procedure. A note was added that users might have to log off the Call Server if no extra TTYs are available.
June 2011	Standard 03.05 and 03.06. This document is up-issued to add recommendations for fax configurations and changes to the TN_TYPE for the 6120 and 6140 WLAN Handsets for the Communication Server 1000 Release 7.5 as well as an update to the VGMC loadware upgrade procedure.
March 2011	Standard 03.04. This document is up-issued to add missing information regarding configuring a node on an existing CS 1000 system for Communication Server 1000 Release 7.5.
January 2011	Standard 03.03. This document is up-issued to support Communication Server 1000 Release 7.5.
November 2010	Standard 03.01 and 03.02. This document is up-issued to support Communication Server 1000 Release 7.5.
June 2010	Standard 02.01. This document is up-issued to support Communication Server 1000 Release 7.0.
February 2010	Standard 01.04. This document is up-issued to support Communication Server 1000 Release 6.0.
June 2009	Standard 01.03. This document is up-issued to support Communication Server 1000 Release 6.0.
May 2009	Standard 01.01 and 01.02. This document is up-issued to support Communication Server 1000 Release 6.0.

#### **Structure**

#### Legacy products and releases

This document contains information about systems, components, and features that are compatible with Avaya Communication Server 1000 software. For more information about legacy products and releases, see <a href="https://www.avaya.com">www.avaya.com</a>.

#### Related information

The following documents are referenced in this document:

- Converging the Data Network with VoIP Fundamentals, NN43001-260
- Transmission Parameters Reference, NN43001-282
- Branch Office Installation and Commissioning, NN43001-314
- WLAN IP Telephony Installation and Commissioning, NN43001-504
- Emergency Services Access Fundamentals, NN43001-613
- Element Manager System Reference—Administration, NN43001-632
- Unified Communication Management Fundamentals, NN43001-116
- IP Deskphones Fundamentals, NN43001-368
- Software Input Output Reference—System Messages, NN43001-712
- Avaya Communication Server 1000M and Meridian 1 Large System Planning and Engineering, NN43021-220
- Communication Server 1000M and Meridian 1 Large System Maintenance, NN43021-700
- Communication Server 1000E Planning and Engineering, NN43041-220
- IP Phone 2001 User Guide, NN43115-102
- IP Phone 2002 User Guide, NN43116-104
- IP Phone 2004 User Guide, NN43117-102
- Avaya 2007 IP Deskphone User Guide, NN43118-100
- Avaya 2033 IP Conference Phone User Guide, NN43111-100
- Avaya 2050 IP Softphone User Guide, NN43119-101
- Mobile Voice Client 2050 User Guide, NN43119-103
- Avaya 1110 IP Deskphone User Guide, NN43110-101
- Avaya 1120E IP Deskphone User Guide, NN43112-103
- Avaya 1140E IP Deskphone User Guide, NN43113-106
- Avaya 1150E IP Deskphone User Guide, NN43114-100
- Avaya 1165E IP Deskphone User Guide, NNNN43101-102

- IP Phone Key Expansion Module User Guide, NN43119-102
- Avaya 1100 Series Expansion Module User Guide, NN43130-101
- Avaya 1210 IP Deskphone User Guide, NN43140-101
- Avaya 1220 IP Deskphone User Guide, NN43141-101
- Avaya 1230 IP Deskphone User Guide, NN43142-101
- Avaya 1200 Series IP Deskphones Key Expansion Module User Guide

#### Conventions

In this document, the following systems are referred to generically as system:

- Communication Server 1000E (CS 1000E)
- Communication Server 1000M (CS 1000M)

In this document, the following hardware is referred to generically as Media Gateway:

- Option 11C Mini Chassis (NTDK91) and Expander chassis (NTDK92) legacy hardware
- Option 11C Cabinet (NTAK11) legacy hardware
- MG 1000E Chassis (NTDU14) and Expander chassis (NTDU15)
- MG 1010 Chassis (NTC310)
- IPE module (NT8D37) with MG XPEC card (NTDW20)

In this document, the following hardware platforms are referred to generically as Server:

- · Call Processor Pentium IV (CP PIV) card
- Common Processor Pentium Mobile (CP PM) card
- Common Processor Media Gateway (CP MG) card
- · Common Processor Dual Core (CP DC) card
- Commercial off-the-shelf (COTS) servers:
  - IBM x360m server (COTS)
  - HP DL320 G4 server (COTS)
  - IBM x3350 server (COTS2)
  - Dell R300 server (COTS2)
  - HP DL360 G7 (Avaya Common Server)
  - HP DL360p G8 (Avaya Common Server R2)

In this document, the following cards are referred to generically as Gateway Controller:

- Media Gateway Controller (MGC) card (NTDW60 and NTDW98)
- Media Gateway Extended Peripheral Equipment Controller (MG XPEC) card (NTDW20)
- Common Processor Media Gateway (CP MG) card (NTDW56 and NTDW59)

The following table shows supported roles for common hardware platforms:

Table 1: Hardware platform supported roles

Hardware platform	VxWorks Server	Linux Server	Co-res CS and SS	Gateway Controller
CP IV	yes	no	no	no
CP PM	yes	yes	yes	no
CP DC	no	yes	yes	no
CP MG	no	no	yes (see note)	yes (see note)
MGC	no	no	no	yes
MG XPEC	no	no	no	yes
COTS1	no	yes	no	no
COTS2	no	yes	yes	no
Common Server	no	yes	yes	no
Common Server R2	no	yes	yes	no

#### Note:

The CP MG card functions as a Server and the Gateway Controller while occupying slot 0 in Media Gateway.

For information about CP MG, see *Linux Platform Base and Applications Installation and Commissioning, NN43001-315.* 

In this document, the following terms apply:

- On systems where System Manager is available, the term UCM in the documentation refers to UCM in System Manager. On systems where System Manager is not available, the term UCM in the documentation remains unchanged.
- On systems where System Manager 6.2 is available, the term Subscriber Manager in the documentation refers to User Profile Management in System Manager; on systems where System Manager 6.1 is available, the term Subscriber Manager refers to Subscriber Manager in System Manager. On systems where System Manager is not available, the term Subscriber Manager in the documentation remains unchanged.
- On systems where Session Manager is available, the term NRS in the documentation refers to Session Manager. On systems where Session Manager is not available, the term NRS in the documentation remains unchanged.

## **Chapter 2: Customer service**

Visit the Avaya Web site to access the complete range of services and support that Avaya provides. Go to <a href="https://www.avaya.com">www.avaya.com</a> or go to one of the pages listed in the following sections.

## **Navigation**

- Getting technical documentation on page 22
- Getting product training on page 22
- Getting help from a distributor or reseller on page 22
- Getting technical support from the Avaya Web site on page 23

## **Getting technical documentation**

To download and print selected technical publications and release notes directly from the Internet, go to <a href="https://www.avaya.com/support">www.avaya.com/support</a>.

## **Getting product training**

Ongoing product training is available. For more information or to register, go to <a href="www.avaya.com/support">www.avaya.com/support</a>. From this Web site, locate the Training link on the left-hand navigation pane.

## Getting help from a distributor or reseller

If you purchased a service contract for your Avaya product from a distributor or authorized reseller, contact the technical support staff for that distributor or reseller for assistance.

## Getting technical support from the Avaya Web site

The easiest and most effective way to get technical support for Avaya products is from the Avaya Technical Support Web site at <a href="https://www.avaya.com/support">www.avaya.com/support</a>.

## **Chapter 3: Overview**

This document describes the functional and operational characteristics of IP Line applications, and associated features, in Avaya Communication Server 1000 (Avaya CS 1000). It also describes how to install, configure, administer and maintain an IP Telephony node.

The IP Line applications manage IP Phone signaling, Session Initiation Protocol (SIP) gateway signaling, H.323 gateway signaling, Personal Directory, and IP Peer Networking, in Avaya CS 1000E and Avaya CS 1000M systems.

## Hardware platforms

#### Server cards

- Common Processor Pentium Mobile (CP PM)
- Common Processor Dual Core (CP DC)
- Common Processor Media Gateway (CP MG) 32
- Common Processor Media Gateway (CP MG) 128

The Server cards can host a Co-resident Call Server and Signaling Server configuration. For more information, see *Co-resident Call Server and Signaling Server Fundamentals*, *NN43001-509*.

#### **COTS Servers**

- IBM x306m (COTS1)
- HP DL320-G4 (COTS1)
- IBM x3350 (COTS2)
- DELL R300 (COTS2)
- HP DL360 G7 (Avaya Common Server)
- HP DL360p G8 (Avaya Common Server R2)

In this document, the generic term COTS refers to all COTS servers. The term COTS1 or COTS2 refers to the specific servers in the preceding list.

The CP PM and CP DC platforms are circuit cards hosted in Media Gateway slots in CS 1000E systems or in slots of Universal Equipment Modules (UEM) in CS 1000M SG and CS 1000M MG systems. The CP MG platform is a circuit card and is hosted in slot 0 of a Media Gateway in CS 1000E systems.

The other platforms are commercial off-the-shelf (COTS) servers. For more information about the platforms, and instructions to install, see *Linux Platform Base and Applications Installation and Commissioning, NN43001-315*.

All hardware platforms have an ELAN and a TLAN network interface. The IP Line applications communicate with the system Call Processor through the system ELAN subnet.

## Software installation

IP Line applications are deployed to a Linux-based Signaling Server (hardware platform) from the Primary Security Server in the CS 1000 system by using the Deployment Manager tool in the Unified Communications Management (UCM) application. This is known as Central Deployment.

You can also deploy IP Line applications to a Linux-based Signaling Server by using the Deployment Manager tool on the local Signaling Server. This is known as Local Deployment. Local Deployment allows a hardware platform to be initialized prior to joining the primary security domain.

Local Deployment and Central Deployment require that all IP Line application software be copied to the Signaling Server prior to the software deployment. In effect, the Signaling Server acts as the Primary Security Server and deploys IP Line applications software to itself.

## Important:

Avaya recommends that you deploy IP Line applications from the Primary Security Server (Central Deployment) to ensure application consistency on all hardware platforms targeted to host IP Line applications in your CS 1000 system.

You can install IP Line applications on more than one Signaling Server in CS 1000E and CS 1000M systems to provide a load-sharing, redundant configuration for high scalability and enhanced reliability. See <u>Redundancy</u> on page 44.

## Software delivery

IP Line software is deployed using Deployment Manager. For more information, see *Linux Platform Base and Applications Installation and Commissioning*, *NN43001-315*.

## Software applications description

A Signaling Server provides a signaling interface to the IP network using the following software applications:

- · Line Terminal Proxy Server
- SIP signaling gateway

- H.323 signaling gateway
- Application Server for the Personal Directory (Unicode Directory), Callers List, and Redial List features
- UCM common services

## **Line Terminal Proxy Server**

The Line Terminal Proxy Server (LTPS) application is the signaling interface for IP Phones. The LTPS application runs on the primary Signaling Server and the Signaling Servers added to the network for load balancing and redundancy. Each instance of the LTPS application supports a maximum of 5000 IP Phones.

With the Call Server, the LTPS delivers a full suite of telephone features. If the Signaling Server is co-resident with the Call Server, the maximum number of IP Phones is 1000. For more information, see *Co-resident Call Server and Signaling Server Fundamentals, NN43001-509*.

The Unified Network IP Stimulus protocol (UNIStim) is the stimulus-based protocol used for communication between IP Phones and the LTPS. The LTPS also manages the firmware for all connected IP Phones.

For a list of all support Avaya IP Deskphones, see IP Phones Fundamentals, NN43001-368.

Phase 2 IP Phones support all CS 1000 Release 7.0 and higher features. Phase 1 IP Phones do not.

You can configure each IP Phone through the Dynamic Host Configuration Protocol (DHCP) to register with a Call Server for feature control. For more information, see <u>DHCP server</u> on page 30.

## **SIP Line Service**

The SIP Line Service fully integrates Session Initiation Protocol (SIP) endpoints in the CS 1000 system and extends CS 1000 telephony features to SIP IP Phones. Signaling Server software includes the SIP Line Service.

## SIP and H.323 signaling gateway (Virtual Trunk)

The Virtual Trunk application manages the SIP and H.323 signaling gateways on the system.

## **Session Initiation Protocol trunking**

Session Initiation Protocol (SIP) is a signaling protocol for creating, modifying, and terminating sessions with one or more participants. These sessions can include IP Phone calls, multimedia distribution, and multimedia conferences. Basic SIP connectivity, referred to as SIP trunking, provides a direct media path between users in a network.

The SIP trunking software functions as

- SIP User Agent
- signaling gateway for all SIP Phones

SIP trunking provides a direct media path between users in a network. The maximum number of SIP Trunks is 3700.

For more information about SIP trunking, see *IP Peer Networking Installation and Commissioning, NN43001-313* and *Network Routing Service Fundamentals, NN43001-130*.

#### H.323 trunking

H.323 is a standard that specifies the components, protocols, and procedures that provide multimedia communication services over packet networks.

The H.323 signaling software (Virtual Trunk) provides the industry-standard H.323 signaling interface to H.323 gateways. It supports both en bloc and overlap signaling. This software uses an H.323 Gatekeeper to resolve addressing for systems at various sites.



For overlap signaling to provide the maximum benefit, Avaya highly recommends that all Signaling Servers in the network be overlap-enabled. Failure to do so results in call-completion delays caused by converting between overlap and en bloc.

The H.323 gateway supports direct, end-to-end voice paths using Virtual Trunks with the following benefits:

- elimination of multiple IP Telephony to circuit-switched conversions
- improved voice quality
- · simplified troubleshooting
- interoperability

For more information about H.323 signaling, see *IP Peer Networking Installation and Commissioning, NN43001-313* and *Network Routing Service Fundamentals, NN43001-130*.

## Application Server for the Personal Directory, Callers List, and Redial List feature

The Application Server for the Personal Directory, Callers List, and Redial List features (IP Phones Application Server) runs on the Signaling Server. Only one database can exist in the network; redundancy is not supported. The IP Phones Application Server database can coexist with the other software applications on a Signaling Server. However, if you have more than 1000 users, Avaya recommends that you store the database on a dedicated Signaling Server (preferably a Follower). The IP Phones Application Server cannot be run on a Signaling Server at a branch office.

You can configure a standalone PD server. You can create a node for the PD where LTPS and VTRK applications are disabled.

#### **UCM - Common Services**

The following UCM common services are supported in CS 1000:

- Security server: Security Services enables element and service management applications to access a common application security infrastructure. The framework manages secure access to Web applications and provides security for Web interfaces and Web utilities.
- Element Manager: Element Manager is a Web interface that provides an alternative to the traditional CLI and overlays.
- Deployment Manager: Linux platform uses Centralized Deployment Manager (CDM) to remotely deploy application software from the primary security server to other Linux servers located in the same security domain.
- Subscriber Manager: Subscriber Manager is deployed as a plug-in application above the UCM framework. Subscriber Manager provides a centralized location for the management of subscriber information for enterprise services. With Subscriber Manager, users can easily manage subscribers and subscriber accounts (phone services) within a network.

## System configurations

Although you can use IP Line applications in various system configurations and the use can vary in those configurations, support is available for two basic system configurations in CS 1000. See <u>Table</u> 2: Possible system configurations on page 28.

Avaya Communication Server 1000 systems have a Signaling Server in the network configuration. The Signaling Server is a server that provides signaling interfaces to the IP network. The Signaling Server central processor drives the signaling for IP Phones and IP Peer networking.

The LTPS runs on the Signaling Server. Avaya IP Deskphones or redirect supported IP Phones list register with the Signaling Server.

**Table 2: Possible system configurations** 

System	Signaling Server applications present		
CS 1000E	Yes		
CS 1000M	Yes		

## **Chapter 4: Description**

### **Contents**

This chapter contains the following topics:

- Introduction on page 29
- Interworking on page 31
- Required packages on page 32
- Fax Modem pass-through on page 32
- Recommendations for Fax configuration in the CS 1000 system on page 35
- Voice Gateway Media Cards on page 38
- Virtual superloops, Virtual TNs, and physical TNs on page 42
- <u>Licenses</u> on page 43
- Administration on page 45

## Introduction

The IP Line application provides an interface that connects IP Deskphones to an Avaya Communication Server 1000 (CS 1000) Call Server. Avaya CS 1000 requires a Signaling Server. This chapter provides a description of the IP Line application.

## Important:

The IP Line version of software must match the Call Server version.

Voice Gateway Media Cards cannot run IP Line application software.

## **Digital Signaling Processor resources**

Digital Signal Processor (DSP) resources provide DSP ports to connect IP and Time Division Multiplexing (TDM) devices in a Media Gateway. DSP resources can be provided by the Media

Gateway Controller (MGC) card DSP daughterboards, the Common Processor Media Gateway (CPMG) 32, the CP MG 128, and Voice Gateway Media Cards.

- · 32 port daughterboard
- · 96 port daughterboard
- · 128 port daughterboard

The CP MG card is available with 32 or 128 DSP ports.

A Gateway Controller with DSP resources can provide an optional solution to installing many Voice Gateway Media Cards in a Media Gateway. However, support for Voice Gateway Media Cards remains available to add additional DSP resources to a Media Gateway. The MGC is only used in a Media Gateway chassis, cabinet, or in an MG 1010.

Speech path delay can occur when DSP resources are involved in call scenarios with a modified speech path. This affects IP-TDM calls combined with the following features:

- · Conferencing
- ACD Observe
- Call monitoring
- OVR Override
- · BKIN Break-In
- QPR QSIG Path Replacement
- TRO Trunk Route Optimization
- ROP Route Optimization
- · EES End to End Signaling

The delay sums up from a time required to close used channel, to fill in ARP header for new channel and a time required to bring the DSP in working mode on a micro-engine level. The delay depends on the Media Card type and on the number of DSP resources that are taken in any given call scenario. The more DSP resources involved the more open/close pairs need to be processed, increasing the delay. The longest possible delay is up to 3 seconds for MC/ITG cards, up to 1 second for MGC/MS32S cards.

For more information about Voice Gateway Media Cards, see <u>Voice Gateway Media Cards</u> on page 38.

For more information about Gateway Controller DSP resources, see *Avaya Communication Server* 1000E Installation and Commissioning, NN43041-310.

#### **DHCP** server

A Dynamic Host Configuration Protocol (DHCP) server can be used to provide the required information so that the IP Phone network connection can connect to the Line Terminal Proxy Server (LTPS).

For more information about DHCP, see *Converging the Data Network with VoIP Fundamentals, NN43001-260* and *IP Phones Fundamentals, NN43001-368*.

## Interworking

The IP Phone uses the IP network to communicate with the LTPS and the optional DHCP server. Figure 1: System architecture on page 31 shows a diagram of the system architecture.

#### CS 1000: The Big Picture CTI Applications Unified Messaging (TR/87, MLS, AML) CallFilot, Microsoft Finance / Trade Property Exchange 2007 UM, Turrets Management SOA / Web Services IBM WYR UM System HMS 4bo Call Accounting ACE SIP, H.323, PRI, T1, NMC Center MCS 5100 / Converged Desktop Microsoft OCS Integration / CS 1000 Consoles onverged Office Clients UCM System and User Features, ... Reliability / Redundancy, QoS, Security, Mobility ESA/911, Military, Analog IBM Sametime Integration

Figure 1: System architecture

## Required packages

IP Phones require the software packages listed in <u>Table 3: Required packages</u> on page 32.

Table 3: Required packages

Package mnemonic	Package number	Package description	Package type (new, existing, or dependency)	Applicable Market
DSET	88	M2000 Digital Sets	Existing	All
ARIE	170	Aries Digital Sets	Existing	All

#### Important:

To configure IP Line in groups five to seven on Option 81C or CS 1000M MG, you need the Fiber Network (FIBN) software package 365.

## Fax/Modem pass-through

The Fax/Modem pass-through feature provides a modem pass through allowed (MPTA) class of service (CoS) for an analog phone TN. MPTA CoS dedicates an analog phone TN to a modem or a fax machine terminal. A connection that initiates from the dedicated TN or calls that terminate at the dedicated TN through a Digital Signal Processor (DSP), use a G.711 NO VAD codec on the Call Server.

Modem pass-through is a specific configuration of a G.711 VoIP channel that improves modem performance compared to standard VoIP configuration. Automatic switching to Voice Band Data (VBD) is a feature of the DSP; the DSP monitors the data stream to distinguish between voice and data calls. The DSP reconfigures to modem pass through mode when it determines the call is a modem call.

The DSP mode on the Mindspeed DSP (MC32S/DB96/DB32) for MPTA to MPTA fax or modem calls displays ModemPT in the dspMode field of the vgwShow command. The Telogy DSP (ITGSA) displays PassThrough.

For modem calls between CS 1000 systems connected by analog and digital trunks, you must configure MPTA CoS on the Call Server of each CS 1000 system for analog units connected to modems. MPTA CoS configuration is necessary because the call setup negotiation does not occur end to end as it is for virtual trunks. If the analog unit on one Call Server uses MPTA CoS and the analog unit on the other Call Server uses modem pass through denied (MPTD) CoS, the modem call fails.

When you configure MPTA CoS on a TN, support is no longer available for the T.38 protocol for that particular TN. Any call setup with an analog phone TN that has MPTA configured must use G.711 codec exclusively, as this is the only codec available for making calls using this TN. G.711 codec exists by default in the DSP configuration.

To ensure the MPTA CoS works correctly, you must select the Enable Modem/Fax pass-through mode check box in the Gateways section of Element Manager. This check box is selected by default in Element Manager. To enable SG3 fax calls over Telogy DSP, you must select the Enable V.21 FAX tone detection check box in Element Manager must. For SMC and MC32S cards, this setting is available in the codec profile section on the Nodes summary page. In the modem pass-through mode of operation, the DSP state appears as MPT on the Gateway Controller and MC32S cards and as PassThru on SMC cards.

BCM 50 supports only modem pass-through over G.711 in Release M50R3.

Only the G.711 codec supports MPT CoS. MPT CoS includes no other codecs. The packet interval for G.711 codec is assigned a value of 20milliseconds (ms) in MPT.

The maximum speed supported for modem and fax is 33.6 Kbps. This limit is imposed by the analog line card.

MPT allows CS 1000 to support the following:

- modem pass through
- Super G3 (SG3) fax at V.34 (33.6 Kbps)
- V.34 rate (33.6 Kbps) modems
- Fax machines that support V.17, V.27, V.29, and V.34

#### Note:

IP trunks do not support MPT CoS.

When the TN on the CS 1000 is configured with MPTA CoS, it supports V.17, V27 and V29 Fax calls. However, the DSP mode is "FaxBegin," not "ModemPT". The MPTA CoS forces calls originated or terminated on the TN to use the G.711 NO VAD Codec. This codec selection supersedes the existing bandwidth management strategy on the CS 1000.

When a CS 1000E connects with a system from another vendor, the modem pass-through feature works if the third-party system supports the modem pass-through mode of operation.

The Voice Gateway application displays different auto-switch states (ModemPT, Passthru) in the dspMode field of the vgwShow command, based on tones detected by the DSP. These tones are generated by modem and fax machines connected in the TDM domain. The Voice Gateway application does not control auto-switch states during fax and modem calls, and the dspMode reports tone indications from DSP. The Mindspeed DSP sends tone-detection events to the host processor and changes to Modem Passthrough and Pass-through auto-switch states (with or without Redundancy), based on the tones detected, as it is configured in Auto-switch mode.

For interface commands, responses, and definitions for MPT, see <u>Table 4: Interface commands and responses</u> on page 33.

Table 4: Interface commands and responses

Command prompt	User response	Description
CLS	MPTA	Turn on the MPT feature.
CLS	MPTD	Turn off the MPT feature.

## Important:

CLS MPTA and CLS MPTD are included in LD 10 for analog line card units.

MPTA-to-MPTA and MPTA-to-MPTD fax or modem calls succeed over the G.711 codec in ModemPT DSP mode. However; MPTD-to-MPTD modem calls fail.

MPTD-to-MPTD fax calls succeed (best effort) over G.711 if the Enable Modem/Fax pass through mode and Enable V.21 FAX tone detection options are configured to On in the gateway. If the Enable Modem/Fax pass through mode is cleared, the fax call goes over the T.38 codec. Avaya recommends the T.38 fax codec for fax calls over SIP and H.323 trunks. To select the T. 38 fax codec, the analog line units at both originating and terminating systems must be set to MPTD CoS.

For information about feature packaging requirements, see <u>Table 5: Feature packaging requirements</u> on page 34.

Table 5: Feature packaging requirements

Package mnemonic	Package number	Package description	Package type (new, existing, or dependency)	Applicable market
Softswitch	402	Identifies a softswitch system	Existing	All
IPMG	403	Identifies a system that is equipped with IPMGs	Existing	All

## **Modem traffic**

CS 1000E supports modem traffic in a campus-distributed network with the following characteristics:

- · Media card configuration:
  - G.711 codec
  - 20 ms packet size
- · one-way delay less than 5 ms
- low packet loss
- V.34 rate (33.6 Kbps)

Performance degrades significantly with packet loss (must be less than 0.5 percent) and when the delay (round trip) is greater than 50 ms and mean jitter is greater than 5 ms.

## Important:

Avaya conducted extensive but not exhaustive tests of modem-to-modem calls, data transfers, and file transfers between a CS 1000E and a MG 1000E, using Virtual Trunks and PRI tandem trunks. While all tests succeeded, Avaya cannot guarantee that all modem brands can operate properly over all G.711 Voice over IP (VoIP) networks. Before you deploy modems, test the modem brand within the network to verify reliable operation. Contact your system supplier or your Avaya representative for more information.

# Recommendations for Fax configuration in the CS 1000 system

Fax settings and performance over Voice over IP (VoIP) solutions vary depending on the network configuration. In order to achieve a successful faxing environment, the VoIP solution must be engineered properly. This section describes the configuration and network design aspects that need to be taken into consideration when implementing faxing in VoIP solutions.

#### CODECs:

#### T.38:

- Older fax machines use V.21
- For lower speeds such as V.21, T.38 protocol should be used in the VoIP segments of the call

#### Modem pass-through (G.711):

- Newer fax machines use modem protocols to achieve higher speeds (V.34)
- The Modem pass-through feature is intended for modems and high speed faxes employing V. 34, using clear channel G.711 over the VoIP segments of the call.
- The Modem pass-through feature detects the phase reversal tone negotiation used for higher speeds and instructs the Digital Signal Processors (DSPs) involved in the call to disable echo cancellation and all other non-linear components.
- The Modem Pass-Through Denied (MPTD) class of service (CoS) for analog fax lines allows the DSPs to switch between T.38 protocol for lower speeds and G.711 protocol for higher speeds.
- The MPTD CoS must be used on analog line card (ALC) units connected to fax machines when there are trunk cards present in the IP Media Gateway (IPMG) and other IPMGs that connect to the TN. The MPTD class of service is required in order to support T.38 and V.34 faxes that could originate or terminate from/to the TN.
- In order for MPTD CoS to work, a system bandwidth strategy of BQ (Best Quality) must be used.
- The Modem Pass-Through Allowed (MPTA) CoS should be used only for modems, as it will force all calls to use G.711 protocol.
- When going to the TN, there is no control over the far-end; however, if the far-end supports T. 38 and Modem pass-through, speeds of 33.6 Kbps should be achievable.

## Important:

Fax performance at higher speeds (33.6 Kbps) requires that all network elements are properly engineered to support it. When high speed faxes cannot be achieved with a consistent success rate, Avaya recommends that the fax units be set at a lower speed (14.4 Kbps).

## **Typical scenarios**

Typical scenarios for faxing in a CS 1000E solution are:

- two faxes connected to analog lines in the same Media Gateway Controller (MGC)
- two faxes connected to analog lines in different MGCs of the same CS 1000E system
- one fax connected to an analog line in an MGC, to an IP trunk, to a remote system with a fax
- one fax connected to an analog line in an MGC, to an analog trunk in the same MGC, and then
  to a TN (Local or Long Distance (LD)) fax
- one fax connected to an analog line in an MGC, to a digital trunk in the same MGC, and then to a TN (Local or LD) fax
- one fax connected to an analog line in an MGC, to a digital trunk in a different MGC of the same CS 1000E system, to a TN (Local or LD) fax



The following scenario is not supported for faxing: one fax connected to an analog line in an MGC, to an analog trunk in a different MGC of the same CS 1000E system, to a TN (Local or LD) fax.

## Recommendations for faxing in a data network

Depending on the fax scenario used, fax calls can traverse the IP network, either internally (e.g., MGC to MGC) or externally (e.g., IP trunks). It is important to engineer the data network to support the following:

- · Media card configuration:
  - G.711/T.38 codecs
  - 20 ms packet size
- Round trip delay must be less than 50 ms
- Packet loss must be less than 0.5%
- V.34 rate (33.6 Kbps) can be used as long as the far end supports the Modem pass-through feature
- Mean jitter is less than 5 ms

## Important:

Performance degrades significantly with packet loss (must be less than 0.5%) and when the delay (round trip) is greater than 50 ms and the mean jitter is greater than 5 ms.

### Important:

Avaya conducted extensive but not exhaustive test of fax calls in different scenarios. While all tests succeeded, Avaya cannot guarantee that all fax brands can operate properly over all G. 711 Voice over IP (VoIP) networks. Before you deploy faxes, test the fax within the network to verify reliable operation. Contact your system supplier or your Avaya representative for more information.

# Configuration for analog line cards connected to faxes

The typical configuration recommended for analog line cards connected to faxes is as follows:

- MGCs:
  - Enable Modem pass-through mode in the Element Manager
  - Enable V.21 FAX tone detection in the Element Manager
  - Set Voice Gateway (VGW) trunks to the zone with Best Quality (BQ)
- Analog lines:
  - Use Class of Service FAXA to set the proper trunk capability for fax calls
  - Use Class of Service Modem Pass-Through Denied (MPTD). This setting allows lower speed faxes (up to 14.4 Kbps) to use T.38, and higher speed faxes to use G.711 clear channel (no echo cancellation, no non-linear DSP features)

# IP Phone registration on a CS 1000 system

On an Avaya Communication Server 1000 (Avaya CS 1000) system, the IP Phones register with the LTPS on the Signaling Server. If more than one Signaling Server exists, the IP Phone registrations are distributed equally among the Signaling Servers to aid in load balancing.

The LTPS maintains a count of the number of IP Phones registered to each LTPS. Each IP Telephony node has one active Leader. The active Leader broadcasts to all LTPS and requests a response if it has room for another IP Phone.

For more information about Signaling Server load-balancing and redundancy, see *Avaya Communication Server 1000M and Meridian 1 Small System Planning and Engineering, NN43011-220*.

# **IP Phone registration**

<u>Table 6: Registration process</u> on page 38 describes the registration process.

**Table 6: Registration process** 

Step	Description
1	The IP Phone receives the IP address of the Connect Server (co-located with the LTPS) through either DHCP or manual configuration.
2	The IP Phone contacts the Connect Server.
3	The Connect Server instructs the IP Phone to display a message requesting the customer IP Telephony node number and TN.
4	The node number and TN are entered. The Connect Server redirects the IP Phone to the Node Leader.
5	The IP Phone contacts the Node Leader. The Node Leader redirects the IP Phone to the LTPS.
6	The IP Phone contacts the LTPS.
7	If the IP Phone is valid, the LTPS registers it with the system.

# **IP Phone unregistration**

Table 7: Unregistration process on page 38 describes the unregistration process.

**Table 7: Unregistration process** 

Step	Description
1	If the LTPS detects a loss of connection with one of the registered IP Phones, it logs the event.
2	The LTPS then sends an unregister message to the system for that IP Phone.

# **Voice Gateway Media Cards**

In this document, Media Card 32-port card and Media Card 32S card are referred to as Voice Gateway Media Card, unless explicitly stated. The media cards plug into shelf slots in Intelligent Peripheral Equipment (IPE) units in Avaya CS 1000M systems and into slots on Media Gateway 1000E units and Media Gateway 1000E Expander units in CS 1000E systems. The MC32-port and Media Card 32S cards occupy one slot.

The Media Card 32-port card provides a channel density of 32 ports.

The Media Card 32S card provides the following features:

- channel density of 32 ports
- Secure Real-time Transport Protocol (SRTP)
- two Digital Signal Processors (DSP), based on an ARM processor

ITG-P media cards are not supported.

IP Line applications are not supported on the Voice Gateway Media Cards.

### **Important:**

In a CS 1000 system, the ELAN (Embedded LAN) subnet isolates critical telephony signaling between the Call Server and the other components. The ELAN subnet is also known as the Embedded LAN subnet. The Telephony LAN (TLAN) subnet carries telephony, voice, and signaling traffic. The TLAN subnet, also known as the Voice LAN subnet, connects to the customer network.

Voice Gateway Media Cards have an ELAN network interface (10BaseT) and a TLAN network interface (10/100BaseT) on the I/O panel.

There is an RS-232 Maintenance Port connection on the Media Card faceplates.



#### Caution:

Do not connect maintenance terminals to both the faceplate and the I/O panel serial maintenance port connections at the same time.

For more information about the card faceplates and components, see Circuit Card Reference, NN43001-311.

### Media Card 32S

The Media Card 32S provides a security layer to secure IP media paths between cards.

# **Secure Real-time Transport Protocol**

The MC32S media card uses Secure Real-time Transport Protocol (SRTP) to secure the IP media path between the card and another MC32S media card or associated DSP daughterboards. When Media Security is configured to On, the Call Server sends a message to the Voice Gateway software on the MC32S card to activate SRTP for the media connection established for that call.

The system administrator configures Media Security.

For information about SRTP, see IP Phones Fundamentals, NN43001-368 and System Management Reference, NN43001-600.

There are two processors on the MC 32S card:

- Control and Signaling Processor (CSP) which runs application and signaling code
- Media Stream Processor (MSP) which processes the media streams.

Table 8: Files downloaded to the MC 32S card on page 39lists the file names and paths for files that are downloaded from the Signaling Server to the MC 32S card.

#### Table 8: Files downloaded to the MC 32S card

File name	Path on Signaling Server	Path on MC 32S card	Description

IPL6.00XX.mc32s	/var/opt/cs1000/tps/fw/	/р	Software binaries
bootp.tab	/etc/opt/cs1000/ sigServerShare/config/	/u	bootp parameter file
config.ini	/etc/opt/cs1000/ sigServerShare/config/	/u	config file

The software for the MC 32S consists of five files, which are located in the IPL6.00XX.mc32s zipped file stored on the Signaling Server. All Gold versions of firmware are loaded on the MC 32S when the card is shipped from the factory. The Gold Boot Code, the upgradeable Boot Code, the Gold MSP Image, the Gold VxWorks Kernel for CSP Image, the Gold App Image, and the upgradeable Field-programmable Gate Array (FPGA) image are stored in separate areas of the MC 32S FLASH memory. A new load can be programmed into the appropriate area of FLASH memory under software control.

Table 9: Files within the zipped file

File name	Description
bootrom.bin	MC 32S boot code image
mainos.sys	VxWorks 6.0 Kernel image for the Control and Signaling Processor (CSP). The CSP runs the application and signaling code.
mainos.sym	mainos.sys and mainos.sym files form the CSP image
Idvoice.axf	Media Stream Processor (MSP) load. The MSP runs the media stream processing code. This load is a binary image.
fpga.xsvf	MC 32S board FPGA load

# **Unsupported products**

The following remote service products do not support the Media Card 32-port line card and Media Card 32S line card:

- Carrier Remote
- · Mini-carrier Remote
- Fiber Remote
- Fiber Remote Multi-IPE

# Signaling and messaging

The LTPS sends Scan and Signaling Distribution (SSD) messages to the Call Processor through the system ELAN subnet. When tone service is provided, the service is signaled to the LTPS by using new SSD messages sent through the ELAN subnet.

# Signaling protocols

The signaling protocol between the IP Phone and the IP Telephony node is the Unified Networks IP Stimulus Protocol (UNIStim). The Reliable User Datagram Protocol (RUDP) is the transport protocol.

### **UNIStim**

The Unified Network IP Stimulus protocol (UNIStim) is the single point of contact between the various server components and the IP Phone.

UNIStim is the stimulus-based protocol used for communication between an IP Phone and an LTPS on the Signaling Server.

# Reliable User Datagram Protocol

Reliable User Datagram Protocol (RUDP) is used for the following purposes:

- signaling between the Call Server and the LTPS
- signaling between the IP Telephony node and the IP Phones

For more information, see **ELAN TCP transport** on page 42.

# **Description**

Signaling messages between the LTPS and IP Phones use RUDP. Each RUDP connection is distinguished by the IP address and port number. RUDP is another layer on top of the User Datagram Protocol (UDP). RUDP is proprietary to Avaya.

The features of RUDP are as follows:

- reliable communication system over a network
- packets are resent if an acknowledgement message (ACK) is not received following a time-out
- · messages arrive in the correct sequence
- · duplicate messages are ignored
- loss of contact detection

When a data sequence is packetized and sent from source A to receiver B, RUDP adds a number to each packet header to indicate the order in the sequence.

- If the packet is successfully transmitted to B, B returns an ACK to A, acknowledging that the packet was received.
- If A receives no message within a configured time, it retransmits the packet.
- If B receives a packet without first receiving the predecessor, it discards the packet and all subsequent packets, and a NAK (no acknowledge) message, which includes the number of the missed packet, is sent to A. A retransmits the first missed packet and continues.

# **ELAN TCP transport**

Although TCP is the signaling protocol between the Call Processor and the Signaling Server, RUDP remains for the keepalive mechanism for the link. This means that RUDP messages are exchanged to maintain the link status between the Call Server and the Signaling Server.

The TCP protocol enables bundled messages. Unlike the RUDP transport that creates a separate message for every signaling message (such as display updates or key messages), the TCP transport bundles a number of messages and sends them as one packet.

The Call Server and LTPS software use handshaking to automatically enable TCP. The LTPS application checks the software version each time it attempts to establish a TCP link with the CS 1000 CPU. TCP transports messages, whereas RUDP establishes and maintains the link.

The LTPS software version must match the Call Processor software version; otherwise, the LTPS terminates the link and logs an error message.

# Virtual superloops, Virtual TNs, and physical TNs

Virtual TNs (VTN) enable configuration of service data for an IP Phone, such as key layout and CoS, without requiring the IP Phone to be dedicated (hard-wired) to a TN.

The concentration of IP Phones is made possible by dynamically allocating a port (also referred to as a physical TN) for a circuit-switched-to-IP Phone call. All system speech path management occurs with a physical TN instead of a virtual TN. Calls occur between an IP Phone and circuit-switched telephone or trunks using the full CS 1000 feature set. Digital Signal Processor (DSP) channels are allocated dynamically to perform the encoding or decoding required to connect the IP Phone to the circuit-switched network.

The IP Phones (virtual TN) are defined on virtual superloops. To create an IP Phone using VTNs, create a virtual superloop in LD 97 or in Element Manager. See Configure virtual superloops for IP Phones on page 215.

A virtual superloop is a hybrid of real and phantom superloops. Like phantom superloops, no hardware (for example, XPEC or line card) is used to define and enable units on a virtual superloop.

As with real superloops, virtual superloops use the time slot map to handle IP Phone(virtual TN)-to-IP Phone calls.

Each Media Card 32-port card provides 32 physical TNs. The physical TNs are the gateway channels (DSP ports). The channels (ports) on the Voice Gateway Media Cards are pooled resources.

Configure the physical TNs (IPTN) in LD 14. They appear as VGW data blocks.

### Licenses

Three types of licenses exist:

- Temporary IP User Licence for IP Phones configured for Branch Office or network-wide redundancy
- Basic IP User License for the IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone, and Avaya 1210 IP Deskphone
- IP User License for the IP Phone 2002, IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, Avaya 1165E IP Deskphone, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, Avaya 2050 IP Softphone, Mobile Voice Client (MVC) 2050, WLAN Handset 2210, WLAN Handset 2211, WLAN Handset 2212, Avaya 6120 WLAN Handset, and Avaya 6140 WLAN Handset

If insufficient Temporary IP User Licenses are available, you can use Basic IP User License and IP User License.

If insufficient Basic IP User Licenses are available for the IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone, and Avaya 1210 IP Deskphone then you can also use the IP User License.

If no Basic IP User Licenses are available for the IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone, and Avaya 1210 IP Deskphone and IP User Licenses are used, an error message appears:

SCH1976: Basic IP User License counter has reached its maximum value. IP User License was used to configure <data> basic IP Phone type 2001. Action: (Recommended) Purchase additional Basic IP User Licenses for IP Phones type 2001, instead of using higher-priced IP User Licenses.

Each time you configure an IP Phone, the system TN ISM counter decrements.

Customers must purchase one license for each IP Phone installed on a CS 1000 system. A new license uses the existing keycode to enable the IP Phone in the system software. The default is zero.

To expand the license limits for the IP Phones, order and install a new CS 1000 keycode. See Features and Services Fundamentals—Book 4 of 6, NN43001-106.

### Important:

Functional Pricing does not support individual licenses. With Functional Pricing, licenses are provisioned in blocks of eight.

### **License limits**

The total number of TNs configured with Temporary IP User Licenses must not exceed 100. The total number of TN configured with Basic IP User Licenses must not exceed 32767. The total number of TN configured with IP User Licenses must not exceed 32767. The total number of IP Phones configured within the system must not exceed the allowable system capacity limit controlled by customer keycodes.

# **Scalability**

The following table summarizes the operational limits of a single Signaling Server. Use the values in the table as a quick overview for planning. For detailed calculations, see *Communication Server* 1000E Planning and Engineering, NN43041-220 or Avaya Communication Server 1000M and Meridian 1 Large System Planning and Engineering, NN43021-220 as appropriate for your CS 1000 system.



#### Note:

You must consider real-time capacity for a specific application, which can constrain an application in reaching resource limits.

Signaling Server application	Limit
Terminal Proxy Server (TPS)	up to 5 000 IP Phones on non Co-Res systems and up to 1 000 IP Phones on Co-Res SS-CS systems.
Virtual Trunk	Up to 3700 trunks.
	Note:
	This limit depends on the split between SIP and incoming and outgoing H.323 calls. For more information see the Planning and Engineering documentation appropriate for your system.
PD	Up to 2250040000 IP Phones for each PD server. Up to 2000 IP Phones on Co-Res SS only systems. Up to 1 000 IP Phones on Co-Res SS-CS systems.

# Redundancy

Redundancy provides load-sharing for the Terminal Proxy Server (TPS) and an alternative route for the SIP and H.323 Gateway software. Signaling Server redundancy ensures that telephony services can withstand single hardware and network failures.

When you plan survivability strategies for the Signaling Server, include a second Signaling Server in the plan to load share. One Signaling Server is a Leader Signaling Server that is the primary TPS. The other Signaling Server is a Follower Signaling Server that is a secondary, redundant TPS.

If the Leader Signaling Server fails, an election process occurs and the Follower Signaling Server becomes the primary TPS. The IP Phones reregister to the Follower Signaling Server, and system operation resumes. If the Follower fails, the IP Phones registered to the Follower reregister to the Leader Signaling Server.

The following scenario explains how redundancy works:

- The IP Phones are distributed between the two Signaling Servers (load-sharing). The SIP and H.323 Gateways run on the Leader Signaling Server.
- The Leader Signaling Server fails.
- The Follower Signaling Server takes on the role of the Leader Signaling Server and acquires the IP address of the Leader Signaling Server if necessary.
- The Time-to-Live (TTL) of IP Phones registered with the failed Signaling Server expires, which causes those IP Phones to reset and register with the new Leader Signaling Server.



#### Note:

Only IP Phones registered with the failed Signaling Server are reset.

- The new Leader Signaling Server assumes responsibility for the SIP and H.323 Gateways.
- Normal operation resumes.

# **Administration**

The following administration interfaces are available to manage IP Line applications:

- Element Manager: Element Manager is used to administer IP Line application software.
- Command Line Interface (CLI): The CLI prompts depends on the type of Voice Gateway Media Card in the system. IPL> prompt appears for the Media Card 32-port. oam> or PDT> prompt appears for the Media Card 32S card.
- CLI on the Signaling Server: Access the CLI through the Linux shell. The commands that you can access will depend on the security role that you use to log on. Use a space between Linux CLI parameters
- Administration and maintenance overlays of Call Servers.

# **Element Manager**

Element Manager is a Web-based user interface used to configure and maintain CS 1000 components. Use the Element Manager to configure and manage IP Line from a Web browser. The Element Manager Web server resides on the Signaling Server within Unified Communications Manager (UCM) framework. For more information about Element Manager residing on a Signaling Server, see *Element Manager System Reference—Administration, NN43001-632*.

### **Command Line Interface**

The Command Line Interface (CLI) provides a text-based interface to perform specific installation, configuration, administration, and maintenance functions.

#### **Access**

Establish a CLI session by connecting a Teletype (TTY) or PC to the card serial port or SSH through the ELAN or TLAN network interface IP address.

For more information about the CLI commands, see IP Line CLI commands on page 399.

# **Overlays**

For information about the overlays, see *Software Input Output — Administration, NN43001-611*.

# **Chapter 5: Features**

### **Contents**

This section contains the following topics:

- Introduction on page 29
- Active Call Failover for IP Phones on page 59
- DSP peg counter for CS 1000E systems on page 77
- Enhanced UNIStim Firmware Download for IP Phones on page 78
- Firmware download using UNIStim FTP on page 100
- NAT Traversal feature on page 106
- Personal Directory, Callers List, and Redial List on page 118
- IP Call Recording on page 119
- pbxLink connection failure detection on page 126
- Display pbxLink information using LD 117 STAT SERV on page 127
- IP Phone support on page 131
- Corporate Directory on page 118
- Element Manager support on page 131
- <u>Call Statistics collection</u> on page 132
- Programmable line/DN feature keys (self-labeled) on page 138
- Zones on page 139
- Network wide Virtual Office on page 140
- Branch Office and Media Gateway 1000B on page 144
- 802.1Q support on page 145
- Data Path Capture tool on page 145
- IP Phone firmware on page 146
- Hardware watchdog timer on page 146
- Codecs on page 147
- IP Phone type checking and blocking on page 147

• Enhanced Redundancy for IP Line nodes on page 149

# Introduction

<u>Table 10: IP Line feature support</u> on page 48 outlines the IP Line features available for Avaya Communication Server 1000 (Avaya CS 1000) systems with Avaya CS 1000 software.

Table 10: IP Line feature support

Feature	CS 1000M	CS 1000E
Support for Element Manager	Yes	Yes
Support for Signaling Server	Yes	Yes
Support for the following IP Phones:	Yes	Yes
• IP Phone 2001		
• IP Phone 2002		
• IP Phone 2004		
Avaya 2007 IP Deskphone		
Avaya 2033 IP Conference Phone		
Avaya 1110 IP Deskphone		
Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, Avaya 1165E IP Deskphone		
Avaya 1210 IP Deskphone, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone		
WLAN Handset 2210, 2211, 2212		
Avaya 6120, 6140 WLAN Handsets		
Support for the following software clients:	Yes	Yes
Avaya 2050 IP Softphone		
Mobile Voice Client (MVC) 2050		
Support for the IP Phone Key Expansion Module (KEM)	Yes	Yes
Support for the Avaya 1100 Series Expansion Module (Expansion Module)	Yes	Yes
Avaya 1200 Series IP Deskphone Key Expansion Module (KEM)	Yes	Yes
Live Dialpad	Yes	Yes
Unicode support	Yes	Yes
IP Client cookies	Yes	Yes
New IP Phone Types	Yes	Yes

Feature	CS 1000M	CS 1000E
Active Call Failover	Yes	Yes
DSP peg counter for the CS 1000E	No	Yes
Enhanced UNIStim firmware downloads for IP Phones	Yes	Yes
Support for external server applications	Yes	Yes
Enhanced VLAN support on Phase II IP Phones; support for Voice VLAN hardware filter providing enhanced traffic control on IP Phone and PC port	Yes	Yes
Network Address Translation (NAT) Traversal	Yes	Yes
Personal Directory, Callers List, and Redial List with password protection	Yes	Yes
UNIStim File Transfer Protocol (UFTP) for IP Phone firmware downloads	Yes	Yes
IP Call Recording	Yes	Yes
pbxLink connection failure detection	Yes	Yes
Dynamic Loss Plan	Yes	Yes
Network-wide Virtual Office	Yes	Yes
Patching	Partial	Yes
802.1Q support	Yes	Yes
Corporate Directory	Yes	Yes
Data Path Capture tool	Yes	Yes
Self-labeled line/programmable feature keys	Yes	Yes
Private Zone	Yes	Yes
Graceful TPS Disable	Yes	Yes
Run-time download	Yes	Yes
Watchdog Timer	Yes	Yes
Password Guessing Protection	Yes	Yes
Ringer and buzzer volume adjustment	Yes	Yes
Set-based installation	No	No
Maintenance Audit enhancement	Yes	Yes
Multilanguage support	Yes	Yes
Enhanced Redundancy for IP Line nodes	Yes	Yes
Avaya 2050 IP Softphone user-selectable codec (not applicable to MVC 2050 as it only supports G.711 codec)	Yes	Yes
You can use the patching CLI command of the Media Card 32-port card and MC 32S card.		

# **Live Dialpad**

IP Line provides support for the Live Dialpad feature. Live Dialpad activates the primary line/DN key when the user makes a call by pressing the keys on the dialpad without lifting the handset, by pressing a line/DN key or the handsfree key.

The Live Dialpad feature is supported on the following IP Phones:

- IP Phone 2001
- IP Phone 2002
- IP Phone 2004
- Avaya 2007 IP Deskphone
- Avaya 2033 IP Conference Phone
- Avaya 2050 IP Softphone
- WLAN Handset 2210/2211/2212
- Avaya 6120/6140 WLAN Handset
- Avaya 1110 IP Deskphone
- Avaya 1120E IP Deskphone
- Avaya 1140E IP Deskphone
- Avaya 1150E IP Deskphone
- Avaya 1165E IP Deskphone
- Avaya 1210 IP Deskphone
- Avaya 1220 IP Deskphone
- Avaya 1230 IP Deskphone

Live Dialpad is enabled and disabled in the Telephone Options menu on the IP Phone. Feature processing occurs on the LTPS. The Call Server stores the on or off state for the Live Dialpad feature.

# **Diagnostics**

Output of the vxShell command e2dsetShow() contains a state of the Live Dialpad feature.

# Unicode

IP Phones use the Unicode feature to work in languages other than English. Using the Unicode feature, the Call Processor can display multilingual text on the following types of IP Phones:

- Avaya 2007 IP Deskphone
- Avaya 1120E IP Deskphone

- Avaya 1140E IP Deskphone
- Avaya 1150E IP Deskphone
- Avaya 1165E IP Deskphone
- IP Phone 2050V3
- Avaya 1110 IP Deskphone
- Avaya 1210 IP Deskphone

The Call Processor can display text in the following languages on the specified types of IP Phones:

- Japanese Kanji
- Japanese Katakana
- Chinese Traditional
- Chinese Simplified
- Arabic
- Korean
- Hebrew
- Greek

The languages listed are not available on IP Phones that do not have Unicode support. If an IP Deskphone without Unicode support registers to a TN with a Unicode-only language configured, the IP Phones defaults to English.

Personal Directory, Callers List, and Redial List support Unicode functionality. Corporate Directory, Calling Party Name Display (CPND) and user-defined feature key labels do not support Unicode functionality.

Japanese – Katakana and Japanese – Kanji cannot be supported simultaneously.

You can enter only a limited subset of Unicode characters locally using an IP Phone dialpad. The Special Characters Input Screen includes the character set used by the currently configured language. For languages with large amounts of characters (for example, Traditional Chinese, Japanese, and Korean), support is not available for localized dialpad input. The Pop-up and USB keyboard add-ons support English input only.

On IP Phones that support Unicode, you use the desired language command in the Telephone Options, Language menu option when configuring the IP Phone. All IP Phones that support Unicode need a special font file to support Asian languages. This font file must be loaded to the IP Phones during configuration using TFTP.

# Language synchronization

Language synchronization occurs strictly through UNIStim messaging. If the IP Phone receives an Assign IT Language from the Call Processor, the IP Phone changes the local prompts to match the specified language.

If a user configures the IP Phone language using the Telephone Options menu, the IP Phone sends a UNIStim Assign NI Language message to the Call Processor. The Call Processor then

synchronizes the language with the IP Phone. The Call Processor can use the Query IT Language message at any time to determine the current language of the IP Phone. If there is no default or programmed mapping for a language specified by the Call Processor, then the IP Phone uses the same language that is previously used.

The Call Processor determines the languages for which the IP Phone has fonts and font mappings. The Call Processor retrieves a list of language codes using the Display Manager Query Supported IT Languages.

# **Unicode Name Directory**

The Unicode Name Directory supports the display of called or caller party name (CPND) in multiple languages on IP Phone that support Unicode. The Unicode Name Directory (UND) is integrated with the Personal Directory (PD), and is part of the PD installation.

You use Unicode Name Directory to:

- display localized names in UTF-8 Unicode character encoding for incoming and outgoing calls
- store up to seven localized names in the database for a subscriber
- support traditional and simplified Chinese, Korean, Japanese and other Unicode languages for called or caller party name display

The content of UND is managed through Unicode Name Directory functionality in the Subscriber Manager (SM) application. This functionality provides the ability to provision localized names for each subscriber account. It also generates calling line IDs/URLs (CLID/URL) for each subscriber telephony account. All of this information is stored in Subscriber Manager for ease of access by all system elements. UND synchronizes with Subscriber Manager to obtain data. For more information about provisioning localized subscriber telephony accounts using Unicode Name Directory functionality in Subscriber Manager, see *Subscriber Manager Fundamentals* (NN43001-120).

# **Unicode Name Directory configuration**

You can configure the Unicode Name Directory (UND) application using Element Manager (EM) on the member server where the UND application is installed, or from the CLI of the Call Processor. You can configure the UND only if the Personal Directory (PD) application is configured.

Configuration of the UND application consists of two steps:

- Enable the UND application.
- Schedule automatic synchronization of the Unicode Name Directory (UND) with the Subscriber Manager.

When you configure the UND application using EM, the scheduling parameters for the automatic synchronization of the UND data with the Subscriber Manager are retrieved from the UCM primary security server and used to populate the Unicode Name Directory web page.


For instructions to configure the UND using EM, see <u>Configuring the Unicode Name Directory using EM</u> on page 52.

#### Configuring the Unicode Name Directory using EM

1. Log on to Element Manager on the member server where the UND application is installed.

#### 2. Choose System > IP Network > Unicode Name Directory.

The Unicode Name Directory window appears.



3. Select the **Name directory Application** check box to enable the PD/UND.

### Note:

If the Personal Directory application is not configured, you are redirected to the **Server Configuration** option in the Personal Directory section of Element Manager. For information about the Personal Directory application and configuration, see <u>Personal Directory application</u> on page 152.

4. Enter a value in the **Lookup timeout** field.

This value is a time in milliseconds.

Allowed values are 500 to 10000. The default value is 3000.

5. Select a **Synchronization type**.

The **Manual** check box is always selected and cannot be cleared.

Select the **Scheduled** check box to schedule synchronizations of the UND data with the Subscriber Manager data.

6. Enter a value in the **Hours** field.

Valid values are 1 to 24.

7. Enter a value in the **Minutes** field.

Valid values are 0 to 59.

8. Select a **Security level** for the synchronization.

Enables or disables a secure SSL connection for the UND <-> Subscriber Manager synchronization.

#### Note:

Insecure synchronization will not work when the UCM firewall rules prevent insecure connection.

- 9. Click Save .
- The content of UND is managed through Unicode Name Directory functionality in the Subscriber Manager (SM) application. For detailed information about management, data migration, and configuration of numbering groups, refer to Subscriber Manager Fundamentals (NN43001-120).

### Note:

To synchronize the UND with the Subscriber Manager data, use the Linux shell command (nd ldapSync) on the member server to start a manual synchronization. Otherwise, the data will be synchronized at the scheduled time.

### **Unicode Name Directory synchronization**

The PD/UND server retrieves user names and phone numbers from Subscriber Manager using the secure LDAP protocol. Entries in the PD/UND database that are associated with subscribers are updated for each subscriber. If the LDAP connection is lost during the synchronization, only those subscribers processed prior to the failure are updated (synchronized). The remaining entries are not updated. Start UND <-> Subscriber Manager synchronization by running the SYNC SYS command in LD 117.

PD/UND synchronization is initiated in one of three ways:

Scheduled synchronization

Synchronization is initiated automatically once a day at the specified time to retrieve data from Subscriber Manager.



#### Note:

Avaya recommends that you schedule synchronization for various PD/UND servers at different times to facilitate load balancing.

Manual synchronization

Synchronization can start manually from a Virtual Terminal (VT). VT starts from the Links, Virtual Terminal or System, IP Network, Maintenance and Reports section of EM, on the member server where the PD/UND application is configured.

You can also use the Unicode Name Directory shell on the member server to start a manual synchronization using the following command:

[admin2@und-pd ~]\$ nd ldapSync

UND application startup

# **Unicode Name Directory requirements for IP Phones**

The Unicode Name Directory application requires that you configure a Calling or Called Party Name Display (CPND) block on the Call Processor for each customer in the CS 1000 system, to correctly

display the calling or called party names on customer IP Phones. In addition, you must configure the CNDA and DNDA CoS on each IP Phone to properly display the calling or called party names.

Language selection on an IP Phone occurs through the Telephone Options, Language command, during initial configuration of the IP Phone, or as required.

#### **Virtual Office interaction**

Virtual Office logon can occur from an IP Phone that does not support Unicode, to an IP Phone with Unicode entries in the Personal Directory (PD) or the Unicode Name Directory (UND). <Unicode name> appears instead of the entry name.

### **IP Client cookies**

IP Client cookies provide a transparent transfer of data from the Call Server to third-party applications, for example, Citrix AG. The cookies are a set of UTF-8 variable names and values, which are duplicated and synchronized between the LTPS and the IP Phone. IP Line uses public cookies that are visible to both the IP Phone and third-party applications. IP Client cookies are not supported on Avaya Phase I IP Phones and third-party IP Phones, such as WLAN Handset 2210/2211/2212, Avaya 6120/6140 WLAN Handset, and Avaya 2033 IP Conference Phone.

Table 11: Cookie definitions

Cookie name	Description	
PrimeDN	A string of digits containing the current primary DN of the IP Phone.	
AgentPosition	A string of digits containing the current agent position of the IP Phone. This string is empty if the agent is not logged on.	
CallState	A UTF-8 string indicating the current call processing state of the IP Phone. The following are possible values:	
	BUSY: an active call is established	
	IDLE: no active calls (there can be calls on hold)	
	RINGING: IP Phone is ringing	
CustNo	A string of digits indicating the IP Phone customer number.	
Zone	A string of digits indicating the IP Phone zone.	
VPNI	A string of digits containing the Virtual Private Network Identifier configured for the IP Phone.	
TN	UFT-8 string containing the TN currently associated with the IP Phone in hexadecimal format. The maximum number of TNs is FFFF.	
Although cookie names and values are UTF-8 strings, the IP Phone need not support Unicode.		

Output from the e2dsetShow() command shows the contents of all display lines, soft keys, feature keys (including feature keys on KEM and Expansion Module) and programmable line/DN keys associated with the IP Phone. This command is available only from the VxShell.

# e2dsetShow()

The e2dsetShow () command expects a pointer to a DSET emulator, which you can obtain by running the dsetShow () command.

```
TN IP Address Private IP Addr Hardware ID
                                                                                                ItType KEM Emulator
6144 192.168.29.8
                                              180019e1e7016e662a IP Phone 1220 1220
                                                                                                                           0x09e581c8
value = 0x0 (0)
vxshell> tps e2dsetShow 0x09e581c8
=== SBI Data ===
1ssBiset 0
для отображения куков используется: cookieShowByTN
cookieShowByTN TN
Print the cookie list for a set specified by TN
 e.g. cookieshowByTN "96 0 1 20"
 --- TPS ---
                               Value
 Name
Name
Ringervolume
CallerIDDisplay
ElapsedSecond
ElapsedSecond
ElapsedHour
ElapsedHour
ElapsedHour
ElapsedMonth
ElapsedWonth
ElapsedYear
HandsfreeRxvolume
HandsfreeRxvolume
HomevPNII
HomeZone
TN
Callstate
CustNo
 Zone
PrimeDN
Total: 18 items
```

Figure 2: dsetShow

# **IP Phone Types**

IP Phone Types provide the following functionality:

- unique TN types for existing IP Phone models
- · special emulation mode for IP Phones that are not known to the TPS
- automatic and manual IP Phone TN type conversion
- enhanced Model Names support is accessed from LD 20

# **Unique TN Types for existing IP Phone models**

TN Types match the brand name of the IP Phone model. The following table identifies the TN\_TYPE for each IP Phone model.

**Table 12: TN Type naming convention** 

IP Phone model name	TN_TYPE
IP Phone 2001	2001P2
IP Phone 2002 Phase I	2002P1
IP Phone 2002 Phase II	2002P2
IP Phone 2004 Phase 0/I	2004P1
IP Phone 2004 Phase II	2004P2
Avaya 2033 IP Conference Phone	2033
Avaya 2050 IP Softphone	2050PC
Mobile Voice Client 2050	2050MC
WLAN Handset 2210	2210
WLAN Handset 2211	2211
WLAN Handset 2212	2212
Avaya 6120 WLAN Handset	1120
	Important: The Avaya 6120 WLAN Handset is configured using TN_TYPE 1120 or as an alternative, you can use generic 2210.
Avaya 6140 WLAN Handset	1140  Important:  The Avaya 6140 WLAN Handset is configured using TN_TYPE 1140 or as an alternative, you can use generic 2210.
Avaya 2007 IP Deskphone	2007
Avaya 1110 IP Deskphone	1110
Avaya 1120E IP Deskphone	1120
Avaya 1140E IP Deskphone	1140
Avaya 1150E IP Deskphone	1150
Avaya 1165E IP Deskphone	1165
Avaya 1210 IP Deskphone	1210
Avaya 1220 IP Deskphone	1220
Avaya 1230 IP Deskphone	1230

### **Emulation Mode**

During IP Phone registration, the LTPS determines the IP Phone TN Type (TN\_TYPE) by looking up the User Interface capabilities (UI\_TYPE) and Firmware ID (FW\_ID) in a mapping table. The mapping table maps the IP Phone UI\_TYPE and FW\_ID with TN\_TYPE. If an IP Phone has a

known UI\_TYPE but an unknown UI\_TYPE and FW\_ID combination, the IP Phone registers in Emulation Mode.

Use the isetShow command or LD 20 to list the IP Phones registered in Emulation Mode.

# **Automatic IP Phone TN conversion (Flexible Registration)**

Flexible Registration Class of Service (CoS) for all IP Phones is configured in LD 11. Flexible Registration CoS can be one of the following values:

- FRA-Flexible Registration Allowed (default)
- FRU-Flexible Registration on Upgrade
- · FRD-Flexible Registration Denied

Use LD 81 to list the IP Phone TNs that have Flexible Registration Allowed (FRA), Flexible Registration on Upgrade (FRU), and Flexible Registration Denied (FRD) classes of service.

When the LTPS attempts to register an IP Phone with the Call Server, the following occurs:

- If the TN has FRD CoS, the Call Server checks the IP Phone type against the TN type.
   Registration is rejected if the types do not match. The Call Server checks the Emulation Flag and blocks registration in the Emulation Mode.
- If the TN has FRA CoS, the Call Server checks the IP Phone type against the TN type. If the types are compatible, the TN is converted, and the IP Phone registers.
- If the TN has FRU CoS, the Call Server checks the IP Phone type against the VTN type. If the
  types are compatible, the TN is converted and the IP Phone registers. After the TN is
  converted, the Flexible Registration CoS value becomes FRD. The Call Server checks the
  Emulation Flag and blocks registration in the Emulation Mode.

The <insert table link> lists groups of IP Phone types that can be converted or interchanged without losing configuration.

#### Table 13: IP Phone TN TYPE groups

2004P1, 2004P2, 2210, 2211, 2212, 2007, 1140, 2050PC, 2050MC, 6140
2002P1, 2002P2, 1120, 1220, 6120
2001P2, 2033, 1110, 1210
1230
1150

### Manual IP Phone TN conversion

Manual IP Phone TN conversion lowers the administrative effort required to replace an IP Phone with another model while preserving the IP Phone features. Use LD 11 to convert an IP Phone TN to another IP Phone TN while preserving the IP Phone features.

Table 14: LD 11 IP Phone interface commands

Prompt	Response	Description
REQ	CHGTYP	Change the IP Phone TN type
TYPE	2004P1, 2004P2, 2002P1, 2002P2, 2001P2, 2050PC, 2050MC, 2033, 2210, 2211, 2212,6120, 6140, 2007, 1120, 1140,1150, 1165, 1210, 1220,1230	Type of TN block to convert
TN	Iscu	For Large Systems
NEWTYP	2004P1, 2004P2, 2002P1, 2002P2, 2001P2, 2050PC, 2050MC, 2033, 2210, 2211, 2212, 6120, 6140, 2007, 1110, 1120, 1140,1150, 1165, 1210, 1220,1230	TN_TYPE to convert  The Call Server lists the features that are lost if the administrator proceeds.
PROCEED	YES No	Perform or reject the IP Phone TN conversion

### **Active Call Failover for IP Phones**

The Active Call Failover (ACF) for IP Phones feature allows active IP calls to survive the following failures:

- IP/IP calls and IP/TDM calls survive signaling path TLAN subnet failures.
  - IP/IP calls means both parties are IP Phones. IP/TDM calls means one party is an IP Phones and the other party is a TDM telephone or trunk.
- IP and IP/TDM calls survive Signaling Server restarts.
- IP and IP/TDM calls survive LTPS ELAN subnet failures.
- IP calls survive a Call Server cold start and Call Server failures in system configurations with a redundant Call Server of the following types
  - Media Gateway 1000B for a branch office configuration
  - Geographic Redundancy Secondary Call Server. The feature addresses the Primary Call Server failures.

IP Phone to IP Phone calls survive the Call Server failures listed above.

- For Call Server call processor types CP PIV and CP-PM:
  - IP/IP calls survive a cold start on all systems.
  - IP/IP and IP/TDM calls survive a warm start on all systems.

Graceful switchover and graceful failover to the redundant Logical Call Processor (LCP) side
of the Call Server makes the failure transparent and allows all the calls to survive without
any loss.

When the IP Phone with an active call re-registers, the call data is rebuilt if the Call Server does not know about the call, using the internal IP Phone information.

The ACF feature for IP Phones meets Joint Interoperability Test Command (JITC) requirements if the LAN/WAN network is engineered to provide full redundancy: that is, if a LAN/WAN network component fails, an alternate path between the clients and LTPS server is provided.

### Minimum requirements

The ACF feature for IP Phones has the following minimum requirements:

- Call Server must run CS 1000 Release 4.5 or later.
- IP Phones (including Avaya 2050 IP Softphone) must support UNIStim Version 2.9. (Use the isetShow command to determine the UNIStim version. One of the columns in the isetShow output is UNIStimVsn.)

### **ACF** mode

The ACF feature for IP Phones enables an IP Phone to re-register in the ACF mode during a supported system failure.

The ACF mode preserves the following:

- active media session
- · LED states of the Mute, Handsfree, and Headset keys
- DRAM content

All other elements (the self-labeled line/programmable feature keys, context-sensitive soft keys, and text areas) are retained until the user presses a key or the connection with the Call Server resumes. If the user presses a key during the failover, the display clears and a localized "Server Unreachable" message appears.

The IP Phone uses this new mode of re-registration only when the Call Server explicitly tells the IP Phone to do so. IP Phones clear all call information if they register to a Call Server or LTPS that does not support the ACF feature.

#### IP Phone ACF timer

You can have one LTPS supporting the ACF feature and one LTPS that does not support the feature in the same system.

A situation can exist where it takes a long time to fix a failure and no failover Call Server is available. During this time, if the user released the call by pressing the Release key or hanging up the telephone, the call-associated resources are not used. The call-associated resources remain on the Call Server because they are not released. To prevent this, the 10-minute Call Server ACF timer is

introduced for each call. The timer prevents call processing-related resources from being unnecessarily used when an IP Phone that had an active call unregisters and never re-registers.

The timer is configured if

- the ACF call status is Unregistered; that is, when both parties go offline.
- only one party is offline, and the other party does not support disconnect supervision.

### Note:

Disconnect supervision can be configured for analog trunks only. Disconnect supervision is supported by default for virtual and digital trunks. The ACF timer is also started if the other party is a virtual trunk with CPDC (Called Party Disconnect Control) configured for RDB (Route Data Block). There are CPDC feature limitations for route usage in this case. For more information, see NN43001–106, Features and Services Fundamentals — Book 2 of 6.

### **ACF** scenarios

Table 15: ACF behaviors on page 61 describes ACF behavior in different scenarios.

Table 15: ACF behaviors

Scenario	Result
TLAN subnet failure	The call is not lost as the IP Phones re-register.
A call is established between IP Phones A and B registered with the same node.	In this scenario, the call exists on the Call Server during the failover time and has the following transitions: UNREGISTERED ->HALF-REGISTERED -> NO ACF
TLAN subnet goes down.	
The IP Phones detect the lost connection and periodically try to re-register.	
The TLAN subnet is up in less than 10 minutes, or an election is called and another accessible LTPS node acquires the node IP address. The IP Phones reregister with the node again.	
Signaling Server platform failure	The call is not lost as the IP Phones re-register.
A call is established between IP Phones A and B registered with the same node.	The scenario is similar to the TLAN subnet failure, but the ACF call transition on the Call Server is instantaneous, because Offline events are generated in a group as the ELAN subnet goes down.
The LTPS node goes down.	
The IP Phones detect the lost connection and periodically try to re-register.	
The LTPS node is up in less than 10 minutes, or an election is called and another accessible LTPS node acquires the node IP address. The IP Phones reregister with the node again.	

Scenario	Result
Call Server warm restart	The call is not lost.
A call is established between IP Phones A and B registered with the same Call Server.	The call is rebuilt after the warm restart and has the following transitions: UNREGISTERED->HALF REGISTERED->NO ACF. The transition is almost instantaneous because the Online messages are sent in a group as a response to the Sync Request.
The Call Server warm restart (INI) occurs.	
The users of IP Phones A and B do not go on-hook or press any keys during the Call Server restart.	
Call Server cold restart	The call is not lost.
A call is established between IP Phones A and B registered with the same Call Server.	The call cannot be rebuilt after the SYSLOAD. The PARTIAL REBUILT -> REBUILT transition is
The Call Server cold restart (SYSLOAD) occurs.	almost instant since the Online messages are sent in a group as a response to the Sync
The users of IP Phones A and B do not go on-hook or press any keys during the Call Server cold restart.	Request.
Main office failure for branch office (scenario 1)	The call is not lost.
Branch IP Phones A and B register with the Media Gateway 1000B and are redirected to the main office.	The HALF REBUILT -> REBUILT transition occurs since the far end is known to the Call Server gateway to the Media Gateway 1000B.
IP Phones A and B registered with the main office establish a call.	
A serious main office failure occurs. The active Branch IP Phones cannot re-register with the main office and re-register with the branch office in local mode. IP Phone A re-registers in local mode first.	
Main office failure for branch office (scenario 2)	The call is not lost.
IP Phones A and B register with the Media Gateway 1000B and are redirected to the main office.	Although the branch office LTPS wrote the IP Phones A and B data to its RLM table when it redirected the IP Phones to the main office, the RLM data is lost and cannot be restored when the branch office restarts. The transition is similar to a Call Server cold start: PARTIAL REBUILT -> REBUILT.
Branch office warm or cold starts.	
Branch users A and B registered with the main office establish a call.	
A serious main office failure occurs so the active branch IP Phones cannot re-register with the main office, and they re-register with the Branch office in local mode. IP Phone A re-registers in local mode first.	
Primary Call Server failure WAN geographically	The call is not lost.
redundant system)	<ul> <li>IP Phones can be configured in two ways:</li> <li>Site 1 is the secondary site and Site 2 is not configured. In this case the scenario is the same as main office failure for branch office (scenario</li> </ul>
<ul> <li>A call is established between IP Phones A and B that are registered with the primary site in the geographically redundant system.</li> </ul>	
The primary site fails.	1): the HALF REBUILT-> REBUILT transition.

Scenario	Result
The IP Phones re-register with the secondary site. IP Phone A re-registers first.	IP Phones have Site 1 defined as the primary site while Site 2 is defined as the secondary site. Registration by Site 1 fails. In this case, the secondary site Call Server does not have the RLM entries for the re-registering IP Phones and the scenario is the same as main office failure for branch office (scenario 2): the PARTIAL REBUILT -> REBUILT transition.
Virtual Office logon failure (scenario 1)	The call is not lost.
IP Phone A logs into IP Phone C and establishes a call with IP Phone B. All three IP Phones register with the same Call Server.	The following ACF transitions occur: NO ACF -> PARTIAL REBUILT -> IDLE -> HALF REBUILT -> REBUILT
TLAN subnet failure occurs. IP Phone A goes offline first, then IP Phone B.	
Active IP Phones A and B re-register with the system when the TLAN subnet restarts. IP Phone A re-registers first and then IP Phone B.	
Virtual Office logon failure (scenario 2)	The call is not lost.
IP Phone A logs into IP Phone C and establishes a call with IP Phone B. All three IP Phones are registered with the same Call Server.	The following ACF transitions occur: NO ACF -> HALF REGISTERED -> IDLE -> HALF REBUILT -> REBUILT
TLAN subnet failure occurs. IP Phone B goes offline first, then IP Phone A.	
Active IP Phone A and B re-register with the system when the TLAN restarts. IP Phone A re-registers first and then IP Phone B.	
Virtual Office logon failure (scenario 3)	IP Phone C cannot log on to the home TN if
IP Phone A logs into IP Phone C and establishes a call with IP Phone B. All three IP Phones are registered with the same Call Server.	another active IP Phone is logged on to its TN. IP Phone C can log on to its home TN only when the call register is released or becomes PARTIAL REBUILT. See Virtual Office login failure
TLAN subnet failure occurs. IP Phones A and B fail and IP Phone C does not fail.	(scenario 1) on page 63 and Virtual Office logon failure (scenario 2) on page 63.
IP Phone C tries to log on to home TN before IP Phones A and B go offline.	
Network TLAN subnet failure	The call is not lost.
IP Phone A has an IP Peer call with a remote user over a virtual trunk.	The scenario is the same as if the far end were a local IP Phone.
IP Phone A TLAN subnet connection fails.	
Active IP Phone A re-registers with the Call Server when the TLAN subnet restarts.	

Scenario	Result
Network Call Server warm start	The call is not lost.
IP Phone A has an IP Peer call with a remote user over a virtual trunk.	The scenario is the same as if the far end were a local IP Phone.
The Call Server warm starts.	
Active IP Phone A re-registers with the Call Server as the TLAN subnet restarts.	
Network Call Server cold start	The call is lost as the Call Server comes up.
IP Phone A has an IP Peer call with a remote user over a virtual trunk.	
The Call Server cold starts.	
Active IP Phone A re-registers with the Call Server as the TLAN subnet restarts.	
Network branch office	The call is not lost.
Branch IP Phones A and B belong to different branches – Branch A and Branch B respectively. IP Phones A and B are registered on the main office Call Server.	Branch A does not know about IP Phone B and Branch B does not know about IP Phone A. Therefore, each branch builds the PARTIAL REBUILT call.
A call is established between IP Phones A and B.	Two local PARTIAL REBUILT calls exist on the
Main office Call Server failure occurs and IP Phones     A and B register with the branches in local mode.	branches as the IP Phones re-register in local mode. The calls are never transitioned to the REBUILT state and exist until the IP Phones release the call.
IP/TDM call with TLAN subnet failure	The call is not lost.
<ul> <li>IP Phone A has a call with a TDM telephone or trunk</li> <li>B.</li> <li>IP Phone A TLAN subnet connection fails.</li> </ul>	The scenario is the same as Network TLAN subnet failure on page 63. The call has the following transitions: NO ACF -> HALF
Active IP Phone A re-registers with the Call Server as	REGISTERED -> UNREGISTERED.
the TLAN subnet restarts.	
Network Call Server warm start	The call is not lost.
IP Phone A has an IP Peer call with a remote user over a virtual trunk.	The scenario is same as if the far end were a local IP Phone.
The Call Server warm starts.	
Active IP Phone A re-registers with the Call Server as the TLAN subnet restarts.	
Network Call Server cold start	The call is lost as the Call Server restarts.
IP Phone A has an IP Peer call with a remote user over a virtual trunk.	
The Call Server cold starts.	

Scenario	Result
<ul> <li>Active IP Phone A re-registers with the server as the</li> </ul>	
TLAN subnet restarts.	

After some failover scenarios (PARTIAL REBUILT calls), call modifications (for example, hold, conf, transfer) are not allowed. In this case localized string "Postfailure Limited Mode" appears when the user initiates call modification.

#### Firmware downloads

If the IP Phone has an active media stream, the LTPS does not request the firmware download to avoid resetting the IP Phone and losing the call. Therefore, a system can have IP Phones with a mixture of firmware versions registered. The firmware can be downloaded later, after the idle IP Phone registers again or can be downloaded manually using appropriate CLI commands.

# **WLAN Handsets 2210/2211/2212, Avaya 6120/6140 WLAN Handsets**

The Wireless LAN (WLAN) Handsets 2210/2211/2212 and Avaya 6120/6140 WLAN Handsets support Active Call Failover in the same manner as Phase II IP Phones if the firmware supports UNIStim 2.9 or later.

### **Operating parameters**

#### **IP Peer calls**

IP Peer calls survive the following failure types:

- TLAN subnet failures.
- Signaling Server platform failures or restarts. When the Signaling Server restarts after the
  failure, all sessions are lost. Therefore, when the local IP Phone or far-end telephone releases
  the call, no RELEASE message is sent to the other party. The other party must go on-hook to
  become idle.
- Call Server warm starts.

IP Peer calls do not survive the Call Server cold start; all virtual trunks are idled as the Call Server restarts after the cold start. In this case, the local IP Deskphone must go on-hook to become idle.

The zone bandwidth usage in the zone table remains zero for all IP Peer calls on this side; zone bandwidth usage is cleared for all calls as the Call Server restarts after the warm start. In this case, Network Bandwidth Management information is lost and the Call Server cannot restore the correct zone bandwidth usage for IP Peer calls.

### IP/TDM calls

IP/TDM calls do not survive a Call Server cold start; all DSP channels are closed as the Call Server restarts after the cold start. In this case, the local IP Deskphone must go on-hook to become idle.

### Dialing state

Only established calls survive failures. All calls having the DIALING state on the Call Server are released when an LTPS or signaling failure occurs that causes an IP Phone to unregister.

Ringing calls are handled as follows:

- If the IP Phone originating the ringing call unregisters, the call is released by the Call Server.
- If the IP Phone receiving the call unregisters, the call receives CFNA treatment if possible.

#### Held calls

From the ACF feature perspective, held calls are considered to be established. This means that the call is preserved on the Call Server despite TLAN subnet or LTPS failure. The IP Phone itself is unaware of the state of any held call.

### Phase 0/1 IP Phones

Phase 0/1 Phones do not support ACF.

### Feature key labels

If user-defined feature key labels changed but no datadump occurred, the changes are lost if the Call Server fails.

# SIP telephones

SIP telephones appear as IP Peer endpoints to the system. See IP Peer calls on page 65.

#### **NAT** devices

The ACF feature cannot handle a NAT device changing the media path mapping between the IP Deskphone private address and public address during the failover period. No method exist to discover the mapping while the port is in use. For instance, if a main office failure occurs and the user re-registers in local mode, NAT mapping changes and the active call cannot survive.

# **Control messages**

The LTPS sends the Audio Stream Control and LEDs Control commands in separate messages. If a failure occurs in the time between the two messages, the Audio Stream and LEDs states may not be synchronized. For example, it is possible for the Audio Stream to be muted and a network failure to occur at just the right moment to prevent the LED Control message for the mute LED from being received by the IP Phone.

### **Held Calls**

When an idle IP Phone (one without an active speech path) re-registers, a firmware download can occur, if needed. If that IP Phone actually had calls on hold, then the held calls cannot be retrieved until after the firmware download finishes.

#### **Codecs**

Not all the codec properties are restored for the failed-over call. The following default codec properties are used for the active failover call:

- G.722 Working Rate is 64 Kb/s
- G.723 Working Rate is 5.3 Kb/s
- · G.729 Annex is Annex A
- VAD is OFF

### **QoS** monitoring

The QoS monitoring is always disabled for the failover call. This is only for the period of the failover call; for all subsequent calls, the QoS monitoring works as configured.

#### **Virtual Office**

Active Call Failover is not supported for the active call from an IP Phone logged on another IP Phone to a TDM resource or virtual trunk. Such a call is released when the LTPS detects that the connection to the IP Phone is lost.

For example, IP Phone A logs on to IP Phone B and talks to a TDM resource or a virtual trunk. If a TLAN subnet failure occurs and IP Phone A re-registers with the home TN, the active call is released as IP Phone A re-registers.

#### Handsfree

In this scenario, IP Phone A has handsfree denied and IP Phone B has handsfree allowed. IP Phone A logs on IP Phone B and talks to IP Phone C using handsfree.

If a TLAN subnet failure occurs and IP Phone A re-registers with the home TN (with handsfree disabled), handsfree is turned off and IP Phone A must go off-hook to continue the conversation.

#### **ELAN** subnet failure

The ACF state cannot be determined on the LTPS side during an ELAN subnet failure. This is because the ACF state is stored on the Call Server and it is not possible to send the ACF state on the LTPS side when the ELAN subnet fails.

### **Feature interactions**

This section shows the ACF feature interactions with Virtual Office and Branch Office.

### **Branch Office**

When the first failed IP Phone re-registers in local mode, the branch office Call Server looks up the far-end branch IP Phone local TN using the specified far-end IP address and builds a local call.

The call can be rebuilt only if both the IP Phones are branch users of the same branch office.

**Example**: A regular main office IP Phone talks to the branch IP Phone registered with the main office. A failure occurs at the main office, so that the branch IP Phone cannot register in normal mode again, and re-registers in local mode. Even if the main office IP Phone survives the failure, the call cannot be rebuilt because the call becomes an IP Peer call between the branch office and main office. This call becomes Partial Rebuilt and exists until released.

#### Virtual Office

It is possible that active IP Phone A, that logged on to IP Phone B before the failure, cannot reregister with the Call Server because IP Phone C performed a Virtual Office logon and uses IP Phone A TN. In this case, the Signaling Server locally handles the Release, Onhook, and Mute events from IP Phone A in the Logged Out state.

### **Survivable Remote Gateway**

The Survivable Remote Gateway (SRG) 1.0 and SRG 50 do not support ACF. If the IP Phone is an SRG user, the active call, either in normal mode or local mode, does not survive a failure.

### **IP Call Recording**

Established calls that are being recorded using the IP Call Recording feature and survive ACF continue to be recorded.

#### NAT

The NAT discovery is delayed for an IP Phone with an active call when it re-registers. NAT discovery messages are sent through the port used for the RTP stream. NAT discovery is not initiated if the LTPS detects that the IP Phone has an active RTP stream.

# Personal Directory, Callers List, Redial List

The display content is cleared and the Personal Directory/Callers List/Redial List applications are reset when the active call failover process starts. The applications can be used again only after the IP Phone re-registers. A user who uses one of the Personal Directory/Callers List/Redial List menus sees the display clear and loses any data in that transaction that was not selected or saved with the Personal Directory/Callers List/Redial List feature.

ACF implementation does not maintain data present only on the Signaling Server. Transient data (for example, the Services key submenu the user is currently in) is lost when the failover occurs and the IP Phone re-registers.

# **Converged Desktop**

If the Call Server maintains the active call information during the active call failover, and the SIP Gateway maintains the link and information with the MCS5100 (the SIP Gateway did not fail or is not

on the Signaling Server that restarts if that is the failure mode), a Converged Desktop call is maintained when the involved IP Phone re-registers to the system. If the Call Server loses the call information or the SIP Gateway Signaling Server restarts, the Converged Desktop call is affected.

A Converged Desktop consists of a telephone and multimedia PC Client (PCC) software.

The following are example scenarios.

**Example 1:** The IP Phone TLAN subnet fails and the IP Phone re-registers with the same or a different TPS.

In this case, both the voice and multimedia sessions survive. If a SIP call is established with the other party in the SIP domain, the call is not released as the IP Phone re-registers. The multimedia applications still work. The presence is updated on PCC after the telephone re-registers.

If the unregistered converged IP Phone releases the call during the TLAN subnet failure, the Presence status is updated on PCC as the idle converged IP Phone re-registers.

**Example 2:** The IP Phone Signaling Server fails and the IP Phone re-registers with the same or a different TPS (active converged IP Phone and SIP Gateway are on different Signaling Servers on the same node).

In this case, both the voice and multimedia sessions survive; the scenario is the same as the TLAN subnet failure in Example 1.

**Example 3:** The IP Phone ELAN subnet fails and the IP Phone re-registers with the same or a different TPS.

The voice session survives. If the ELAN subnet restarts before the IP Phone changes the call state (that is, releases the call), then the multimedia session is not affected.

If the IP Phone releases the call when the ELAN subnet is still down, the PCC status is updated when the idle converged IP Phone re-registers with the system.

If the call is released by the supervisory timer, the status is updated on PCC after the ELAN subnet restarts and the Converged Desktop AML ELAN subnet link is enabled (the CSA104 message is output on the Call Server).

**Example 4:** Call Server warm start.

The voice and multimedia sessions survive. The Presence status is updated on PCC as the converged IP Phone releases the call after the warm start.

Example 5: Call Server cold start.

The voice and multimedia sessions are closed as the Call Server comes up. The Presence status becomes Connected - Idle even if the call is rebuilt and active after the Call Server cold start.

#### IP Phone firmware downloads

The firmware is not downloaded to an IP Phone that has an active RTP stream open when it registers with the failover system. The firmware is downloaded later when the idle IP Phone registers again or by using appropriate CLI commands.

### **IP Call Recording**

If an IP Phone is configured with a CLS of RECA (IP Call Recording Allowed) and survives an Active Call Failover, the Call Recording device continues to record the call.

### IP Phone as ACD agent or supervisor telephone

If an IP Phone is used as an ACD agent (or supervisor) and the Call Server fails, the following can occur:

- In the case of a Call Server warm start (INI), the active calls are retained on the agent telephone.
- In the case of a Call Server cold start (SYSLOAD), the active calls are dropped and the agents are logged off.

This applies to both the in-calls (PRIMARY) key and any secondary DN key on the ACD telephone.

TPS failures do not affect general ACD functionality because the Call Server uses the ACD feature.

#### CS 1000 base features

No feature works when the active IP Phone disconnects and tries to re-register with the Call Server. All the features are available in the context of the failover call after the IP Phone re-registers (if it is not a PARTIAL REBUILT call).

The feature context is lost if the Call Server fails.

The feature context is not lost on the Call Server if the TLAN/ELAN subnet fails. Only the feature data on the IP Phone display is lost.

#### Feature context in Call Server failures

The context of any feature is lost on the Call Server if the Call Server fails (Call Server warm or cold start). The LTPS IP Phone display is lost as the IP Phone re-registers. This means if a feature is activated and the Call Server fails, all the user input and data is lost.

Example: IP Phone A is in a call; the user presses the Transfer key and starts to dial a DN. The Call Server cold or warm starts. Therefore, IP Phone A does not accept the user input and tries to reregister with the Call Server. When the Call Server restarts and the IP Phones re-register, IP Phone A does not have the Call Transfer activated. The held call is also lost; it is not rebuilt after INI or by the ACF feature, because the call is not active.

### TLAN/ELAN subnet and LTPS failures

When a network or Signaling Server failure occurs and the active IP Phone has some features activated, the feature context and data is not lost on the Call Server. The user can use the feature after the IP Phone re-registers. Only the LTPS display is lost when the IP Phone re-registers.

Example: IP Phone A is in a call; the user presses the Transfer key and starts to dial a DN. A TLAN subnet failure occurs when the first digit is dialed. The user is unaware of the failure and continues dialing the DN. The digits dialed after the failure are ignored, the IP Phone detects the failure, clears the display, and tries to re-register with the server.

The TLAN restarts and the IP Phone re-registers. Although the IP Phone is now idle and the display is cleared, the IP Phone can resume dialing the DN starting from the second digit. The IP Phone can also return to the held call by pressing the held call DN key.

#### **CDR**

No ACF-specific information is added to the Call Detail Record (CDR) records.

If the Call Server fails, the CDR records for the call before the failure occurred are lost. CDR restarts as the active IP Phone re-registers. Therefore, the records are generated only for the post-failure period of time.

If the LTPS or network fails, CDR continues. The CDR stops only if

- the Call Server supervisory timer expires
- the IP Phone is idle when it re-registers
- the active IP Phone re-registers and then the call is released

The records include the failover time as well. This means that the user can be under-charged if the Call Server fails and over-charged if the LTPS or network fails.

#### CallPilot

ACF considers CallPilot to be a TDM resource and interaction of an IP Phone with CallPilot as an IP/TDM call. See <a href="IP/TDM calls">IP/TDM calls</a> on page 66 and <a href="Table 15">Table 15</a>: ACF behaviors</a> on page 61.

**Example:** IP Phone A calls telephone B and is redirected to CallPilot on no answer. The IP/TDM call is established between the IP Phone A and CallPilot.

The media session between IP Phones and CallPilot is dropped due to INI. You can restart the session by, for example, cold start, warm start, or ungraceful switchover.

During any failure, user input does not pass to CallPilot. The user must resume entering responses after the IP Phone re-registers.

#### Interactions considered as IP/TDM calls

The ACF feature also considers interaction of an IP Phone with the following to be an IP/TDM call:

- CallPilot Mini
- Meridian Mail
- Meridian Mail Card Option
- Companion DECT Telephones (DMC8 version)
- Remote Office 9150
- · Mini Carrier Remote
- Carrier Remote
- Periphonics Open IVR (VPS/is)
- Integrated Call Assistant

- Integrated Conference Bridge
- Integrated Recorded Announcer
- Integrated Personal Call Director
- Integrated Voice Services

### Avaya NES Contact Center Management Server

The ACF feature interacts with the Avaya NES Contact Center Management Server environment in the following cases:

- · Acquired ACD agent is an IP Phone.
  - If a failure occurs when the IP Phone is active, the ACD IP Phone behaves as described in IP Phone as ACD agent or supervisor telephone on page 70.
  - If the active unregistered ACD agent changes the call state during the failure period (for example, releases the call), the status message is sent to the Symposium and CTI applications as the idle agent re-registers with the system.
- Associated non-ACD telephone is an IP Phone.
  - If a failure occurs when the IP Phone is active, the ACD IP Phone behaves as any other IP Phone. If the active associated IP Phone changes the call state during the failure period (for example, releases the call), the status message is sent to the Symposium and CTI applications as the idle telephone re-registers with the system.

#### MCS 5100

The SIP calls between the CS 1000 IP Phone and a SIP party on the MCS 5100 side are IP Peer calls. Such calls survive any failure except a Call Server cold start.

# Installation and configuration

The ACF feature for IP Phones requires no installation. It is active by default on any CS 1000 system running CS 1000 Release 4.5 or later.

On a system running CS 1000 Release 4.5 or later, every node running the CS 1000 Release 4.5 or later LTPS software has the ACF feature enabled for the registered IP Phones.

# **Configurable RUDP Time-out and Retries Count**

When a network failure occurs and the IP Phone connection is lost, the IP Phone does not instantly start the failover. The IP Phone waits for a period of time for a reply from the server (the length of time is the value of RUDP timeout in milliseconds). If the IP Phone does not receive a reply from the server in that length of time, the IP Phone retransmits the message. The IP Phone retransmits the message the number of times of the Retries count value, and then starts the failover process; the IP Phone tries to reconnect to S1, then to S2, and so on.

You can configure the time-out and number of retries in the Linux shell of the Signaling Server. See <u>Table 16: RUDP Timeout and Retries Count commands</u> on page 73.

**Table 16: RUDP Timeout and Retries Count commands** 

Command	Description
usiSetPhoneRudpRetries	Configure the RUDP Retries Count maximum for IP Phones
	1 – (10) – 20
usiGetPhoneRudpRetries	Display the RUDP Retries Count maximum for IP Phones
usiSetPhoneRudpTimeout	Configure the RUDP Timeout value (in ms) for IP Phones
	50 – (500) – 1000 in increments of 50 milliseconds
usiGetPhoneRudpTimeout	Display the RUDP Timeout value (in ms) for IP Phones
If the customer has a network with low network delays, one or both parameters can be reduced to make an	

If the customer has a network with low network delays, one or both parameters can be reduced to make an IP Phone more responsive to failures. If the network delay values are high, you can increase the values to prevent the IP Phones from being reset due to significant network delay.

The configured values are saved in the [usiLib] section of the TPS.ini file and downloaded to all UNiStim IP Phones registered to the Signaling Server. When a supported IP Phone registers with the Signaling Server, the IP Phone downloads the new values.

You must configure these values on every Signaling Server in the node.

# Overlay and command modifications

Because call failover is an exceptional situation, ACF information is output only if it exists.

### Status definitions

#### **UNREG**

The ACF call is UNREGISTERED (UNREG). This occurs when both parties go offline. This state is always monitored by the 10-minute ACF timer. The call is released if the Call Server ACF timer expires.

#### **HREG**

The ACF call is HALF-REGISTERED (HREG). This occurs when one telephone involved in the call is registered with the Call Server, but the other telephone fails or is not connected to the Call Server. The CS ACF timer is started only if the other party does not support disconnect supervision.



#### Note:

Disconnect supervision can be configured for analog trunks only. Disconnect supervision is supported by default for virtual and digital trunks. The ACF timer is also started if the other party is a virtual trunk with CPDC (Called Party Disconnect Control) configured for RDB (Route Data Block). There are CPDC feature limitations for route usage in this case. For more information, see NN43001-106, Features and Services Fundamentals — Book 2 of 6.

#### **HREB**

The ACF call is HALF-REBUILT (HREB). This occurs when no call-associated data was found and the Call Server creates the data. HREB happens when the first of the two telephones involved registers with the Call Server, while another telephone is still not connected to the Call Server. When the far-end telephone registers, the partially-rebuilt call is promoted to REBUILT state.

#### **PREB**

The ACF call is PARTIAL-REBUILT (PREB). This occurs when no call-associated data is found. The far-end IP address is not known on the Call Server, or the far-end IP address is translated to the virtual trunk TN. The Call Server creates the data leaving the far-end TN undefined.

This scenario happens when

- the far-end telephone is a local telephone, but while it was registered with the remote Call Server, the local Call Server cold started and TN-to-IP address associations were lost
- the far-end telephone is a remote telephone

The terminating-party TN in the PREB call is 0.



No signaling passes to the far-end telephone involved in the HREG, HREB, and PREB calls. This means that any features that involve both parties do not work with such calls.

#### **REB**

The ACF call is REBUILT (REB). The calls have both parties available, but all call data except bandwidth and connected transducers is lost.

### LD 32 STAT command

If ACF information exists for the requested IP Phone, it is output as follows:

ACF STATUS <status> TMR <timer>

#### <status> is

- · UNREG for unregistered calls
- HREG for half-registered calls
- REB for rebuilt calls

· PREB for partially-rebuilt calls

#### <timer> is

- an integer value if the timer exists for the call
- N/A if there is no Call Server ACF timer attached

See Figure 3: LD 32 STAT output with ACF example on page 75.

```
.stat 81 1
BUSY UNREGISTERED 00
ACF STATUS UNREG TMR 110

.stat 81 2
BUSY REGISTERED 00
ACF STATUS HREG TMR N/A

.stat 81 3
BUSY REGISTERED 00
ACF STATUS REB TMR N/A
```

Figure 3: LD 32 STAT output with ACF example

### LD 80 TRAC command

If ACF information exists for the requested IP Phone, it is output as follows:

```
ACF STATUS <status> TMR <timer> ORIG <orig_state>
```

#### <status> is

- UNREG for unregistered calls
- · HREG for half-registered calls
- · REB for rebuilt calls
- PREB for partially-rebuilt calls

#### <timer> is

- an integer value if the timer exists for the call
- N/A if there is no Call Server ACF timer attached

ORIG <orig\_state> can be REGISTERED or UNREGISTERED.

The following figure shows a sample output for IP Phones involved in UNREGISTERED and PARTIAL-REBUILT calls:

```
ACTIVE TN 081 0 00 00 V PHYSICAL TN 003 0 00 04
ORIG 008 0 00 00 0 SCR MARP 0 5500 2616

TERM 081 0 00 00 V PHYSICAL TN 000 0 00 00 SCR MARP RING ON 0
8100 I2004
DIAL DN 8100
MAIN PM ESTD
TALKSLOT ORIG 17 TERM 14
EES DATA:
NONE
QUEU NONE
CALL ID 0 197
ACF STATUS UNREG TMR 110 ORIG UNREGISTERED TERM UNREGISTERED
.TRAC 0 8100
ACTIVE TN 081 0 00 00 V PHYSICAL TN 003 0 00 04 ORIG 008 0 00 00 0 SCR MARP 0 5500 2616 TERM 000 0 00 00 V PHYSICAL TN 000 0 00 00 0
DIAL DN 8100
MAIN_PM ESTD
TALKSLOT ORIG 17 TERM 14
EES_DATA:
NONE
QUEU NONE
CALL ID 0 201
ACF STATUS PREB TMR N/A ORIG REGISTERED
                                                     TERM UNREGISTERED
```

Figure 4: LD 80 TRAC with ACF example

### LD 117 STIP ACF command

A subcommand ACF is added to the existing LD 117 STIP command.

Table 17: LD 117 STIP ACF command

Command	Description
STIP ACF <status></status>	Displays the Active Call Failover (ACF) information.
	<status> – optional parameter. Specifies the status to be output. Outputs all IP Phones involved in the following types of calls:</status>
	UNREG: UNREGISTERED calls
	HREG: HALF-REGISTERED calls
	REB: REBUILT calls
	HREB: HALF-REBUILT calls
	PREB: PARTIAL-REBUILT calls
	ALL: all types of ACF calls
	If no status parameter is entered, all types of ACF calls are output.

# Output

The output is similar to the existing LD 117 STIP output, with the addition of a column titled ACF STATUS. If the call is in an inactive state, the value of the Call Server ACF timer follows that status, separated by a colon (:).

# **LD 117 STIP ACF in Element Manager**

Support for the STIP ACF command in LD 117 is provided by Element Manager. Select System, Maintenance. Select LD 117 - Ethernet and Alarm Management. Select Ethernet Diagnostics. The Ethernet Diagnostics window appears.

<u>Figure 5: LD 117 STIP ACF in Element Manager</u> on page 77 illustrates the placement of the **STIP ACF** command with the other STIP commands.




Figure 5: LD 117 STIP ACF in Element Manager

A list of command parameters are available after you select the STIP ACF command. The ALL command parameter is the default.

Click the Submit button after you select an available parameters to run the command. The output appears in the box in the lower portion of the Web page.

Online Help describes the parameters available for the STIP ACF command.

# DSP peg counter for CS 1000E systems

Digital Signaling Processor (DSP) resources residing on a Voice Gateway Media Card in the IP Media Gateway (IPMG) of a CS 1000E system convert TDM voice to IP packets. The Voice

Gateway Media Cards have a limited number of DSP resources that perform the conversion. When all DSP resources are busy, IP-to-TDM calls and TDM-to-TDM calls between IPMGs are blocked. IP-to-IP calls are not blocked.

The DSP Peg Counter feature provides three counters. The first peg counter provides a count of the number of attempts to allocate a DSP resource on an IPMG. The second provides a count of the number of times calls were blocked on an IPMG due to a lack of DSP resources. If the call failed due to a lack of bandwidth, this is reflected in the third peg counter. The counters are a part of customer traffic measurement in LD 2.

For more information, see *Traffic Measurement: Formats and Output Reference, NN43001-750* and *Software Input Output — Administration, NN43001-611*.

# **Enhanced UNIStim Firmware Download for IP Phones**

Firmware files are stored on and are downloaded from the Signaling Server.

The Enhanced UNIStim Firmware Download for IP Deskphones provides a method of delivering new firmware for Avaya IP Deskphones.

Specifically, this feature provides the following functionality:

- Enhanced firmware file header that includes the IT\_TYPE and name string for each IP
  Deskphone type. Element Manager and the LTPS can read this information and automatically
  display the mapping to the administrator.
- Revised definition of the IP Client IP Deskphone identification.
- Maintenance Mode for the Signaling Server that allows simultaneous firmware downloads from the UFTP server. The administrator manually initiates Maintenance Mode (Turbo Mode) in which premarked node Signaling Servers use all possible resources for processing firmware upgrade jobs.
- Identification of the registered IP Deskphones using string names and providing detailed identification of IP Deskphones that register in Emulation Mode.
- UNIStim IP Deskphones can register with a previous version of firmware if the UFTP servers are busy, and then periodically offer the option to start the firmware upgrade to the IP Phone user.
- Introduction of missing firmware file retrieval to the Branch Office from the Main Office.

System management commands are provided to collect information about registered IP Deskphones, models, and firmware.

# **Operating parameters**

Enhanced UNIStim Firmware Download feature is supported on the following systems running CS 1000 Release 4.5 or later.

• CS 1000M HG

- CS 1000M SG
- CS 1000M MG
- CS 1000E

The Enhanced UNIStim Firmware Download feature has the following operating parameters:

- Supports only firmware downloads performed by the UFTP server to the UNIStim IP Phones that support the UFTP download protocol.
- Enhanced functionality is provided only if the recommended commands are used. For example, using the shell cp command instead of the firmwareFileGet command bypasses the other features and is therefore not supported.
- Firmware retrieval mechanism described for the Branch Office LTPS retrieves only firmware
  files it finds missing. It does not compare the list of firmware on the Branch Office LTPS and
  Main Office LTPS to determine whether the Branch Office has the most recent firmware, or
  perform any automatic comparisons and update operations. The Branch Office LTPS receives
  firmware files only when the umsUpgradeAll command was issued on the Main Office LTPS.

### **Feature interactions**

#### **Active Call Failover for IP Phones**

The Active Call Failover feature handles cases when an IP Phone registers with an active RTP stream (has a call active at the time of registration). The check of IP Phone firmware is skipped in this case, and the IP Phone registers with the LTPS.

The Active Call Failover scenario is the same as the postponed firmware upgrade scenario described in <u>Table 22: IP Phones registration and download scenarios</u> on page 83. After the call ends, the user is prompted to start the firmware upgrade.

For more information about Active Call Failover for IP Phones, see <u>Active Call Failover for IP Phones</u> on page 59.

# System view

# IP Phone firmware upgrades

Each IP Phone that registers with the LTPS is queried for the firmware ID and IT\_TYPE. The system response depends on the results of the query. See <u>Table 18: System response</u> on page 80.

Table 18: System response

Query result	Response
LTPS software supports the reported IT_TYPE (see Table 19: Supported IT_TYPES on page 80) and the Upgrade Manager has firmware for the firmware ID.	Registration of the IP Phone continues. The IP Phone firmware upgrade occurs if possible.
LTPS software supports the reported IT_TYPE, but the Upgrade Manager has no firmware for the given firmware ID.	Registration of the IP Phone continues with no firmware download.
LTPS software does not support the IT_TYPE reported.	Registration of the IP Phone is rejected.
The branch office IP Phone is upgraded at the branch office before the IP Phone is redirected to the main office.	Registration of the IP Phone continues with no firmware download.

### Firmware file management

To manage available firmware, the following information is collected about each firmware file on the Signaling Server:

- firmware ID
- firmware version
- applicable IT\_TYPE (see <u>Table 19</u>: <u>Supported IT\_TYPES</u> on page 80)
- · applicable model names

# **IT\_TYPEs**

<u>Table 19: Supported IT\_TYPES</u> on page 80 lists the IT\_TYPES supported by the Upgrade Manager for CS 1000 Release 5.5

Table 19: Supported IT\_TYPES

IT_TYPE	IP Deskphone
0x02	IP Phone 2004, Avaya 2007 IP Deskphone, WLAN 2210/2211/2212, Avaya 6120/6140 WLAN Handset, Avaya 1140E IP Deskphone, Avaya 1165E IP Deskphone
0x03	IP Phone 2002, Avaya 1120E IP Deskphone 1120E
0x04	IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone
0x20	Avaya 2050 IP Softphone, Mobile Voice Client 2050
0x06	Avaya 1150E IP Deskphone
0x08	Avaya 1210 IP Deskphone
0x09	Avaya 1220 IP Deskphone
0x0B	Avaya 1230 IP Deskphone

Two events provide data about firmware files to be updated by the LTPS:

- LTPS restart
- 2. new firmware file upload from either the LTPS Command Line Interface (CLI) or Element Manager

In the first case, the LTPS explores possible locations of firmware files and collects information about found files in the internal database. In the second case, when a new firmware file is uploaded, the LTPS updates the internal database with information extracted from the file.

Element Manager uses data from the firmware file to provide information about the firmware file and the IP Deskphones to which the firmware can be downloaded.

#### Firmware file names

Firmware file names are originally in the format SSFFYxx.bin. See <u>Table 20: Original firmware file</u> <u>name format</u> on page 81.

**Table 20: Original firmware file name format** 

Designator	Definition	Values
SS	Site code where firmware was built	06 – Calgary 30 – Ottawa
FF	Firmware type	02 – Phase 0/1 IP Phone 2004 03 – Phase 1 IP Phone 2002 04 – Phase 2 IP Phone 2001, IP Phone 2002, IP Phone 2004
Y	Alphabetic character	A - 0 B - 1 C - 2 D - 3 (and so on)
XX	Release number	Two-digit decimal integer (for example, . 38)

The files are renamed according to the following rules:

- Phase 0/1 IP Phone 2004 firmware is renamed to x00.fw
- Phase 1 IP Phone 2002 firmware is renamed to x01.fw
- All other firmware files are renamed to xFF.fw:
  - x emphasizes that FF is a hexadecimal number
  - FF is the firmware ID for the file

Table 21: Firmware file naming conventions

x00.fw	IP Phone 2004 Phase 0/1
x00.fw	IP Phone 2002 Phase 1
x02.fw	IP Phone 2004 Phase 2
x02.fw	IP Phone 2002 Phase 2

Table continues...

x02.fw	IP Phone 2001 Phase 2
x10.fw	Avaya 2033 IP Conference Phone
x21.fw	Avaya 2007 IP Deskphone Phase 2
x23.fw	Avaya 1110 IP Deskphone
x24.fw	Avaya 1120E IP Deskphone
x25.fw	Avaya 1140E IP Deskphone
x26.fw	Avaya 11^%E IP Deskphone
x27.fw	Avaya 1150E IP Deskphone
x2A.fw	Avaya 1200 series IP Deskphones

The xFF.fw format also applies to the firmware file for the Phase 2 IP Phone 2001, IP Phone 2002, and IP Phone 2004. The file was named IPP2SET.fw but is renamed to x02.fw to conform to the naming convention.

### **Download maximums**

The following modifications are available on the Signaling Server to the Upgrade Manager:

- The default number of allowed simultaneous downloads is 50.
- Maintenance Mode (Turbo Mode) that the administrator manually initiates is available in which
  premarked node Signaling Servers use all possible resources to process firmware upgrades.
  The following commands are used to manage the Maintenance Mode:
  - uftpTurboMode
  - uftpTurboModeTimeoutSet
  - uftpTurboModeShow

The uftpTurboMode command is used with RST FW (soft-resets (re-registration to LTPS) all IP Deskphones with specified F/W ID) and RST ZONE (soft-resets (re-registration to LTPS) all IP Phones) commands in LD 117. For more information about commands in a specified zone, see <u>Table 23: Maintenance Mode commands</u> on page 85.

For more information about Maintenance Mode, see Maintenance Mode on page 84.

# Immediate and delayed firmware downloads

The IP Phones display various messages to indicate the status of IP Phone registration and firmware downloads. <u>Table 22: IP Phones registration and download scenarios</u> on page 83 lists some scenario examples with the resulting IP Phone information.

Table 22: IP Phones registration and download scenarios

Scenario	Result
Normal firmware download for known IP Phone type	The IP Phone is connecting to the LTPS.
	The firmware download starts.
	If download is successful, IP Phone continues with normal registration.
Postponed firmware upgrade	The IP Phone is connecting to the LTPS.
	IP Phone cannot download firmware. It can proceed with registration using old firmware.
	At the completion of call (if download resources are available), IP Phone displays "Upgrade F/W now?"
	IP Phone displays Yes and No soft keys to use to select choice. If you select Yes, the firmware download begins. If you choose nothing, the IP Phone downloads the firmware after the timer expires.
	If you select No, the IP Phone display returns to idle state. Off-hook dialing, on-hook dialing, and external events such as an incoming call imply a No response.
Unknown firmware ID for known	The IP Phone is connecting to the LTPS.
IT_TYPE	No firmware upgrade occurs, but the IP Phone can register.
Unknown IT_TYPE	IP Phone has no display. The IP Phone resets continuously.
	IP Phone registration is not allowed.
	Log message is sent to LTPS administrator.
Branch Office LTPS determines IP Phone requires firmware upgrade	The firmware download is initiated. The IP Phone is placed into local mode.
	The message appears until firmware is downloaded. The IP Phone upgrade starts.
	If firmware download is unsuccessful after 10 retries, the IP Phone remains in local mode.

# Note:

When you issue the umsUpgradeAll command on TPS all IP Phones (with "old" Firmware) are restarted and try to upgrade to the new firmware. However, if TPS is not in maintenance mode and doesn't have enough resources to start a firmware upgrade then some IP Phones might be registered with "old" firmware. Please refer to "Postponed firmware upgrade" section in the table "IP Phone registration and download scenarios". If TPS is in maintenance mode, umsUpgradeAll upgrades all IP Phones. If there are not enough resources for upgrade, then IP Phone will be put in pending queue and upgraded as soon as TPS has CPU resources to proceed.

### **Maintenance Mode**

Maintenance Mode enables the UFTP server to use most of the processing resources to handle the downloads.

The actual number of simultaneous downloads is determined by measuring the CPU idle time, so each new firmware download session starts if there are less than 50 download sessions for the Signaling Server already taking place and one of the following is true:

- · there are less than five download sessions currently active
- Signaling Server is in regular mode (not in Maintenance Mode) and its CPU usage is less than 85 percent
- Signaling Server is in Maintenance Mode and its CPU usage is less than 100 percent

The UMS tries to start a pending download session every 5 seconds.

### **!** Important:

When Maintenance Mode is enabled, UFTP download process can affect call processing signaling.

Maintenance Mode can be exited in several ways:

- manually, by using the uftpTurboMode "stop" command
- automatically, after the Upgrade Manager is idle for MM minutes after at least one download starts This prevents a time-out while the system is configured and the downloads start. After a download starts, if MM minutes pass with no new firmware upgrade jobs starting, the normal mode of operation resumes. Configure the idle timeout timer using the uftpTurboModeTimeoutSet command.
- automatically, after expiration of the Maintenance Mode period

Active firmware upgrade jobs are not cancelled when the Maintenance Mode exits. No new jobs are added until the number of active jobs is below the default value.

Maintenance Mode is available only on the Signaling Server. Maintenance Mode affects only Signaling Servers designated for Maintenance Mode. Some Signaling Servers in the node can operate in Maintenance Mode while others do not. The Signaling Server is designated for Maintenance Mode with the uftpTurboMode "on" command. The Maintenance Mode designation is saved and maintained even if the Signaling Server is power-cycled or restarted. Firmware downloads do not affect Call processing for Signaling Servers operating in normal mode.

Firmware upgrades are postponed when at least one Signaling Server is in Maintenance Mode.

<u>Table 23: Maintenance Mode commands</u> on page 85 lists the commands used for Maintenance Mode.

**Table 23: Maintenance Mode commands** 

Command	Description
uftpTurboMode <"HH:MM/start/stop/on/off">, <mm> &lt;"show"&gt;</mm>	Configures Maintenance Mode
	HH:MM: time to enter Maintenance Mode in 24-hour format
	start: enter Maintenance Mode immediately
	stop: stop Maintenance Mode
	on: allow Signaling Server to enter Maintenance Mode
	off: do not allow Signaling Server to enter Maintenance Mode
	MM: optional parameter that defines the length of time in minutes that Maintenance Mode is to be maintained
	show: displays the same output as uftpTurboModeShow
	If you enter no parameter, Upgrade Manager uses uftpturboMode "start".
uftpTurboModeTimeoutSet <mm></mm>	Configures the idle timeout timer for Maintenance Mode
	MM: optional parameter that defines the number of minutes the Upgrade Manager waits after the last firmware download job starts before returning the Signaling Server to normal mode If this parameter is 0 (zero), the Upgrade Manager never exits Maintenance Mode unless the umsUpgradeModeSet command is issued with the "stop" parameter.
	If you enter no parameter, then the current timeout setting appears.
uftpTurboModeShow	Displays current status of Maintenance Mode.

The following is an example of output when Maintenance Mode is to start at 11:00 p.m.

```
uftpTurboMode "23:00"
```

The log file /var/log/cs1000/ss\_common.log will contain the following record:

```
Mar 31 02:53:12 si-linux tps: (INFO) tUMS: F/W download Turbo Mode is scheduled for 23:00. Will run after 408 seconds
```

# **Call Server commands**

#### **LD 20**

A response ISET is introduced to the LD 20 TYPE prompt. When you enter ISET, the prompt MODEL\_NAME appears. The MODEL\_NAME prompt allows you to specify the Short Model Name mnemonic to filter TN block output. If you use only the ISET response, printed TN blocks contain the long IP Phone Model Name.

Table 24: LD 20 Listing or printing TN blocks of specified IP Phone model

Prompt	Response	Description
REQ	LTN	List TN blocks.
	PRT	Print TN blocks.
TYPE	ISET	Enable filtering by IP Phone model name.
MODEL_NAME	xxxxxx	IP Phone model (for example, 2004P2).

#### The following is an example of the input and output.

```
>1d 20
REO: PRT
TYPE: ISET
TN
CUST
TEN
DATE
PAGE
DES
MODEL NAME: 2004P2
KEM RANGE
IP PHONE MODEL: IP PHONE 2004 PHASE2
DES FAKE
TN 064 0 00 00 VIRTUAL
TYPE 2004P2
CDEN 8D
CUST 0
ZONE 000
FDN
TGAR 1
LDN NO
NCOS 0
SGRP 0
RNPG 0
SCI 0
SSU
XLST
SCPW 6400
SFLT NO
CAC_CIS 3
CAC_MFC 0
CLS CTD FBD WTA LPR MTD FND HTD ADD HFD CRPD
MWD LMPN RMMD SMWD AAD IMD XHD IRD NID OLD VCE DRG1
POD DSX VMD CMSD SLKD CCSD SWD LND CNDD
CFTD SFD MRD DDV CNID CDCA MSID DAPA BFED RCBD
ICDD CDMD LLCN MCTD CLBD AUTU
GPUD DPUD DNDD CFXD ARHD CLTD ASCD
CPFA CPTA HSPD ABDD CFHD FICD NAID DNAA RDLA BUZZ AGRD MOAD
UDI RCC HBTD AHD IPND DDGA NAMA MIND PRSD NRWD NRCD NROD
DRDD EXR0
USMD USRD ULAD CCBD RTDD RBDD RBHD PGND FLXD FTTC DNDY DNO3 MCBN
FDSD NOVD VOLA VOUA CDMR
CPND LANG ENG
HUNT
PLEV 02
CSDN
```

```
AST
IAPG 0
AACS NO
ITNA NO
DGRP
MLWU LANG 0
DNDR 0
KEY 00 SCR 640 0 MARP
ANIE 0
01
02
03
04
05
06
07
80
09
10
11
12
13
14
15
16
17 TRN
18 AO6
19 CFW 16
20 RGA
21 PRK
22 RNP
23
24 PRS
25 CHG
26 CPN
27
28
29
30
31
DATE 8 JUL 2004
```

#### LD 117

LD 117 commands are as follows:

- STIP FW <XX> <A> <BB> <FF>: list IP Phone with specified firmware ID and, optionally, firmware version. If no parameters are entered, output is a list of available model names.
- STIP MODL <MMMM>: list IP Phones of specified model name.
- RST ZONE <ZoneNumber> <START/STOP> <HH:MM>: reset IP Phones in specified zone.
- RST FW <FWID> <START/STOP> <HH:MM>: reset IP Phones with specified F/W ID.

See Table 25: LD 117 commands on page 88.

Table 25: LD 117 commands

Command	Description
STIP FW <xx> <a> <bb> <ff></ff></bb></a></xx>	Displays information from the Resource Locator Module (RLM) for IP Phones with specified firmware ID and running specified firmware version.
	<xx>: firmware ID</xx>
	<a>: major version designator</a>
	<bb>: minor version designator</bb>
	<ff>: filter to apply on firmware version; can be one of the following:</ff>
	=: equal to
	~:not equal to
	<: less than
	>: greater than
	Only the XX parameter is required.
	STIP FW <xx> <a> <bb> is equivalent to STIP FW <xx> <a> <bb> EQ.</bb></a></xx></bb></a></xx>
	STIP FW <xx> <a> lists all registered IP Phones with firmware ID equal to <xx> and major version designator equal to <a>.</a></xx></a></xx>
	STIP FW <xx> lists all registered IP Phones with firmware ID equal to <xx>.</xx></xx>
STIP MODL <mmmm></mmmm>	Displays information from the RLM for all IP Phones of the specified model, where:
	MMMM = IP Phone model
	If you omit the <mmmm> parameter, a table of existing model names and associated mnemonics appears.</mmmm>
RST ZONE <zonenumber></zonenumber>	Immediately soft-resets (re-registration to LTPS) all IP Phones, where:
	ZoneNumber = zone number
RST ZONE <zonenumber> <start <br="">STOP&gt; <hh:mm></hh:mm></start></zonenumber>	Schedule or cancel soft-resets (re-registration to LTPS) of all IP Phones in specified zone.
	<zonenumber>: zone number in which to reset IP Phones</zonenumber>
	START/STOP: IP Phones reset, where:
	START: configures reset time schedule
	STOP: cancels scheduled reset
	If START is specified and you omit the last parameter, then IP Phones reset immediately.

Table continues...

Command	Description
	<hh:mm>: hour and minute when IP Phones are to be reset</hh:mm>
	With only the first parameter, or no parameters, the schedule of IP Phones resets prints.
RST FW <fwid> <start stop=""> <hh:mm></hh:mm></start></fwid>	Soft-resets (re-registration to LTPS) all IP Phones with specified firmware ID.
	<f id="" w="">: firmware ID of IP Phones that should be reset</f>
	<start stop="">: schedules or cancels IP Phones hard-reset. If you select START and you omit the last parameter, then IP Phones reset immediately.</start>
	<hh:mm>: hour and minute when IP Phones should be reset</hh:mm>
	With only the first parameter, or with no parameters specified, the schedule of IP Phones resets prints.

# LTPS CLI commands

LTPS CLI commands are as follows:

- firmwareFileGet
- uftpAutoUpgradeTimeoutSet
- isetFWShow

See Table 26: LTPS CLI commands on page 89.

Table 26: LTPS CLI commands

Command	Description
firmwareFileGet "ServerIP", "UserID", "Password", "/path/to/file", "file name" ProtocolID	Uploads a firmware download from a specified FTP server. After the download is completed, the downloaded file is checked for Enhanced Header (or proper naming). If the file is a valid firmware file, the UMS database is updated accordingly.
	ServerIP: FTP server IP address to download the firmware from
	UserID, Password: credentials for logging on to the FTP server
	/path/to/file: absolute or relative path to the firmware file (does not include the file name)
	file name: name of the firmware file on the FTP server
	Use the firmwareFileGet command instead of firmwareFileGetI2004, firmwareFileGetI2002, and firmwareFileGetIPP2.
	ProtocolID: 0 - FTP protocol; 1 - SFTP protocol. ProtocolID is optional. SFTP is used by default.

Table continues...

Command	Description
uftpAutoUpgradeTimeoutSet <mm></mm>	Configures the length of time the IP Phone waits for a user response after "Upgrade F/W now?" appears before automatically beginning the firmware upgrade.
	MM: user response timeout in minutes. A value of 0 (zero) means Print current settings.
	If no parameter is entered, the current value prints.
isetFWShow	Displays the status of IP Phones firmware.

# firmwareFileGet example

```
firmwareFileGet "192.168.0.1", "admin1", "0000
"/var/opt/nortel/tps/fw"
```

### firmwareFilePut example

```
firmwareFilePut "192.168.0.1", "admin1", "0000 "/var/opt/nortel/tps/fw"
```

### uftpAutoUpgradeTimeoutSet output example

```
uftpAutoUpgradeTimeoutSet 4
Log file /var/log/nortel/ss_common.log will contain the following line: Mar 31 02:53:12
si-linux tps: (INFO) tUMS: New value of auto F/W upgrade timeout is 240 seconds.
uftpAutoUpgradeTimeoutSet
Log file /var/log/nortel/ss_common.log will contain the following line: Mar 31 02:53:12
si-linux tps: (INFO) tUMS: Current value of auto F/W upgrade timeout is 240 seconds.
```

### isetFWShow output example

#### LTPS CLI commands

The output for the following commands prints IP Phone model name (long or short), firmware ID, firmware version:

- uftpShow
- umsPolicyShow
- · isetGet

Short model name example is 2004P2. Long model name example is IPPhone2004 Phase 2.

### uftpShow output example

The output displays the IP Phone Model Name, firmware ID, and firmware version in ABB format.

```
uftpShow
----- UFTP Server Configuration -----
UFTP Server IP address...... 192.168.29.42 [port: 5105]
Concurrent downloading limit.... 15 sets
Total firmware = 5
FW ID FWVsn Model PolicyName file name
----- 0x00 B.65 IP Phone 2004 DEFAULT /ums/i2004.fw
0x00 B.65 IP Phone 2002 DEFAULT /ums/i2002.fw
0x02 D.44 IP Phone 2001 DEFAULT /ums/x02.fw
0x02 D.44 IP Phone 2002 Ph2 DEFAULT /ums/x02.fw
0x02 D.44 IP Phone 2004 Ph2 DEFAULT /ums/x02.fw
    ----- Run Time Data -
Last UFTP reset...... 1/14/2096 08:38:19
Cumulation Period...... 0004 01:55:01
Successful downloads..... 1
Fail downloads..... 0
  ----- Active Downloads -----
Current downloading sets..... 0
Model IP Address Downloaded[KByte]
```

### umsPolicyShow output example

The output displays the IP Phone Model Name, firmware ID, and firmware version in ABB format.

# isetGet output

The output displays the IP Phone Model Name and firmware version in ABB format.

# **Element Manager**

To support the Enhanced UNIStim Firmware Download for IP Phones feature, Element Manager provides the following functions:

- Extraction and display of information from the Enhanced firmware file. For example, when new
  firmware is downloaded to Element Manager firmware location from the FTP server, Element
  Manager examines the file for the text string containing firmware ID, firmware version,
  applicable IT\_TYPEs, and model names.
- Ability to upload a new firmware file to the LTPS using the firmwareFileGet command.
- An interface to initiate or obtain the status for the firmware download Maintenance Mode using the CLI commands uftpTurboMode, uftpTurboModeShow, and uftpTurboModeTimeoutSet.

The uftpTurboMode CLI commands are used with the RST FW and RST ZONE commands.

- An interface to reset IP Phones by firmware ID and zone using the LD117 commands RST FW and RST ZONE.
  - See <u>Table 23: Maintenance Mode commands</u> on page 85 for a description of LD 117 commands.
- Output of either ECNT MODL is parsed to obtain the list of available IP Phone models. Use this
  output to allow a user to transparently specify the model name; that is, Element Manager
  replaces the actual model name with associated mnemonic.
- An interface to display the output of the LD 117 commands ECNT MODEL, ECNT FW, ECNT PEC, STIP MODL, and STIP FW.
- Management of the compatibility matrix of various firmware versions with the Call Server and LTPS software release using the output of these LD 117 commands.
- Interaction with the Avaya Software Download Web site to download bundles of firmware files.

# IP Phone firmware management in Element Manager

For information about updating the IP Phone firmware in Element Manager, see <u>Upgrade the Voice</u> <u>Gateway Media Card and IP Phone firmware</u> on page 248.

# **Ethernet Diagnostics in Element Manager**

To access Ethernet Diagnostics in Element Manager, perform the steps in <u>Accessing Ethernet Diagnostics in Element Manager</u> on page 92.

#### **Accessing Ethernet Diagnostics in Element Manager**

1. In the Element Manager navigator, select **System > Maintenance**.

The Maintenance window appears. See Figure 6: Maintenance window on page 93.



Figure 6: Maintenance window

By default, **Select by Overlay** is selected.

2. Select LD 117 – Ethernet and Alarm Management in the <Select by Overlay> list, and then select Ethernet Diagnostics in the <Select Group> list.

The Ethernet Diagnostics window appears. See <u>Figure 7: Ethernet Diagnostics window</u> on page 93.

Alternatively, select Select by Functionality.

Select **Ethernet Diagnostics** from the **<Select by Functionality>** list. See <u>Figure 8: Select by Functionality list</u> on page 94.

The Ethernet Diagnostics window appears.




Figure 7: Ethernet Diagnostics window




Figure 8: Select by Functionality list

For more information about the LD 117 commands, see <u>LD 117</u> on page 87.

### **ECNT** commands

The following commands are available in LD 117 under ECNT in the Status Command list. See <u>Figure 9: ECNT commands</u> on page 95.

- ECNT FW
- ECNT MODL
- ECNT PEC
- ECNT CARD
- ECNT NODE
- ECNT SS
- ECNT ZONE

### Important:

ECNT CARD, ECNT NODE, ECNT SS, and ECNT ZONE were formerly found in LD 32.




Figure 9: ECNT commands

#### STIP commands

STIP MODL and STIP FW are listed in the STIP commands in the Status Command list. See <u>Figure 10: STIP commands</u> on page 95.




Figure 10: STIP commands

#### **RST** commands

RST ZONE and RST FW are listed in the RST commands in the Status Command list. Both RST commands reset IP Phones for the parameters specified. See <u>Figure 11: RST commands</u> on page 96.

**Ethernet Diagnostics** 

#### STAT LINK IP - Link status -- IP • Submit STAT SERV - Server status • Submit STIP TN - IP Status -- TN • PRT IPDN - Print DNs with a given IP address • ECNT FW - Etherset Count -- FWID MajorVer MinorVer Filter RST ZONE - Reset IP Phone -- Zone START/STOP HH:MM RST ZONE - Reset IP Phone -- Zone START/STOP HH:MM RST FW - Reset IP Phone -- FWID START/STOP HH:MM STAT RFC2833 - RFC2833 Status -- TN Instruction: Select command, add value and click on [Submit]

Figure 11: RST commands

# Maintenance Mode commands in Element Manager

The Signaling Server Maintenance Mode (Turbo Mode) commands are as follows:

- uftpTurboMode
- uftpTurboModeShow
- uftpTurboModeTimeoutSet
- uftpAutoUpgradeTimeoutSet

#### uftpTurboMode

Use the uftpTurboMode command to designate one or more Signaling Servers for firmware upgrade Maintenance Mode, or to schedule Maintenance Mode on the designated Signaling Server to either start immediately or at a specific time. See <a href="Figure 14">Figure 14</a>: uftpTurboMode window in Element <a href="Manager">Manager</a> on page 97.

To access the uftpTurboMode command, perfrom the steps in <u>Accessing the uftpTurboMode command</u> on page 96.

#### Accessing the uftpTurboMode command

1. In the navigator, select IP Network, Maintenance and Reports.

The Node Maintenance and Reports window appears. See <u>Figure 12: Node Maintenance</u> and Reports window on page 97.



Figure 12: Node Maintenance and Reports window

- 2. Click the plus sign (+) to the left of the Node ID of the desired node to view the node elements.
- 3. Click **GEN CMD** for a Signaling Server.

The General Commands window appears. See <u>Figure 13: General Commands window</u> on page 97.




Figure 13: General Commands window

- 4. From the **Group** list, select **uftp**.
- 5. From the Command list, uftpTurboMode .
- 6. If you select **HH:MM**, enter the time in the Hours and Minutes boxes. No other option requires parameters.



Figure 14: uftpTurboMode window in Element Manager

#### 7. Click Run.

The command output appears in the pane below the command.

### uftpTurboModeShow

The uftpTurboModeShow command displays the current status of Maintenance Mode (None, Active, or Scheduled). To access the uftpTurboModeShow command using Element Manager, perform the steps in Accessing the uftpTurboModeShow command on page 98.

#### Accessing the uftpTurboModeShow command

- 1. In the navigator, select IP Network > Maintenance > Reports.
  - The Node Maintenance and Reports window appears. See <u>Figure 12: Node Maintenance</u> <u>and Reports window</u> on page 97.
- 2. Click the plus sign (+) to the left of the Node ID of the desired node to view the node elements.
- 3. Click **GEN CMD** for the desired Signaling Server.
  - The General Commands window appears. See <u>Figure 13: General Commands window</u> on page 97.
- 4. From the **Group** list, select **uftp**.
- 5. From the **Command** list, select **uftpTurboModeShow**. See <u>Figure 15: uftpTurboModeShow</u> <u>window in Element Manager</u> on page 98.



Figure 15: uftpTurboModeShow window in Element Manager

The command output appears in the pane below the command.

6. Click Run.

#### uftpTurboModeTimeoutSet

The uftpTurboModeTimeoutSet command configures the idle timer for Maintenance Mode. To access the uftpTurboModeTimeoutSet command using Element Manager, follow <u>Accessing uftpTurboModeTimeoutSet command</u> on page 98.

#### Accessing uftpTurboModeTimeoutSet command

- 1. In the navigator, select IP Network > Maintenance > Reports.
  - The Node Maintenance and Reports window appears.
- 2. Click the plus sign (+) to the left of the Node ID of the desired node to view the node elements.

3. Click **GEN CMD** for a Signaling Server.

The General Commands window appears. See <u>Figure 13: General Commands window</u> on page 97.

- 4. From the Group list, select uftp .
- 5. From the **Command** list, select **uftpTurboModeTimeoutSet** . See <u>Figure 16:</u> <u>uftpTurboModeTimeoutSet window</u> on page 99.

This command accepts the MM parameter.




Figure 16: uftpTurboModeTimeoutSet window

- 6. Enter the time in minutes in the **Timeout In** box.
- 7. Click Run.

The command output appears in the pane below the command.

#### uftpAutoUpgradeTimeoutSet

The uftpAutoUpgradeTimeoutSet command configures the idle timer for starting the firmware download. To access the uftpAutoUpgradeTimeoutSet command using Element Manager, follow Accessing uftpAutoUpgradeTimeoutSet command on page 99.

#### Accessing uftpAutoUpgradeTimeoutSet command

- 1. In the navigator, select IP Network > Maintenance > Reports.
  - The Node Maintenance and Reports window appears.
- 2. Click the plus sign (+) to the left of the Node ID of the desired node to view the node elements.
- 3. Click **GEN CMD** for a Signaling Server.
  - The General Commands window appears. See <u>Figure 13: General Commands window</u> on page 97.
- 4. From the **Group** list, select **uftp**.
- 5. From the **Command** list, select **uftpAutoUpgradeTimeoutSet** . See <u>Figure 17:</u> <u>uftpAutoUpgradeTimeoutSet window in Element Manager</u> on page 100.

This command accepts the MM parameter.



Figure 17: uftpAutoUpgradeTimeoutSet window in Element Manager

- 6. Enter the time in minutes in the **Timeout In** box.
- 7. Click Run.

The command output appears in the pane below the command.

# iset commands in Element Manager

Access **isetFWShow** in the General Commands window from the iset group in the **Group** list. See <u>Figure 18</u>: iset commands on page 100.




Figure 18: iset commands

# Firmware download using UNIStim FTP

Previously, IP Phones on CS 1000 systems downloaded firmware using Trivial File Transfer Protocol (TFTP). Firewalls often have the well-known TFTP port (port 69) disabled to maintain

security. When port 69 is blocked, IP Phones cannot obtain firmware downloads. This situation prevents the IP Phone from registering and coming into service.

To eliminate the file transfer problem with the firewalls and TFTP, a UNIStim File Transfer Protocol (UFTP) download solution is implemented.

UFTP enhances security, because it is a proprietary protocol, as opposed to TFTP which is an open protocol. It enables end users to improve the firewall security by closing port 69 to block TFTP in the firewall and policy-based switches and routers.

### Important:

For the UFTP IP Phone firmware download to work, you must explicitly open port 5100 (UNIStim signaling) and port 5105 (UFTP signaling).

If a network firewall is in use, you must explicitly open ports 5100 (UNIStim signaling) and 5105 (UFTP signaling) in the IP Phone-to-UFTP server direction. Opening these ports enables UNIStim and UFTP firmware download messages to travel through the firewall. Firewalls can safely enable both ports. See <u>Table 27</u>: <u>Source and destination port usage on either side of the connection</u> on page 101.

Table 27: Source and destination port usage on either side of the connection

Port	IP Phone signaling	IP Phone UFTP	UFTP Server
Source port	5000 (see below)	5000 (see below)	5105
Destination port	5100	5105	5000 (see below)

### Important:

The UFTP firmware download is compatible with the NAT Traversal feature. If the IP Phone is behind a Network Address Translation (NAT) device, then a different public signaling port is used. The public signaling port is assigned dynamically. See <u>Figure 19</u>: <u>Using NAT with UFTP</u> on page 101.




Figure 19: Using NAT with UFTP

Two Download log files log the results of the UFTP firmware downloads: uftplog0.txt and uftplog1.txt. One file is active and one file is inactive. When a file is full, it becomes the inactive file, and the other file is written to. The active file displays the most recent entries.

On the Signaling Server, the log files are in the /var/log/cs1000/ folder. The Download log files are limited to 400 K each, for a total of 800 K. Approximately 5000 log messages can be saved in each log file.

The Download log files are generated during initialization of the UFTP Server task. If the Download log files do not exist during the startup of the UFTP Server task, new Download log files are created.

The Download log file is a circular file, writing over the oldest information when the log file is full. Each log file entry contains the following download information about the IP Phone:

- · Firmware download date
- · Firmware download start time
- Firmware download status (specifies if the download succeeded or failed)
- · IP Address of the IP Phone
- IP Phone type
- Firmware download error code. If the Firmware download was successful, this field is empty. The following is the list of all possible error codes:
  - 00 = F/W not exist
  - 01 = F/W size is 0
  - 02 = F/W corrupt
  - 03 = RUDP connection down
  - 04 = Response time out
  - 05 = Reason: Unknown

The format of the download log message is as follows:

<Date> <Download start time> <Download Status> <IP address of the IP Phone> < IP Phone type> <Error Code>

The following is an example of the Download log message.

```
31/01/04 17:04:36 F/W Dnld fail:(47.11.215.44) i2004 Ph2
(F/W Corrupted)
31/01/04 17:05:46 F/W Dnld success:(47.11.215.44) i2004
```

### **CLI** commands

The following CLI commands support UFTP firmware downloads:

- uftpNodeShow
- uftpShow
- uftpRunTimeDataReset
- activeDlogShow
- inactiveDlogShow
- dnldFailShow

### uftpNodeShow

The uftpNodeShow command provides a complete UFTP IP Deskphone firmware download summary of each node. This includes the configured cards in the node that are not responding.

Each node summary contains the following information:

- Index
- TN LL S CC or C C
- Host Type
- TLAN IP Address
- Data Period
- Active Download Count (Act)
- Server Up Time (Srv Up Time)
- Successful Download Count (Ok)
- · Failure Download Count (Fail)

<u>Figure 20: uftpNodeShow command output</u> on page 103 is an example of output from the uftpNodeShow command.

Figure 20: uftpNodeShow command output

### uftpShow

The uftpShow command displays the following information:

- · configuration information about UFTP
- count of successful downloads because the Signaling Server restarted
- count of downloads that failed or prematurely ended because the Signaling Server restarted

- number of active downloads, and a list of each, including the following information:
  - type of IP Phone
  - IP addresses of the IP Phones that downloaded firmware
  - number of bytes downloaded

<u>Figure 21: uftpShow command output</u> on page 104 is an example of output from the uftpShow command.

```
oam> uftpShow
 ----- UFTP Server Configuration -----
UFTP Server IP address ...... 192.167.103.2 [port: 5105]
Concurrent downloading limit .... 100 sets
FirmWare ModelName
                                                    PolicyName FileName
        IP Phone 2004 Phase 0/1 DEFAULT /u/fw/x00.fw
IP Phone 2002 Phase 1 DEFAULT /u/fw/x01.fw
IP Phone 2004 Phase 2 DEFAULT /u/fw/x02.fw
IP Phone 2002 Phase 2 DEFAULT /u/fw/x02.fw
IP Phone 2001 Phase 2 DEFAULT /u/fw/x02.fw
IP Phone 2007 Phase 2 DEFAULT /u/fw/x21.fw
IP Phone 1120E DEFAULT /u/fw/x24.fw
IP Phone 1140E DEFAULT /u/fw/x25.fw
IP Phone 1150E DEFAULT /u/fw/x27.fw
DBB
DBB
DBB
C4C
C46
C46
C46
Total firmware = 9
            ----- Run Time Data -----
Successful downloads ..... 0
Fail downloads ..... 0
  ----- Active Downloads -----
Current downloading sets ..... 0
              IP Address Downloaded[KByte]
 TermType
```

Figure 21: uftpShow command output

# uftpRunTimeDataReset

The uftpRunTimeDataReset command resets the run-time data field in the UFTP data block.

<u>Figure 22: uftpRunTimeDataReset command output</u> on page 104 is an example of output from the uftpRunTimeDataReset command.



Figure 22: uftpRunTimeDataReset command output

### activeDlogShow

The activeDlogShow command displays the active log file information for UFTP IP Phone firmware downloads. When you enter no parameter, the output displays the contents of the entire active log file. When you enter a line number, activeDlogShow[numOfLine], the output displays the active log file by the number of lines.

<u>Figure 23: activeDlogShow command output</u> on page 105 is an example of output from the <u>activeDlogShow</u> command.

Figure 23: activeDlogShow command output

### inactiveDlogShow

The inactiveDlogShow command displays the nonactive dlog file information for UFTP IP Phone firmware downloads. When you enter no parameter, the output displays the contents of the entire file. When you enter a line number, inactiveDlogShow [numOfLine], the output displays the nonactive dlog file by the number of lines.

<u>Figure 24: inactiveDlogShow command output</u> on page 105 is an example of output from the inactiveDlogShow command.

```
oam> inactiveDlogShow inactiveDlogShow
Active F/W download file: /u/log/UFTPLOG0.TXT
Space remaining: 399755

Inactive F/W download file: /u/log/UFTPLOG1.TXT
/u/log/UFTPLOG1.TXT

12/27/03 19:58:41 f/w dnld success: (47.11.217.11) 12002
12/27/03 20:24:30 f/w dnld success: (47.11.217.12) 12002
12/27/03 21:42:11 f/w dnld success: (47.11.217.15) 12002
12/27/03 22:17:40 f/w dnld success: (47.11.217.20) 12004
```

Figure 24: inactiveDlogShow command output

#### dnldFailShow

The dnldFailShow command displays the download failed status logged in the active and inactive files. When you enter no parameter, the output displays all the failed UFTP download information in

the active and inactive files. When you enter a line number, dnldFailShow[numOfLine], the output displays the download fail status in the active and inactive files by the number of lines.

<u>Figure 25: dnldFailShow command output</u> on page 106 is an example of output from the dnldFailShow command.

```
oam> dnldFailShow
Active F/W download file: /u/log/UFTPLOG0.TXT

12/29/03 19:58:41 F/W dnld fail: (47.11.217.11) 12004 (F/W not exist)
12/29/03 20:24:30 F/W dnld fail: (47.11.217.12) 12004 (F/W size is 0)
12/29/03 21:42:11 F/W dnld fail: (47.11.217.15) 12002 (RUDP connection down)
12/29/03 22:17:40 F/W dnld fail: (47.11.217.20) 12004 (Response time out)

inactive F/W download file: /u/log/UFTPLOG1.TXT

12/28/03 19:58:41 F/W dnld fail: (47.11.217.11) 12004 (RUDP connection down)
12/28/03 20:24:30 F/W dnld fail: (47.11.217.12) 12004 (RUDP connection down)
12/28/03 21:42:11 F/W dnld fail: (47.11.217.15) 12002 (RUDP connection down)
12/28/03 22:17:40 F/W dnld fail: (47.11.217.20) 12004 (Response time out)
```

Figure 25: dnldFailShow command output

# **NAT Traversal feature**

Network Address Translation (NAT) provides the following benefits:

- the ability to network multiple sites with overlapping private address ranges
- added security for servers on a private network
- conservation of public IP address allocation

A NAT device (router) exists between a private network and a public network. The NAT device maps private addresses to public addresses.

With the NAT Traversal feature, several IP Phones are now supported behind a single Cone NAT router with, or without, Virtual Private Network (VPN) capabilities. This support enables large-scale deployment of Voice over Internet Protocol (VoIP) in teleworking and Small Office/Home Office (SOHO) environments.

The following Cone NAT routers are supported:

- Full Cone
- Restricted Cone
- Port Restricted Cone

### **!** Important:

A Cone NAT router with more than one connected IP Phone must support hairpinning. Hairpinning occurs when an IP Phone behind a NAT router can send packets to the Public IP address and port of another IP Phone connected to the same NAT router.

### Important:

Support is not available for Symmetric NAT routers. If the IP Phone is behind a Symmetric NAT, IP Phone registration is unsuccessful and the IP Phone displays a "NAT Error! ITG3053" message.

### **Echo Servers**

NAT Traversal is a function of CS 1000 Release 4.5 or later, and not a function of the NAT router. NAT Traversal uses two Echo Servers that reside on the Signaling Server. Echo Server 1 detects the presence of a NAT router, while Echo Server 2 detects the type of NAT router. Both Echo Server 1 and Echo Server 2 are required for the NAT Traversal feature to function properly.

If a compatible NAT router is detected, successful IP Phone registration occurs and the software invokes the NAT Mapping Keep Alive function to prevent loss of the IP connection. If an incompatible NAT is detected, an error appears on the IP Phone display and the IP Phone cannot register.

# Mapping

When an IP Phone is used in a private network behind a NAT device, the NAT router strips the IP Phone private IP address and private port number and assigns a public IP address and public port number.

To support multiple IP Phones behind one NAT device, NAT must map between public/private IP addresses, and ports for each IP Deskphone behind it. A mapping exists for both a signaling port and a media (voice) port.

Placing an IP Phone behind Multiple NAT devices is an unsupported configuration. If you need a configuration with multiple NATs between the IP Phone and the Voice Gateway Media Card, all NATs on the path must follow the rules described in the following sections for signaling and media streams.

Use the NAT device to implement and configure mapping. The IP Line application implements no mappings.

# **NAT** and signaling

NAT hides the true identity of the IP Phone from the LTPS. The LTPS is aware of an IP Phone based only on the public IP address and port of the signaling messages. A signaling message originates from the IP Phone on the private side from port 5000. That signaling message then maps from the private side to a public IP and port; that is, the IP address detected by the LTPS.

Signaling messages between the Voice Gateway Media Card and IP Phones are carried by RUDP. Each RUDP connection is distinguished by the IP address and port number.

The NAT device performs private-to-public mapping for the signaling port for each IP Phone behind it to support multiple IP Phones. The TPS uses fixed port numbers for signaling. The NAT device must perform consistent private-to-public mapping for these port numbers. <u>Table 28: Signaling UDP Ports</u> on page 108 lists the UDP port number used.

**Table 28: Signaling UDP Ports** 

UDP Port	Device	Use
5 000	IP Phone	Incoming signaling messages to the IP Phones, including UFTP messaging
5 100	LTPS	Incoming call processing messages to the LTPS
5 105	UFTP	Incoming UFTP packets to the UFTP server
4 100	LTPS	Incoming registration message to Connect Server
7 300	LTPS	lincoming registration messages to node Master

Port numbers on the Voice Gateway Media Card use a fixed numbering scheme where the starting number for the port range is configurable. The first port on the card uses the configured starting port number; the remainder of the port numbers follow in sequence. Each port has two sequential numbers: one for RTP and one for RTCP.

Do not change this port at any time. Map this port to port 5200 on the IP Phones.

**Table 29: IP Line UDP Ports** 

UDP Port	Device	Use
5 200–5 262	Media Card	RTP packets (configurable starting port number – IP Phoneport matches it)
5 201–5 263	Media Card	RTCP packets into Media Card (port number is RTP port number + 1)
5 200	IP Phone	RTP packets into IP Phone (port matches first RTP port of the Voice Gateway Media Card)
5 201	IP Phone	RTCP packets into IP Phone(port matches first RTCP port of the Voice Gateway Media Card)

# **NAT Mapping Keep Alive**

The normal operation of the LTPS and the IP Phone requires the LTPS to send a periodic Watchdog Reset UNIStim message. This message resets the hardware watchdog timer running on the IP Phone and specifies the period for the timeout. If the LTPS does not send the Watchdog Reset message before the watchdog timer expires, the IP Phone resets and begins a new registration cycle with the LTPS.

To avoid loss of the IP connection, the NAT Mapping Keep Alive function sends the Watchdog Reset message more frequently. Avaya recommends using the default values. However, if you must increase the frequency of the Reset Watchdog message, increase the NAT Mapping Keep Alive timer value.

You can configure NAT Traversal to provision the length of time the audio and signaling port mapping is refreshed. You can configure NAT Traversal in Element Manager, or on the Call Server in LD 117.

By default, all IP Phone behind a NAT device have the signaling and audio path kept alive. The default value is 30 seconds. You can decrease the value to 20 seconds or increase it to 600 seconds.

#### Mute and Hold considerations

IP Line software has two special situations when interworking with NAT: Mute and Hold.

#### Mute

Table 30: Mute process on page 109 describes the Mute process.

Table 30: Mute process

	Description	
Problem		
1	When a user enables Mute, the LTPS sends a Mute Transmit (Tx) command to the IP Phone. That command forces the IP Phone to generate silence in the transmit direction.	
2	If the IP Phone uses an evocator that implements silence suppression, for example G.729AB, the IP Phone sends one silence frame to the far end, and then stops sending frames until Mute is cancelled.	
3	Data sent from the IP Phone stops.	
4	The NAT device determines that the IP Phone UDP connection is not active in the transmit direction and starts aging the translation.	
5	Depending on the length of time the call is muted and the duration of the NAT translation aging time out value, the NAT device might timeout the translation and drop the connection.	
6	All packets coming from the far end are dropped by the NAT device.	
7	When mute is cancelled, the IP Phone starts transmitting again.	
8	NAT considers this to be a new connection and creates a new translation. NAT sends data to the far end using this new translation, resulting in half-duplex voice connection between the IP Phone and the far-end device.	
9	Data sent to the far end device arrives but the data returning is lost.	
Solution	•	

Table continues...

	Description
1	The IP Phone periodically sends an extra non-RTP packet to the far end to keep the NAT translation alive, ensuring that the NAT session timeout does not expire.
2	The non-RTP packet is constructed to fail any RTP validation tests so it is not played out by the far-end device (IP Phone or gateway channel).

#### Hold

The Hold function differs from the Mute function as Hold does not cause problems with the audio stream. <u>Table 31: Hold process</u> on page 110 describes the Hold process.

Table 31: Hold process

	Description
1	When an IP Phone user places a call on Hold, the audio stream in both the Transmit (Tx) and Receive (Rx) directions closes.
2	The NAT device begins aging the translation.  When the audio stream is closed and no voice path is present, the IP Phone sends periodic non-RTP packets to keep the NAT translation alive. Therefore, when a call is placed on Hold, the IP Phone defaults to sending these non-RTP packets.
3	When the call is retrieved from Hold, a new set of open audio-stream messages is issued by the LTPS and new connections are established reusing the same NAT translation.

### **NAT and VLAN**

Support of Virtual LAN (VLAN) depends entirely on the Layer 2 switch to which the IP Phone is immediately connected. Users behind a NAT router may find that the configuration of a VLAN ID is unsupported by the NAT router. See the documentation of the NAT router to determine if VLAN ID support is available.

Users who attempt to use an IP Phone with VLAN enabled on a NAT router that does not support VLAN cannot connect to the CS 1000 system. If DHCP is used, the IP Phone cannot obtain an IP address.

## Important:

Most NAT routers do not support 802.1Q Tagging. If 802.1Q Tagging is not supported on the NAT device, the check box 802.1Q support in Element Manager under the QoS section must remain unchecked. See <a href="Figure 26: 802.1Q Tagging on Node Summary page in Element Manager">Figure 26: 802.1Q Tagging on Node Summary page in Element Manager</a> on page 111. If 802.1Q Tagging is enabled for IP Phones behind NAT, the IP Phones can send the initial "Resume Connection" message, but then the IP Phones reset and no call path is established.




Figure 26: 802.1Q Tagging on Node Summary page in Element Manager

# **NAT Traversal and Proactive Voice Quality Management**

Real-Time Control Protocol (RTCP) signaling provides statistics (for example, latency, packet loss, and jitter) about the Real-Time Transfer Protocol (RTP) stream. For the RTCP signaling to be successful, the PUBLIC RTCP port number must be the RTP port number plus 1. For example, if the PUBLIC RTP port is 12 000, then the PUBLIC RTCP port must be 12001.

The NAT router typically assigns the RTCP port number as RTP port number plus 1. However, the NAT router is not guaranteed to properly assign the RTCP port number; in which case, the RTCP message exchange fails and the Proactive Voice Quality Management feature does not receive the required RTCP data. A message appears on the LTPS console and syslog file and an SNMP trap (ITG3054) is generated.

The NAT Traversal feature attempts a best effort approach to initiate the NAT router to properly assign the RTPC port number. The best effort approach depends on the NAT router implementation, can vary from NAT router to NAT router, and cannot be guaranteed by the NAT Traversal feature.

# **Configuring NAT Traversal in Element Manager**

To configure the Echo Servers IP addresses, port numbers and NAT Keep Alive time-out setting using Element Manager, in the Element Manager navigator select IP Network, Network Address Translation.

See Figure 27: NAT configuration on page 112.




Figure 27: NAT configuration

# **Configuring NAT Traversal in LD 117**

Commands are available in LD 117 to configure and print the Echo Servers IP addresses, port numbers and NAT Keep Alive time-out setting.

Echo Servers require no configuration to work. The default IP address of 0.0.0.0 means that Echo Server 1 uses the TLAN network interface IP address. The default IP address of 0.0.0.0 means that Echo Server 2 uses the Node IP address.

An IP address of 0.0.0.0 means the default local Echo Server is enabled.

## Important:

The NAT Traversal feature is essentially automatic. Change the IP addresses or ports only in exceptional cases when you use an Echo Server external to the CS 1000 system.

If IP addresses are specified, they must be for servers external to the system. The IP addresses cannot be the same. You can use duplicate IP addresses only if the default of 0.0.0.0 is used. If the IP addresses are the same (and not 0.0.0.0), an error message is generated and the input is not accepted.

Table 32: LD 117 commands for NAT

Command	Description
CHG ES1 <echo 1="" address="" ip="" server=""></echo>	Change Echo Server 1 IP address and port number:
<echo 1="" port="" server=""></echo>	Default Echo Server 1 IP Address = 0.0.0.0
	Default Echo Server 1 Port number = 10000
	Echo Server 1 default IP address uses the TLAN IP address of the LTPS.

Table continues...

Command	Description
CHG ES2 <echo address="" ip="" server=""></echo>	Change the Echo Server 2 IP address and port number, where:
<echo port="" server=""></echo>	Default Echo Server 2 IP Address = 0.0.0.0
	Default Echo Server 2 Port number = 10000
	Echo Server 2 default IP address uses the node IP address on the node leader card.
PRT ES1	Print Echo Server 1 IP address and port number.
PRT ES2	Print Echo Server 2 IP address and port number.
PRT ESS	Print both Echo Servers IP addresses and port numbers.
CHG NKT <time-out setting=""></time-out>	Change NAT Mapping Keep Alive Time-out setting of port mapping for devices behind a NAT router time out setting = 20-(30)-600 seconds
PRT NKT	Print NAT Mapping Keep Alive Time-out setting of port mapping for devices behind a NAT router.

#### CHG ES1/CHG ES2

If the IP addresses entered for ES1 and ES2 are the same and both are not 0.0.0.0 or for external servers, an error message is generated and the input is not accepted. You can enter any value from 1000 to 60000 for the port. If the port value is outside of that range, an error message is generated. You can configure only the port (and not the IP addresses) by entering data similar to the following:

$$=>$$
chg es1 0 5400

The value 0 for the IP address is interpreted as 0.0.0.0. This means the Echo Server runs locally using the configured port value.

The port values both default to 10 000. If you configure an IP address, you must configure the port. If you configure no port or IP address, then an error message appears.

If you configure neither Echo Server, then the LTPS on the Signaling Server uses two local instances of the Echo Server. If you configure both Echo Servers, then the LTPS uses the external Echo Servers. If an external Echo Server fails, that functionality is lost unless the external Echo Server implements a transparent redundancy scheme. The external Echo Server handles its own redundancy and reliability.

#### **PRT** commands

<u>Figure 28: PRT commands output</u> on page 114 is an example of the output of the PRT commands when the default values s are used. If other IP addresses or port numbers are configured, then these appear in place of the 0.0.0.0 or 10 000 in the examples in <u>Figure 28: PRT commands</u> output on page 114.

=>		
=>PRT ESS		
Kcho Server	IP Address	Port
1	0.0.0.0	10000
2	0.0.0.0	10000
Time-out: 30		
=>	Decoman	
->		
=>PRT ES1		
	IP Address	
1	0.0.0.0	10000
=>		
->		
=>PRT ES2		
	IP Address	Dozet
	ir Aditess	FOLC
	0.0.0.0	10000
->		
->		
->PRT NKT		
NAT Keep ali	ve time-out: 30 g	econds
=>		

Figure 28: PRT commands output

### **CLI** commands

The CLI commands described in this section provide information about IP Phones behind a NAT device and the Echo Servers.

#### isetReset

The isetReset command resets an IP Phone based on the entered IP address or TN. The IP address must be the Public IP address for IP Phones behind a NAT. If the entered IP address identifies an IP Phone that is behind a NAT and no other IP Phone shares the address, then the IP Phone is reset.

However, if the entered IP address identifies multiple IP Phones (multiple IP Phones behind a NAT sharing the same public IP address), then an error message is printed. This message, as shown in the following example, indicates there is more than one IP Phone using the IP address, lists the IP Phones and the TNs, and recommends that you use the isetReset TN command.

```
isetReset "47.11.217.102"

WARNING: There are 2 IP Phones that use the public IP address of 47.11.217.102 Please reset the IP Phone using the TN: isetReset "TN".
```

The number of IP Phones that share the same public IP address is printed.

Commands such as isetScpwQuery, isetScpwModify, and isetScpwVerify have the same error handling as isetReset. If you enter an IP address that multiple IP Phones use, an error message prints, as shown in the following example.

```
WARNING: There are 2 IP Phones that use the public IP address of 47.11.217.102.
```

#### isetGet

The isetGet command can search on the NAT type.

NAT = xxx where x is:

- C: the IP Phone is behind a Cone NAT
- S: the IP Phone is behind a Symmetric NAT
- U: the IP Phone is behind a NAT of unknown type (response only received from Echo Server 1)
- P: waiting on a response from the IP Phone, or the IP Phone never received a response from Echo Server 1
- ..:Blank space: the IP Phone is not behind any kind of NAT (normal case)
- Y: true when an IP Phone NAT is C, S or U
- N: true when an IP Phone NAT is . . (blank), meaning no NAT is detected

The following example shows:

```
isetGet "NAT == Y"
```

displays the output (partial output from the left side of the screen):

```
IP Address NAT Type RegType State Up Time
47.11.179.168 C i2004 Regular online 0 04:20:34
47.11.179.167 C i2004 Regular online 0 03:48:17
```

#### echoServerShow

The echoServerShow command provides configuration information about the Echo Servers and information about interactions with the Echo Servers for the IP Phones on an LTPS. Use this command on an LTPS card to investigate a problem with an IP Deskphone registered to that LTPS card. The command provides information about the Echo Servers from the viewpoint of the LTPS on the card where you enter the command.

The command has one optional parameter, action; the only valid value is 99. When you enter echoServerShow 99, the counter values are reset after they appear. When you enter onlyechoServerShow, the counter values appear without the counter being reset.

The output for each Echo Server displays the following information:

Configured: the IP address port configured for this Echo Server in LD 117

- Actual: the IP address port used for this Echo Server, followed by an explanation in parentheses. This is different from the Configured parameter only when the default address (0.0.0.0) is configured. The explanation in parentheses is one of the following:
  - (TLAN IP, this card): the IP address used is the TLAN network interface of this card; the Echo Server is active on this card.
  - (node IP, this card): the IP address used is the Node IP address; the Echo Server is active on this card because it is the node leader.
  - (node IP, other card): the IP address used is the Node IP address, but another card is currently the Node leader; the Echo Server is not active on this card.
  - (not this card): the IP address is not the card TLAN IP address or the Node IP address; the Echo Server is not active on this card.
- LTPS request sent: the number of Resolve Port Mapping Request messages sent from the LTPS to IP Phones, with this Echo Server identified as the one to contact.
- Failed resp rec.d: the number of Resolve Port Mapping Ack messages received from the IP
   Phones that had the public IP address and port configured as 0.0.0.0:0000. Each increment of
   this counter indicates an IP Phone never received the Discover Port Mapping Ack response
   from the Echo Server (all 10 attempts failed).

The two peg counts indicate the interaction this LTPS is having with the Echo Server. It is not a direct sign of the health of the Echo Server; network conditions for IP Phones registered to this LTPS may prevent communication with this Echo Server while another LTPS IP Phones have no problem. The echoServerShow command output can help to understand why a particular IP Phone registered to a LTPS may be having difficulties or helps to uncover patterns of communication problems between IP Phones and Echo Servers.

A sample output is shown in Figure 29: echoServerShow sample output on page 116.

```
->echoServerShow

Echo Server 1

Configured: 0.0.0.0:10000
Actual: 47.11.212.54:10000 (TLAN IP, this card)
LTPS request sent: 112665
Failed resp rec'd: 0

Echo Server 2

Configured: 0.0.0.0:10000
Actual: 47.11.212.60:10000 (node IP, other card)
LTPS request sent: 82201
Failed resp rec'd: 0
NAT Timeout: 30 seconds
```

Figure 29: echoServerShow sample output

When you enter the echoServerShow command with the reset parameter 99, the counter values appear and then reset. If you enter the echoServerShow command again and no subsequent requests, the counter values appear as 0.

A sample output is shown in Figure 30: echoServerShow 99 sample output on page 117.

```
->echoServerShow 99
Echo Server 1
...........
Configured: 0.0.0.0:10000
Actual: 47.11.212.54:10000 (TLAN IP, this card)
LTPS request sent: 81563
Failed resp rec'd: 40
Echo Server 2
-----
Configured: 0.0.0.0:10000
Actual: 47.11.212.60:10000 (node IP, other card)
LTPS request sent: 50199
Failed resp rec'd: 4
NAT Timeout: 30 seconds
->echoServerShow
Echo Server 1
______
Configured: 0.0.0.0:10000
Actual: 47.11.212.54:10000 (TLAN IP, this card)
LTPS request sent: 0
Failed resp rec'd: 0
Echo Server 2
Configured: 0.0.0.0;10000
Actual: 47.11.212.60;10000 (node IP, other card)
LTPS request sent: 0
Failed resp rec'd: 0
NAT Timeout: 30 seconds
```

Figure 30: echoServerShow 99 sample output

## vgwShow

The vgwShow command permits the optional entry of an IP Phone IP address and port. A search is made of all the Voice Gateway Media Cards in the node to find the IP Phone IP address and port. With the introduction of NAT Traversal, more than one IP Phone can map to a single IP address. You can enter the public port number for an IP Phone.

```
vgwShow <"IPAddr">, <port>
```

If you enter no port number, the first entry found with the specified IP address on a Voice Gateway Media Card is returned. An example is shown in <a href="Figure 31: vgwShow with IP address command output">Figure 31: vgwShow with IP address command output</a> on page 118.

```
-> vgwShow "47.11.215.136"

Value = 0 = 0x0

-> Found on Card TN 005-00 , RLAN IP 47.11.216.174, TLAN IP 47.11.215.143 , number of matches 2

Chan ChanState DspMode Codec Tn Reg AirTime rxTsap txTsap

17 Rumy Voice G.711-20 0x0505 yem 21 47.11.215.143:5234 47.11.215.136:2237

-> Found on Card TN 003-00 , RLAN IP 47.11.216.175, TLAN IP 47.11.215.146, number of matches 1

Chan ChanState DspMode Codec Tn Reg AirTime rxTsap txTsap

1 Rumy Voice G.711-20 0x0307 yem 21 47.11.215.145:5202 47.11.215.136:5200
```

Figure 31: vgwShow with IP address command output

When the IP address is found in the list of VGW channels for a card other than the card where you entered the command, the VGW channel information for the first occurrence is returned, plus a count of the number of times the IP address occurs in that card list. Multiple instances can occur when the customer network is configured so that multiple IP Phones are behind a NAT device sharing the NAT device public IP address.

If more than one match occurs, the administrator can log on to that specific card and enter the vgwShow command without entering an IP address and port number. This command prints all the busy channels on the card. To quickly find an IP Phone, use the IPDN or DNIP commands in LD 117 to obtain the IP Phone media stream public IP address and port number; then enter the public IP address and port number as parameters for the vgwShow command.

# **Corporate Directory**

The Corporate Directory feature is based on the Avaya 3900 Digital Deskphone Corporate Directory feature.

For more information about the Corporate Directory feature, see Corporate Directory on page 336

# Personal Directory, Callers List, and Redial List

The Personal Directory, Callers List, and Redial List features are supported on CS 1000 systems running CS 1000 software.

Use the Personal Directory feature to enter or copy names into a personal directory, and to edit or delete all entries in the directory.

The Callers List and Redial List are call log features. The content of these lists is generated during call processing. A user can scroll through the Callers List to see who called. The user can dial a number from the Redial List.

Password protection is available to control access to a user Personal Directory, Callers List, and Redial List.

## Important:

Configure Calling Party Name Display (CPND) on the system to enable Personal Directory, Callers List, and Redial List.

For more information, see <u>Personal Directory application</u> on page 152.

# **IP Call Recording**

IP Call Recording provides the IP address and port information for an IP Phone in Information Elements (IE) over Application Module Link (AML) for Meridian Link Services (MLS). This information correlates the TN of a specific IP Phone with the associated IP address for a call recording application. When enabled in LD 17, IP Call Recording sends a modified AML message for each call. The modified message identifies the call IP endpoint and makes it possible to correlate the RTP packets for that call to a particular IP Phone.

IP Call Recording introduces the IE pair:

- This Party IP IE (monitored party)
- Other Party IP IE (remote party)

The IP IE pair is similar to the existing IE pairs:

- For DN: This Party DN IE, Other Party DN IE
- For TN: This Party TN IE, Other Party TN IE

The IP IEs are optional in the Unsolicited Message Status (USM) (Active) and USM (Restore) messages:

- If the USM message applies to a monitored key on a digital telephone, then the IP IEs are not sent.
- If the USM message applies to a monitored key on an IP Phone, then the IP IEs are sent: one for the monitored party and one for the remote party.

A call recording application is provided with status update messages for the call keys of any IP Phone it monitors. These USM messages contain the IP address and port number for the monitored IP Phone and the remote party in the active call. By using a Layer 2 switch that supports port mirroring, the call recording device can monitor the media stream for the active call and record it.

## **Enhanced IP Call Recording**

IP Call Recording provides a direct method to capture and record VoIP calls. The feature enhancement implements a mechanism to record the IP media stream to an external media-recording device by instructing the IP Phone to send a duplicate media stream to a third-party call-recording application, which provides the recording and playing function for the IP calls.

The following IP Phones support IP Call Recording: the Phase II IP Phone 2001, IP Phone 2002, IP Phone 2004, Avaya 2050 IP Softphone, Avaya 2033 IP Conference Phone, Avaya 2007 IP Deskphone, Avaya 1110 IP Deskphone, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone,

Avaya 1150E IP Deskphone, Avaya 1165E IP Deskphone, WLAN Handset 2210/2211/2212, Avaya 6120 WLAN Handset, Avaya 6140 WLAN Handset.

The Avaya 1210 IP Deskphone, Avaya 1220 IP Deskphone, and Avaya 1230 IP Deskphone do not support IP Call Recording.

The IP Call Recording enhancement enables the following types of recording:

- Bulk Call Recording: All calls are automatically recorded for an IP Phone. The Call Recording
  application issues a Start Recording Request message for the User ID, and all calls are
  recorded until the Call Recorder application issues a Stop Recording Request.
- Quality Monitor Recording: The Call Recorder records conversation for a call. The Call
  Recording application can monitor the Call Recording application (CR) data such as Calling
  Line ID (CLID) or Automatic Number Identification (ANI) to determine if it needs to record a call.
  The Call Recording application issues a Start/Stop Recording Request to the User ID for only
  the duration of the specific call. Quality monitor recording enables manual recording of
  individual calls with the following options:
  - You can start or stop call recording at any time during a call.
  - You can repeatedly pause and restart call recording during a call, to record excerpts from a conversation.
  - You can retroactively begin call recording. At any time during the conversation, you can save the entire call. You need not start recording when the call begins.
  - You can configure call recording to maintain ACD Emergency key functionality.

The CR initiates the IP Call Recording. A Start Recording Request message contains the User ID to be recorded and the IP addresses and port information of where the duplicate media stream is to be sent.

In LD 11, the CoS RECA/RECD (IP Call Recording Allowed/IP Call Recording denied) is available for the IP Phones that support IP Call Recording. The default is RECD. See <u>LD 11</u> on page 123.

## Warning tones

If you require a Recording Warning Tone, you can turn on and off this tone on the Call Server by using the existing UNIStim message Stream Based Tone on or off. The message requires the predefined parameters for the tone, such as tone ID, frequency, and volume.

## **Bandwidth requirements**

The use of IP Call Recording doubles the bandwidth requirements of the call.

For example, in a call using the G.711 codec, one voice packet data stream requires approximately 80 K. As the IP Call Recorder uses two separate streams for the incoming and outgoing calls, there are four streams that require a total of 320 K for the voice packet data. In a typical 100 Mb/s LAN network environment, if 80 percent of the bandwidth was configured for voice data, then this network could support a maximum of 500 simultaneous IP Phone calls.

$$(100 \times 1000 \times 0.8/160) = 500$$

When you enable the IP Call Recording feature, the network is limited to a maximum of 250 calls.

For remote users connecting to the IP Call Recorder Server through a WAN connection, consider the impact of the bandwidth usage to the QoS. In this case, the IP Call Recorder Server must provide the QoS parameters when it instructs the IP Phone to echo the voice data.

Depending on the ability of the IP Call Recorder Server to handle the RTP stream, you might require more than one IP Call Recorder Server in a large call center environment. Middleware (software that connects two sides of an application and passes data between them) must have an algorithm to balance the traffic between servers.

#### **Feature interactions**

This section describes IP Call Recording feature interactions.

### Mute key

When you press the Mute key, the IP Phone keeps both the primary and the duplicate audio stream open. When you press the Mute, the recording state remains active, but only the incoming conversation is recorded. Press the Mute key a second time to resume normal recording.

### **Hold key**

When you press the Hold key, a Stop Recording Request message is sent from the Call Server, and the duplicate media stream is closed. A new audio stream is opened for the other active call. When the hold is released, a new Start Recording Request is sent from the Call Server to the IP Deskphone and recording begins again.

## Transfer key

After you press the Transfer key and the transfer is accepted, the current audio stream is closed. A new audio stream for the new call is opened, followed by a Start Recording Request message. If the IP Phone that accepted the transferred call does not have call recording enabled, the transferred call is not recorded.

#### Call Forward

When you forward a call, the audio stream is opened for the destination IP Phone. If the destination IP Phone does not have call recording enabled, the forwarded call is not recorded.

#### Conference call

In a conference call, each IP Phone opens a media stream. The IP Phone duplicate media stream to the CR is maintained if that IP Phone is part of the conference.

Agent Observe injects a tone that interferes with the Recording Warning tone.

## Identifying the IP Phone

IP Call Recording requires the unique identification of each IP Phone to be recorded.

In a Multiple Appearance Directory Number (MADN) configuration, the Call Server enables the association of two MADN keys on a particular TN. A maximum of two associated (AST) keys exists for each TN.

In a Multiple Appearance DN Redirection Prime (MARP) configuration, the Call Server enables the association of MARP DNs on different TNs. A maximum of two associated (AST) keys exists for each TN.

The following table provides an example of AST configuration in LD 11.

Table 33: LD 11 AST configuration

Prompt	Response	Description
AST	ASTKEY1	Key numbers to be associated on this TN.
	ASTKEY2	ASTKEY1 and ASTKEY2 are the numbers of the keys to be associated. In this example, ASTKEY1 = 0 and ASTKEY2 = 1.
KEY	KEY 0 SCR XXXX	XXXX is the DN which is a MARP and already configured on another
	MARP ON TN L S C U	TN.
	MARP	
	CPND	
	VMB	
	ANIE	
KEY	KEY 1 SCR XXXX	XXXX is the same DN as configured on KEY 0.
	MARP ON TN L S C U	
	MARP	
	CPND	
	VMB	
	ANIE	

# **Administration**

This section describes how to administer the IP Call Recording feature.

### **LD 17**

LD 17 provides the Enhanced Unsolicited Status Message (USM) IE enable (IPIE) prompt.

The IPIE prompt enables or disables system-wide IP Call Recording. The functionality is disabled by default. When IP Call Recording is enabled, a modified Application Module Link (AML) message that identifies the IP endpoint is sent for each call. The IPIE prompt is in LD 17 under system parameters (PARM).

Table 34: LD 17 IP Call Recording

Prompt	Response	Description
REQ	CHG	Change existing data
TYPE	PARM	Change system parameters
LPIB	96 – 7500	Low priority Input Buffers
NDRG	(NO) YES	New Distinctive Ringing
MARP	(YES) NO	Multiple Appearance Redirection Prime feature allowed
IPIE	(NO) YES	Enhanced Unsolicited Status Message (USM) IE enable
		YES = Allow This Party IP IE and Other Party IE to send with USM
FRPT	(NEFR) OLFR	(Deny) or allow access to incoming calls by FRE station

Element Manager does not support LD 17 for PARM.

### **LD 11**

Use the CoS RECD/RECA responses to configure whether an IP Phone allows call recording.

Table 35: LD 11 Service change request for CoS RECA/RECD

Prompt	Response	Description
REQ	ADD	Add new data
	CHG	Change existing data
TYPE	aaaa	Supported IP Phone type
		aaaa = 2001P2, 2002P2, 2004P2, 2007, 2050PC, 2050MC, 2033, 1210, 1220, 1230, 1120, 1140, 1150, 1165, 2210, 2211, 2212, 6120, 6140
TN		Terminal Number of IP Phone

Table continues...

Prompt	Response	Description
	Iscu	Where I = loop, s = shelf, c = card, u = unit
CLS	RECA	IP Call Recording allowed
	(RECD)	IP Call Recording denied

If the RECA CoS applies to a non-IP Phone, error SCH1599 message is generated.

If the CoS on an IP Phone changes during an active call, the Call Server tears down the call. If an IP Phone TN is deleted during an active call on the IP Phone, the Call Server tears down the call.

#### **LD 20**

The CoS options RECA/RECD appear in LD 20 when you request a printout for an IP Deskphone, as shown in the following example.

```
> ld 20
REQ: PRT
TYPE: TNB
CUST: 0
.....
CLS CTD FBD .....
RECD (or RECA)
```

## **LD 80**

In LD 80, the output of the call trace command includes IP Call Recording-related information.

```
trak <TN>
.trak 61 9
ACTIVE VTN 061 0 00 09
ORIG VTN 061 0 00 02 KEY 0 SCR MARP CUST 0 DN 4002 TYPE I2002
MEDIA ENDPOINT IP: 47.11.215.40 PORT: 5200
VTN 061 0 00 09 KEY 0 SCR MARP CUST 0 DN 4009 TYPE I2004
MEDIA ENDPOINT IP: 47.11.215.47 PORT: 5200
IPCR Tx MEDIA FAREND ENDPOINT IP: 47.11.181.174 PORT: 5000 *
IPCR Rx MEDIA FAREND ENDPOINT IP: 47.11.181.174 PORT: 5001 *
MEDIA PROFILE: CODEC G.711 MU-LAW PAYLOAD 20 ms VAD OFF
DIAL DN 4009
MAIN PM ESTD
TALKSLOT ORIG 19
EES DATA:
NONE
QUEU NONE
CALL ID 500 799
```

The asterisk (\*) indicates Call Recording information.

#### **LD 81**

Use the RECA/RECD responses to the FEAT prompt in LD 81 to count the number of IP Phones with the CoS RECA or RECD.

Table 36: LD 81 Count the IP Phones with CoS RECA or RECD

Prompt	Response	Description
REQ	LST	List the IP Phones
	CNT	Count the IP Phones
CUST	xx	Customer number
FEAT	RECA	IP Phones with IP Call Recording allowed
	RECD	IP Phones with IP Call Recording denied

#### **LD 83**

In LD 83, the RECA/RECD CoS appears when the IP Phone TNB prints.

### **LD 117**

In LD 117, the output of the following STIP commands includes IP Call Recording-related status information.

- STIP NODE: Displays the Resource Locator Module information for the specified node
- STIP TN: Displays the Resource Locator Module information for the specified TN or group of TNs
- STIP TYPE: Displays the Resource Locator Module information for the specified TN type
- STIP ZONE: Displays the Resource Locator Module information for the specified zone
- STIP TERMIP: Displays the Resource Locator Module information for the specified IP address

# **Examples of STIP output**

#### Example 1:

```
=> stip termip 47.11.215.101
TN type HWID STATUS HOSTIP SIGNALING IP
61 0 0 1 i2001 MAC: REG 47.11.216.138 47.11.215.101:5000
```

```
18000ae401da5f6602
CODEC(BW): G711u noVAD(1904), G711a noVAD(1904), G729A(784), G723(544)
MODEL: IP Phone 2001 Phase 2 FWID: 2 FWVer: D99 PEC: NTDU90AA
Under Recording: No Warning Tone: Not Required
IPCR Tx Path: 47.11.181.174:6000 IPCR Rx Path: 47.11.181.174:6001
(Italics indicate the IP Call Recording information)
```

#### Example 2:

```
=> stip termip 47.11.215.101
TN type HWID STATUS HOSTIP SIGNALING IP
61 0 0 1 i2001 MAC: REG 47.11.216.138 47.11.215.101:5000
18000ae401da5f6602
CODEC(BW): G711u noVAD(1904)*, G711a noVAD(1904), G729A(784), G723(544)
MODEL: IP Phone 2001 Phase 2 FWID: 2 FWVer: D99 PEC: NTDU90AA
Under Recording: Yes Warning Tone: Not Required
IPCR Tx Path: 47.11.181.174:6000 IPCR Rx Path: 47.11.181.174:6001
(Italics indicate the IP Call Recording information)
```

#### Example 3:

```
=> stip tn 61 9
TN type HWID STATUS HOSTIP SIGNALING IP
61 0 0 9 i2004 MAC: REG 47.11.216.138 47.11.215.47:5000
18000ae401ddb26602
CODEC(BW): G711u noVAD(1904)*, G711a noVAD(1904), G729A(784), G723(544)
MODEL: IP Phone 2004 Phase 2 FWID: 2 FWVer: D99 PEC: NTDU92AA
Under Recording: Yes Warning Tone: On
IPCR Tx Path: 47.11.181.174:5000 IPCR Rx Path: 47.11.181.174:5001
(Italics indicate the IP Call Recording information)
```

# pbxLink connection failure detection

The pbxLink Connection Failure Detection feature provides a way to detect the link status of registered elements. An alarm is generated if the pbxLink is not detected after the Call Server warm or cold starts.

The Call Server monitors the pbxLink.

The Call Server maintains a list of all known registered elements (Signaling Servers). When restarted, a Call Server has a 5-minute delay to enable these known elements to reestablish contact with the Call Server.

If a known element fails to register with the Call Server, an ELAN0028 alarm is generated.

If an unknown Signaling Server registers with the Call Server, an ELAN0029 alarm is generated.

Display pbxLink information by using Element Manager or LD 117. See the following sections for more information

# Display pbxLink information using Element Manager

For CS 1000 systems, use the Element Manager IP Network, Maintenance and Reports, Gen Cmds, Group - pbxLink, Command - pbxLinkShow window to display the pbxLink information. See Figure 32: pbxLinkShow in Element Manager on page 127.




Figure 32: pbxLinkShow in Element Manager

# Display pbxLink information using LD 117 STAT SERV

The suite of STAT SERV (Statistics Services) commands enables a technician to display link-status information for Signaling Servers that are registered to a Call Server.

STAT SERV can provide consolidated link-status information by application type, IP address, host name, and IP Telephony Node ID.

STAT SERV status information includes the following:

- node ID
- · host name
- ELAN IP address
- · element role
- platform type
- connection ID
- enabled applications
- registered and unregistered endpoints, such as IP Phones
- information about the pbxLink and enabled applications
- Signaling Server resource count

The Signaling Server resource count helps to determine the number of virtual trunks that you can configure.

### pbxLink information

The STAT SERV command provides the following pbxLink information:

- the time the pbxLink was last established
- the time the pbxLink was lost, if previously established
- the time the pbxLink last attempted to establish a connection, if the pbxLink failed to establish a connection
- the Signaling Server resource count

### **Application information**

If an active link to an element is established, the Call Server obtains information about the applications that run on the element.

<u>Table 37: Queried information in STAT SERV</u> on page 128 lists the applications and describes the information provided by those applications.

**Table 37: Queried information in STAT SERV** 

Application or element	Information provided
LTPS application	Number of registered IP Phone.
	Number of busy IP Phones.
VTRK application	Number of registered VTRKs.
	Number of busy VTRKs.
Signaling Servers	Time that the element established the link with the Call Server.
	Elements that failed to register or lost the link.

Figure 33: Sample LD 117 STAT SERV output on page 129 shows an example of LD 117 STAT SERV output.

```
=> stat serv
             LDR SRV
NODE ELANIP
                                        PBXLINK
HOSTNAME
ID
                                        STATE
3976 192.168.35.234 YES
                              CPPMv1 LINK UP
cppm-ss-4.asa.merann.ru
    APPS:
             LTPS
                      VTRK
    PBXLINK DATE: 24/03/2009
    PBXLINK TIME: 16:19:18
    CONNECTID:
                   549b7b8
    Sets: [reg - 00000] [busy - 00000]
    VTRK: [reg - 00000] [busy - 00000]
    SIPL VTRK: [reg - 00000] [busy - 00000]
    SIGNALLING SERVER CAPACITY (SSRC): 2048
       Type: Nortel CPPMv1
       Location: 0 0 4
       Product Eng.Code: NTDW61BAE50003
       Serial Number: NNTMG19Y84B8CPPM
       Memory Size: 2048 MB
       Disk Size 37 GB
4250 192.168.35.30 YES N/A
                                      FAILED
hp8-e.asa.merann.ru
    APPS:
              LTPS
```

CONNECTID: 0

Figure 33: Sample LD 117 STAT SERV output

PBXLINK DATE: 20/03/2009 PBXLINK TIME: 15:22:57

<u>Table 38: STAT SERV response fields and description</u> on page 129 lists the descriptions for the fields in the STAT SERV response.

Table 38: STAT SERV response fields and description

STAT SERV response field	Description
NODE ID	Identifies the related node.

Table continues...

STAT SERV response field	Description		
	Value is a number from 0–9999.		
HOSTNAME	Identifies the alias that the system gives the host.		
	Value is a string.		
ELANIP	Identifies the element IP connection to the Call Server.		
	Value is an IP address.		
LDR	Specifies if the element is the Leader for the related node.		
	Value is Yes or No.		
SRV	Specifies the element type:		
	SS:Signaling Server		
APPS	Specifies the application running on the element:		
	• LTPS		
	• VTRK		
PBXLINK STATE	Specifies the element current pbxLink state:		
	• LINK UP		
	• LOST		
	• FAILED		
	INV CONN (element is connected, but the configuration is not on the Call Server, which indicates that this element might be connected to the wrong Call Server)		
PBXLINK DATE/TIME	Specifies when the element pbxLink state last changed.		
CONNECTED	Specifies the element connection ID.		
Sets	Values are as follows:		
	reg: the number of IP Phones registered to the element		
	busy: the number of IP Phones that are currently busy		
VGWs	Values are as follows:		
	reg: the number of voice gateways (DSP resources) are configured on the element		
	busy: the number of voice gateways (DSP resources) active or busy on the element		
VTRK	Values are as follows:		
	• reg: the number of VTRK channels configured on the element		
	busy: the number of VTRK channels active or busy on the element		
SSRC	Signaling Server capacity		

# **IP Phone support**

The IP Line application supports the following IP Phones:

- IP Phone 2001. See IP Phone 2001 User Guide
- IP Phone 2002 Phase II. See IP Phone 2002 User Guide
- IP Phone 2004 Phase II. See IP Phone 2004 User Guide
- Avaya 2007 IP Deskphone. See Avaya 2007 IP Deskphone User Guide, NN43118–100
- IP Audio Conference Phone 2033. See Avaya 2033 IP Conference Phone User Guide, NN43111–100
- Avaya 1110 IP Deskphone. See Avaya 1110 IP Deskphone User Guide, NN43110–101
- Avaya 1120E IP Deskphone. See Avaya 1120E IP Deskphone User Guide, NN43112-103
- Avaya 1140E IP Deskphone. See Avaya 1140E IP Deskphone User Guide, NN43113-106
- Avaya 1150E IP Deskphone. See Avaya 1150E IP Deskphone User Guide, NN43114-100
- Avaya 1165E IP Deskphone. See Avaya 1165E IP Deskphone User Guide, NN43101–102
- Avaya 1210 IP Deskphone. See Avaya 1210 IP Deskphone User Guide, NN43140-101
- Avaya 1220 IP Deskphone. See Avaya 1220 IP Deskphone User Guide, NN43141–101
- Avaya 1230 IP Deskphone. See Avaya 1230 IP Deskphone User Guide, NN43142–101
- Avaya 2050 IP Softphone. See Avaya 2050 IP Softphone User Guide, NN43119–101
- Mobile Voice Client (MVC) 2050. See Mobile Voice Client 2050 User Guide
- WLAN Handset 2210. See WLAN Handset 2210 User Guide
- WLAN Handset 2211. See WLAN Handset 2211 User Guide
- WLAN Handset 2212. See WLAN Handset 2212 User Guide
- Avaya 6120 WLAN Handset; Avaya 6140 WLAN Handset. See Avaya 6120/6140 WLAN Handset User Guide, NN43150–100

For additional information, see the following documents:

- Avaya 1100 Series Expansion Module User Guide, NN43130-101
- Avaya 1200 Series IP Deskphones Key Expansion Module Quick Reference Guide, NN40050-116
- WLAN IP Telephony Installation and Commissioning, NN43001-504
- Avaya IP Deskphones Fundamentals, NN43001-368

# **Element Manager support**

Element Manager is installed using the Unified Communications Management (UCM) Common Services security framework on a HP DL360 G7, HP DL360p G8, Dell R300, IBM x306, IBM x3350, or an HP DL320 G4 commercial off the shelf (COTS) server, and CP PM servers. Element Manager

is accessed through the UCM Common Services framework. The framework supports Single Signon so that the user can access multiple systems. Access the framework through supported web browser. For information about supported browsers, logging on to UCM Common Services, logging on to Element Manager, and configure the UCM Common Services framework, see *Unified Communication Management Fundamentals*, *NN43001-116*.

Element Manager is a Web interface that provides an alternative to the traditional CLI and overlays. The interface is available if you use a Web browser. No special client software is required.

You can use Element Manager to configure an IP Telephony Node, check and upload loadware and firmware files, and retrieve the CONFIG.INI and BOOTP.TAB configuration files from the Call Server.

For more information, see Element Manager System Reference—Administration, NN43001-632.

### **Call Statistics collection**

You can collect statistics on the Quality of Service (QoS) of calls connected by the Call Server.

Commands in LD 32 and LD 117 print the number of IP Phones registered on a zone, node, or Signaling Server. Traffic printouts are available for each zone at user-configurable intervals for the following:

- · blocked calls
- · bandwidth used
- · call attempts and completions

# **Counting IP Phones**

The commands to count registered IP Phones are available in LD 32 and LD 117.

Commands in LD 117 are as follows:

- ECNT FW <XX> <A> <BB> <FF>: count the number of IP Phones with specified firmware ID and, optionally, firmware version.
- ECNT MODL <MMMM>: count the number of IP Phones of the specified <model>. If you omit the MMMM parameter, the IP Phone Model Names and the associated mnemonics are listed.
- ECNT PEC <PEC>: count the number of IP Phones with a specified Product Engineering Code (PEC).

Previously, all ECNT commands were in LD 32. The following existing LD 32 ECNT commands are now duplicated in LD 117 to maintain a consistent interface. However, they continue to be maintained in LD 32.

- ECNT CARD <Loop> <Shelf> <Card> <CustomerNumber>
- ECNT NODE <NodeNumber>
- ECNT SS <HostName>

• ECNT ZONE <ZoneNumber> <CustomerNumber>

<u>Table 115: LD 117 Count registered IP Phones</u> on page 395 describes these commands.

Error messages appear when you enter invalid data for these commands. The messages include information such as the correct ranges for the command parameters. See the following tables for the error messages:

- <u>Table 39: ECNT Card command error messages</u> on page 133.
- Table 40: ECNT Zone command error messages on page 133.
- Table 41: ECNT Node command error messages on page 134.
- Table 42: ECNT SS command error message on page 134.

Table 39: ECNT Card command error messages

Error	Error Message	
Slot out of range error	Slot out of range. Range: [61–99]	
Slot non-virtual loop error	Slot does not correspond to a virtual loop.	
Slot not configured loop error	Slot corresponds to a virtual loop but it is not configured.	
Customer out of range error	Customer out of range. Range: [0–31]	
Customer not configured error	Customer does not exist.	
Combination of invalid slot and invalid	Slot does not correspond to a virtual loop.	
customer	Customer out of range. Range: [0–31]	

Table 40: ECNT Zone command error messages

Error	Error Message	
Zone out of range error	Zone out of range. Range: 0-8000	
	⚠ Caution:	
	Beginning in Release 7.0, Adaptive Network Bandwidth Management provides bandwidth zone numbers in the range 0–8000. If you are interoperating with an earlier release you must use bandwidth zone numbers in the range 0–255; call processing issues occur if you use bandwidth zone numbers greater than 255.	
Zone not configured error	Zone not configured.	
Customer out of range error	Customer out of range. Range: [0–31]	
Customer not configured error	Customer does not exist.	
Combination of invalid zone and invalid	Zone not configured.	
customer error	Customer out of range. Range: [0–31]	

Table 41: ECNT Node command error messages

Error	Error Message	
Node out of range error	Node out of range. Range: [0–9 999]	
Node not configured error	Node not registered.	

Table 42: ECNT SS command error message

Error	Error Message
SS not found in system error	Signaling Server <name> does not exist.</name>

# **IP Phone Zone Traffic Report 16**

A system traffic report, IP Phone Zone Traffic Report 16, in LD 2 is created on the system to print IP Phone data at the zone level. The data prints for the following categories at the end of each collection period for each zone:

- · Total inter and intrazone calls made
- Total inter and intrazone calls blocked
- Percent average inter and intrazone bandwidth used
- Percent maximum inter and intrazone bandwidth used
- Total inter and intrazone bandwidth threshold exceeded count

The counters are reset after the data prints.

The Total inter/intra zone bandwidth threshold exceeded count prints the number of times a user-configured bandwidth threshold was exceeded for the zone during the collection period. LD 2 commands to configure the system threshold use a value defined for the bandwidth threshold.

Table 43: System threshold commands

Command	Description	
TTHS TH tv	Prints the current system thresholds.	
STHS TH tv TV	Configures the system thresholds.	

A TH value of 5 is used for the zone bandwidth threshold.

The system thresholds TV value is the percentage of the zone maximum bandwidth. The range values are 000 to 999, where 000 corresponds to 00.0% and 999 corresponds to 99.9%. The default is 90.0%.

The following example first configures the system bandwidth to 75 percent and then prints the actual value.

.STHS 5 750 .TTHS 5

<u>Table 44: IP Phone Zone Traffic Report 16 intrazone data output</u> on page 135 describes the intrazone IP Phone Zone Traffic Report 16 output data.

Table 44: IP Phone Zone Traffic Report 16 intrazone data output

Data	Description
cmi	Intrazone calls made
cbi	Intrazone calls blocked
pi	Intrazone peak bandwidth (%)
ai	Intrazone average bandwidth usage (%)
vi	Intrazone bandwidth usage threshold violations
cmip	Counts of measuring interval
cul	Counts of unacceptable latency
cupl	Counts of unacceptable packet loss
cuj	Counts of unacceptable jitter samples
cur	Counts of unacceptable R factor
cuerl	Counts of unacceptable Echo Return Loss
cwl	Counts of warning latency
cwj	Counts of warning jitter
cwpl	Counts of warning packet loss
cwr	Counts of warning R factor
cwerl	Counts of warning Echo Return Loss
ccms	Calls completed with media security
ccnms	Calls completed without media security
cfnp	Calls failed by near end policy
cffr	Calls failed by incoming release
	May not be due to security policy negotiation failure
cosr	Outgoing calls switched to RTP
cisr	Incoming call switched to RTP
cfnr	Calls failed due to lack of resources (SRTP-capable DSPs)

<u>Table 45: IP Phone Zone Traffic Report 16 interzone data output</u> on page 135 describes the interzone IP Phone Zone Traffic Report 16 output data.

Table 45: IP Phone Zone Traffic Report 16 interzone data output

Data	Description
cmo	Interzone calls made

Table continues...

#### Features

Data	Description
cbo	Interzone calls blocked
ро	Interzone peak bandwidth (%)
ao	Interzone average bandwidth usage (%)
vo	Interzone bandwidth usage threshold violations
cmip	Counts of interval measuring samples
cul	Counts of unacceptable latency samples
cupl	Counts of unacceptable packet loss
cuj	Counts of unacceptable jitter samples
cur	Counts of unacceptable R factor samples
cuerl	Counts of unacceptable Echo Return Loss
cwl	Counts of warning latency samples
cwj	Counts of warning jitter samples
cwpl	Counts of warning packet loss
cwr	Counts of warning R factor samples
cwerl	Counts of warning Echo Return Loss
ccms	Calls completed with media security
ccnms	Calls completed without media security
cfnp	Calls failed by near end policy
cffr	Calls failed by incoming release
cosr	Outgoing calls switched to RTP
cisr	Incoming call switched to RTP
cfnr	Calls failed due to lack of resources (SRTP-capable DSPs)

```
LD 2
TFC000
.invs 16
0000 TFS016
ZONE 000
INTRAZONE
 INTERZONE
 ZONE 001
 INTRAZONE
 INTERZONE
 20NE 002
INTRAZONE
 INTERZONE
 ZONE 003
INTRAZONE
 INTERZONE
 ZONE 004
INTRAZONE
 INTERZONE
```

Figure 34: Example of the output from Traffic Report 16

All other commands (SOPS, COPS, TOPS) function in the normal manner. <u>Table 46: SOPS, COPS, TOPS</u> commands on page 137 shows the SOPS, COPS, and TOPS commands:

Table 46: SOPS, COPS, TOPS commands

.tops 1 2 3 4 5 14	Display the current system report list	
.sops 1 2 3 4 5 14 16 Add report 16 to print		
.tops 1 2 3 4 5 14 16	Display system report list with report 16 added	
.cops 1 2 3 4 5 14 16 16	Delete report 16	
.tops 1 2 3 4 5 14	display system report list with report 16 deleted	

# Programmable line/DN feature keys (self-labeled)

An IP Phone user can program the label on the feature key. This label change is saved and then displayed on the feature key.

## **Availability**

Table 47: Feature key availability on IP Phones on page 138 describes the feature key availability on the IP Phones.

Table 47: Feature key availability on IP Phones

Model	Feature keys	Feature keys using Shift	Maximum label character length
IP Phone 2002	4	N/A	10
IP Phone 2004	6	12	10
Avaya 2050 IP Softphone	6	12	10
MVC 2050	6	12	10
Avaya 1120E IP Deskphone	6	N/A	10
Avaya 1140E IP Deskphone	6	12	10
Avaya 1150E IP Deskphone	6	12	10
Avaya 1165E IP Deskphone	8	16	10
Avaya 1220 IP Deskphone	4	N/A	9
Avaya 1230 IP Deskphone	10	20	9

The IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone, and Avaya 1210 IP Deskphone do not support feature keys.

The feature key labels for each IP Phone are stored in the Call Server database. When the Call Server performs an EDD, the feature key labels are saved to the database. The feature key label information is retrieved from the file into memory during the sysload of the Call Server. When the system performs an INI or sysload, feature key label changes performed by users between the last EDD and the INI or sysload are lost.

When the IP Phone registers with the Call Server, the Call Server looks up the feature key label in the memory, based on the TN of the IP Phone. If the labels are found, they are sent to the IP Deskphone when the key map download occurs. If the labels are not found, the Call Server sends out the key number strings or key functions.

Comments on this document? infodev@avaya.com

For more information about self-labeled line/programmable feature keys, see IP Phones Fundamentals, NN43001-368.

### **Zones**

To optimize IP Line traffic bandwidth use between different locations, the IP Line network is divided into zones, representing different topographical areas of the network. All IP Phones and IP Line ports are assigned a zone number, which indicates the zone to which they belong.

For more information about zones and zone configuration, see *Converging the Data Network with VoIP Fundamentals*, *NN43001-260*.

#### **Shared Zone**

The current default zone type is a Shared Zone. IP Phones configured in Shared Zones use DSP resources configured in shared zones. If all gateway channels of the Shared Zones are used, the caller receives an overflow tone and the call is blocked.

Select gateway channels in the following order:

- Select a channel from the same zone as the zone where the IP Phone is configured.
- Select any available channel from the Shared Zones channels.

#### **Private Zone**

The Private Zone enables DSP channels configured in a Private Zone to be used only by the IP Phones that are configured for that Private Zone. If the IP Phones require additional DSP resources than are available in the zone, DSP from other Shared Zones are used.

IP Phones configured in Shared Zones cannot use the Private Zones channels.

Select the gateway channels in the following order:

- Select a channel from the same Private Zone as the zone where the IP Phone is configured.
- Select any available channel from the pool of Shared Zones channels.

## **Resource-sharing for Shared and Private Zones**

If a resource-critical IP Phone is configured for a Private Zone, and the zone has insufficient resources, the search continues into the Shared Zones within the same customer for an available DSP channel.

However, if an IP Phone is configured in a Shared Zone, the Call Server limits the search to the pool of shared DSP channels. The search does not extend into the Private Zones' channels.

When you configure the allocation of shared versus private resources, consider the required number of private resources. You must configure enough DSP resources to prevent the IP Phones in Shared Zones from running out of channels.



#### Warning:

Zones used for IP Media Gateway (IPMG) purposes must be configured as Shared so that other IP devices that are not in the same Zone can gain access to the IPMG devices.

The Call Server does not search for voice gateway channels in Private Zones when the IP Phone is configured in a Shared Zone. Only IP Phones configured in the same Private Zone can use the Private Zone voice gateway channels.

Because the voice gateway channels in the Private Zone are not accessible to IP Phones in the Shared Zone, ensure that only enough private channels are configured to cover the IP Phones in the Private Zone. Do not configure more channels than are required in the Private Zone as the Shared Zone IP Phones cannot access these channels.

#### Lack of DSP resources

DSP resources for each customer are placed in one common pool. A DSP channel is allocated to an IP-to-circuit-switched call based on a round-robin search algorithm within the pool.

If an available resource is not found, the overflow tone is given. For most installations, this approach works because all IP Phone users share the IP Line DSP resources. The DSP can be provisioned using a DSP-to-IP Phone ratio similar to trunk resources, because the DSP are used only for circuitswitched access or conference calls.

When IP-to-PSTN calls are used, such as with ACD agents or other users who consistently use trunk resources to make calls, it becomes difficult to provision the system to guarantee an available DSP channel when these users need it. If the other users suddenly make a lot of conference calls or trunk calls, the DSP resources can deplete and calls cannot be made. This occurs because all DSP channels are in one pool.

## **DSP resources and Private Zones**

IP Line provides the Private Zone Configuration feature for DSP configuration and allocation to the zone configuration. This feature enables the configuration of one or more gateway channels as a private resource. This guarantees DSP availability for critical or ACD agent IP Phone.

You can configure a zone as shared or private.

# **Network wide Virtual Office**

Network-wide virtual office allows a user to log on to any IP Phone within the network.

The Virtual Office feature provides a call service to travelling users who want to use a different physical IP Phone (other than the IP Phone they normally use). Users can log on to another IP Phone using their DN and preconfigured Station Control Password (SCPW).

After a user logs on, they can access their DN, autodial numbers, key layout, feature keys, and voice mail indication and access that are configured on their own home or office IP Phones. For example, if a user goes to another office or to a different location within the same office, they can log on to any available IP Phone and have all the features of the home or office IP Phone. When the user logs off the IP Phone, the features that were transferred to that IP Phone are removed.

#### Virtual Office for multi-customer configuration

The IP Network-wide Virtual Office feature supports only one customer group. If you configure more than one customer group, the IP Network-wide Virtual Office feature supports the one with the lowest customer number.

## **Network Wide Virtual Office and the Network Routing Server**

Network Wide Virtual Office uses the Network Connect Service (NCS) on either Network Routing Server (NRS) or Avaya Aura® Session Manager.

With NRS. Network Wide Virtual Office is limited to a single NRS zone. As long as Virtual Offices share the same NRS, a Virtual Office login can redirect an IP phone to any system.

## Requirements

A Signaling Server, standalone NRS, or Session Manager is required in the network.

## Supported IP Phones

Virtual Office is supported for the IP Phone 2001, IP Phone 2002, IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2033 IP Conference Phone, Avaya 1210 IP Deskphone, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, Avaya 1110 IP Deskphone, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, Avaya 1165E IP Deskphone, Avaya 2050 IP Softphone, MVC 2050, WLAN Handset 2210/2211/2212, and Avaya 6120/6140 WLAN Handsets..

For IP Phone 2004, Avaya 2050 IP Softphone, MVC 2050, Avaya 2007 IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1165E IP Deskphone, WLAN Handsets 2210/2212/2212, and Avaya 6120/6140 WLAN Handsets, users can log on from an IP Phone 2002 and Avaya 1120E IP Deskphone under certain conditions. See IP Phone type checking and blocking on page 147.

Table 48: Virtual Office logon from various IP Phones on page 142 shows which users can log on to particular IP Deskphones.

Table 48: Virtual Office logon from various IP Phones

IP Deskphone User	Virtual Office logon
IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone, or Avaya 1210 IP Deskphone	Log on from another IP Phone 2001, Avaya 2033 IP Conference Phone , Avaya 1110 IP Deskphone, Avaya 1210 IP Deskphone, Avaya 1230 IP Deskphone, Avaya 1220 IP Deskphone, IP Phone 2002, IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2050 IP Softphone, MVC 2050, WLAN Handset /2211/2212, Avaya 6120/6140 WLAN Handsets, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, and Avaya 1165E IP Deskphone. See IP Phone type checking and blocking on page 147.
IP Phone 2002, Avaya 1120E IP Deskphone, or Avaya 1220 IP Deskphone	Log on from another IP Phone 2002, IP Phone 2004, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, Avaya 2007 IP Deskphone, Avaya 2050 IP Softphone, MVC2050, WLAN Handset 2210/2211/2212, Avaya 6120/6140 WLAN Handsets, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, and Avaya 1165E IP Deskphone.
	Log on under certain conditions when they attempt a Virtual Office logon from an IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone, and Avaya 1210 IP Deskphone. See IP Phone type checking and blocking on page 147.
Avaya 1230 IP Deskphone	Log on from another Avaya 1230 IP Deskphone.
	Log on under certain conditions when they attempt a Virtual Office logon from an IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone, Avaya 1220 IP Deskphone, IP Phone 2002, IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2050 IP Softphone, MVC 2050, WLAN Handset 2210/2211/2212, Avaya 6120/6140 WLAN Handsets, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, and Avaya 1165E IP Deskphone. See IP Phone type checking and blocking on page 147.
IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 1140E IP Deskphone	Log on from another IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2050 IP Softphone, MVC 2050, WLAN Handset 2210/2211/2212, Avaya 6120/6140 WLAN Handsets, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, and Avaya 1165E IP Deskphone.
	Log on under certain conditions when they attempt a Virtual Office logon from an IP Phone 2001, IP Phone 2002, Avaya 1210 IP Deskphone, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone and Avaya 2033 IP Conference Phone. See IP Phone type checking and blocking on page 147.
Avaya 2050 IP Softphone or MVC2050	Log on from another Avaya 2050 IP Softphone, MVC 2050, IP Phone 2004, Avaya 1230 IP Deskphone, Avaya 2007 IP Deskphone, WLAN Handset 2210/2211/2212, Avaya 6120/6140 WLAN Handset, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone and Avaya 1165E IP Deskphone.
	Log on under certain conditions when they attempt a Virtual Office logon from IP Phone 2002, Avaya 1210 IP Deskphone, Avaya 1220 IP Deskphone, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, and Avaya 1165E IP Deskphone. See IP Phone type checking and blocking on page 147.

Table continues...

IP Deskphone User	Virtual Office logon
	Virtual logon for an Avaya 2050 IP Softphone, and MVC 2050 user to an IP Phone 2001, Avaya 2033 IP Conference Phone, and Avaya 1110 IP Deskphone is blocked.
Avaya 1150E IP Deskphone	Log on from an Avaya 1150E IP Deskphone only. Virtual Office log on for an Avaya 1150E IP Deskphone to any other IP Phone is blocked.
	The agent IP Phone must have a secondary (or private) DN assigned, which is then used as the VO User ID.

Virtual Office User Allowed (VOUA) and Virtual Office logon Allowed (VOLA) must be configured on the IP Phones as follows:

- The IP Phone where the user wants to virtually log on (destination) must have Virtual Office User Allowed (VOUA) configured.
- The IP Phone where the user wants to log on (source) must have Virtual Office logon Allowed (VOLA) configured.

## Failed password attempt

Three failed password attempts to log on using the Virtual Office feature locks the user out from Virtual Office logon at the Call Server for one hour. The Call Server lock can be removed by an administrator using a LD 32 command to disable and re-enable that TN. See Communication Server 1000M and Meridian 1 Large System Maintenance or Software Input Output Reference — Maintenance, NN43001-711.

## **Passwords and IP Phone Registration**

An IP Phone registers using the TN (in the EEPROM). A valid user ID and password determine the Home LTPS for the IP Phone during the Virtual Office connection. A Network Routing Server (NRS) is required if the Home LTPS is not the LTPS where the IP Phone is registered when the Virtual Office logon occurs.

## **Virtual Office capabilities**

Virtual Office provides the following capabilities:

- A network-wide connection server (Network Routing Server [NRS]) is provides addressing information of call servers, based on a user DN.
- A key sequence is entered at an IP Deskphone to initiate the logon sequence. Then the current network DN and a user-level password is entered. The password is the Station Control Password configured in LD 11. If a SCPW is not configured, the Virtual Office feature is blocked.
- A user logs off on leaving the location.

For more detailed information about Virtual Office, see IP Phones Fundamentals, NN43001-368.

# **Bandwidth Management for Network wide Virtual Office**

Bandwidth is calculated for IP users who use the Virtual Office feature to log on to their home IP Phones from various Call Servers within the network.

When an IP user moves from the home location to a location that has another Call Server and logs on to a Virtual Office from the home Call Server, the IP Phone used for Virtual Office registration obtains the following information:

- DN number associated with the user ID
- TN parameters including the configured bandwidth zone

The zone information is saved in the Current Zone field. All features that depend on configured zone information receive the correct bandwidth calculations. Configured Zone and Current Zone fields replace the current Bandwidth Zone field. The Configured Zone field stores the configured zone number. This value changes only if the zone is reconfigured. The Current Zone field stores the current zone number. This value changes with each Virtual Office log on.

For more information about the Bandwidth Management for Network wide Virtual Office feature, see *Converging the Data Network with VoIP Fundamentals, NN43001-260.* 

# **Branch Office and Media Gateway 1000B**

The Media Gateway 1000B (MG 1000B) provides a way to extend CS 1000 features to one or more remotely located branch offices using the Branch Office feature. A branch office is a remote location in the network where IP Phones, PSTN access, and TDM telephones are located.

At least one Signaling Server must be at the main office and each branch office.



To provide NRS redundancy in a network with branch offices, Avaya recommends that you configure a Failsafe NRS at each branch office that is not otherwise configured with a Primary or Alternate NRS.

For more information about MG 1000B, see *Branch Office Installation and Commissioning, NN43001-314*.

The total number of IP Deskphones in all offices can be no greater than the capacity of the main office, as specified in Avaya Communication Server 1000E: Planning and Engineering, NN43041-220 or Avaya Communication Server 1000M and Meridian 1 Large System Planning and Engineering, NN43021-220.

# 802.1Q support

The following IP Phones support 802.1Q:

- IP Phone 2001
- IP Phone 2002
- IP Phone 2004
- Avaya 2007 IP Deskphone
- · Avaya 2033 IP Conference Phone
- Avaya 1210 IP Deskphone
- Avaya 1220 IP Deskphone
- Avaya 1230 IP Deskphone
- Avaya 1110 IP Deskphone
- Avaya 1120E IP Deskphone
- Avaya 1140E IP Deskphone
- Avaya 1150E IP Deskphone
- Avaya 1165E IP Deskphone

The Avaya 2050 IP Softphone supports 802.1Q through the PC operating system. This support defines the virtual LAN (VLAN) within a single LAN. This improves bandwidth management, limits the impact of broadcast and multicast messages, and simplifies VLAN configuration and packet prioritization. A higher level of security between network segments can result.

### Configuration of 802.1Q on IP Phones

The 802.1Q support for the IP Phones is configured using the IP Phone user interface or DHCP. The DHCP approach eliminates the need to manually configure the VLAN ID during the installation.

To configure 802.1Q, configure the following values:

- p bits
- VLAN ID

For more information about manual or automatic IP Phone configuration, see *IP Phones Fundamentals*, *NN43001-368*.

# **Data Path Capture tool**

IP Line contains the Data Path Capture tool, a built-in utility used to capture audio information. This tool helps debug audio-related gateway problems and allows after-the-fact analysis of what the user heard.

You can use CLI commands to use the Data Path Capture tool.

# **IP Phone firmware**

See the ReadmeFirst documentation to determine the IP Phone minimum firmware (F/W) versions supported by IP Line.

### **Default location of firmware files**

For CS 1000 system configurations, the default storage location for the firmware files is on the Signaling Server in the /var/opt/cs1000/tps/fw/ directory. Use Element Manager to load, remove and manage firmware files.

# Hardware watchdog timer

A hardware watchdog timer is enabled on the Voice Gateway Media Cards. This feature enhances the existing exception handler and maintenance task audits.

The hardware watchdog timer handles scenarios such as the following:

- the CPU failing
- the code running and not triggering an exception
- resetting the card and returning it to normal operation

The timer runs on the Voice Gateway Media Cards processors. The card main processor is polled every 20 seconds. If three pollings are missed, then the card is reset. This gives the main processor 60 seconds to respond, which covers most normal operating conditions.

A reset reason is logged and saved when a card resets. The reset reason appears as a message during the startup sequence and appears in the SYSLOG file.

The following are examples of reset reasons:

- JAN 04 12:17:45 tXA: Info Last Reset Reason: Reboot command issued Output after card reset using the CLI command cardReboot .
- JAN 04 12:17:45 tXA: Info Last Reset Reason: Watchdog Timer Expired Output after card reset due to watchdog timer expiration.
- JAN 04 12:17:45 tXA: Info Last Reset Reason: Manual reset Output after card reset due to either the faceplate reset button press or a power cycle to the card.
- JAN 04 12:17:45 tXA: Info Last Reset Reason: Unknown Output after card reset due either the card F/W not supporting the reset reason or a corruption of the reset reason code.

The last reset reason can also appear at any time by entering the CLI command lastResetReason.

Linux servers also have hardware watchdog timers. For more information, see *Linux Platform Base* and *Applications Installation and Commissioning, NN43001-315*.

### **Codecs**

Codec refers to the voice coding and compression algorithm used by the DSP on the Media Card. Different codecs provide different levels of voice quality and compression properties. The specific codecs and the order in which they are used are configured on the LTPS and CS 1000.

The G.723.1 codec has bit rates of 5.3 kb/s and 6.3 kb/s. In IP Line, the G.723.1 codec can only be configured with a 5.3 kb/s bit rate; however, the system accepts both G.723.1 5.3 kb/s and 6.4 kb/s from the far-end.

T.38 is the preferred codec type for fax calls over virtual trunks. However, the G.711 Clear Channel codec is used if the far-end does not support the T.38 codec.

The G.722 codec has bit rates 48 kb/s, 56 kb/s, and 64 kb/s. This codec can only be configured with a 64 kb/s bit rate, however, the system accepts both 48 kb/s and 56 kb/s from the far end.

For detailed information about codecs, see Codecs on page 171.

# IP Phone type checking and blocking

If the registration is a regular request (as opposed to a Virtual Office logon), the Call Server checks the configured TN type against the actual IP Phone type.

When the LTPS attempts to register the IP Phone with the Call Server, the following occur:

- If the TN has Flexible Registration Denied (FRD) CoS configured, the Call Server checks the IP Phone type against the TN type. If the types do not match, the registration attempt is rejected and registration in Emulation Mode is blocked.
- If the TN has the default Flexible Registration Allowed (FRA) CoS configured, the Call Server checks the IP Phone type against the TN type. If the types are compatible, the TN is converted and the IP Phone registers.
- If the TN has Flexible Registration on Upgrade CoS configured, the Call Server checks the IP
  Phone type against the Virtual TN (VTN) type. If the types are compatible, the TN is converted
  and the IP Phone registers. After the TN is converted, the Flexible Registration CoS is
  configured to FRD and registration in Emulation Mode is blocked.

However, if the registration request is a virtual logon, this check does not occur. All IP Phones can register on any IP TN type when the logon is through Virtual Office.

Special checking on the self-labeled line/programmable feature keys occurs when an IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2050 IP Softphone, Avaya 1120E IP Deskphone, Avaya

1140E IP Deskphone, or Avaya 1165E IP Deskphone user logs on from an IP Phone 2002 or Avaya 1220 IP Deskphone, or when an IP Phone 2002, or Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2050 IP Softphone, MVC 2050, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, or Avaya 1165E IP Deskphone user logs in from an IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1210 IP Deskphone, or Avaya 1110 IP Deskphone.

Special checking is required to prevent a user from logging on from an IP Phone that cannot display an incoming call because the IP Phone used to log on does not have the self-labeled line/programmable feature keys to display the incoming call. If the logon is permitted, the IP Phone can ring without providing the user a way to answer the call. The configuration of the logging on user is examined for self-labeled line/programmable feature key types that receive incoming calls. If self-labeled line/programmable feature key types appear on any keys not on the type of IP Phone being used for the logon, the logon is blocked.

The logon from an IP Phone 2002 is blocked for users configured for Automatic Call Distribution (ACD).

# IP Phone 2002, Avaya 1220 IP Deskphone, and Avaya 1120E IP Dekphone logon restrictions

Because the IP Phone 2002, Avaya 1220 IP Deskphone, and Avaya 1120E IP Deskphone support only four feature keys, a restricted VO logon is applied to IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2050 IP Softphone, Avaya 1230 IP Deskphone, Avaya 1140E IP Deskphone, and Avaya 1165E IP Deskphone TN when they log on using an IP Phone 2002, Avaya 1220 IP Deskphone, or Avaya 1120E IP Deskphone.

### Note:

In case of a restricted VO logon, the phones display a Restricted message, indicating that some functionality is not available because of the fewer number of keys on the phone used.

When the IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2050 IP Softphone, Avaya 1230 IP Deskphone, Avaya 1140E IP Deskphone, or Avaya 1165E IP Deskphone user logs on from an IP Phone 2002, Avaya 1220 IP Deskphone, or Avaya 1120E IP Deskphone, the logon is blocked if the user configuration has one of the following:

- key 0 defined as ACD
- any key from 4 to 15 defined as AAK, CWT, DIG, DPU, GPU, ICF, MCN, MCR, MSB, PVN, PVR, SCR, or SCN

# IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1210 IP Deskphone, and Avaya 1110 IP Deskphone logon restrictions

Because the IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1210 IP Deskphone, and Avaya 1110 IP Deskphone do not support feature keys, a restricted VO logon applies to IP Phone 2002, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, IP Phone 2004, Avaya 2007 IP

Deskphone, Avaya 2050 IP Softphone, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, and Avaya 1165E IP Deskphone TN when the user logs on using an IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1210 IP Deskphone, and Avaya 1110 IP Deskphone.

### Note:

In case of a restricted VO logon, the phones display a Restricted message, indicating that some functionality is not available because of the fewer number of keys on the phone used.

When an IP Phone 2002, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2050 IP Softphone, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, or Avaya 1165E IP Deskphone user logs on from an IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1210 IP Deskphone, or Avaya 1110 IP Deskphone, the logon is blocked if the user configuration has one of the following:

- key 0 defined as ACD
- any other key (from 1 to 15) defined as AAK, CWT, DIG, DPU, GPU, ICF, MCN, MCR, MSB, PVN, PVR, SCR, or SCN.

# **Enhanced Redundancy for IP Line nodes**

The Enhanced Redundancy for IP Line nodes feature relaxes the checking performed by a node on the Node ID that is presented by a registering IP Phone. Under the circumstances described in this section, an IP Phone with a three-digit Node ID can register to a node configured with a four-digit Node ID. To enable the registration to be successful, the three-digit Node ID must match the first three digits of the node four-digit Node ID.

This feature enhances the IP Phone survivability in the case of network outages or equipment failure; it allows an IP Phone to register to more than one node on a system. By configuring the IP Phone S1 and S2 Connect Server IP addresses to the node addresses of two nodes, and properly configuring the Node IDs, the IP Phone can register to another secondary node if it cannot register to the primary node.

The rules are as follows:

- if the Node ID on the system has three digits or less, the Node ID from the IP Phone must match exactly
- if the Node ID on the system has four digits and
  - if the Node ID from the IP Phone has fewer than three digits, reject the registration.
  - if the Node ID from the IP Phone has only three digits and they match the first three digits of the four digit Node ID (left to right), then allow the IP Phone to register. If the first three digits do not match, reject the registration.
  - if the Node ID from the IP Phone has four digits, the Node ID must match exactly. If the four digits do not match, reject the registration.

Up to 10 nodes can be configured on a system (three-digit Node ID base plus 0 to 9 for the fourth digit). The IP Phones are distributed among the nodes by programming different S1 and S2 IP

addresses into the IP Phones. The IP Phones register to the primary Connect Server (the S1 IP address) if possible.

If a network outage or equipment failure prevents the registration to the primary Connect Server, the IP Phone can register to a secondary Connect Server (the S2 IP address). This feature enables a node registered IP Phones to spread across the spare IP Phone registration capacity of the other nodes in the system in the event of a network outage or equipment failure.

### **Example:**

The installer configures two nodes on a system with Node IDs 3431 and 3432. An IP Phone configured with Node ID 343 can register with either node.

If the IP Phone presents one of the following Node IDs, it is rejected for registration

- 3
- 34
- 3433

The TN must still match before the IP Phone is allowed to register.

If the customer does not want to use the Enhanced Redundancy for IP Line Nodes feature, programming two- or four-digit Node ID retains the exact match requirement.

# **Patch Management**

Patching Manager (PM) is a centralized patch deployment application that supports patching for all Linux-based elements. This includes patching of all Linux bases and applications on these elements (except for Call Server on the Co-resident Call Server and Signaling Server).



### Note:

Patching for the Call Server (on VxWorks or Linux) and other VxWorks devices such as media cards is supported by Element Manager.

Linux patching involves the patching of a specific version of an RPM. The RPM is the base building block of the Linux patching process.

RPM patches are issued only as Serviceability Updates (SU) and each Serviceability Update can contain only one RPM. Serviceability Updates have the same filename as the RPM file it contains; however, the Serviceability Update has a different extension.

Binary patches are created and distributed against a specific RPM name and release. Patches are given a unique patch name, which are automatically generated by the Meridian Patch Library (MPL). Binary patches are linked to their RPM using the patch header.

All other patching on Linux, such as JAR, WAR, and BIN are treated in the same manner as binary patches and each is tied to a specific release of an RPM.

Some patches may be dependent on one or more patches to be in-service before the latest patch is activated.

For more information about the Patching Manager, see Patching Fundamentals, NN43001-407.

# Migration from Solid database to MySQL

The Solid RPM package will be replaced by two groups of RPMs. One group will be the MySQL third-party RPM. The other group is the Avaya application RPM which is renamed from Solid to dbcom. The two groups of RPMs are part of the Avaya application image and are included in the Linux application load-build.

There will not be any impact on the user interface due to MySQL migration.

### Note:

When the Solid database is upgraded to MySQL, the database server TCP port is changed from 1313 to 3306.

### Note:

When the Solid database is upgraded to MySQL, all Solid database utilities are removed.

### **Database application creation and operation**

The dbcom application creation is based on the original Solid RPM creation and follows the Linux base RPM guidelines. The current Linux base appinstall and appstart are used for the MySQL installation and operation. After the application is installed, the default database configuration, accounts and passwords will be loaded. These include:

- NRS/NRS Manager: the account name "nrs" with the default password from the Secret Manager (SM) has full privileges on the databases NRS\_A, NRS\_B, and NRS\_D. The databases will be empty initially.
- PD: the account name "pd" with the default password from the Secret Manager (SM) has full privileges on the database pddb. The database will be empty initially.
- EM/BCC: the account name "mgmt" with the default password from the Secret Manager (SM) has full privileges and it can create the databases on the fly. The default empty databases are systemdatabase and template database.

Similar to operation of the Solid database, the following commands are supported under the admin2 account and should be used to start, stop, restart and check the status of the MySQL database engine:

- · appstart dbcom start
- appstart dbcom stop
- appstart dbcom restart
- appstart dbcom status

# **Chapter 6: Personal Directory application**

### **Contents**

This section contains the following topics:

- Introduction on page 152
- Personal Directory on page 154
- Callers List on page 155
- Redial List on page 157
- IP Phone Application Server configuration and administration on page 158
- IP Phone Application Server database maintenance on page 163
- Call Server configuration on page 167
- Password administration on page 167
- Unicode Name Directory on page 169

# Introduction

The Personal Directory application supports the creation of a Personal Directory for IP Phone users.

Personal Directory, Callers List, and Redial List are supported on the IP Phone 2002, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2050 IP Softphone, Mobile Voice Client (MVC) 2050, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, Avaya 1165E IP Deskphone, WLAN Handset 2210, WLAN Handset 2211, WLAN Handset 2212, Avaya 6120 WLAN Handset, and Avaya 6140 WLAN Handset.

Personal Directory, Callers List, and Redial List are not supported on the IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1210 IP Deskphone, and Avaya 1110 IP Deskphone.

The IP Phone Application Server ELAN network interface IP address must be configured. See IP Phone Application Server configuration and administration on page 158.

### Important:

Calling Party Name Display (CPND) must be configured as a Class of Service (CoS) on the system to enable Personal Directory, Callers List, and Redial List.

An IP Phone user creates and manages the Personal Directory. The IP Phone user can enter or copy names to the Personal Directory and delete entries from the personal directory. Personal Directory is not a call log feature.

Callers List and Redial List are call log features. The content of these lists is generated during call processing. CPND must be configured as a CoS to generate the names in the logs. Content cannot be changed; however, a user can delete or, in some cases, copy entries or lists.

Table 49: Comparison of Personal Directory with Callers List and Redial List on page 153 compares the Personal Directory with the Callers List and Redial List features.

Table 49: Comparison of Personal Directory with Callers List and Redial List

Operation	Personal Directory	Callers List and Redial List
Display date and time of transaction	No	Yes
Modify entry	Yes	No
Dial from the list	Yes	Yes
Delete entry	Yes	Yes
Content view mode (The IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, Avaya 1165E IP Deskphone, WLAN Handsets 2210/2211/2212, Avaya 6120 WLAN Handset, and Avaya 6140 WLAN Handset display name and DN simultaneously. The IP Phone 2002, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, and Avaya 1120E IP Deskphone display either the name or DN. The phones cannot simultaneously display the name and DN.) If caller name is not defined, then only the DN is displayed.	Yes	Yes
Delete list	Yes	Yes
Edit and dial (Temporarily modify an entry and dial out. Does not modify record in database.)	No	Yes
Access through soft keys	Yes	Yes
Maximum number of entries	100	20 (Redial List) 100 (Callers List)

### **Virtual Office**

Personal Directory, Callers List, and Redial List are available when you use Virtual Office (VO). Data is stored on the Signaling Server, not on the IP Phone. This means when a user logs on using Virtual Office or logs on in a branch office in Normal Mode, they can always access the stored names and numbers.

# Media Gateway 1000B

Personal Directory, Callers List, and Redial List are supported in a branch office configuration when the Media Gateway (MG) 1000B in the branch office location is in Normal Mode. Personal Directory, Callers List, and Redial List are not available in Local Mode, as the entries are stored on the main office Signaling Server.

# User key for Personal Directory, Callers List, and Redial List

An IP Phone Private Network Identifier (PNI) + Home Location Code (HLOC) + primary DN (PDN) make up the lookup key for the IP Phone Personal Directory, Callers List, and Redial List data.

For the HLOC, if a CLID table entry exists (CLID = yes in LD 15) for the Primary DN (PDN) or the first non-ACD key DN, the CLID table HLOC is used. When no CLID entry exists, the HLOC defined in LD 15 Network Data section is used (it might be 0 if HLOC is not configured).

The PNI ensures the HLOC + PDN is unique across customers on a system if the system is for multiple customers.

Because the user PDN and HLOC are used, then to identify a specific user, a user primary DN and HLOC must be unique to the network to support their specific Personal Directory, Callers List, and Redial List. If using Multiple Appearance DN (MADN) for a group of users and you must provide users with their own Personal Directory, Callers List, and Redial List, do not configure the Primary DN (PDN) as MADN.

If the MADN is used as the PDN for a group of users, this results in a shared Personal Directory, Callers List, and Redial List. This means that a call arriving on any IP Phone sharing the PDN MADN appears in the Callers List. Calls to a secondary DN on another IP Phone in the shared group appear in the Callers List for all IP Phones, even though the call did not ring on the other IP Phone.

# **Personal Directory**

Personal Directory has the following specifications:

- maximum entries = 100
- maximum characters in name = 24
- maximum characters in DN = 31
- · multiple actions:
  - add new entry
  - edit entry
  - delete entry

- delete contents of directory
- copy an entry from Personal Directory to Personal Directory
- copy an entry from Corporate Directory to Personal Directory
- dial the DN of an entry
- name search
- password protection to control access to Personal Directory
- 1-minute time-out

Personal Directory is deployed as part of the Signaling Server software package. You can stop and restart the Personal Directory without stopping and restarting other Signaling Server applications.

### Note:

To start Personal Directory on TPS it is not enough to provide TPS ELAN IP address in Element Manager, it is also necessary to enable Personal Directory service in Node configuration interface in Element Manager.

### **Callers List**

Callers List has the following specifications:

- maximum entries = 100
- maximum characters in name = 24
- maximum characters in DN = 31
- · multiple actions:
  - dial the DN of an entry
  - edit the entry
  - copy the entry
  - delete the entry
- · sorted by the time the call is logged
- contains caller name, DN, time of last call, and the number of times the caller calls this user
- Idle Display option: displays and counts all calls or only unanswered calls
- displays caller name (Redial List only displays the caller DN)
- after the 100 entry limit is reached, the newest entry overwrites the oldest entry
- 1-minute time-out

### Important:

If a phone configured with the Phoneset display feature is acquired by Contact Center, the Phoneset display overrides the Calling Party Name Display (CPND) feature and prevents Callers List from

updating. For more information, see *Avaya Aura*<sup>™</sup> *Contact Center Administration*–*Client Administration*, *NN44400-611*.

# **Call log options**

Use Call log options to configure the following preferences on the IP Phone:

- whether the Callers List logs all incoming calls or only unanswered calls
- · whether Idle Set Display indicates when new calls are logged to the Callers List
- whether a name stored in the Personal Directory that is associated with the incoming call DN appears instead of the name transmitted by the Call Server
- the three area codes to display after the DN, rather than before it (for example, local area codes)

### Note:

You might include the access code, for example 91 for North America, in the area code configuration. Including the access code ensures a match between incoming calling line information, and the corresponding entry in the user's Personal Directory.

Follow the steps in <u>Accessing the call log options</u> on page 156 to access the call log options for the IP Phone.

### Accessing the call log options

- On the IP Phone, press the **Services** key.
   The Telephone Options menu appears.
- 2. Select Telephone Options, Call Log Options.
- 3. Select the desired options.

### Important:

You can change the Call log option on the registered sets using LD 17 (DLAC).

<u>Table 50: Call log options</u> on page 156 summarizes the call log options.

### Table 50: Call log options

Call log option	Description	Default value
Log all or unanswered incoming calls	Configures the Callers List to log all incoming calls or only the unanswered incoming calls.	Log all calls. Can be changed in LD 17 (DLAC).
New Call Indication	When New Call Indication is on, a message appears on the IP Phone to inform the user of a new incoming call. If not configured, nothing appears.	On

Table continues...

Call log option	Description	Default value
Preferred Name Match	Configures whether the displayed caller name is the CPND from the Call Server or the name associated with the DN stored in the Personal Directory	CPND from the Call Server appears
Area code set-up	Configures how the incoming DN appears. If the area code of the incoming call matches a specified area code, the DN appears in the configured manner (for example, the area code can appear after the DN)	No area code
Name display format	Configures the format of the name display of the incoming call on the IP Phone <first name=""> <last name=""> <last name=""> <first name=""></first></last></last></first>	<first name=""> <last name=""></last></first>

The IP Phone 2002, Avaya 1220 IP Deskphone, Avaya 1230 Deskphone, and Avaya 1120E IP Deskphone do not display the New Call Indication on the idle screen at the same time as the date and time. Instead, the New Call Indication alternates with the date and time display.

### **Redial List**

Redial List has the following specifications:

- maximum entries = 20
- maximum characters in a name = 24
- maximum characters in a DN = 31
- contains name, DN, and the time the last call to that DN occurred in each entry
- the newest entry overwrites the oldest entry after the 20-entry limit is reached
- sort by the time the call is logged
- multiple actions:
  - dial the DN of an entry
  - edit the entry
  - copy the entry
  - delete the entry
  - delete contents of a list
- 1-minute time-out

# IP Phone Application Server configuration and administration

The IP Phone Application Server runs on the Signaling Server with the SS package deployed. For more information about deploying Signaling Server software, see <u>Signaling Server software</u> installation using <u>Deployment Manager</u> on page 185.

If less than 1000 users are supported, then the IP Phone Application Server can run on the same Signaling Server as Element Manager. If more than 1000 users are supported, then the IP Phone Application Server must run on another Signaling Server (preferably a Follower) with no co-located applications. Therefore, you must configure in Element Manager the ELAN network interface IP address of the Signaling Server where the IP Phone Application Server is installed. You must also enable the IP Phone Application Server in the IP Telephony node.

The IP Phone Application Server can be shared across multiple IP Telephony nodes on the same Call Server.

# Configure the IP Phone Application Server and remote backup

To configure the IP Phone Application Server in an existing IP Telephony node see Configuring the IP Phone Application Server in an existing node on page 158.

To configure the IP Phone Application Server in a new node and if the IP Phone Application Server must support more than 1000 users, see <u>Configuring the IP Phone Application Server on a new node</u> on page 160.

The default transfer method is SFTP. If a backup was done in an earlier release than Avaya CS 1000 Release 6.0 to FTP server, then SFTP must be supported to do the restore. Otherwise, SFTP connect fails and PD restore will not be completed.

### Configuring the IP Phone Application Server in an existing node

- In the Element Manager navigator, select IP Network > Nodes: Servers, Media Cards. The IP Telephony Nodes window appears.
- 2. Select the link for a Node ID.

The **Node Details** window appears for that node.




Figure 35: Node Details


Note:

The Node IPv6 address in the above screen displays a string of zeros due to the IPv6 address length. You can use the compressed form, where a single continuous sequence of 0 blocks are represented by a double colon (::). This symbol can appear only once in an address. For example, the multicast address FFED:

0000:0000:0000:0000:BA98:3210:4562 in compressed form is FFED::BA98:3210:4562.

3. Click the **Personal Directories (PD)** link in the Applications (click to edit configuration) section of the window. **The Personal Directory Server (PD) Configuration Details** window appears.

Node ID: 7777 - Personal Directory Server (PD) Configuration Details



- 4. Select the Enable Personal Directory (PD) service on this node check box.
- 5. Click Save.

The **Node Details** window appears.

6. Click Save.

The **Node Saved** window appears.

7. Click Transfer Now.

The **Synchronize Configuration Files** window appears.

8. Select all servers and click **Start Sync** .

The Synchronization Status changes to Sync in progress and then to Synchronized.

9. Select all servers and click **Restart Applications**.

Perform the steps in the following procedure to configure the IP Phone Application server on a new node.

### Configuring the IP Phone Application Server on a new node

 In the Element Manager navigator, select IP Network > Nodes: Servers, Media Cards to configure a new node.

The IP Telephony Nodes window appears.

2. Click Add.

The **Node Details** window appears.

- 3. Enter a unique Node ID in the Node ID box.
- 4. Configure the IP addresses and subnet masks for the Signaling Server.
- 5. Select the necessary applications including Personal Directory (PD). If the IP Phone Application Server must support more than 1000 users, choose only Personal Directory (PD).
- 6. Click Next.




Figure 36: New IP Telephony Node - Personal Directory check box

- Select from the list and click Add to associate servers with this node. If the IP Phone
  Application Server must support more than 1000 users, select only one server with the SS
  package deployed.
- 8. Select one of the servers and click **Make Leader**.
- 9. Click Next.
- Additional configuration windows appear for each selected application. Configure each of them and click **Next**.
- 11. The **Confirm new Node** details window appears. Click **Finish**.
  - The **Node Saved** window appears.
- 12. Click **Transfer Now**. The **Synchronize Configuration Files** window appears.
- 13. Select all servers and click **Start Sync**. The Synchronization Status changes to Sync in progress and then to Synchronized.
- 14. Select all servers and click **Restart Applications**.

# **Personal Directories Server Configuration**

Because you can back up and restore the IP Phone Application Server database, you must configure information to support the backup and restore feature. See <u>Figure 37: Personal Directories Server Configuration window</u> on page 162.

The following parameters are configured:

- ELAN network interface IP address of the IP Phone Application Server where the database is located
- check box to turn on or off the remote backup functionality
- IP address of the server where the backup is saved
- path, file name, user ID, and password to support the backup and restore feature

Managing: 192.167.100.3

System » IP Network » Personal Directories » Server Configuration

### Server Configuration




Figure 37: Personal Directories Server Configuration window

<u>Table 51: Sample IP Phone Application Server configuration</u> on page 162 provides a sample IP Phone Application Server configuration.

Table 51: Sample IP Phone Application Server configuration

Data field name	Example	Description
Server Configuration		
Server IP Address	92.168.10.12	IP address of the database server (for example, the Leader Signaling Server ELAN network interface IP address).

Table continues...

Data field name	Example	Description
Backup Configuration		
Perform scheduled remote backup	Check box is selected	Select check box to enable scheduled remote backups.
Remote backup time of day (hh:mm)	00:00	The time of day to perform the backup (default is 00:00 midnight).
Remote backup IP address	47.11.22.11	Remote backup server IP address.
Remote backup path	/auto/etherset	Remote path where the back up file is saved.
Remote backup file name	ipldb.db	File name of the backup file.
Remote backup userid	etherset	Logon name for the remote backup.
Remote backup password	etherset	Password for remote backup.

The Personal Directory, Callers List, and Redial List features are not available to the user if the IP Phones lose contact with the Signaling Server. The features are available again only when contact with the Signaling Server is reestablished.

### **Alarms**

If the IP Phone Application Server is not installed on the primary Signaling Server, and the other Signaling Server cannot contact the IP Phone Application Server, then an SNMP alarm is raised. The alarm indicates that the Personal Directory, Callers List, and Redial List are not available. If this occurs, the other Signaling Server tracks the Signaling Server where the IP Phone Application Server resides. When contact with the IP Phone Application Server is made, Personal Directory, Callers List, and Redial List access resumes.

# IP Phone Application Server database maintenance

Use Element Manager to maintain the IP Phone Application Server database.

Configure a daily backup to occur at a scheduled time.

You can recover an IP Phone Application Server database for all users or for one user entries.

# IP Phone Application Server database backup

Follow the steps in <u>Backing up the IP Phone Application Server database server manually</u> on page 164 to manually back up the IP Phone Application Server database.

You can also schedule a backup of the database. See <u>Configure the IP Phone Application Server</u> and remote backup on page 158.

### Backing up the IP Phone Application Server database server manually

 In the Element Manager navigator, click Tools > Backup and Restore > Personal Directories.

The **Personal Directories Backup and Restore** window appears.

2. Click Personal Directories Backup.

The **Personal Directories Backup** window appears. See <u>Figure 38: Personal Directories</u> Backup window on page 164.




Figure 38: Personal Directories Backup window

- 3. Enter the data for the Remote backup IP address, Remote backup userid, Remote backup password, Remote backup path, and Remote backup file name fields.
- 4. Click Submit.

# Full database recovery

Perform the steps in <u>Performing a full database recovery</u> on page 164 to perform a full database backup for the IP Phone Application Server.

### Performing a full database recovery

1. Select Tools > Backup and Restore > Personal Directories.

The **Personal Directories Backup and Restore** window appears.

2. Click Personal Directories Restore.

The **Personal Directories Restore** window appears. See <u>Figure 39: Personal Directories</u> <u>Restore window</u> on page 165.




Figure 39: Personal Directories Restore window

- 3. From the **Action** list, select **SFTP from Remote Site** if the backup is saved on a remote server. If the backup is already saved locally on the server, go to Step 8.
- 4. Enter the data for the Remote backup IP address, Remote backup userid, Remote backup password, Remote backup path, and Remote backup file name fields.
- 5. Click Submit.
- 6. Click OK.

After the file is transferred to the local drive, an message appears indicating the successful file transfer.

7. Click OK.

The file is transferred to the server but the database is not yet restored.

- 8. Reset all the IP Phones using **isetResetAll** on every LTPS in the system and allow the IP Phones to register.
- 9. From the Action list, select Restore All Users .
- Click Submit.
- 11. Click **OK** .

The data for all users is restored and the existing data in the Personal Directories database is overwritten.

# Important:

The length of time to restore a database depends on the number of records.

# Selective database recovery for a single user

Follow the steps in <u>Performing a selective database recovery</u> on page 166 to recover a database for a single user. A valid backup file is required to recover a database.

### Performing a selective database recovery

- 1. Select Tools > Backup and Restore > Personal Directories.
  - The **Personal Directories Backup and Restore** window appears.
- 2. Click Personal Directories Restore.
  - The **Personal Directories Restore** window appears.
- 3. From the Action list, select Restore Single User.

The **Personal Directories Restore** window for a single user opens. See <u>Figure 40: Personal Directories Restore</u> for a single user window on page 166.




Figure 40: Personal Directories Restore for a single user window

- 4. Enter the Customer Number and Directory Number (DN) of the user.
- 5. Select the check boxes for the data that you want to restore.
- Click Submit.

### Fault clearance

The database recovery clears any faults.

### Recommendation

Avaya recommends that you install the IP Phone Application Server on a dedicated Signaling Server to ensure that database operations do not affect call processing.

### **Call Server configuration**

To provide password protection for an IP Phone user Personal Directory, Callers List, and Redial List, Station Control Password (SCPW) must be configured on the Call Server. If SCPW is not configured, password administration on the IP Phone cannot be accessed.

In LD 15 and in Element Manager, a new prompt, DFLT\_SCPW, is added to the Flexible Feature Code (FFC) parameters for the Call Server. When DFLT\_SCPW is Yes, the system assigns a default password (the primary DN) to IP Phone users when an IP Phone is added or changed in LD 11.

### Important:

System administrators must ensure that users change the default password on the IP Phone to control access, as the default password is the same on all IP Phones when DFLT\_SCPW is Yes.

The new prompt DFLT\_SCPW and the existing prompt Station Control Password Length (SCPL) are prompted for only if FFC package 139 is enabled.

The SCPL is also defined in LD 15 Flexible Feature Code (FFC) configuration parameters and in Element Manager. If the SCPL length changes, the change takes effect only after a data dump and then a sysload of the Call Server. The SCPL changes to the new length during the sysload. If the length is increased, then 0 is inserted at the beginning of the SCPW to conform to the new length. If the password length is reduced, then the leading digits are removed during the sysload.

# **Password administration**

The Station Control Password (SCPW) controls access to the user private Personal Directory, Callers List, and Redial List information.

By default, when the IP Phone first registers to the system, the password protection is off. If a default password is defined for the user, the user can enable or disable password protection and change the password. The changed password is updated on the Call Server and can be viewed in LD 20. Other applications that use this password, such as Virtual Office and Remote Call Forward, are affected by the password change.

# Initial password

When an IP Phone first registers with the system, by default the password protection is turned off. SCPW must be initially configured for each user. If no SCPW has been defined, password protection for the IP Phone cannot be enabled. The prompt DFLT SCPW in LD 15 specifies that a

default SCPW is assigned to an IP Phone user when an IP Phone is added or changed in LD 11. See Table 52: LD 15 Enable a default SCPW on page 168.

Table 52: LD 15 Enable a default SCPW

Prompt	Response	Description
REQ:	CHG	Change existing data.
TYPE:	FFC	Change Flexible Feature Code parameters.
CUST		Customer number as defined in LD 15.
FFCS	(NO) YES	Change Flexible Feature Code end-of dialing indicator.
ADLD	(0) to 20	Auto Dial Delay (in seconds).
DFLT_SCPW	(NO) YES	Default Station Control Password.
		NO = disable Default Station Control Password (default).
		When DFLT_SCPW = YES, the system automatically assigns an SCPW when a new IP Phone is created.
		An SCPW is not automatically assigned to an existing IP Phone unless that IP Phone is given a service change.

# **Password guessing protection**

A password retry counter tracks how many incorrect password entries are made. If the IP Phone password verification fails three times in one hour, the user is locked out for 1 hour. This means that the Personal Directory, Callers List, and Redial List cannot be accessed and password administration cannot occur. A message appears on the IP Phone to indicate that access is locked.

After 1 hour, the retry counter is reset and access is unlocked. The retry counter also resets when the user correctly enters the password.

The administrator can reset the counter and unlock the access either in Element Manager or in LD 32.

If a user is locked out from using the SCPW to access Personal Directory, Callers List, and Redial List, they also are blocked from access to their Virtual Office logon, because VO uses the same SCPW. Conversely, a user who is locked out from the VO logon is also locked out from accessing their Personal Directory, Callers List, and Redial List.

# Forgotten password

If the user forgets the IP Phone password, the administrator can reset the retry counter and change the user password in Element Manager. After the administrator changes the password, the lock is released automatically.

# **Unicode Name Directory**

With the Unicode Name Directory System feature, the CS 1000 caller or called party name appears in up to seven other languages. This new feature enhances the functionality of IP Phones that can display Unicode. The Unicode Name Directory feature provides localized names on a subscriber base and generates the Calling Line IDs and URIs on a subscriber telephony account on a network level to serve the Unicode Name Directory server.

The Unicode Name Directory provides the following features:

- display of localized name in UTF-8 Unicode character encoding for incoming and outgoing calls
- storage for up to seven localized names in the database for a particular subscriber
- support for Korean, traditional and simplified Chinese, Japanese and other Unicode languages for called or caller party name display
- ability to work with Avaya IP Deskphones 2007, 1120E, 1140E, 1150E, 1165E, 2050V3, 1110, 1210, 1220, 1230
- a Web interface for Unicode Name Directory server configuration

Unicode Name Directory integrates with Personal Directory (PD) is part of the Personal Directory installation. The Unicode Name Directory is enabled in the Call Server only if Personal Directory is configured. For more information about configuring Unicode Name Directory, see *Element Manager System Reference—Administration*, *NN43001-632*.

Personal Directory and Unicode Name Directory can be installed as a part of Local software deployment or Centralized software deployment. For more information about deployment options, see *Linux Platform Base and Applications Installation and Commissioning, NN43001-315.* 

# Unicode Name Directory feature restrictions and limitations

The following is a list of restrictions and limitations that apply to the UND feature.

- UND is not supported by SIP terminals that support Unicode.
- UND inherits all limitations of CPND and Preferred Name Match features.
- Manual intervention is required to migrate from Release 5.5 where the patched solution exists: backup and export the Release 5.5 PD database and UND database XML files. Convert XML file into CSV file. Restore and import the Release 5.5 PD database and UND database CSV files into the latest Release. Refer to Subscriber Manager Fundamentals, NN43001-120.
- UND is limited only for those user names and phone numbers which are propagated from Subscriber Manager to Unicode Name Directory database.
- Unicode name will not be displayed during a trunk call if the trunk side does not provide reliable Caller Line ID (CLID) and correct type of the call.
- Only characters supported by the IP Phone (including phone firmware and font files) can be
  used to display the name. If a system administrator enters for localized name Unicode
  characters not supported by the IP Phone, user name will be displayed incorrectly during the
  call.

- Cannot display Japanese, Chinese and Korean characters simultaneously. Avaya 1110 IP Deskphone, Avaya 1120E IP Deskphone and IP Phone 12x0 can store only one downloadable font in the firmware. Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, Avaya 1165E IP Deskphone, and Avaya 2007 IP Deskphone can store four fonts simultaneously.
- The Primary and alternate redundancy model is not supported for the Unicode Name Directory application.
- Unicode Name Directory application as a part of PD cannot serve multiple telephone nodes located on different Call Servers.
- Only half-width Japanese Katakana font is supported for name displaying.
- Phone numbers entered in Subscriber Manager for a specific subscriber as 'external' should be unique. UND feature does not guarantee correct user name displaying in case the 'external' number is not unique.
- Signaling Server should have certificates signed by Primary Security server to establish secure LDAP connection with Subscriber Manager.
- UND service applies only to the primary Call Server system which provides calls under normal mode. When the Call Server system switches over to redundant systems (such as Geographic Redundant Call Server system and Branch Office Call Server system), UND service is not available.

# **IP Phones configuration**

The following configuration of IP Phones must be in place before Unicode Name Directory can be properly used.

- CPND block configuration. To properly display names on an IP Phone, CPND block must be configured on the Call Server for each customer using UND.
- Class-of-Service configuration. The CNDA and DNDA classes of service must be enabled for each IP Phone that will use Unicode Name Directory.
- Language selection. For those IP Phones that support Unicode Name Directory, select the language through the Telephone Options, Language menu.



IP Phones that support Unicode require a special font file to display Asian languages. Download the font file to the IP Phone using TFTP server. For more information, see the installation guide for the specific IP Phone.

# **Chapter 7: Codecs**

### **Contents**

This section contains the following topics:

- Introduction on page 171
- Codec configuration on page 173
- Codec registration on page 174
- Codec negotiation on page 177
- Codec selection on page 179

### Introduction

Codecs refers to the voice coding and compression algorithms used by the Digital Signal Processors (DSPs) on a Media Card. Codecs provide levels of audio quality and compression rates. IP Phones and Media Cards support different codecs. The codecs, and the order in which they are used, are configured on the LTPS and on the Avaya Communication Server 1000 (Avaya CS 1000) system. The Avaya CS 1000 system selects the appropriate codecs based on user-configurable parameters.

For instance, configure an IP Phone-to-IP Phone call in the same zone within a LAN using G.711 at 64 kb/s. Configure an IP Phone-to-IP Phone call over a WAN using G.729A or G.729AB at 8 kb/s. These data rates are for voice streams only. Packet overhead is not included.

### Predefined codec table

The Line Terminal Proxy Server (LTPS) and the Voice Gateway Channel Server on a Media Card have a predefined table of codec option sets that can be supported.

The first entry in the table has the highest quality audio (BQ = Best Quality) and requires the largest amount of bandwidth. The last entry requires the least amount of bandwidth (BB = Best Bandwidth) with lower voice quality.

When the Call Server sets up a Call Server connection between an IP Phone-to-IP Phone, the predefined table determines which codec it selects for that connection. This information is provided to the system as part of the IP Phone registration sequence.

For more information about the registration sequence, see Converging the Data Network with VoIP Fundamentals, NN43001-260.

### Codec selection

The systems use this information to set up a speech path and to select a codec that both endpoints support. As part of zone management, the system further selects the codec based on whether it tries to optimize quality (BQ) or bandwidth usage (BB).

### Caution:

When voice compression codecs are used, voice quality is impaired if end-to-end calls include multiple compressions.

Table 53: Supported codecs on page 172 shows which codecs the CS 1000 system supports.

### **Important:**

The G.723.1 codec has bit rates of 5.3 kb/s and 6.3 kb/s. The G.723.1 codec can only be configured with a 5.3 kb/s bit rate; however, the system accepts both G.723.1 5.3 kb/s and 6.3 kb/s from the far end.

### Important:

T.38 is the preferred codec type for fax calls over virtual trunks. However, the G.711 Clear Channel codec is used if the far end does not support the T.38 codec.

Table 53: Supported codecs

Codec	Payload size
G.711 a-law, G.711 mu-law, NOVAD	10, 20, and 30 ms
G.711 Clear Channel	Supported for fax calls on gateway channels
G.722	10 ms, 20 ms, 30 ms, and 40 ms
G.723.1	30 ms
G.729A	10, 20, 30, 40, and 50 ms
G.729AB	10, 20, 30, 40, and 50 ms
T.38	Supported for fax calls on gateway channels

The MVC 2050 supports only the G.711 codec with a 30-ms payload.

The G.722 codec is only supported on the following IP Phones with UNIStim 5.0 firmware:

- Avaya 1120 IP Deskphone
- Avaya 1140 IP Deskphone
- Avaya 1165 IP Deskphone
- Avaya 1220 IP Deskphone
- Avaya 1230 IP Deskphone

If multiple nodes are on a system and the same codec is selected on more than one node, ensure that each node has the same voice payload size configured for the codec.

# **Codec configuration**

Configure the codec in the DSP Profile section of Element Manager.

### **Codec selection in Element Manager**

<u>Figure 41: Codec list in Element Manager</u> on page 173 shows the list of codec types that appear in Element Manager.

Node ID: 6060 - Voice Gateway (VGW) and Codecs




Figure 41: Codec list in Element Manager

You cannot clear the automatically selected G.711 and T.38 Fax codecs. Even though you cannot clear these codecs, you can change the payload size and the jitter buffer for G.711. For G.711 Clear Channel, only the jitter buffer can be changed.

Select any desired, or none of the G.722, G.723.1, and G.729A codecs. If the G.729A or G.722 codec is selected, the payload size and the jitter buffer settings can be changed. If the G.723.1 codec is selected, only the jitter buffer can be changed, as the only supported payload size is 30 ms.

For codec configuration in Element Manager, see <u>Configure Voice Gateway Profile data</u> on page 238.

# **Codec registration**

After you configure the codecs, the IP Phones and DSPs must register the configured codecs with the Call Server.

### **Codec registration for IP Phones**

The IP Deskphones always register both the G.711 a-law and mu-law codecs, and all user-configured codec. The codecs that the user can configure are G.729A, G.729AB, and G.723.1.

The minimum number of codecs registered for an IP Deskphones is two: G.711 a-law and G.711 mu-law (G.711 is always configured).

The maximum number of codecs registered for an IP Deskphones is six: G.711 a-law, G.711 mulaw, G.722, G.723.1, G729A, and G729AB.

### Important:

IP Deskphones do not register the fax codecs (T.38 and G.711 Clear Channel).

Only certain IP Deskphones with UNIStim 5.0 firmware support the G.722 codec. If the IP Deskphone supports the G.722 codec, the codec appears in the list of codecs available for the user to configure.

### Example 1

A user configures a G.711 mu-law codec (with a 30-ms payload) and a G.723.1 codec (with a 30-ms payload).

The following three codecs are actually registered:

- G.711 mu-law (30 ms)
- G.711 a-law (30 ms)
- G.723.1 (30 ms)

### Example 2

A user configures four codecs:

- G.711 a-law codec with a 10 ms payload
- G.729A codec with 50 ms payload
- G.729AB codec with 30 ms payload
- G.723.1 codec with a 30 ms payload

The following five codecs are actually registered:

- G.711 a-law (10 ms)
- G.711 mu-law (10 ms)
- G.729A (50 ms)
- G.729AB (30 ms)
- G.723.1 (30 ms)

# **Codec registration for DSPs**

DSPs register the following codecs:

- Both G.711 a-law and G.711 mu-law codecs are always registered.
- Both fax codecs (T.38 and G.711 Clear Channel) are always registered.
- One best bandwidth (BB) codec, if at least one of G.729A, G.729AB, or G.723.1 codecs is configured. The BB codec is based on the codec type. The order of preference for choosing the BB codec is G.729AB, G.729A, and then G.723.1.

### Important:

When G.723.1 codec is configured on the Media Card 32-port cards, the number of channels is reduced to 24. This is a limitation of the DSP software. The unused channels are not registered; therefore, the Call Server software does not access them.

### **Minimum Codecs**

The minimum number of codecs registered for DSPs is four:

- G.711 a-law
- G.711 mu-law
- T.38
- · G.711 Clear Channel

### **Maximum Codecs**

The maximum number of codecs registered for DSPs is six:

- G.711 a-law
- G.711 mu-law
- T.38
- G.711 Clear Channel
- one of G.729AB and/or G.729A, or G.723.1

### Example 1

A user configures four codecs:

- · G.711 a-law codec with a 10 ms payload
- G.729A codec with 50 ms payload
- · G.729AB codec with 30 ms payload
- G.723.1 codec with a 30 ms payload

The following six codecs are registered:

- G.711 a-law (10 ms)
- G.711 mu-law (10 ms)
- G.729AB (30 ms)

- G.729A (50 ms)
- T.38
- G.711 Clear Channel

The G.729AB codec is selected, as it is the first in the order of preference of the BB codecs. The G. 723.1 codec does not get registered.

### Example 2

A user configures three codecs:

- G.711 mu-law codec with a 20 ms payload
- · G.729A codec with 30 ms payload
- G.723.1 codec with a 30 ms payload

The following five codecs are actually registered:

- G.711 mu-law (20 ms)
- G.711 a-law (20 ms)
- G.729A (30 ms)
- T.38
- G.711 Clear Channel

The G.729A codec is selected, as it precedes the G.723.1 codec in the order of preference of the best bandwidth codecs.

# Voice Gateway codec registration

The Voice Gateway registers codecs for the gateway channels as follows:

- G.711 a-law and G.711 mu-law are always registered.
- T.38 and G.711 Clear Channel fax codecs are always registered. G.711 Clear Channel is used for IP Trunk connections to Avaya Business Communications Manager (Avaya BCM), which does not support T.38 fax.
- A minimum of two codecs are registered if only G.711 is configured.
- A maximum of four codecs can be registered: the G.711 a-law and mu-law for BQ codec, and some BB codecs (defined by the following rules).
  - If the G.729A codec is configured, only the G.729A codec is registered with the Call Server.
  - If the G.729AB codec is configured, the G.729A codec and the G.729AB codec are registered with the Call Server.
  - If the G.723 codec is configured, the G.723 codec is registered with the Call Server.

### Example 1

G.711 a-law, G.729A, G.729AB, and G.723.1 are configured. The Voice Gateway registers G.711 a-law, G.711 mu-law, G.729A, and G.729AB.

### Example 2

G.711 mu-law, G.729A, and G.723.1 are configured. The Voice Gateway registers G.711 alaw, G. 711 mu-law, and G.729A.

### Example 3

G.711 mu-law and G.723.1 are configured. The Voice Gateway registers G.711 a-law, G.711 mu-law, and G.723.1.

# **Codec negotiation**

Codec refers to the voice coding and compression algorithm used by DSPs. Each codec has different QoS and compression properties. For every virtual trunk call, a common codec must be selected for the call. This is known as codec negotiation.

IP Peer Networking supports the per-call selection of codec standards, based on the type of call (interzone or intrazone). The codec preference sequence sent over SIP or H.323.

For more information about interzone and intrazone, see *Converging the Data Network with VoIP Fundamentals*, *NN43001-260*.

# **Codec sorting**

The codec preference sequence sent over SIP or H.323 depends on the bandwidth policy selected for the Virtual Trunk zone and the involved IP Phones. For Best Quality, the list is sorted from best to worst voice quality. For Best Bandwidth, the list is sorted from best to worst bandwidth usage.

# **Codec sorting methods**

Two methods are available to sort the codec list:

- BQ sorting: the codec list is sorted so that the first codec in the list is the best BQ codec, the second codec is the second best BQ codec in the list, and so on.
- BB sorting: the codec list is sorted so that the first codec in the list is the best BB codec, the second codec is the second best BB codec in the list, and so on.

Table 54: BQ and BB codec sorting lists on page 177 shows the codec list sorting order for the BQ and BB codecs. To know if a codec is BQ (as compared to another codec), see the lists in columns 1 and 2. To determine if a codec is BB (as compared to another codec), see the lists in columns 3 and 4. The BQ or BB codec is listed at the top of the column.

Table 54: BQ and BB codec sorting lists

Best Quality (BQ) sorting		Best Bandwidth (BB) sorting	
For mu-law systems	For a-law systems	For mu-law systems For a-law system	
G.722_64_10 ms	G.722_64_10 ms	G.729AB_50 ms	G.729AB_50 ms

Best Quality (BQ) sorting		Best Bandwidth (BB) sorting	
For mu-law systems	For mu-law systems For a-law systems		For a-law systems
G.722_64_20 ms	G.722_64_20 ms	G.729AB_40 ms	G.729AB_40 ms
G.722_64_30 ms	G.722_64_30 ms	G.729AB_30 ms	G.729AB_30 ms
G.722_64_40 ms	G.722_64_40 ms	G.729AB_20 ms	G.729AB_20 ms
G.722_56_10 ms	G.722_56_10 ms	G.729AB_10 ms	G.729AB_10 ms
G.722_56_20 ms	G.722_56_20 ms	G.729A_50 ms	G.729A_50 ms
G.722_56_30 ms	G.722_56_30 ms	G.729A_40 ms	G.729A_40 ms
G.722_56_40 ms	G.722_56_40 ms	G.729A_30 ms	G.729A_30 ms
G.711_mu_law_10 ms	G.711_a_law_10 ms	G.729A_20 ms	G.729A_20 ms
G.711_mu_law_20 ms	G.711_a_law_20 ms	G.729A_10 ms	G.729A_10 ms
G.711_mu_law_30 ms	G.711_a_law_30 ms	G.723.1_5.3 kb/s_30 ms	G.723.1_5.3 kb/s_30
G.711_a_law_10 ms	G.711_mu_law_10 ms	G.723.1_6.4 kb/s_30 ms	ms
G.711_a_law_20 ms	G.711_mu_law_20 ms	G.722_64_40 ms	G.723.1_6.4 kb/s_30 ms
G.711_a_law_30 ms	G.711_mu_law_30 ms	G.722_64_30 ms	G.722_64_40 ms
G.722_48_10 ms	G.722_48_10 ms	G.722_64_20 ms	G.722_64_30 ms
G.722_48_20 ms	G.722_48_20 ms	G.722_64_10 ms	G.722_64_20 ms
G.722_48_30 ms	G.722_48_30 ms	G.722_56_40 ms	G.722_64_10 ms
G.722_48_40 ms	G.722_48_40 ms	G.722_56_30 ms	G.722_56_40 ms
G.729A_10 ms	G.729A_10 ms	G.722_56_20 ms	G.722_56_30 ms
G.729A_20 ms	G.729A_20 ms	G.722_56_10 ms	G.722_56_20 ms
G.729A_30 ms	G.729A_30 ms	G.722_48_40 ms	G.722_56_10 ms
G.729A_40 ms	G.729A_40 ms	G.722_48_30 ms	G.722_48_40 ms
G.729A_50 ms	G.729A_50 ms	G.722_48_20 ms	G.722 48 30 ms
G.729AB_10 ms	G.729AB_10 ms	G.722_48_10 ms	G.722_48_20 ms
G.729AB_20 ms	G.729AB_20 ms	G.711_mu_law_30 ms	G.722_48_10 ms
G.729AB_30 ms	G.729AB_30 ms	G.711_mu_law_20 ms	G.711_a_law_30 ms
G.729AB_40 ms	G.729AB_40 ms	G.711_mu_law_10 ms	G.711_a_law_20 ms
G.729AB_50 ms	G.729AB_50 ms	G.711_a_law_30 ms	G.711 a law 10 ms
G.723.1_5.3 kb/s_30 ms	G.723.1_5.3 kb/s_30 ms	G.711_a_law_20 ms	G.711 mu law 30
G.723.1_6.4 kb/s_30ms	G.723.1_6.4 kb/s_30 ms	G.711_a_law_10 ms	ms
T.38	T.38	T.38	G.711_mu_law_20
G.711CC	G.711CC	G.711CC	ms
			G.711_mu_law_10 ms

Best Quality (BQ) sorting		Best Bandwidth (BB) sorting	
For mu-law systems For a-law systems		For mu-law systems	For a-law systems
			T.38
			G.711CC

### **Codec selection**

For every Virtual Trunk call, a codec must be selected before the media path can be opened. When a call is setup or modified (that is, media redirection), one of two processes occurs:

- The terminating node selects a common codec and sends the selected codec to the originating node.
- The codec selection occurs on both nodes.

Each node has two codec lists: its own list and the far end list. To select the same codec on both nodes, it is essential to use the same codec selection algorithm on both nodes. The following conditions are met before codec selection occurs:

- Each codec list contains more than one payload size for a given codec type (depending on the codec configuration).
- Each codec list is sorted by order of preference (the first codec in the near end list is the near end most preferred codec, the first codec in the far end list is the far end preferred codec).

# **Codec selection algorithm**

When the codec lists meet the above conditions, one of the following codec selection algorithms selects the codec to be used:

- H.323 Master/Slave algorithm
- SIP Offer/Answer model
- Best Bandwidth codec selection algorithm

### H.323 Master/Slave algorithm

The H.323 Master/Slave algorithm operates in the following manner:

The Master node uses its codec list as the preferred list and finds a common codec in the far
end's list. For example, the Master finds the first codec in its list (for example, C1), checks the
list at the far end and if the codec matches the Master (also C1) than that is the selected
codec. Otherwise, it finds the second codec in its list and verifies it against the far end. The
process continues until a common codec is found between the Master and far end.

 The Slave node uses the far end's list as the preferred list and finds in its own list the common codec.

### SIP Offer/Answer model

The SIP codec negotiation is based on the Offer/Answer model with Session Description Protocol (SDP).

The following three cases of codec negotiation are supported:

- The calling user agent sends an SDP offer with its codec list in the invite message with a sendrecv attribute. In this case, the called user agent selects one codec and sends the selected codec in an SDP answer. The SDP answer is included in the 200 OK message (response to the INVITE) with the sendrecv attribute as the preferred method of operation.
- The calling user agent sends an SDP offer with its codec list in the invite message with a sendrecv attribute. The called user agent returns more than one codec in the SDP answer. In this case, that many codecs are included in the response, the calling user agent picks the first compatible codec from the called user agent list, and sends a new SDP offer with a single codec to lock it in.
- If the SDP of the calling user agent is not present in the INVITE message, then the called user agent sends its codec list in an SDP offer in the 200 OK message, with the sendrecv attribute. The calling user agent selects one codec and sends it in an SDP answer inside the ACK message, with a sendrecv attribute.

# **Best Bandwidth Codec Selection algorithm**

The Best Bandwidth codec selection algorithm solves the issues caused by the H.323 Master/Slave algorithm. The Best Bandwidth algorithm selects one common codec based on two codec lists. Every time the selection is done with the same two lists, the selected codec matches. The Best Bandwidth codec decision is based on the codec type only. It does not consider the fact that some codecs, while generally using less bandwidth, can consume more bandwidth than others at certain payload sizes.

Best Bandwidth also applies to SIP.

<u>Table 55: Best Bandwidth codec Selection between any two codecs types</u> on page 181 shows the codec that would be selected between any two codecs. For example, if the two codecs are the G. 729A and G.723.1, the selected codec is the G.729A.

Table 55: Best Bandwidth codec Selection between any two codecs types

Codec type	G.711_a-Law	G.711_mu- Law	G.722	G.729A	G.729AB	G.723.1
G.711_a-Law	G.711_a-Law	G.711_muLaw	G.722	G.729A	G.729AB	G.723.1
G.711_mu-Law	G.711_mu-Law	G.711_mu-Law	G.722	G.729A	G.729AB	G.723.1
G.722	G.722	G.722	G.722	G.729A	G.729AB	G.723.1
G.723.1	G.723.1	G.723.1	G.723.1	G.729A	G.729AB	G.723.1
G.729A	G.729A	G.729A	G.729A	G.729A	G.729AB	G.729A
G.729AB	G.729AB	G.729AB	G.729AB	G. 729AB	G.729AB	G.729AB

For more information about codec selection and negotiation, see *Converging the Data Network with VoIP Fundamentals, NN43001-260*.

# **Chapter 8: Installation task flow**

#### **Contents**

This section contains the following topics:

- Introduction on page 182
- Before you begin on page 182
- Installation summary on page 182
- Table 56: IP Phone configuration data summary sheet on page 184

#### Introduction

Use the task flow information in this chapter to determine the proper steps for the installation or upgrade of the IP Line applications.

Read Codecs on page 171 before you install an IP Telephony node.

# Before you begin

Ensure that the Avaya Communication Server 1000 (Avaya CS 1000) system runs the latest Avaya CS 1000 software Release.

# **Installation summary**

Use the following summary of steps as a reference guide to install and configure an IP Telephony node. This summary is intended to serve as a pointer to the more detailed procedures in later chapters and to provide a sequential flow to the steps in the overall installation procedure.

#### Preinstallation and configuration steps

1. Complete the IP Phone configuration data summary sheet. See <u>Table 56: IP Phone configuration data summary sheet</u> on page 184.

- 2. Install the hardware components:
  - a. Install the Voice Gateway Media Card. See <u>Installing the Media Card</u> on page 208 for installing the Media Card 32-port cards.
  - b. Cable the Voice Gateway Media Cards:
    - a. Install the Shielded 50-pin to Serial/ELAN/TLAN Adapter for the Media Card 32-port cards. See <u>Installing the Shielded 50-pin to Serial/ELAN/TLAN Adapter onto the Media Card</u> on page 211.
- 3. Configure IP Line data on the system:
  - a. Configure the IP address for the ELAN network interface. See <u>Configuring the ELAN network interface IP address for the active ELNK</u> on page 212.
  - b. Configure VoIP bandwidth management zones. See <u>Configure VoIP bandwidth</u> <u>management zones (LD 117)</u> on page 212.
  - c. Configure IP Line physical TNs.
  - d. Configure virtual superloops. See <u>Configure virtual superloops for IP Phones</u> on page 215.
  - e. Configure IP Phone features. See Configure IP Phone features in LD 11 on page 216.
- 4. Configure IP Line data using Element Manager:
  - a. Manually add an IP Telephony node. See <u>Manually add an IP Telephony node</u> on page 228.
  - b. Configure SNMP traps and community strings access for security. See <u>Configuring</u> SNMP trap destinations and community strings on page 237.
  - c. Configure DiffServ CodePoint (DSCP) data, 802.1Q support, and NAT support. See Configure Quality of Service on page 241.
  - d. Configure file server access. See Configure file server access on page 243.
  - e. Configure the loss plan. See Configure loss and level plan on page 244.
  - f. Configure Voice Gateway Media Card properties. See <u>Add card and configure the card properties of the Voice Gateway Media Card</u> on page 244.
- 5. Transmit Voice Gateway Media Card configuration data to the Voice Gateway Media Cards:
  - a. Transmit node and card properties to the Leader. See <u>Transmitting node properties to Leader</u> on page 247.
- 6. Upgrade the card software and IP Phone firmware:
  - a. Verify card software version. See <u>Determine Voice Gateway Media Card software version</u> on page 249.
  - b. Verify the IP Phone firmware release.
  - c. Download software and firmware files from the Avaya Web site. See <u>Download the</u> current loadware and IP Phone firmware on page 250
  - d. Upload the software and firmware files to the file server. See <u>Upload the loadware and firmware files to the Signaling Server</u> on page 250.
  - e. Upgrade the software on the Voice Gateway Media Card. See <u>Upgrade the Voice Gateway Media Card loadware</u> on page 251.

- f. Restart the card. See Restart the Voice Gateway Media Card on page 252.
- g. Upgrade the IP Phone firmware on the card. See Upgrade the IP Phone firmware on page 253.
- 7. Assemble and install an IP Phone. See IP Phones Fundamentals, NN43001-368.
- 8. Configure the IP Phone Installer Passwords (see IP Phone Installer Password on page 267).
  - a. Enable and configure the administrative IP Phone Installer Password. See Configuring the Administrative IP Phone Installer Password on page 272.
  - b. If needed, enable and configure a temporary IP Phone Installer Password. See Configuring the temporary IP Phone Installer Password on page 274.

Avaya recommends that you complete an IP Phone configuration data summary sheet as you install and configure IP Phones.

Table 56: IP Phone configuration data summary sheet

No DHCP								
			DHCP					
IP address	Sub- net mask	Gateway IP address	Connect Server IP address*	Node ID	VTN	DN	User Name	User Location
			_					<u>-</u>
*Connect Server IP address is the Node IP address of the IP Telephony node								

# Chapter 9: Signaling Server software installation using Deployment Manager

You must install Signaling Server software using Deployment Manager. For information about installing the Signaling Server software using Deployment Manager, see *Linux Platform Base and Applications Installation and Commissioning, NN43001-315.* 

### **Contents**

This chapter contains the following information:

- Introduction on page 185
- <u>Software Deployment Packages</u> on page 187
- Pre-installation checklist on page 187
- Linux Base installation on page 187
- Signaling Server application installation on page 188
- Access UCM on page 189
- Element Manager configuration on page 190

## Introduction

This chapter explains how to deploy Signaling Server software and supported applications on the Avaya CS 1000 system.

When you install the Linux base platform, you deploy the Signaling Server software, which you can access through the Unified Communications Management (UCM) console. For more information about the Linux platform base install, see *Linux Platform Base and Applications Installation and Commissioning, NN43001-315.* 

#### **Installation Task Flow**

This section provides a high-level task flow to install CS 1000 Release 7.6.

CS 1000 Network Start Back up databases Establish UCM Deployment Server and Primary Security Server NN43001-315 Build software library and provide keycodes NN43001-315 Define pre-deployment strategy and commit NN43001-315 Signaling Server Deploy applications to servers with bootable Linux media or patched release 6.0 Start Back up databases Servers Linux Server Install Linux Base bootable VxWorks Call Server media on server **Network Services** NN43001-315 **IM Presence** Define pre-deployment MAS strategy and commit to NRS Signaling Server Subscriber Manager NN43001-315 CS 1000 Systems Deploy to server with bootable Linux media or patched CS 1000 release 6.0 CS 1000 HS NN43001-315 Signaling Server Configure Signaling Server NN43001-315 NN43001-125 Manage Security Associate Element Manager\* NN43001-604 to Call Server End NN43001-632 End

Figure 42: Linux base and applications installation task flow

# **Software Deployment Packages**

Install Avaya applications using Deployment Manager.

You can deploy the Signaling Server software from one of the following predefined deployment packages:

- Signaling Server (SS)
- Signaling Server and Network Routing Service
- Call Server (CS) and Signaling Server (basic stand-alone Co-resident system. For more information about the Co-resident system, see Co-resident Call Server and Signaling Server Fundamentals, NN43001-509.

After you deploy the Signaling Server software, configure the software applications through Element Manager. The CS 1000 software applications include: LTPS, Vtrk (SIPgw and H.323GW), Personal Directory (PD). Voice Gateway Media Card loadware is also included as part of the Signaling Server software.

#### Pre-installation checklist

The Co-resident CS and Signaling Server requires a server hardware platform with a 40 GB hard drive. For memory requirements, see the Signaling Server memory requirements as described in Overview on page 194. For more information, see Communication Server 1000E Planning and Engineering, NN34041-220.

The CP PM card BIOS must be Release 18 or later. You must determine the server BIOS version. and upgrade the BIOS if necessary. For more information, see Co-resident Call Server and Signaling Server Fundamentals, NN43001-509.

For more information about BIOS versions for COTS platforms, see Linux Platform Base and Applications Installation and Commissioning, NN43001-315.

# **Linux Base installation**



#### Note:

You must install the Linux base platform before you complete the procedures described in this section.

Perform the Linux Base installation from the command line interface (CLI) using a bootable Removable Media Device (RMD). The bootable RMD can be a Compact Flash (CF) card, USB 2.0 storage device, or a DVD, depending on your hardware platform. Configure the ELAN, TLAN IP address, gateway, subnet masks, and date and time settings during the Linux Base installation. A DVD install is available for COTS platforms.

For more information about the Linux Base installation, see Linux Platform Base and Applications Installation and Commissioning, NN43001-315.



#### Note:

After you complete the Linux base installation, you must configure the server as a primary, backup or member server in the UCM security framework. This configuration is completed using the default Avaya userID and password when logging on TO UCM to perform the security configuration. For more information, see Linux Platform Base and Applications Installation and Commissioning, NN43001-315.

# Signaling Server application installation

Use the Deployment Manager to install the Signaling Server application on the servers.

The Deployment Manager installs the Call Server, Signaling Server, and System Management applications as Linux Red Hat Package Manager (RPM) packages.

Deployment Manager access occurs through the Web-based CS 1000 UCM navigator.

The Deployment Manager can operate in two modes;

Centralized Deployment Manager (Remote):

The Deployment Manager runs on the UCM Primary Security Server. You must start the UCM navigator and log on to the UCM Primary Security Server. In this model, the Centralized Deployment Manager deploys application software to the target servers in the UCM security domain.

Local Deployment Manager:

The Deployment Manager runs on the target server. Accessing the Deployment Manager is similar to the Centralized Deployment option except you must log on to the local target server by using the default user ID and password. This mode is typically used when you want to install software on the target server before you configure it to join the UCM security framework.

In both Centralized and Local modes, the application software Application Image (NAI) on the software delivery media is uploaded from the client workstation to the server where Deployment Manager runs:

- For the Centralized Deployment Manager, the application software image is transferred to the hard disk of the UCM primary security server.
- For the Local Deployment Manager, the application software image is transferred to the hard disk on the target server.



For the Centralized Deployment Manager, you need to upload the application software only once. You can then deploy the software image to multiple target servers in the UCM security domain.

The Deployment Manager supports new installation and upgrades. Both processes are similar but contain the following differences:

- For the upgrade, you cannot remove or add any new type of application on the Co-res CS and SS; you must use the existing package configuration. You can upgrade only the existing applications to newer versions.
- For the upgrade, existing data is backed up and restored when you install the new version of the application software.

#### Note:

If you change the package configuration, you must manually back up data on the target by using the sysbackup command before you use the Deployment Manager to install a new package configuration on the Co-res CS and Signaling Server.

For detailed information, see *Linux Platform Base and Applications Installation and Commissioning,* NN43001-315.

#### Note:

The Signaling Servers in a network are configured as Master and Slave by providing the Node IP through Element Manager with the Node IP attached to the Network Interface. When the Master server is down, the Slave server automatically acts as Master and uses the existing Node IP to operate.

The Signaling Server is configured with IPv6 SIP Proxy address. The SIP GW registers to the SIP Proxy Server (SPS) through IPv4 or IPv6 interface depending on the IP version supported by SPS. The SIP GW registers both IPv4 and IPv6 addresses as its contact addresses, if SPS supports dual stack. If SPS supports IPv4 only, the SIP GW registers IPv4 address as its contact address.

#### **Access UCM**

Centralized Deployment Manager allows software application deployment from the primary security server to other Linux servers in the same security domain. The primary security server is the central repository for the software application load and deployment occurs remotely, which eliminates the need to log on to each target server. For more information, see *Linux Platform Base and Applications Installation and Commissioning*. *NN43001-315* 

You must access UCM to deploy software through the Deployment Manager.

#### **Deploying Signaling Server software to a server**

- 1. Log on to the UCM Deployment Manager.
- 2. Select the **Software Deployment** link.

The Target Deployment window appears.



Figure 43: Target Deployment window

- 3. Select a host name from the list, and click **Deploy**.
- 4. Select the check boxes for the software applications that you want to deploy to the server: EM, NRS, NRS+SS, SIPL, SS.

When you select a check box, other check boxes might then be unavailable if the selected software cannot co-reside with the unavailable software.

5. Click **Deploy**.

After you deploy the Signaling Server software, configure the VTRK (SIPgw and H.323gw) components. These features can be configured as part of IP Telephony node configuration. For more information, see <a href="Manually add an IP Telephony node">Manually add an IP Telephony node</a> on page 228.

IP Telephony nodes are configured through Element Manager. Ensure that Element Manager is deployed and configured. For more information, see *Linux Platform Base and Applications Installation and Commissioning*, NN43001-315.

# **Element Manager configuration**

The following sections provide information to set up the Web browser.

## **System requirements for Element Manager**

For information about supported browsers and logging on to Element Manager see *Unified Communication Management Fundamentals*, NN43001-116.

The Element Manager Virtual Terminal Environment requires the Java Runtime Environment (JRE).

## Configuring the Internet Explorer browser

Before you can use Element Manager, you must complete the following tasks:

- Enable pop-ups in the browsers search utility (mandatory)
- Configure the Internet Explorer browser settings (mandatory)
- Configure the Windows Display settings (highly recommended)

#### Important:

Avaya discourages using the browser Back, Forward, and Refresh buttons.

Element Manager pages contain dynamic data content. Avaya does not recommend that you use the Back button. Element Manager provides a navigation path on the top of every page.

Avaya recommends that you use the navigation path to go to the previous page.

#### Note:

The interface for the Internet Explorer browser settings and Windows Display settings can vary by browser version and by operating system.

If you use a browser search utility (such as the Google search engine or the Yahoo! search engine), ensure that pop-ups are enabled. Typically, you enable pop-up windows from the toolbar of the search utility.

#### Important:

Do not block pop-ups if you use a search utility (such as Google or Yahoo!) in your browser.

Use the following procedure to configure the following Internet Explorer browser settings.

- · Turn off Internet Explorer caching.
  - Internet Explorer caching interferes with the Element Manager, so you cannot see real-time changes as they occur.
- · Configure empty session information.
- Clear the AutoComplete options.

#### Configure the Internet Explorer browser settings

- 1. Click **View > Text Size > Medium** to configure the text size in the browser.
- 2. Click **Tools** > ,**Internet Options** on the Internet Explorer browser window.

The system displays the Internet Options window.

- 3. Turn off Internet Explorer caching:
  - a. On the General tab under the Temporary Internet files section, click Settings.
     The Settings window appears.
  - b. Under the **Check for newer versions of stored pages** section, select **Every visit to the page**.
  - c. Click OK.

- 4. Configure empty session information:
  - a. Select the **Advanced** tab.

The Advanced Settings window appears.

- b. Under Security, select Empty Temporary Internet Files folder when browser is closed.
- 5. Clear the AutoComplete options.
  - a. Select the Content tab.
  - b. Under Personal Information, click AutoComplete.

The AutoComplete Settings window appears.

- c. Under the **Use AutoComplete for** section, clear **Forms** and **User names and** passwords on forms.
- 6. (Optional) Configure the Windows display settings.
  - a. Select Start, Settings, Control Panel, Display.

The Display Settings window appears.

- b. Select the **Settings** tab.
- c. Select True Color (32 bit) from the Colors list.
- d. Under Screen area, select 1280 by 1024 pixels.
- e. Click OK.

#### **Configuring the Mozilla Firefox browser**

1. On the Mozilla Firefox browser, click **Tools** > **Internet Options**.

The system displays the Internet Options window.

- 2. Enable pop-ups:
  - a. Click the Content tab.
  - b. Clear the **Block pop-up windows** check box.
- 3. Configure the empty session information and the AutoComplete option:
  - a. Click the **Privacy** tab.

The system displays the Options window.

- b. In the History section, click Use custom settings for history in the Firefox will field.
- c. Clear the Remember search and form history check box.
- d. Select the **Clear history when Firefox closes** check box.
- e. Click OK.

The system closes the Options window.

# Chapter 10: Signaling Server Software upgrade

Avaya Communication Server 1000 (Avaya CS 1000) Signaling Server software requires a Linux platform and is updated using Deployment Manager. For information about upgrading the Signaling Server software using Deployment Manager, see *Linux Platform Base and Applications Installation and Commissioning*, NN43001-315.

#### **Contents**

This chapter contains the following information:

- Introduction on page 193
- Overview on page 194
- Before starting your upgrade on page 194
- Upgrade paths on page 195
- <u>Upgrade procedures</u> on page 197

## Introduction

This chapter contains instructions to upgrade the software on your existing Signaling Server. Support is available to upgrade from Succession 1000 Release 3.0, CS 1000 Release 4.0, Communication Server 1000 Release 4.5, Communication Server 1000 Release 5.0, CS 1000 Release 5.0, CS 1000 Release 7.0, and CS 1000 Release 7.5.

All Signaling Servers are subject to software upgrades in CS 1000 Release 7.6. CP PM, IBM X306m, and HP DL320-G4 Signaling Servers cannot run software older than CS 1000 Release 5.0, so are subject to a software upgrade only from CS 1000 Release 5.0.



You can contact Avaya Services to assist you with your upgrade.

## Important:

The Upgrade procedure includes options to copy new IP Phone firmware and Voice Gateway Media Card loadware to the Signaling Server. If you use these options during the upgrade, ensure that you upgrade the firmware and loadware on all connected IP Phones and Voice Gateway Media Cards respectively.

#### **Overview**

In Succession 1000 Release 3.0, only H.323 signaling was supported on the Signaling Server. Session Initiation Protocol (SIP) signaling was introduced on the Signaling Server in CS 1000 Release 4.0. CS 1000 Release 4.0 also introduced Network Routing Service (NRS) functionality on the Signaling Server. When upgrading your Signaling Server from Succession 1000 Release 3.0 to a newer release, conversion of the H.323 signaling infrastructure to an NRS infrastructure is a critical component of the upgrade. For more information on an NRS upgrade, see *Network Routing Service Installation and Commissioning, NN43001-130*.

The following table lists the Signaling Server memory requirements:

Table 57: Signaling Server memory requirements

Signaling Server platform	Memory (RAM)
CP PM	2 GB
CP MG	4 GB
CP DC	4 GB
HP DL320-G4 or IBM x306m	2 GB
Dell R300 or IBM x3350	4 GB
Common Server (HP DL360 G7)	4 GB
Common Server R2 (HP DL360p G8)	4 GB

# Before starting your upgrade

Read through the following important information before getting started with your CS 1000 Release 7.6 upgrade:

- The Signaling Server is out of service during a software upgrade.
- Ensure that you back up all data to a remote device or FTP server.

ISP 1100 servers are not supported in CS 1000 Release 7.6; all saved data must be migrated to a supported hardware platform. For servers, all hard drives must be reformatted before an upgrade to CS 1000 Release 7.6.

 In earlier versions of CS 1000, there might be more than one database. For example, Signaling Server might be installed with IP Line and NRS. Ensure that you back up all databases that exist.

All databases might not be restored to the same platform in CS 1000 Release 7.6. For example, Signaling Server applications and NRS can be deployed to different platforms in Release 7.6.

# Signaling Server software upgrade task flow

To upgrade Signaling Server to CS 1000 Release 7.6, complete the following tasks:

- Back up all databases to a remote device or FTP server. See the procedures in this chapter. For information about the NRS database, see *Network Routing Service Installation and Commissioning, NN43001-130*.
- Deploy the Linux base platform. For more information, see *Linux Platform Base and Applications Installation and Commissioning*, NN43001-315.
- Deploy and configure the Signaling Server package. For more information, see <u>Signaling</u> <u>Server application installation</u> on page 188
- Log on to Unified Communications Manager (UCM). For more information, see <u>Access</u>
   UCM on page 189
- Access Element Manager through UCM to restore your databases.

# **Upgrade paths**

The following upgrade paths are available to upgrade your Signaling Server software:

- from Succession 1000 Release 3.0 to CS 1000 Release 7.6 (see <u>Upgrade from Succession 1000 Release 3.0</u> on page 196)
- from CS 1000 Release 4.0 to CS 1000 Release 7.6 (see <u>Upgrade from CS 1000 Release 4.0</u> on page 196)
- from CS 1000 Release 4.5, 5.0, and 5.5 to CS 1000 Release 7.6 (see <u>Upgrade from</u> Communication Server 1000 Release 4.5, 5.0, and 5.5 on page 196)
- from CS 1000 Release 6.0 to CS 1000 Release 7.6 (see <u>Upgrade from Communication Server 1000 Release 6.0</u> on page 196

# **Upgrade from Succession 1000 Release 3.0**

The following task list contains all tasks necessary to upgrade your Signaling Server software from Succession 3.0 to CS 1000 Release 7.6.

1. Upgrade the Signaling Server software.

For instructions, see <u>Upgrading the Signaling Server software</u> on page 198.

# **Upgrade from CS 1000 Release 4.0**

The following task list contains all of the tasks necessary to upgrade your Signaling Server software from CS 1000 Release 4.0 to CS 1000 Release 7.6.

1. Back up the IP Phone Application Server database (if present).

For instructions, see <u>Backing up the IP Phone Application Server database</u> on page 197

2. Determine if an NRS database is present.

For more information about upgrading the NRS application, see *Network Routing Service Installation and Commissioning*, *NN43001-130*.

Upgrade the Signaling Server software.

For instructions, see Upgrading the Signaling Server software on page 198.

4. Restore the IP Phone Application Server database (if present).

For instructions, see Restoring the IP Phone Application Server database on page 201.

# Upgrade from Communication Server 1000 Release 4.5, 5.0, and 5.5

The following task list contains the tasks necessary to upgrade your Signaling Server software from CS 1000 Release 4.5, 5.0, and 5.5 to CS 1000 Release 7.6.

Perform the instructions to upgrade Signaling Server software (see <u>Upgrading the Signaling Server software</u> on page 198).

# **Upgrade from Communication Server 1000 Release 6.0**

In CS 1000 Release 7.6, you must update the Signaling Server software using Deployment Manager. For information about upgrading the Signaling Server software using Deployment Manager, refer to *Linux Platform Base and Applications Installation and Commissioning, NN43001-315*.

# **Upgrade procedures**

This section contains the procedures that you use during the Signaling Server software upgrade.

- <u>Backing up the IP Phone Application Server database</u> on page 197
- <u>Upgrading the Signaling Server software</u> on page 198
- Synchronize IP Telephony nodes on page 198
- Restoring the IP Phone Application Server database on page 201

#### **Backing up the IP Phone Application Server database**

Perform the following procedure to back up the IP Phone Application Server database.

 In the Element Manager navigator, click Tools > Backup and Restore > Personal Directories.

The **Personal Directories Backup and Restore** window appears.



Figure 44: Personal Directories backup and restore

2. Click Personal Directories Backup.

The **Personal Directories Backup** window appears.




Figure 45: Personal Directories backup

- 3. Enter the data for the Remote backup IP address, Remote backup userid, Remote backup password, Remote backup path, and Remote backup file name fields.
- 4. Click Submit.

#### **Upgrading the Signaling Server software**

Perform the following procedure to upgrade the software on your Signaling Server.

 Log on to the Primary UCM server and select Software Deployment under CS 1000 Services.

The **Deployment View** window appears with the Servers view displayed.

- 2. Click the radio button next to the Linux server to be upgraded.
- 3. From the **Deployment Actions** drop-down menu, select **Backup**.
- 4. Select the backup location and click the **Start Backup** button.

When the backup completes, the status changes to **Successful**.

5. Install Linux Base. When prompted by the Linux installer, provide the backup data.

#### Note:

You can also complete this step using the sysrestore command after Linux is installed.

For information about installing Linux Base, see *Linux Platform Base and Applications Installation and Commissioning, NN43001–315*.

- 6. Click the **Software Loads** hyperlink to confirm the appropriate software has been uploaded to the deployment server and is available for the upgrade.
- 7. Click **Deployment View** on the navigation pane to return to the Deployment View window.
- 8. Select the radio button for the Linux server to upgrade.
- 9. From the **Deployment Actions** drop-down menu, select **System Upgrade**.
- 10. Click **OK**.

#### Synchronize IP Telephony nodes

#### Note:

If there is only one TTY available, you may have to log off from the Call Server CLI before completing this procedure.

Perform the following procedure to synchronize the IP Telephony nodes using Element Manager.

- 1. Log on to UCM using the Primary UCM Server ID and password credentials.
- 2. Log on to Element Manager.
- 3. Select System > IP Network > Nodes: Server, Media Cards.

The IP Telephony Nodes window appears.

#### Managing: 192.168.55.152 Username: admin2

System » IP Network » IP Telephony Nodes

#### IP Telephony Nodes

Click the Node ID to view or edit its properties.




Figure 46: IP Telephony Nodes window

4. Select the link for a Node ID.

The **Node Details** window appears.

5. On the **Node Details** window, ensure the information is correct. Select the various links (TPS, Gateway) to ensure that information is correct.




Figure 47: Node Details window

6. In the **Associated Signaling Servers & Cards** section of the window, select the Signaling Server from the **Select to add** list and click **Make Leader**.




Figure 48: Node Details window - select Leader Signaling Server

7. Click Save.



If you have upgraded to Communication Server 1000 Release 7.x, you must configure the Application Node ID field before saving the node details.

8. Select the follower Signaling Server from the list and click **Add**. Click **Save**.

The **Node Saved** window appears.




Figure 49: Node Saved window

9. Click Transfer Now.

The **Synchronize Configuration Files** window appears.




Figure 50: Synchronize Configuration Files window

10. Select the check boxes for the nodes to synchronize and select **Start Sync**.

The Synchronization Status column displays Synchronized when the synchronization finishes.

11. Click **Restart Applications** to restart the Signaling Server applications.

The LTPS, Gateway (SIP and H.323), and PD applications are now successfully deployed.

#### Restoring the IP Phone Application Server database

Perform the following procedure to restore the IP Phone Application Server database.

1. In the Element Manager navigator, select **Tools > Backup and Restore > Personal Directories**.

The **Personal Directories Backup and Restore** window appears.



Figure 51: Personal Directories backup and restore

2. Click Personal Directories Restore.

The **Personal Directories Restore** window appears.



Figure 52: Personal Directories restore

- 3. From the **Action** list, select **FTP from Remote Site** if you saved the backup on a remote server.
- 4. Enter the data for the Remote backup IP address, Remote backup userid, Remote backup password, Remote backup path, and Remote backup file name fields.
- 5. Click Submit.
- 6. Click OK.
- 7. Select **System**, **IP Networks**, **Maintenance and Reports**. The Node Maintenance and Reports window appears.
- Click Reset.

The **Base Manager** window for the server appears.




Figure 53: Base Manager window

- 9. Select Personal Directory and click Restart.
- 10. Click **OK** to confirm that you want to restart the application.

The status of the Personal Directory restart updates when the restart finishes.

### **!** Important:

The length of time to restore an IP Phone Application Server database depends on the number of records.

# Chapter 11: Installation and initial configuration of an IP Telephony node

#### **Contents**

This section contains the following topics:

- Introduction on page 204
- Equipment considerations on page 205
- Install the hardware components on page 205
- Initial configuration of IP Line data on page 211
- Node election rules on page 226

## Introduction

This chapter explains how to install and initially configure a new IP Telephony nodes, Voice Gateway Media Cards (Media Card line cards), and associated cables.

Before you install an IP Telephony node, see *Converging the Data Network with VoIP Fundamentals, NN43001-260* for information about IP network engineering guidelines.

Before configuring an IP Telephony node, you must:

- Install the server and deploy the Linux platform base. For more information, see *Linux Platform Base and Applications Installation and Commissioning, NN43001-315.*
- Deploy the Signaling Server package. For more information, see <u>Signaling Server software</u> <u>installation using Deployment Manager</u> on page 185.

# Installation and configuration procedures

This chapter contains the following procedures:

Installing the CompactFlash card on the Media Card on page 207

- Installing the Media Card on page 208
- Installing the Shielded 50-pin to Serial/ELAN/TLAN Adapter onto the Media Card on page 211
- Configuring the ELAN network interface IP address for the active ELNK on page 212

# **Equipment considerations**

This section lists the required and optional equipment to install, configure, and maintain the Voice Gateway Media Cards and IP Phones.

## Required equipment

The required equipment includes the following:

- a personnel computer to manage IP Line, with web browser. For information about supported browsers, see *Unified Communication Management Fundamentals, NN43001-116*.
- local TTY or terminal in a switch room (to configure a Leader)
- two shielded CAT 5 Ethernet cables to connect the Voice Gateway Media Card to an external switch (recommended) or hub equipment
- 10/100BaseT network interface (optional autosensing) to support TLAN and 10BaseT ELAN network interface connections
- 10/100BaseT network interface (optional autosensing) in each location where an IP Phone resides
- · serial cables

### **Optional equipment**

The optional equipment includes the following:

- a server configured with Dynamic Host Configuration Protocol (DHCP); for example, a NetID server
- an external modem router to enable a remote dial-up connection to the ELAN subnet for technical support (RM356 modem router is recommended)

# Install the hardware components

For Media Card 32-port card installation instructions, see Installing the Media Card on page 208.

## Voice Gateway Media Card

The Media Card 32-port card and the MC 32S card are known as Voice Gateway Media Cards.

# Summary of installation steps

The following table summarizes the steps to install each Voice Gateway Media Card.

**Table 58: Installation summary** 

Step	Media Card line cards
Unpack the card.	Remove all contents from the packaging box.
Install the CompactFlash Card.	Installing the CompactFlash card on the Media Card on page 207.
Install the Media Cards.	Installing the Media Card on page 208.
Install the A0852632 Shielded 50-pin to Serial/ ELAN/ TLAN Adapter.	Installing the Shielded 50-pin to Serial/ELAN/TLAN Adapter onto the Media Card on page 211.
Add the card and configure the card properties.	In Element Manager: Adding a card and configuring Voice Gateway Media Card properties on page 244.
Transmit and transfer properties.	In Element Manager: <u>Transmitting node properties</u> to <u>Leader</u> on page 247.

# Installing and cabling the Media Card 32-port card

The Media Card 32-port card requires only one slot in the IPE shelf.



#### Caution:

#### **CAUTION WITH ESDS DEVICES**

Wear an ElectroStatic Discharge strap when you handle Media Card line cards. As an additional safety measure, handle all cards by the edges, and when possible, with the loosened packaging material still around the component.

## CompactFlash installation

The Media Card package contains the following items:

- Media Card
- · CompactFlash card
- retaining pin

The CompactFlash card must be installed on the Media Card before you install the Media Card in the system. Perform the steps in Installing the CompactFlash card on the Media Card on page 207 to install the CompactFlash card.

If it is necessary to remove the CompactFlash card, perform the steps in Removing the CompactFlash on page 410.

#### Installing the CompactFlash card on the Media Card

1. Remove the Media Card and CompactFlash card from the packaging.



#### Electrostatic alert:

#### **CAUTION WITH ESDS DEVICES**

Observe the precautions for handling ESD-sensitive devices. Wear a properly connected antistatic wrist strap while you remove the cards from the packaging and work on a static-dissipating surface.

2. Locate the CompactFlash card socket in the lower left corner of the Media Card. See Figure 54: CompactFlash card socket on Media Card on page 207.



Figure 54: CompactFlash card socket on Media Card

3. Position the CompactFlash card with the label facing up, the metal clip pulled up, and the contact pins toward the socket as shown in Figure 55: Position the CompactFlash in socket on page 208.



Figure 55: Position the CompactFlash in socket

- Insert the CompactFlash card in the socket.
   Ensure force is applied equally at both ends of the CompactFlash when you insert it.
- 5. Gently insert the CompactFlash card, so that it is fully in contact with the connectors on the drive.
- 6. Push down the metal clip so that the CompactFlash card is locked in.

#### Install the Media Card

To install a Media Card, perform the steps in <u>Installing the Media Card</u> on page 208.

#### Installing the Media Card

1. For each Media Card in the node, identify the IPE card slot selected for the Media Card.

Use the information from the Table 59: Media Card installation by module type on page 208.

Table 59: Media Card installation by module type

CS 1000 Modules	Media Card	
NT8D37BA/EC IPE modules	All available IPE card slots	
NT8D37AA/DC IPE modules	0, 4, 8, and 12	

- 2. Remove existing I/O panel cabling associated with any card previously installed in the selected card slot.
- 3. Insert the Media Card into the card guides and gently push it until it contacts the backplane connector. Hook the locking devices.

The red LED on the faceplate remains lit until you configure and enable the card in the software, at which point the LED turns off.

The card faceplate window displays startup self-test results (T:xx) and status messages. A display F:xx indicates that a self-test failed. Some failures indicate that you must replace the card.

See <u>Transfer node configuration from Element Manager to the Voice Gateway Media</u>
<u>Cards</u> on page 247. See <u>Table 120: Media Card 32-port card faceplate maintenance display codes</u> on page 404 for a listing of the Media Card display codes.

# Voice Gateway Media Card ELAN and TLAN network interfaces

#### CS 1000M system

The ELAN and TLAN network interfaces are provided by A0852632 Shielded 50-pin to Serial/ELAN/TLAN Adapter (see Figure 56: Shielded 50-pin to Serial/ELAN/TLAN Adapter on page 210)

The ELAN network interface supports 10BaseT operation and the TLAN network interface supports 10/100BaseT operation. To support the 100BaseT operation on Large Systems, the TLAN network interface requires specialized I/O panel mounting connectors, which replace the standard connectors on the system.

Cables and connectors for the ELAN and TLAN network interface functions include the following:

- the NTCW84JA I/O panel filter block
- NTMF94EA ELAN, TLAN, RS-232 Serial Maintenance I/O interface cable
- A0852632 Shielded 50-pin to Serial/ELAN/TLAN Adapter. Standard shielded, CAT5 LAN cables (less than 100 meters) are recommended to attach the LAN ports to the local network.

# Install the Shielded 50-pin to Serial/ELAN/TLAN Adapter

The Media Card can support a single connector solution to access the TLAN and ELAN network interfaces. This connector (see <u>Figure 56: Shielded 50-pin to Serial/ELAN/TLAN Adapter</u> on page 210) is called the A0852632 Shielded 50-pin to Serial/ELAN/TLAN Adapter. It replaces the single NTMF94EA ELAN, TLAN, RS-232 Serial Maintenance I/O interface cable (octopus cable).

The adapter breaks out the signals from the I/O connector to the following components:

- ELAN network interface
- TLAN network interface
- one RS-232 (local console) port





Figure 56: Shielded 50-pin to Serial/ELAN/TLAN Adapter

On Large Systems, the NT8D81AA cable is used to bring all 24 Tip and Ring pairs to the I/O panel. The NTCW84JA I/O panel mounting block must be installed on Large Systems before the A0852632 Shielded 50-pin to Serial/ELAN/TLAN Adapter is installed. See <a href="Figure 56">Figure 56</a>: Shielded 50-pin to Serial/ELAN/TLAN Adapter on page 210.

To ensure proper connection, install the adapter securely; otherwise, connectivity can be lost.

#### **EMC Shielding Kit**

An ITG EMC shielding kit (NTVQ83AA) must be installed on the ELAN and TLAN network interface cables to meet regulatory requirements at the installation site. As shown in <a href="Figure 57: ITG EMC">Figure 57: ITG EMC</a>
Shielding Kit Deployment on page 210, a ferrite must be placed on both the ELAN and TLAN network interface CAT5 Ethernet cables during installation. Cable ties are then placed to retain the ferrites in the correct position.



**EMC Kit Deployment** 

Figure 57: ITG EMC Shielding Kit Deployment

Perform the steps in <u>Installing the Shielded 50-pin to Serial/ELAN/TLAN Adapter onto the Media Card</u> on page 211 to install the ITG EMC shielding kit (NTVQ83AA) on the ELAN and TLAN network interface cables.

#### Installing the Shielded 50-pin to Serial/ELAN/TLAN Adapter onto the Media Card

- 1. Install the Shielded 50-pin to Serial/ELAN/TLAN Adapter into the card connector (1, 2, 3, or 4) where the Media Card is located.
- 2. Connect a shielded Cat 5 cable from the customer TLAN switch equipment to the port labeled TLAN.
- 3. Connect a shielded Category 5 cable from the customer ELAN hub or switch equipment to the port labeled ELAN.
- 4. Install the NTAG81CA serial cable into the faceplate maintenance port.

# Initial configuration of MC 32S card

The MC 32S card ships from the factory with a blank compact flash card. When the card first powers up, it starts from a Gold Control and Signaling Processor (CSP) image. The Gold CSP image is a scaled-down version due to size restrictions on the on-board compact flash card. You must format the compact flash card and install the full CSP software before the MC 32S card functions at full capability.

The software for the MC 32S card consists of five files, which are located in a zip file and stored on the Signaling Server. All Gold versions of firmware are loaded on the MC 32S when the card ships from the factory.

# Initial configuration of IP Line data

Before you start the configuration:

- Ensure the system is running CS 1000 Release 7.0 software.
- Verify the license system limit in LD 22. The license system limit must have sufficient unused units to support the number of IP Phones to be installed. For more information, see Software Input Output Reference — Maintenance, NN43001-711.
- Expand the license limit, if necessary, by ordering additional licenses. See <u>Licenses</u> on page 43 for more information.

# Summary of procedures

This section contains the following procedures:

 Configuring IP address for the system active ELNK Ethernet network interface (LD 117) on page 212.

- Configure VoIP bandwidth management zones (LD 117) on page 212.
- Configure virtual superloops for IP Phones on page 215.
- Configure IP Phone features in LD 11 on page 216.

# Configuring IP address for the system active ELNK Ethernet network interface (LD 117)

To configure the Call Server ELAN network interface IP address (active ELNK), perform the steps in Configuring the ELAN network interface IP address for the active ELNK on page 212.

#### Configuring the ELAN network interface IP address for the active ELNK

- 1. Go to LD 117.
- 2. Create host entries with the IP address on the ELAN subnet by entering one of the following commands:

```
NEW HOST PRIMARY IP xx.xx.xx
NEW HOST SECONDARY IP xx.xx.xx.xx(for Large Systems only)
```

3. Assign the host entry IP address to active and inactive ELNK interfaces on the ELAN subnet by entering one of the following commands:

```
CHG ELNK ACTIVE PRIMARY IP
CHG ELNK INACTIVE SECONDARY IP (for Dual CPU only)
```

- 4. Verify the IP address for the Ethernet network interface by entering the following command: PRT ELNK.
- 5. Enter the following command: Update DBS.
- 6. Go to LD 137. Check the status of the Ethernet network interface by entering the command: STAT ELNK. If the ELNK network interface is disabled, enable it by entering: ENL ELNK.

# Configure VoIP bandwidth management zones (LD 117)

You can define up to 8001 zones using LD 117. The Call Server uses the zones for VoIP bandwidth management. For more information, see Converging the Data Network with VoIP Fundamentals. NN43001-260.



#### Caution:

Beginning in Release 7.0, Adaptive Network Bandwidth Management provides bandwidth zone numbers in the range 0-8000. If you are interoperating with an earlier release you must use bandwidth zone numbers in the range 0-255; call processing issues occur if you use bandwidth zone numbers greater than 255.

The term intrazone means within the same zone. Interzone means between two zones.

Table 60: LD 117 bandwidth management zone configuration on page 213 lists the zone parameters as follows:

- p1: total bandwidth (kb/s) available for Intrazone calls
- p2: defines the codec for intrazone calls (that is, preserve voice quality or preserve bandwidth). Best Quality (BQ) provides the best voice quality but uses the most bandwidth. Best bandwidth (BB) uses the least amount of bandwidth but reduces voice quality.
- p3: total bandwidth available for interzone calls
- p4: preferred strategy for the choice of the codec for interzone calls
- p5: zone resource type. The type is either shared or private.

For information about Private Zone configuration, see **Zones** on page 139.

LD 117 also includes the DIS and ENL commands to disable or enable a zone. When a zone is created, the default state is enabled.



#### Caution:

You must first configure zone 0 in LD 117 before you configure other zones or all calls associated with zone 0 are blocked.

Table 60: LD 117 bandwidth management zone configuration

Command	Description
NEW ZONE xxxxx p1 p2 p3 p4 p5	Create a new zone, where:
	xxxxx = zone number = (0)–8000.
	⚠ Caution:
	Beginning in Release 7.0, Adaptive Network Bandwidth Management provides bandwidth zone numbers in the range 0–8000. If you are interoperating with an earlier release you must use bandwidth zone numbers in the range 0–255; call processing issues occur if you use bandwidth zone numbers greater than 255.
	p1: intrazone available bandwidth = 0 – (10 000) – 100 000 (kb/s)
	p2: intrazone preferred strategy = (BQ – Best Quality) or BB – Best Bandwidth
	p3: interzone available bandwidth = 0 – (10 000) – 100 000 (kb/s)
	p4: interzone preferred strategy = BQ for Best Quality or BB for Best Bandwidth
	p5: zone resource type = (shared) or private
New ZONE xxxxxxxxx	Create a zone with default values for the parameters:

Table continues...

Command	Description		
	p1: 10 000 (kb/s) p2: BQ p3: 10 000 (kb/s) p4: BQ p5: shared		
CHG ZONE xxxxxxxx p1 p2 p3 p4 p5	Change zone parameters. You must reenter all parameters, even those that are unchanged.		
OUT ZONE xxxxxxxx	Remove a zone.		
DIS ZONE xxxxxxxx	Disable a zone. No new calls are established inside, from, or toward a disabled zone.		
ENL ZONE xxxxxxxx	Enable a zone.		
PRT ZONE xxxxxxxx	Print zone and bandwidth information; xxxxxxxx specifies a		
PRT ZONE ALL	zone. If no zone is specified, information for all zones is printed. PRT ZONE ALL also prints information for all zones.		

# **Element Manager for Zone Configuration**

Optionally, you can configure zones for CS 1000 systems using Element Manager instead of LD 117.

To view Element Manager for zone configuration, perform the steps in <u>Viewing Element Manager for Zone Configuration</u> on page 214

#### **Viewing Element Manager for Zone Configuration**

- 1. Log on to UCM and access Element Manager.
- 2. In the navigator, select **IP Network > Zones**.

The Zones window appears. See Figure 58: Zone List on page 214.



Figure 58: Zone List

3. Under **Configuration**, click **to Add** to add a new zone.

The Zone Basic Property and Bandwidth Management window appears. See <u>Figure 59:</u> <u>Zone Basic Property and Bandwidth Management window</u> on page 215.




Figure 59: Zone Basic Property and Bandwidth Management window

# Configure virtual superloops for IP Phones

You must configure one or more virtual superloops to support IP Phone Virtual TN (VTN) in LD 97 or in Element Manager.

#### Large Systems and CS 1000E

In Large Systems and CS 1000E, virtual superloops contend for the same range of loops with phantom, standard and remote superloops, digital trunk loops, and all service loops. Virtual superloops can reside in physically equipped network groups or in virtual network groups.

#### **Group maximums**

Without Fiber Network (FIBN) Package 365, a maximum of five network groups is available, 0 to 4. With Package 365, a maximum of eight network groups is available, 0 to 7.

For normal traffic engineering, provision up to 1024 VTN on a single virtual superloop for a Large System/CS 1000E. For nonblocking, do not exceed 120 VTN on a single virtual superloop for a Large System/CS 1000E.

Avaya recommends that configure virtual superloops starting in the highest non physically equipped group available. <u>Table 61: LD 97 Virtual superloop configuration for Large Systems/CS 1000E</u> on page 215 lists the prompts and responses required to configure virtual superloops in LD 97.

Table 61: LD 97 Virtual superloop configuration for Large Systems/CS 1000E

Prompt	Response	Description
REQ	CHG	Change existing data.
TYPE	SUPL	Superloop

Table continues...

Prompt	Response	Description
SUPL	Vxxx	V represents a virtual superloop and xxx is the number of the virtual superloop:
		xxx: 0 to 156 and multiple of four for a Large System without FIBN package 365
		xxx: 0 to 252 and multiple of four for a Large System with FIBN package 365

#### **Configuring virtual superloops in Element Manager**

To configure a virtual superloop in Element Manager, perform the steps in <u>Configuring a virtual</u> <u>Superloop in Element Manager</u> on page 216.

#### Configuring a virtual Superloop in Element Manager

1. In the Element Manager navigator, select **System > Core Equipment > Superloops**.

The Superloops window appears. See <u>Figure 60: Configuring a virtual superloop in Element Manager</u> on page 216.




Figure 60: Configuring a virtual superloop in Element Manager

- 2. Select the superloop number from the **Choose a Superloop Number** list.
- 3. Select Virtual from the type list.
- 4. Click to Add.

### Configure IP Phone features in LD 11

The existing License header that prints at the start of LD 11 includes the new License limit for the IP Phone. See Table 56: IP Phone configuration data summary sheet on page 184.

Table 62: LD 11 Configure an IP Phone

Prompt	Response	Description
REQ	NEW	New
:	CHG	Change
	CHGTYP	Change TN type
	PRT	Print
	OUT	Out
	CPY	Сору
	MOV	Move
TYPE :	2001P2, 2002P1, 2002P2, 2004P1, 2004P2, 2033, 2007, 2050PC, 2050MC, 1110, 1120, 1140, 1150, 1165, 1210, 1220, 1230, 2211, 2212, 6120, 6140	For IP Phone 2001, IP Phone 2002, IP Phone 2004, Avaya 2033 IP Conference Phone, Avaya 2007 IP Deskphone, Avaya 1210 IP Deskphone, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, Avaya 2050 IP Softphone, Mobile Voice Client 2050, Avaya 1110 IP Deskphone, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, Avaya 1165E IP Deskphone, WLAN Handsets 2210/2212/2212, Avaya 6120 WLAN Handset, and Avaya 6140 WLAN Handset.
		88 and 170. The IP Phones are also restricted by the IP Phone License setting.
TN	Iscu	I = loop, s = shelf, c = card, u = unit.
		Enter loop (virtual loop), shelf, card, and unit (terminal number), where unit = 0 to 31.
DES	az	ODAS telephone designator.
CUST	xx	Customer number as defined in LD 15.
ZONE	0 to 8000	Zone number to which this IP Phone belongs.
		Verify that the zone number exists in LD 117.
CLS	ADD	ADD: Automatic Digit Display, default for IP Phone.
		For a complete list of responses, see Software Input Output — Administration, NN43001-611.
KEY	xx aaa yy zzzz	IP Phone function key assignments:
		xx: keys 0 to 7
		xx: keys 8 to 15 keys, using the Shift key for Avaya 1165E IP Deskphone
		xx: keys 6 to 11, using either the Shift key for IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, WLAN Handsets 2210/2211/2212, Avaya 6120 WLAN Handset, or Second Page functionality for Avaya 1220 IP Deskphone and Avaya 1230 IP Deskphone

Prompt	Response	Description
		xx: keys 0 to 3 for the IP Phone 2002, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone and Avaya 1120E IP Deskphone
		These keys are self-labeled physical keys that you can program with any feature. For the WLAN Handset 2210, 2211, 2212, Avaya 6120 WLAN Handset, the keys are self-labeled virtual keys that you can program with any feature.
		xx: 0 for the IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1210 IP Deskphone, and Avaya 1110 IP Deskphone; any other key number entered returns an error message.
		aaa: key name or function
		yyy, zzz: additional information required for the key.
		Keys 16 to 26 are reserved for dedicated IP Phone context- sensitive soft keys.
		Table 67: LD 11 IP Phone dedicated context-sensitive soft key assignment on page 225 lists the dedicated IP Phone key name values (aaa). Other key name values are in Software Input Output — Administration, NN43001-611.

## **Configure the IP Phone Key Expansion Module**

Configure the optional IP Phone Key Expansion Module (KEM) in LD 11.

The IP Phone 2002 and IP Phone 2004 support the IP Phone KEM.

Table 63: LD 11 Configure the IP Phone KEM

Prompt	Response	Description
REQ	NEW	Add new data.
:	CHG	Change existing data.
TYPE	2002P1, 2002P2, 2004P1,	IP Phone 2002 (Phase I and Phase II)
:	2004P2	IP Phone 2004 (Phase I and Phase II)
ZONE	0 to 255 8000	Zone number to which the IP Phone 2002 or IP Phone 2004 belongs.
KEM	(0)-2	Number of attached IP Phone KEMs
		Up to two IP Phone KEMs can be attached to an IP Phone. Press Enter without entering a number to leave the value unchanged.

Prompt	Response	Description
	xx aaa yyyy (cccc or D) zzz	
KEY		IP Phone function key assignments
		The following key assignments determine calling options and features available to a telephone. The KEY prompt repeats until you press <code>Enter</code> .
		xx: key number
		For IP Phone 2002: xx: 0 to 31, when KEM: 0 xx: 0 to 55, when KEM: 1 xx: 0 to 79, when KEM: 2
		For IP Phone 2004: xx: 0 to 31, when KEM: 0 xx: 0 to 79, when KEM: 1 xx: 0 to 79, when KEM: 2
		Type xx: NUL to remove a key function or feature.
		aaa: key name or function
		yyyy: additional information required for the key
		zzz: additional information required for the key aaa
		The cccc or D entry deals specifically with the Calling Line Identification feature:
		cccc: CLID table entry of (0)-N; N = the value entered at the SIZE prompt in LD 15 minus 1. You can enter a CLID table entry if aaa: ACD, HOT d, HOT L, MCN, MCR, PVN, PVR, SCN, or SCR.
		D: the character D. When you enter the character D, the system searches the DN keys from key 0 and up, to find a DN key with a CLID table entry. The CLID associated with the found DN key is used.
		The position of the (cccc or D) field varies depending on the key name or function.
PAGEOFST	<page> <keyoffset></keyoffset></page>	Automatically calculates the IP Phone KEM key based on the entered values. This prompt enables the system administrator to enter a Page number of 0 or 1 and a Key Offset number from 0 to 23. Once entered, the KEY prompt is prompted with the appropriate KEY value filled in.
		Enter <cr> to terminate data entry.</cr>
		Applies to an IP Phone 2004 with KEM = 1, and where <cr> was entered at the KEY prompt. This does not apply to an IP Phone 2002.</cr>
		When values are entered for Page and KeyOffset, the KEY xx prompt displays, followed by PAGEOFST prompt. This loop continues until no values ( <cr> only) are entered at the PAGEOFST prompt.</cr>

Prompt	Response	Description
KEY xx		Edit the IP Phone KEM key number specified by PAGEOFST, where: xx = the number of the key (for example, KEY 36)
		Enter <cr> to keep the current setting.</cr>
KEMOFST	<kem> <keyoffset></keyoffset></kem>	Automatically calculates the IP Phone KEM key based on the entered values. This prompt enables the system administrator to enter a KEM number of 1 or 2 and a Key Offset number from 0 to 23. Once entered, the KEY prompt is prompted with the appropriate KEY value filled in.
		Enter <cr> to terminate data entry.</cr>
		When values are entered for KEM and KeyOffset, the KEY xx prompt appears, followed by KEMOFST prompt. This loop continues until no values ( <cr> only) are entered at the KEMOFST prompt.</cr>
		This applies an IP Phone 2002 if <cr> was entered at the KEY prompt, and an IP Phone 2004 with KEM = 2, and where <cr> was entered at the KEY prompt.</cr></cr>
KEY xx		Edit the IP Phone KEM key number specified by KEMOFST: xx: the number of the key (for example, KEY 36)
		Enter <cr> to keep the current setting.</cr>

## Configure the Avaya 1100 Series Expansion Module

Configure the optional Avaya 1100 Series Expansion Module in LD 11.

The Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, and Avaya 1165E IP Deskphone support the Expansion Module.

Table 64: LD 11 Configure the Expansion Module

Prompt	Response	Description
REQ	NEW/CHG	Add new or change existing data.
TYPE	1120, 1140, 1150, 1165	For Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, and Avaya 1165E IP Deskphone
KEM	(0) - 3/ <cr></cr>	Number of attached Expansion Modules (0). Up to three Expansion Modules are supported.
CLS	KEM3	KEM3 CLS is defined.

Prompt	Response	Description
KEY	0 – <seetext>/ <cr></cr></seetext>	Key number range expanded to support number of Expansion Modules specified by KEM prompt. The range on the IP Deskphone is as follows:
		xx: key number
		For IP Phone 1120E:
		xx: 0 to 31 when KEM: 0
		xx: 0 to 49 when KEM: 1
		xx: 0 to 67 when KEM: 2
		xx: 0 to 85 when KEM: 3
		For Avaya 1140E IP Deskphone and Avaya 1150E IP Deskphone:
		xx: 0 to 31 when KEM: 0
		xx: 0 to 67 when KEM: 1
		xx: 0 to 67 when KEM: 2
		xx: 0 to 85 when KEM: 3
PAGEOFST	<page> KeyOff-set&gt; <cr></cr></page>	You are prompted for PAGEOFST if an Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, or an Avaya 1165E IP Deskphone is attached, if one Expansion Module is specified at the KEM prompt, and if <cr> is entered at the KEY prompt. This prompt enables you to enter a Page number of 0, or 1, and a Key Offset number from 0 to 17. Once entered, the KEY is prompted with the appropriate KEY value filled in. <cr> ends the input.</cr></cr>
KEY <key></key>	<key conf="" data=""></key>	<key> is the key number for the Page + Key Offset entered at PAGEOFST. Enter the key configuration <cr> or just <cr>.</cr></cr></key>
KEMOFST	<kem> Key-Off-set&gt; <cr></cr></kem>	You are prompted for KEMOFST if an Avayaa 1120E IP Deskphone is attached and if one, two, or three Expansion Modules are specified at the KEM prompt, and if <cr> is entered for KEY prompt.</cr>
		This prompt enables you to enter a KEM number of 1, 2, or 3 and a KEY Offset number from 0 to 17. Once entered, the KEY prompt is prompted with the appropriate KEY value filled in. <cr> ends the input.</cr>
KEY <key></key>	<key conf="" data=""></key>	<key> is the key number for the KEM + Key Offset entered at KEYOFST. Enter the key's configuration <cr> or just <cr>.</cr></cr></key>

## **Configure the Avaya 1200 Series IP Deskphones Expansion Module**

Configure the optional Avaya 1200 Series IP Deskphones Expansion Module in LD 11.

The Avaya 1220 IP Deskphone and Avaya 1230 IP Deskphone support the Avaya 1200 Series IP Deskphones Expansion Module.

Table 65: Configure the Avaya 1200 Series IP Deskphones Expansion Module

Prompt	Response	Description
REQ	NEW/CHG	Add new or change existing data.
TYPE	1220, 1230	For Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone
KEM	(0) - 4/ <cr></cr>	Number of attached Expansion Modules (0). Supports up to four Expansion Modules.
KEY	0 - <see text="">/ <cr></cr></see>	Key number range depends on the number of Avaya 1200 Series IP Deskphones Expansion Module specified by KEM prompt:
		xx: key number
		For the Avaya 1230 IP Deskphone:
		xx: 0 to 31 when KEM: 0
		xx: 0 to 55 when KEM: 1
		xx: 0 to 79 when KEM: 2
		xx: 0 to 67 when KEM: 3
		xx: 0 to 79 when KEM: 4
		For the Avaya 1220 IP Deskphone:
		xx: 0 to 31 when KEM: 0
		xx: 0 to 43 when KEM: 1
		xx: 0 to 55 when KEM: 2
		xx: 0 to 67 when KEM: 3
		xx: 0 to 79 when KEM: 4
PAGEOFST	<page></page>	This prompt appears if one or two Avaya
	<keyoff-set></keyoff-set>	1200 Series IP Deskphones Expansion Modules are specified at the KEM prompt,

Prompt	Response	Description
	<cr></cr>	if <cr> is entered at the KEY prompt, and if attached to an Avaya 1230 IP Deskphone.</cr>
		This prompt enables the administrator to enter: Page number: 0 for KEM 1
		1 for KEM 1 when you configure 1 KEM and 2 KEM when you configure 2 KEMs
		2 for KEM 1
		3 for KEM 2
		and a Key Offset number from 0 to 11.
KEY <key></key>	<keys conf="" data=""></keys>	<pre><key> is the key number for the Page + Key Offset entered at PAGEOFST. Enter the key configuration <cr> or just <cr>.</cr></cr></key></pre>
KEMOFST	<kem> <key-off-set> <cr></cr></key-off-set></kem>	This prompt appears for the Avaya 1220 IP Deskphone or if three or four Avaya 1200 Series IP Deskphones Expansion Modules are specified at the KEM prompt for the Avaya 1230 IP Deskphone and <cr> is entered for KEY prompt.</cr>
		This prompt enables the administrator to enter a KEM number of 1, 2, 3, or 4 and a Key Offset number from 0 to 11. After you enter the KEM number, the KEY prompt appears with the appropriate KEY value filled in. <cr> ends the input.</cr>
KEY <key></key>	<keys conf="" data=""></keys>	<key> is the key number for the KEM + Key Offset entered at KEYOFST.</key>
		Enter the key configuration <cr> or just <cr>.</cr></cr>

## **Configure the Expansion Module 2050**

Configure the optional Expansion Module 2050 in LD 11.

The Avaya 2050 IP Softphone supports the Expansion Module 2050.

**Table 66: Configure the Expansion Module 2050** 

Prompt	Response	Description
REQ	NEW/CHG	Add new or change existing data.

Prompt	Response	Description
TYPE	2050	For Avaya 2050 IP Softphone
KEM	(0) - 3/ <cr></cr>	Number of attached Expansion Modules 2050 (0). Supports up to three Expansion Modules 2050.
KEY	0 - <see text="">/ <cr></cr></see>	Key number range expanded to support number of Expansion Modules 2050 specified by KEM prompt. The range on the Avaya 2050 IP Softphone is as follows:
		xx: key number
		xx: 0 to 31 when KEM: 0
		xx: 32 to 49 when KEM: 1
		xx: 50 to 67 when KEM: 2
		xx: 68 to 85 when KEM: 3
PAGEOFST	<page> <keyoff-set> <cr></cr></keyoff-set></page>	PAGEOFST is prompted if one Expansion Module 2050 is specified at the KEM prompt and <cr> is entered at the KEY prompt. This prompt enables you to enter a Page number of 0 or 1 and a Key Offset number from 0 to 17. Once entered, the KEY is prompted with the appropriate KEY value filled in. <cr> ends the input.</cr></cr>
KEY <key></key>	<keys conf="" data=""></keys>	<key> is the key number for the Page + Key Offset entered at PAGEOFST. Enter the key configuration <cr> or just <cr>.</cr></cr></key>
KEMOFST	<kem> <key-off-set>/ <cr></cr></key-off-set></kem>	KEMOFST is prompted if two or three Expansion Modules are specified at the KEM prompt and <cr> is entered for KEY prompt. This prompt enables you to enter a KEM number of 1, 2, or 3 and a KEY Offset number from 0 to 17. Once entered, the KEY prompt is prompted with the appropriate KEY value filled in. <cr> ends the input.</cr></cr>
KEY <key></key>	<keys conf="" data=""></keys>	<key> is the key number for the KEM + Key Offset entered at KEYOFST. Enter the key configuration <cr> or just</cr></key>
		<cr>.</cr>

## IP Phone dedicated context-sensitive soft keys

Table 67: LD 11 IP Phone dedicated context-sensitive soft key assignment on page 225 describes the features that can be assigned to dedicated context-sensitive soft keys 17 to 26 on the IP Phone 2001, IP Phone 2002, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone, Avaya 2050 IP Softphone, MVC 2050, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, Avaya 1165E IP Deskphone, WLAN Handsets 2210/2211/2212, Avaya 6120 WLAN Handset, and Avaya 6140 WLAN Handset. Remove unused feature keys by configuring the dedicated context-sensitive soft keys to NUL. Some features depend on the CoS.

If an attempt is made to configure anything other than the permitted response, the system generates an error code. For related error messages, see *Software Input Output Reference—System Messages, NN43001-712*.

Table 67: LD 11 IP Phone dedicated context-sensitive soft key assignment

IP Phone key number	Responses Allowed
Key 16	MWK, NUL
	MWK: Message Waiting key
Key 17	TRN, NUL
	TRN: Call Transfer key
Key 18	A03, A06, NUL
	AO3: 3-party conference key AO6 – 6-party conference key
Key 19	CFW, NUL
	CFW: Call Forward key
Key 20	RGA, NUL
	RGA: Ring Again key
Key 21	PRK, NUL
	PRK: Call Park key
Key 22	RNP, NUL
	RNP: Ringing Number pickup key
Key 23	SCU, SSU, SCC, SSC, NUL
	SCU: Speed Call User SSU:System Speed Call User SCC: Speed Call Controller SSC: System Speed Call Controller
Key 24	PRS, NUL
	PRS: Privacy Release key
Key 25	CHG, NUL

IP Phone key number	Responses Allowed
	CHG: Charge Account key
Key 26	CPN, NUL
	CPN: Calling Party Number key

## Node election rules

A Signaling Server with Virtual Trunks configured wins an election because it registers on the NRS with an IP node. Because the IP node can be provided to a Branch Office system during redirection to normal mode or to another CS 1000 peer system during network-wide Virtual Office logon, the TPS application must be enabled on the Signaling Server which runs the VTRK application.

The rules for the node election process are as follows:

- · A Leader always wins over a Follower.
- Within each class (Leader/Follower), the Signaling Server with the longest up time wins.
- If a tie for up time occurs, the Signaling Server with the lowest IP address wins.

The precedence of the rules is from 1 (highest) to 3 (lowest).

# Chapter 12: Configuration of IP Telephony nodes using Element Manager

## **Contents**

This section contains the following topics:

- Introduction on page 227
- Configure IP Line data using Element Manager on page 228
- Transfer node configuration from Element Manager to the Voice Gateway Media Cards on page 247
- Upgrade the Voice Gateway Media Card and IP Phone firmware on page 248
- Assemble and install an IP Phone on page 257
- Change the default IPL CLI Shell password on page 257
- Configure the IP Phone Installer Passwords on page 257
- Import node configuration from an existing node on page 257

## Introduction

This chapter explains how to configure IP Telephony nodes using Element Manager. Access Element Manager using a personal computer with web browser. For information about supported browsers see *Unified Communication Management Fundamentals*, *NN43001-116*. The personal computer must connect to a LAN that has access to the Signaling Server Node IP address, either directly or routed through the network.

The ELAN subnet IP address might be required, instead of the Node IP address, to access the Element Manager logon window in secure environments.

This chapter also provides instructions for upgrading IP Phone firmware.

Read the IP network engineering guidelines in *Converging the Data Network with VoIP Fundamentals*, *NN43001-260* before installing an IP Telephony node.

## Configure IP Line data using Element Manager

Element Manager can be used to manually add and configure an IP Telephony node on Avaya Communication Server 1000 (Avaya CS 1000) systems. You can configure and manage more than one node using Element Manager.

#### **Node Definition**

A node is defined as a collection of Signaling Servers. Each node in the network has a unique Node ID. This Node ID is an integer value. A node has only one Primary Signaling Server. All other Signaling Servers are defined as Followers.

All IP addresses and subnet mask data must be in dotted decimal format. Convert subnet mask data from Classless Inter-Domain (CIDR) format. For more information, see .

## Internet Explorer browser configuration

Element Manager requires a web browser. For information about supported browsers, see *Unified Communication Management Fundamentals*, *NN43001-116*.



Internet Explorer caching interferes with the Element Manager application; you cannot see real-time changes as they occur. For this reason, you must turn off Internet Explorer caching.

See <u>Configuring the Internet Explorer browser</u> on page 191 for more information.

## **Summary of procedures**

The following is the summary of the steps required to configure a node using Element Manager:

- 1. Manually add an IP Telephony node on page 228
- 2. Configuring SNMP trap destinations and community strings on page 237
- 3. Configure Voice Gateway Profile data on page 238
- 4. Configure Quality of Service on page 241
- 5. Configure file server access on page 243
- 6. Configure loss and level plan on page 244

## Manually add an IP Telephony node

Follow the steps in <u>Adding an IP Telephony node manually</u> on page 229 to add an IP Telephony node using Element Manager.

When you work in the IP Network, Node: Servers, Media Cards window, Element Manager times out after a period of inactivity. A warning appears 5 minutes before Element Manager times out. If you

click OK within the warning time-out period, the timer is reset. If you do not respond, the session terminates and you must log on again. Any data that you change but do not submit is lost.

#### Adding an IP Telephony node manually

- 1. Log on to UCM with appropriate credentials.
- 2. In Element Manager, select IP Network > Node: Servers, Media Cards.

The IP Telephony Nodes window appears.

If this is the first node to add, the No nodes are configured message appears. Two options are available: **Add** or **Import**.

The IP Telephony Nodes window lists all configured nodes. To view a node and the elements, select the link for the Node ID.

3. Click Add.

The New IP Telephony Node window appears.

4. Type an identifier for the node in the **Node ID** field.

The Node ID can be a value between 0 and 9999. When you define the node number, determine if the Enhanced Redundancy for IP Line Nodes functionality is required. For more information on Enhanced Redundancy for IP Line Nodes, see <a href="Enhanced Redundancy for IP Line Nodes">Enhanced Redundancy for IP Line nodes</a> on page 149. If it is required, factor the requirement into the node number assignment process.

The Node ID field corresponds to the Node ID field in the IP Phone configuration. Note the node number used during the IP Phone configuration.


- 5. Type the IP address for the Call Server in the Call server IP address field.
- 6. Select the radio button corresponding to the required value in the **TLAN address type** field.

If the TLAN address type supports IPv4 only, select the value **IPv4 only**. If dual stack is supported, select the value **IPv4 and IPv6**.

- 7. Enter the details for the ELAN in the following fields:
  - a. Type the ELAN subnet gateway IP address in dotted decimal format in the **Gateway IP** address field.

This is the IP address of the router interface on the ELAN subnet, if present. If there is no ELAN subnet gateway, type 0.0.0.0.

- b. Type the ELAN subnet mask address in dotted decimal format in the **Subnet mask** field.
- 8. Enter the details for the TLAN in the following fields as shown in the figure:



- a. Type the TLAN node IPv4 address in the Node IPv4 address field.
- b. Type the TLAN subnet mask address in dotted decimal format in the **Subnet mask** field.
- c. Type the TLAN node IPv6 address which is the global unicast address in the **Node IPv6** address field.

For example: 2001:DB8::214:c2ff:fe3b:3588

- 9. Select the check box corresponding to **SIP Line** to deploy the SIP Line software application to the element.
- 10. Select the check box corresponding to **UNIStim Line Terminal Proxy Server (LTPS)** to deploy the LTPS software application to the element.
- 11. Select the check box corresponding to **Virtual Trunk Gateway (SIPGw, H323Gw)** to deploy the Virtual Trunk Gateway software application.

## **!** Important:

Do not click **Save** until you enter all information for the node. If you click **Save** . You can click **Edit** to return to the IP Telephony Node window and continue the configuration.

#### 12. Click Next.

The next page of the New IP Telephony Node window appears.




Figure 61: New IP Telephony Node window - Step 2

- 13. Select the required Signaling Server from the **Select to add** field.
  - If you select **Media card**, the New Media Card window appears.
- 14. To make a node as the leader, perform the following steps:
  - a. Select the check box corresponding to the signaling server.

- b. Click Make Leader.
- 15. To associate servers with the node, click **Add**.
- 16. Click **Next** to proceed to the next window of the New IP Telephony node configuration.
- 17. If you selected the UNIStim Line Terminal Proxy Server (LTPS) check box in the page one of the configuration, provide the information for the UNIStim Line Terminal Proxy Server (LTPS).




Figure 62: New IP Telephony Node window - Step 3

- a. IP Address: Type the IP address where the firmware for IP Phones are downloaded from.
- b. **File path:** Type the path where the files are located.
- c. Server Account/User ID: Type the server account name or user id.
- d. **Password:** Type the password for the server account.
- 18. Click **Next** to proceed to the next window of the New IP Telephony node configuration. In this page you can configure the settings for the Virtual Trunk Gateway.




Figure 63: New IP Telephony Node window - Step 4


- 19. Provide the information corresponding to following parameters in the General tab of the window.
  - a. **Vtrk gateway application:** Provides option to select Gateway applications. The three supported modes are SIP Gateway (SIPGw), H.323Gw, and SIPGw and H.323Gw
  - b. **SIP domain name:** The SIP Domain Name is the SIP Service Domain. The SIP Domain Name configured in the Signaling Server properties must match the Service Domain name configured in the NRS. The SIP Domain Name is used in building all SIP messages and appears in the phone context, and must be less than 128 characters in length. The valid characters are a-z, 0-9, period (.), hyphen (-), comma (,), and underscore (\_). If the SIP Gateway application is enabled, you must enter a SIP Domain Name.
  - c. **Local SIP port:** The Local SIP Port is the port to which the gateway listens. The default value :is 5060.
  - d. **Gateway endpoint name:** This is the user name that is used when authenticating this gateway with the NRS (SIP Proxy/ Redirect Server) or the MCS 5100 Proxy Server.
  - e. **Gateway password:** This is the password that is used when authenticating this gateway with the NRS (SIP Proxy/Redirect Server) or the MCS 5100 Proxy Server.
  - f. H.323 ID: Each H.323 Gatekeeper is configured with an H.323 Gatekeeper alias name, which is an H323-ID. Enter any text string to describe the H.323 Virtual Trunk source in the H323 ID text box.


- g. **Enable failsafe NRS:** Option to enable Failsafe NRS. This acts as a replica of the Primary SIP Redirect Server when Primary goes down.
- h. **SIP ANAT** Select the IPv4 or the IPv6 button to establish a media session with the remote user. If the IP Phone is dual stack capable, then the user can choose IPv4 or IPv6 as a mode to communicate with the other dual stack capable IP Phone.
- i. **Monitor IP Addresses** Select the check box to enable the virtual trunk health monitor. Enter an IP address in the Monitor IP box and click **Add**.
- 20. Select the **SIP Gateway Settings** link to view and enter all the parameters for the SIP gateway.

#### Managing: 192.168.55.152 Username: admin2

System » IP Network » IP Telephony Nodes » Node Details » Virtual Trunk Gateway Configuration

#### Node ID: 353 - Virtual Trunk Gateway Configuration Details





- 3 45 bits 16 bits 64 bits

  001 global routing prefix subnet ID Interface ID Global Unicast IPv6 Address.

  Example:
  2001:DB8::214:c2ff:fe3b:3588
- 21. Click **Next** to proceed to the next window of the New IP Telephony node configuration.
- 22. On the last window of the new node configuration, review the information and click Finish.

## **SNMP** configuration

For more information about SNMP, see *Communication Server 1000 Fault Management—SNMP, NN43001-519.* 

## Configuring SNMP trap destinations and community strings

IP Line introduces single point configuration for SNMP traps. To configure the SNMP trap destinations and community strings for the Call Server, Signaling Server, and Media Gateway Controller in Element Manager, perform the steps in <a href="Configuring SNMP trap destinations">Configuring SNMP trap destinations</a> on page 237.

## Important:

You must perform a datadump to save the configuration information permanently whether the parameters are configured in Element Manager or in LD 117.

#### **Configuring SNMP trap destinations**

1. In the Element Manager navigator, click **System > Alarms > SNMP**.

The SNMP Configuration window appears. See <u>Figure 64: SNMP configuration window</u> on page 237.




Figure 64: SNMP configuration window

- 2. In the **Trap Source** section, enter the following parameters:
  - · Navigation Site Name
  - Navigation System Name

These parameters are used during trap generation.

- 3. In the MIB-2 System Group Parameters section, enter the appropriate parameters from the system administrator:
  - System Contact
  - System Location
  - System Name

- 4. In the **Community** section, enter the following parameters for system management community strings for access to the Management Information Base (MIB) and trap generation, and administrator community strings for access to the MIB views.
  - System Management Read
  - · System Management Write
  - · Trap community
  - Administrator Group

The SNMP community strings control access to the IP Telephony node. Element Manager uses the community strings to control the transmitting and retrieving of configuration data files for database synchronization.

- 5. In the **Trap Destinations** section, enter the IP address of the trap destination. SNMP traps are sent to the IP address entered. A maximum of 8 IP addresses can be configured.
- 6. Click Save.

The parameters are automatically synchronized to the Call Server, Signaling Server, and Media Gateway Controller.

After the parameters are synchronized, the associated host route entries are added to the routing table automatically. If a trap destination is removed, the corresponding routing table entry is removed as a result.

## **Configure Voice Gateway Profile data**

Perform the steps in <u>Configuring DSP Profile data</u> on page 238 to configure the Voice Gateway Profile data.

#### **Configuring DSP Profile data**

- In Element Manager, select System > IP Network > Nodes: Server, Media cards.
   The IP Telephony Nodes window appears.
- 2. Select a link for a Node ID.

The Node Details window appears.

- 3. Select the Voice Gateway (VGW) and Codecs link.
- 4. The Voice Gateway (VGW) and Codecs window appears. See <u>Figure 65: Voice Gateway</u> <u>and Codecs</u> on page 239. This window displays VGW information and a list of codecs. Leave the default values unless Avaya Support directs you to change them.

Managing: 172.16.100.30 Username: admin

System » IP Network » IP Telephony Nodes » Node Details » VGW and Codecs

Node ID: 1100 - Voice Gateway (VGW) and Codecs




Figure 65: Voice Gateway and Codecs

To select a codec, scroll through the list, and click the corresponding **Select** check box. A maximum of four codecs can be selected.

#### Recommendation

Avaya recommends that you configure the system with both G.711 and G.729A if a possibility exists that an Avaya 2050 IP Softphone can be configured with the "I use a modem to connect to the network" check box checked. If the node does not have G.729A or G.723 configured, Avaya 2050 IP Softphone users with that check box selected will have calls blocked.

This does not apply to the MVC 2050 as it supports only G.711 capability; no dial-up capability is available.

For more information, see IP Phones Fundamentals, NN43001-368.

The codec list contains five codec settings for G.711, G.722, G.723.1, G.729A, and T.38 FAX for the Voice Gateway Media Card.

- 5. Provide information for the following parameters in the General section of the window.
  - a. **Echo Cancellation:** Echo cancellation is enabled by default. Do not clear this check box. Never disable echo canceller unless directed by Avaya Support.
  - b. **Echo Cancellation:** Echo cancellation is enabled by default. Do not clear this check box. Never disable echo canceller unless directed by Avaya Support.
  - c. **Use canceller, with tail delay:** Select the maximum value available. The default value is 128 ms. Never reduce the echo cancellation value unless directed by Avaya Support.
  - d. **Voice activity detection threshold:** The default value is –17 db. The range is –20 db to +10 db.
  - e. **Idle noise level:** The default value is –65 db. The range is –327 db to +327 db.
  - f. **DTMF Tone detection:** Select to enable DTMF tone detection. This is enabled by default.
  - g. **Enable V.21 FAX tone detection:** Select to enable V.21 FAX tone detection. This is enabled by default.
- 6. By default, the G.711, G711 Clear Channel, and T.38 FAX codecs are selected; you cannot clear them. However, you can change the following:
  - The payload size, jitter buffer setting, and companding law for the G.711 codec. The default is G.711 mu-law.
  - Only the jitter buffer can change for the G.711 Clear Channel codec.
    - Up to four additional codecs can be optionally selected: G.722, G.7231, G.729A, or G. 729AB, codecs.
  - If the G.722, G.729A or G.729AB codec are selected, the payload and jitter buffer can change. The payload defaults are the maximum supported payload.
  - If the G.723.1 codec is selected, only the jitter buffer can change. The payload size of 30 ms is the only supported payload.

The supported G.723.1 codec has bit rates of 5.3 kb/s and 6.3kb/s.

Element Manager enables some jitter buffer adjustments on the browser side:

- A change of payload resets the Nominal Voice Playout (NVP) and Maximum Voice Playout (MVP) values to the default recommended values: NVP = 2 \* payload MVP = NVP + 2 \* payload
- A change of NVP value changes the MVP value to the default (MVP = NVP + 2 \* payload) and changes the values listed in the MVP list so the minimum value does not violate the requirement of NVP + 2 \* payload.
- The MVP value can be changed. The values range from the minimum recommended value to the maximum allowed value for the selected codec type.
- 7. Configure the following values for the codec:
  - a. Codec Name: The codec name is based on the selected codec.
  - b. Voice payload size (ms/frame): The payload size is determined by the selected codec.

For each codec type, the payload uses the default value: 20 ms for G.711, 20 ms for G.722, 20 ms for G.729, and 30 ms for G.723.1.

If a system has multiple nodes and the same codec is selected on more than one node, ensure that each node has the same voice payload size configured for the codec.

- c. **Voice playout (jitter buffer) nominal delay:** Configure the nominal value to the highest setting that the device allows. The range is 20 to 200 ms and depends on the codec. Changing this value can automatically adjust the other settings for this codec. For more information, see *Converging the Data Network with VoIP Fundamentals, NN43001-260.*
- d. **Voice playout (jitter buffer) maximum delay:** The maximum delay has a range of 60 to 500 ms and depends on the codec. Changing this value can automatically adjust the other settings for this codec.
- e. **Voice Activity Detection (VAD)** Select this check box to enable Voice Activity Detection.

Because Avaya CS 1000 does not support VAD for G.722 and G723.1 codec, Element Manager does not support configuration of VAD for G.722 and G723.1.

- 8. Select parameters for the fax codecs.
  - a. **FAX maximum rate:** The FAX maximum rate is one of the following values: 2400, 4800, 7200, 9600, 12000, or 14400. The default value is 14400 bps.
  - b. **FAX playout nominal delay:** The default value is 100 ms. The range is 0 ms to 300 ms.
  - c. **FAX no activity timeout:** The default value is 20 seconds. The range is from 10 seconds to 32000 seconds.
  - d. **FAX packet size:** Select the desired FAX packet size. The default value is 30 bytes. The range is from 20 to 48 bytes.
- 9. Repeat step 5 for each selected codec.

## **Configure Quality of Service**

The Quality of Service (QoS) section includes the settings for the following:

- DiffServ CodePoint (DSCP)
- 802.1Q support

Perform the steps in Configuring QoS on page 241 to configure QoS.

#### **Configuring QoS**

- 1. In Element Manager, select System, IP Network, Nodes: Server, Media cards.
- 2. Select a link for a Node ID.

The Node Details window appears.

3. Select the Quality of Service (QoS) link.

The Quality of Service (QoS) window appears. See <u>Figure 66: Quality of Service (QoS)</u> window on page 242.




Figure 66: Quality of Service (QoS) window

4. The Differentiated Service (DiffServ) CodePoint (DSCP) value determines the priorities of the management and voice packets in the IP Line network. The range for both management and voice packet DiffServ is 0 to 63 inclusive.

The DiffServ value can be configured, if required, to obtain better QoS over the IP data network (LAN/WAN).

The value entered depends on the policy in the customer data network.

## Important:

Do not change DiffServ from the default values unless instructed by the IP network administrator.

Modify the Control packets priority and Voice packets priority values only if directed by the IP network administrator.

The recommended configuration values are as follows:

- a. Control packets: A value of 40 Class Selector 5 (CS5). The range is 0 to 63. This configures the priority of the signaling messaging.
- b. Voice packets: A value of 46 Control DSCP Expedited Forwarding (EF). The range is 0 to 63.
- 5. 802.1Q enables Virtual LANs (VLANs) to be defined within a single LAN. This improves bandwidth management and limits the impact of broadcast storms and multicast messages.
  - a. VLAN Tagging: 802.1Q support is disabled by default.
  - b. 802.1Q Bits value (802.1p): The priority field is a three-bit value, with a default value of 6. The range is 0 to 7. A value of 6 is recommended by Avaya. The p bits within the 802.1Q standard enables packet prioritization at Layer 2, which improves network throughput for IP telephony data.
- 6. Click Save.

## Configure file server access

Firmware files for the IP Phones are stored on a Signaling Server. Each time a Follower Signaling Server powers up or restarts, IP Phone firmware files are retrieved from the Leader Signaling Server. You can configure the Leader Signaling Server to retrieve the IP Phone firmware files from an external sFTP site server during startup. All files, which match xFF.fw naming convention are retrieved and registered.

#### Note:

When you use the FTP Server to upload an IP Phone firmware version on the Signaling Server, any previous IP Phone firmware that was uploaded through the FTP Server will not be saved. To downgrade the firmware on IP Phone to the previous IP Phone firmware, repeat the process again by uploading the previous IP Phone firmware through the FTP Server.

To configure the file server, perform the steps in Configuring access to the file server on page 243.

#### Configuring access to the file server

- 1. Log on to UCM with appropriate credentials.
- In Bsuiness Element Manager, select IP Network, Nodes: Servers, Media Cards. The IP Telephony window appears. See <u>Figure 67: UNIStim Line Terminal Proxy (LTPS)</u> Configuration Details window on page 243.
- 3. Select the link for a Node ID. The Node Details window appears.
- 4. Select the **Terminal Proxy Server (TPS)** link. The UNIStim Line Terminal Proxy (LTPS) Configuration Details window appears.




Figure 67: UNIStim Line Terminal Proxy (LTPS) Configuration Details window

- 5. Specify the parameters needed to connect to the file server:
  - a. **Firmware download server IP address:** Enter the IP address of the file server where the firmware is downloaded.
  - b. **Firmware file path:** Enter the path for the location of the firmware files.

#### Note:

You can point to another IP Telephony Node that already has firmware updated. If the Firmware download server IP Address is an existing IP Telephony Node, specify the Firmware File Path as /var/opt/cs1000/tps/fw/.

- c. **User ID:** Enter the User ID required to access the file server.
- d. **Password:** Enter the Password required to access the file server.

For information about the Enhanced UNIStim Firmware Download for IP Phones, see Enhanced UNIStim Firmware Download for IP Phones on page 78.

## Configure loss and level plan

The loss and level plan determines parameters, such as transmission gain, that vary from country to country.

#### **Default Values**

The default values in the system are for the North American loss plan.

#### **Non-North American countries**

Installing IP Line in any other country requires that you configure the pad values in Table 15 to that country loss plan. If you install the system in other countries, the GPRI package (International 1.5/2.0 Mb/s Gateway package 167) must be used, and the NTP-specified values must be entered in LD 73. At the PDCA prompt, enter Table 15.

For more information, see Transmission Parameters Reference, NN43001-282

## Add card and configure the card properties of the Voice Gateway Media Card

If the network administrator provides IP addresses and subnet masks in CIDR format, for example, 10.1.1.10/24, convert the subnet mask to dotted decimal format. See <u>Subnet Mask Conversion from CIDR to Dotted Decimal Format</u> on page 432.

In the Cards section, cards can be added, changed, or removed in the node one at a time.

Perform the steps in <u>Adding a card and configuring Voice Gateway Media Card properties</u> on page 244 to add a Voice Gateway Media Card and configure the properties or to configure the properties of an existing Voice Gateway Media Card.

#### Adding a card and configuring Voice Gateway Media Card properties

- In Element Manager, select System, IP Network, Nodes: Server, Media Cards.
   The IP Telephony Nodes window appears.
- 2. Select the link for a Node ID.
- 3. In the Associated Signaling Servers & Cards section of the window, select **Media Cards** from the Select to add menu.

4. Click **Add** . The New Media Card Details window appears. See <u>Figure 68: New Media Card Details window</u> on page 245.





Figure 68: New Media Card Details window



- 5. In the Identification and Status section of the window, enter the following information.
  - a. HostName: This is the Host name.
    - Note:

The Media Card HostName cannot contain dots and other special characters.

- b. Card TN: Enter the card slot number from 1 to 50.
- c. **Server Type:**Select the server type.
  - Note:

DSP IPv6 address field is enabled only if you select the server type as MC32S card, and if IPv4 and IPv6 option is selected for TLAN address type of the corresponding node in Node Details page. If only IPv4 is selected for TLAN address type of the node, DSP IPv6 address field is displayed but the field is disabled during MC32S card configuration.

- d. MAC Address: This is the motherboard Ethernet address.
- 6. In the Network section of the window, enter the TLAN and ELAN network information.
  - a. **Telephony LAN (TLAN) IP address:** This is the TLAN network interface IP address for the card.

Communication Server 1000 supports dual stack capability and hence the TLAN network IP address information includes both the IPv4 and IPv6 addresses. Global unicast IPv6 addressing is the only supported IPv6 address type. If the IP Phone supports dual stack, then the user can prefer IPv4 or the IPv6 mode to communicate with the remote user. The user needs to enter the respective IP address in the **DSP IP address** and **DSP IPv6 address** fields.

- b. **Embedded LAN (ELAN) IP address:** This is the ELAN network interface IP address for the card. Element Manager and the system use this IP address to communicate with the card.
- Note:

The Gateway IP address field usually displays the same value as the Node Gateway address, but this value can be different depending on how the card was configured.

- 7. Click **Save** to transfer the changes to the Call Server.
- 8. To add additional cards to the node, click **Add** again and enter the card information. Repeat this step for each card that you add to the node.
- 9. To edit the properties of a Voice Gateway Media Card, select the link for the card to display the card properties.

## Transfer node configuration from Element Manager to the Voice Gateway Media Cards

Before you start the node configuration transfer, ensure the following:

- The Voice Gateway Media Cards and cables are installed.
- The ELAN and TLAN network interfaces of all cards have access to the IP network.
- To enable access to Element Manager through a Web browser, a network PC must be able to access the node Signaling Server, either directly or remotely.

The IP Telephony node and card properties are configured using Element Manager. The configuration data is saved to the Call Server and then transferred to the Voice Gateway Media Cards.

#### Saving the configuration

The configuration data is saved when **Save** in the Edit window is clicked. The files are saved to the Call Server. After the data is saved, the configuration must be transferred to the Voice Gateway Media Card. When Transfer/Status in the Edit window is clicked, Element Manager instructs each card where to retrieve the files using FTP. The Voice Gateway Media Card then retrieves the CONFIG.INI and BOOTP.TAB files.

## Transmit node properties

To transmit the node properties to the Leader, perform the steps in <u>Transmitting node properties to Leader</u> on page 247.

#### Transmitting node properties to Leader

1. If you change the node or card configuration data, in the Node Details window, click **Save** to save the data to the Call Server .

A confirmation dialog box appears.

2. Click **OK** to confirm the save of the node data.

The Node Details window closes, and the Node Configuration window appears.

3. In the Node Configuration window, click **Transfer/Status** associated with the node.

The Transfer/Status window appears.

- 4. Select the Leader card check box.
- 5. Click Transfer to Selected Elements.

A transfer confirmation dialog box appears.

6. Click OK.

Element Manager notifies the Leader and the Voice Gateway Media Cards, which then retrieve the CONFIG.INI and BOOTP.TAB files from the Call Server.

The Transfer Progress window appears and displays each Voice Gateway Media Card in the node.

The Voice Gateway Media Cards retrieve the CONFIG.INI and BOOTP.TAB files from the Call Server.

- 7. When the transfer is complete, click **OK** in the **Transfer Successful** dialog box.
  - If the transfer is successful for a card, the Status column displays Complete. If the transfer is unsuccessful, the Status column displays Fail.
- 8. Restart the Signaling Server if any IP address information changes.



#### Warning:

Do not use a pencil to reset the Voice Gateway Media Card. The graphite carbon can create an electrical short circuit on the board.

## **Upgrade the Voice Gateway Media Card and IP Phone** firmware



#### **Warning:**

Before you start the upgrade, ensure that you configure a PWD1 user name and password on the Call Server. If no PWD1 user name and password exists, configure them in LD 17. This is necessary to enable logon to the Signaling Server.

Ensure that the following software is installed on the PC:

- Software to extract zipped files (WinZip or equivalent)
- Web browser. For information about supported browsers, see *Unified Communication* Management Fundamentals, NN43001-116.

## Upgrade procedure steps

The following steps are required to upgrade the Voice Gateway Media Card loadware and IP Phone firmware:

- 1. Determine the version of the software currently installed on the Voice Gateway Media Card. See Determine Voice Gateway Media Card software version on page 249.
- 2. Determine the version of the IP Phone firmware.
- 3. Obtain the most recent software from the Signaling Server. See Download the current loadware and IP Phone firmware on page 250.
- 4. Upload the software and firmware files using the File Upload system utility in Element Manager. See Uploading loadware and firmware files on page 250.
- 5. Upgrade the Voice Gateway Media Card software. See Upgrading the card loadware on page 251.

6. Restart the Voice Gateway Media Card. See <u>Restarting the Voice Gateway Media Card</u> on page 252.

## **Upgrade options**

After the Voice Gateway Media Card loadware and IP Phone firmware is verified, there are three upgrade options:

- Upgrade the Voice Gateway Media Card software only. It may be necessary to upgrade only the Voice Gateway Media Card software. This option is used most frequently; however, verify if an IP Phone firmware upgrade is also required.
- 2. Upgrade both the Voice Gateway Media Card software and the IP Phone firmware.
- 3. Upgrade only the IP Phone firmware.

Restart all the IP Phones. Select a test IP Phone and reset the firmware only on that test IP Phone before you upgrade all IP Phones. If the upgrade works properly, use the umsUpgradeAll command to upgrade all the IP Phones.

For more information, see Enhanced UNIStim Firmware Download for IP Phones on page 78.

## IP Phone firmware requirements

The IP Phone 2001, IP Phone 2002, IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone, Avaya 1210 IP Deskphone, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, Avaya 1120E IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, and Avaya 1165E IP Deskphone firmware can be upgraded in the field.

#### **UFTP**

IP Phone use UNIStim File Transfer Protocol (UFTP) to transfer the firmware; therefore, the customer network must support UFTP. The customer network must open UDP port 5105.

If the firmware cannot be transferred due to firewall restrictions (such as when the IP Phone is behind a firewall that has port 5105 blocked), then upgrade the IP Phone with the current firmware version before you distribute the telephone.

## **Determine Voice Gateway Media Card software version**

To determine the software version on the Voice Gateway Media Card, log on to the Voice Gateway Media Card. At the command line, enter swVersionShow to retrieve information as shown in the following example.

#### swVersionShow example

pdt> swVersionShow unixbld3's loadbuild - basedon ip1-5.92.22 (MC32S)
was built on Tue Feb 10 07:39:49 EST 2009
Additional Modules:

mainos.sym

BOOTCODE: ipl-5.92.22

HOST MSP: MAA05 DB2 MSP: 2AB01 FPGA: V007

#### Download the current loadware and IP Phone firmware

You must download the file of Product Category: VOIP & Multimedia Communications, Product Name: Signaling Server and IP Peer Networking, Content type: Releases. Obtain the precise Release, Status, and Title of the file from your next level of support. See <a href="http://www.avaya.com/support">http://www.avaya.com/support</a> for download instructions.

## Upload the loadware and firmware files to the Signaling Server

The next step is to upload the files from the Element Manager PC to the file server. Use the Centralized File Upload window to upload and store software and firmware on the Signaling Server. These files can then be downloaded to the IP Phones and the Voice Gateway Media Cards using the firmware and loadware upgrade functions available from the Software Upgrade menu. The Signaling Server can be used as a central distribution point to load and activate loadware, firmware and patches. To upload the files, follow the step in Uploading loadware and firmware files on page 250.

For patches, Element Manager need not to upload to the Signaling Server first. The Signaling Server obtains the patch file directly from the Element Manager PC.

#### Uploading loadware and firmware files

In the Element Manager navigator, click Software > File Upload.

The File Upload window appears. See <u>Figure 69: Centralized File Upload window</u> on page 250.




Figure 69: Centralized File Upload window

2. Click Browse.

The Choose File window appears. In the Choose File window, select the path and file to upload. Alternatively, enter the path and file name for the file to upload.

Only one loadware or firmware file can be uploaded at a time.

Once selected, the path and file name appear in the box to the left of the Browse button.

#### 3. Click File Upload.

The uploaded file appears in the list at the top of the window.

To delete older versions of the firmware and loadware files, select the corresponding check box and click **Delete** at the top of the column of check boxes.

## **Upgrade the Voice Gateway Media Card loadware**

After the files are uploaded to the file server, the Voice Gateway Media Cards must be upgraded to the newest loadware version. To upgrade the card loadware, perform the steps in Upgrading the card loadware on page 251.



#### **Marning:**

When upgrading a CS 1000 system from 4.5 to 7.0, remember to install the MPLR 24008 patch on the 4.5 system before upgrading. The patch ensures that the VGMC card upgrades properly.

Files in the /fw folder on the MC 32 VGMC card are read-only. You must remove this protection and delete the files in the /fw folder before you try to upgrade the loadware. You must perform these steps to remove the read-only attribute and delete the existing files from the /fw folder.

## Removing the read-only protection and delete existing files in the /fw folder

- 1. Remove the flash memory card from the VGMC card.
- 2. Insert the flash memory card into your laptop or into the card reader on your computer.
- 3. Delete the files in the /fw folder on the flash memory card.
- 4. Reinstall the flash memory card in the VGMC.
- 5. Perform the steps in <u>Upgrading the card loadware</u> on page 251.

#### Upgrading the card loadware

## **Important:**

If a VGMC is upgraded using Element Manager, both the card and Element Manager must be the same release.

- 1. In the Element Manager navigator, click Software, Voice Gateway Media Card. The Voice Gateway Media Card (VGMC) Loadware Upgrade window appears.
- 2. Expand the node by clicking the plus sign (+) to the left of the node.
- 3. Select the card to upgrade by selecting the check box to the left of the card information. Element Manager supports upgrading the software on up to four cards at the same time.
- 4. In the lower part of the window, select the most current software version.

If the card receiving the upgrade is a Media Card 32S card, select the most current version of the Media Card 32S card software.

5. Click **Loadware Upgrade** at the bottom left of the window.

A confirmation dialog box appears.

6. Click **OK** to confirm the card upgrade.

The upgrade begins.

The Loadware Upgrade Progress window appears.

The upgrade status appears for each card selected to receive the upgrade. The upgrade status can be Work in progress, Upgrading, Fail, or Finished.

- 7. Click OK.
- 8. Repeat steps 3 to 7 to upgrade the other card.

#### Note:

If you are upgrading a VGMC to an inter-release, such as from Communication Server Release 4.0 to 7.0, you can minimize downtime by upgrading the VGMC and system in the following order:

- Upgrade the media card to the new release loadware using the previous (or current) release of Element Manager. Although the new loadware is installed, the card continues to run on the previous release software until the system is rebooted.
- Upgrade the Call Server, Signaling Servers, and Element Manager to the new release. There is a System and Node outage during the upgrade.
- Reboot the servers.
- When the system and servers come back up, the newly upgraded media cards are ready to register to the Call Server and process calls.

## Restart the Voice Gateway Media Card

Perform the steps in Restarting the Voice Gateway Media Card on page 252 to restart a Voice Gateway Media Card.

#### **Restarting the Voice Gateway Media Card**

- 1. Disable the Voice Gateway Media Card.
- 2. Click the Element Manager navigator, select IP Network, Maintenance and Reports.

The Node Maintenance and Reports window appears.

- 3. To expand the node containing the card to restart, click the plus sign (+) to the left of the node.
- 4. Click the Voice Gateway Media Card associated **Reset** button to restart the card.

The cards remain in the Disabled state after the upgrade, so a Reset command can be used. You can also reset the card by using a pointed object to press the Reset button on the card faceplate.

- 5. Click the card **Status** button in the Node Maintenance and Reports window to verify the status of the Voice Gateway Media Card.
- 6. Use the LD 32 ENLC command to re-enable the Voice Gateway Media Cards.
- 7. Repeat these steps for each Voice Gateway Media Card that received the software upgrade.

## Re-enable the Voice Gateway Media Card

Perform the steps in Re-enabling the Voice Gateway Media Card on page 253 to re-enable the Voice Gateway Media Card.

#### Re-enabling the Voice Gateway Media Card

In the Element Manager navigator, click System > Maintenance.




Figure 70: Maintenance window

- From the Select by Overlay list, select LD 32 Network and Peripheral Equipment.
   The Network and Peripheral Diagnostics window appears.
- 3. From the Card Commands list, select ENLC Enable and reset card.
- 4. Under Command Parameters, enter card number.
- 5. Click Submit.
- 6. Repeat steps 3 to 5 for each Voice Gateway Media Card to re-enable.

## **Upgrade the IP Phone firmware**

After you upgrade the IP Line software on the Signaling Server, determine if you must also upgrade the IP Phone firmware. If an upgrade is required, you must upgrade the Signaling Server to the newest IP Phone firmware version.

## **!** Important:

A firmware download does not occur with IP Phones performing a Virtual Office logon or Media Gateway 1000B (MG 1000B) logon to a remote system. No firmware upgrade occurs during a Virtual Office logon or MG 1000B user registration with the LTPS. The registration is allowed because the IP Phone firmware version must be 1.33 or later to perform a Virtual Office logon or MG 1000B user registration.

The umsUpgradeAll command has no impact on Virtual Office logon IP Phones. These IP Phones are not reset. If the Virtual Office logon is on the same Call Server, then the IP Phone firmware upgrade occurs after the user logs off. If the Virtual Office logon is between Call Servers, then the IP Phone registers to the home LTPS and follows the normal firmware rules for regular registration.

When the umsUpgradeAll command runs, MG 1000B user IP Phones that are on active calls are flagged. After the IP Phones become idle, the IP Phones are switched by the Call Server back to the MG 1000B for the firmware upgrade.

Perform the steps in <u>Upgrading the IP Phone firmware</u> on page 254 to upgrade IP Phone firmware.

#### **Upgrading the IP Phone firmware**

1. In the Element Manager navigator, click **Software > IP Phone Firmware**.

The IP Phone Firmware window appears. See <u>Figure 71: IP Phone Firmware window</u> on page 254.




Figure 71: IP Phone Firmware window

- 2. Select the IP Telephony Node from the list to view the firmware on the Leader Terminal Proxy Server (TPS) of each Telephony Node configured on the Call Server.
- 3. Select the IP Phone type to update the firmware for the current IP Telephony node. The phones in the Phone Type column are the phones listed in the Currency file.
- 4. Click Update.

The Update Phone Firmware opens for the selected IP Phone type. See <u>Figure 72: Update Phone Firmware window</u> on page 255.



Figure 72: Update Phone Firmware window

- 5. Click **Browse** to locate the firmware file on the PC.
- 6. Click **Upload** to upload the firmware to the Leader TPS of the selected IP Telephony node. Check the status column to ensure the server placed the new file in service.
- 7. Click **Update** to distribute the firmware.

Check the updated status message, which indicates that the file is in service.

The IP Phones continue to run the old firmware until each IP Phone re-registers with the Signaling Server containing the new IP Phone firmware.

8. Repeat the preceding steps for all the card that have to be upgraded.

Commands are available from the Linux shell to immediately upgrade a single IP Phone, all IP Phones immediately, or to schedule all IP Phones for an upgrade. Before you upgrade, verify that the Signaling Server has the correct IP Phone firmware version.

- 9. Select an IP Phone for test purposes.
- 10. SSH to the Signaling Server and then log on to the Linux shell, and enter the following:

```
isetReset "xxx.xxx.xxx.xxx"
```

xxx.xxx.xxx is the IP Address of the selected IP Phone.

- 11. Monitor the display on the test IP Phone. As the IP Phone upgrades the firmware, note the IP Address of the Signaling Server from which the IP Phone receives the upgrade.
- 12. Press the **Services** key (key with globe with arrow pointing East and West. The Services key enables access to the **Telephone Options** list.
  - a. Press **Select** to select Telephone Options.
  - b. Use the **Navigation** keys to scroll to **Set Info**.
  - c. Press the **Select** soft key, then press the **Navigation** keys until it displays **FW Version**. Select the appropriate firmware on the Signaling Server.

- 13. Lift the IP Phone handset and make a call to verify the IP Phone works.
- 14. Enable and schedule Firmware Download Maintenance Mode to ensure that the Signaling Server uses the processing power for the firmware upgrade. For more information, see Enhanced UNIStim Firmware Download for IP Phones on page 78.
- 15. Before you proceed, ensure the time on the Signaling Server is configured correctly. Telnet to the Signaling Server and log on to the Linux shell, enter the following:

```
umsUpgradeAll "hh:mma/p"
```

hh: mma/p specifies the time when the upgrade occurs, a represents a.m., and p represents p.m. The time is in Standard format.

For example, umsUpgradeAll "11:30a" or umsUpgradeAll "2:45p".

At the time specified, all IP Phones registered to the Signaling Server go out of service. This can take several minutes.

After the firmware upgrade, the IP Phones are brought online as they complete the firmware upgrade.



#### Caution:

If you use the umsUpgradeAll command without the time parameter, all IP Phones registered that are logged on are immediately removed from service. Use the time parameter with the command to prevent this.

After the test IP Phone is working, the umsUpgradeAll command does not require the time parameter. However, if the time parameter is not used, the command immediately resets all the IP Phones currently registered on the Signaling Server.

- 16. Inspect the list to ensure all IP Phones have the correct firmware version.
- 17. For any IP Phones that did not upgrade successfully, try one of the following (in order):
  - Use the isetReset IP Address command.
  - Enter the following combination of key strokes at the telephone console:

release, mute, up, down, up, down, 9, release.

• Power the telephone off and then on again.

If the upgrade failed on any IP Phone, the cause is probably one of the following:

- The Signaling Server did not upgrade the software successfully.
- An IP Phone firmware version was unable to be upgraded by the Signaling Server in the normal manner.
- The umsUpgradeAll command was not issued.

If the upgrade failed, redo the appropriate procedure. If the upgrade fails again, contact a technical support representative for further assistance.

For more information about configuring the IP Phones, see IP Phones Fundamentals, NN43001-368.

### Assemble and install an IP Phone

To assemble and install an IP Phone, see IP Phones Fundamentals, NN43001-368.

# Change the default IPL CLI Shell password

The IPL> Command Line Interface (CLI) is password-protected to control Telnet access and access to the local maintenance port. The same user name and password also controls FTP access to the Voice Gateway Media Card. The IPL> CLI has a default user name of admin1 and a default password of 0000.

The default user name and password will be changed as a preventative security measure to PWD1 after synchronization with CS.

# Configure the IP Phone Installer Passwords

The IP Phone Installer Password, used to change the TN on the telephone, controls registration with a virtual line TN on the Call Server. See IP Phone Installer Password on page 267 for more information about the IP Phone Installer Passwords.

To enable and configure the administrative IP Phone Installer Password, see Configuring the Administrative IP Phone Installer Password on page 272.

If required, enable and configure a temporary IP Phone Installer Password. See Configuring the temporary IP Phone Installer Password on page 274.

You can also use Element Manager to configure the IP Phone Installer Passwords. See Setting the IP Phone Installer Password on page 326.

## Import node configuration from an existing node

You can import a node and the configuration data from an existing node into Element Manager.

For example, if Node 151 exists, but does not exist on the Call Server, then Node 151 can be imported into Element Manager. After you import a node, you can update and edit the configuration data.



#### 🔀 Note:

You cannot import a node from a different release.

#### Importing node files

- In the Element Manager navigator, select IP Network, Nodes: Servers, Media Cards.
   The IP Telephony Nodes window appears.
- 2. Click Import Node Files.

The Import Node Files window appears. See <u>Figure 73: Import Node Files window</u> on page 258.



Figure 73: Import Node Files window

- 3. Enter the Embedded LAN (ELAN) network interface IP address of the Leader card in the box. This address is used to retrieve the node files.
- 4. Click Import.

If the node already exists on the Call Server, a message appears indicating that the node already exists on the Call Server.

If the node does not exist, Element Manager tries to write the configuration to the Call Server. If it succeeds, a message appears indicating the import was successful. If Element Manager cannot write the configuration to the Call Server, the reason appears in the text area of the Import Node Files window.

In the message box, click **OK** to proceed to the Node Summary window. The node information can then be viewed and, if necessary, edited.

If the node import is not successful, an error message appears in the box area.

# Changing the Node ID on an Existing CS 1000 System

#### **Background**

The IP Telephony nodes are pre-configured during software installation. The node configuration files - **BOOTP.TAB** and **CONFIG.INI**, are then imported into Element Manager for further configuration of the nodes.

The configuration files are copied on the Call Server in /u/db/node directory when the node configuration is saved.

The BOOTP.TAB file is saved as /u/db/node/nodexxxx. btpand the CONFIG.INI file is saved as /u/db/node/nodexxxx.cfg, where xxxx is the node ID:

- nodexxxx.btpis the BOOTP.TAB file
- nodexxxx.cfgis the CONFIG.INI

If a node is removed, the associated files are also removed. For every node that is created, a **nodeyyyy.btp** and **nodeyyyy.cfg** file are created in the/u/db/nodedirectory.

The other node files are:

- /u/db/node/node.pch. Node.pch is read on click at the Node Summary link in Element Manager.
- /u/db/node/nodexxxx.xml. Nodexxxx.xml is used to display the config in Element Manager.
   Nodexxxx.btp is converted into Nodexxxx.xml when editing a Node.

In order to change the Node ID on the system, changes need to be made in the bootp.tab configuration file. Follow the steps below.

Do not manually edit the node files. Manually editing these files can cause corruption of Element Manager.

# Procedure 28: Changing the Node ID on existing CS 1000 system Procedure

- In the Element Manager navigation pane, click IP Network > Nodes: Servers, Media Cards.
- 2. Select the node and click **Export**.
- 3. Delete the node from Element Manager.
- 4. Rename the exported xml file and update the file with the new Node ID.
- 5. In Element Manager, import the node from the xml file.

For information about importing a node, see Import node configuration from an existing node.

#### Related links

Import node configuration from an existing node on page 257

# **Chapter 13: IP Line administration**

### **Contents**

This chapter contains the following topics:

- Introduction on page 260
- IP Line feature administration on page 261
- Password security on page 265
- IP configuration commands on page 276
- TLAN network interface configuration commands on page 276
- Display the number of DSPs on page 277
- Display IP Telephony node properties on page 277
- Display Voice Gateway Media Card parameters on page 278
- Packet loss monitor on page 280
- Transfer files using the CLI on page 280
- Reset the Operational Measurements file on page 281

## Introduction

This chapter explains how to administer IP Line and the Voice Gateway Media Cards on the Avaya Communication Server 1000 (Avaya CS 1000) system.

Administration procedures include activities such as monitoring the system status, operational reports, performing upgrades, changing configuration, and adding, changing, and removing cards.

The Voice Gateway Media Card provides four administration interfaces:

Element Manager

Element Manager is a Web server that provides a GUI using a web browser. For information about supported browsers, see *Unified Communication Management Fundamentals*, *NN43001-116*. Element Manager is used to Telnet to the card, install and upgrade software and firmware, configure alarm event reporting, view and update card property and configuration data, add new cards to a node, schedule reports, and other related tasks.

IPL> and oam> Command Line Interface (CLI)

Use the CLI to display card and node status, change passwords, check channel states, and other card information. The CLI is also used for expert level support and debugging. The prompt for the CLI on the Media Card 32-port is IPL>. The prompt for the CLI on the Media Card 32S is oam>. Access the CLI through a direct serial connection to the I/O panel serial port, the Maint Port on the faceplate, or through a Telnet session. Use a VT-100 terminal emulation program set to 9600 baud, 8 bits, no parity, one stop bit.

Overlavs

## IP Line feature administration

#### **Corporate Directory**

LD 11 accepts Class of Service (CoS) CRPA/CRPD for IP Deskphones.



Corporate Directory is not supported on the IP Phone 2001P2, Avaya 2033 IP Conference Phone, Avaya 1210 IP Deskphone, and Avaya 1110 IP Deskphone.

Table 68: Corporate Directory: LD 11 configuration

Prompt	Response	Description
REQ	NEW CHG	Add new data or change existing data.
TYPE:	2001P2,	Enter terminal type.
	2002P1, 2002P2,	
	2004P1, 2004P2, 2050PC, 2050MC, 2033, 2007, 1110,	
	1210, 1220, 1230,1120, 1140, 1150, 1165, 2210, 2211, 2212	
TN	Iscu	Enter IP Phone TN.
CLS	CRPA CRPD	Enable or Disable the Corporate Directory feature for this TN.

The Call Server service change does not affect Corporate Directory immediately. If an IP Phone is in Corporate Directory mode, and there is a service change to configure CoS as CPRD, then the current display and key handling remain unaffected. The changed CoS occurs only when the user quits the Corporate Directory application and enters again.

# **Private Zone configuration**

DSP channels and IP Phones are Shared or Private based on zone configuration. Use the parameter zoneResourceType in the zone configuration commands in LD 117 to configure this setting.

The <zoneResourceType> parameter specifies the zone to be either shared or private.

A zone is configured in LD 117 as follows:

**NEW ZONE** <zoneNumber> [<intraZoneBandwidth> <intraZoneStrategy> <interZoneBandwidth> <interZoneStrategy>]

**CHG ZONE** <zoneNumber> [<intraZoneStrategy> <zoneResourceType>] [<intraZoneStrategy> <interZoneBandwidth> <interZoneStrategy> <zoneResourceType>]

By default, a zone is configured as Shared (zoneResourceType=shared).

#### **Virtual Office**

The IP Phone Virtual Office feature uses the Station Control Password (SCPW) feature. The SCPW password can be maintained either through LD 11 administration or by the user if Flexible Feature Code (FFC) code access is configured. If the SCPW is not configured for a TN registering by means of the Virtual Office feature, the logon is rejected. An error message appears to indicate to the user that a password must be configured.

Enable the SCPW in the Customer Data Block (CDB) by configuring the length of the SCPW (scpl). The SCPW must be at least four digits.

To logon using Virtual Office, the TN associated with the current IP Phone registration must be configured with the CoS VOLA (Virtual Office logon Allowed). The TN associated with the User ID for the logon must be configured with the CoS VOUA (Virtual Office User Allowed).

Two CoSs restrict Virtual Office usage:

- VOLA/VOLD: defines whether this TN (physical IP Phone) allows or disallows a Virtual Office logon option.
- VOUA/VOUD: defines if a specific remote user can log on to this TN (allows or disallows a particular user to logon using Virtual Office).

Table 69: LD 11 Virtual Office logon for IP Phones on page 262 shows the CoS for LD 11.

Table 69: LD 11 Virtual Office logon for IP Phones

Prompt	Responses	Description
REQ:	NEW CHG	Add new data or change existing data.
TYPE:	2001P2, 2002P1, 2002P2, 2004P1,	Enter terminal type.

Table continues...

Prompt	Responses	Description
2004P2, 2050PC, 2050MC, 2033, 2007, 1110, 1120, 1140, 1150, 1165, 1210, 1220, 1230, 2210, 2211, 2212, 6120, 6140		The system accepts this response if it is equipped with packages 88 and 170.  The IP Phone 2001, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone, Avaya 1210 IP Deskphone, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, IP Phone 2002, Avaya 2050 IP Softphone, and MVC 2050 are also restricted by the IP Phone License setting.
CUST	xx	Customer number as defined in LD 15.
CLS	(VOLA) VOLD	Virtual Office logon operation is allowed or denied on this TN.
CLS	(VOUA) VOUD	Allow/Deny Virtual Office user on this TN using other IP Phone.

## **Emergency Services Access while logged in to Virtual Office**

If an IP Phone user dials 911 while logged on to Virtual Office, the LTPS redirects the 911 call to the local area 911 service (PSAP), not the remote Call Server 911 service. <u>Table 70: e911 process for IP Phone logged on to Virtual Office</u> on page 263 describes the process.

Table 70: e911 process for IP Phone logged on to Virtual Office

Step	Description
1	The LTPS terminates the call on the remote Call Server.
2	The LTPS displays Emergency Call on the IP Phone.
3	The LTPS logs the IP Phone off Virtual Office.
4	The LTPS reconnects to the local Call Server.
5	The LTPS restarts the 911 call, thus reaching the correct PSAP.
	The extra processing adds 5 seconds to the call setup time.
6	After the emergency call ends, the IP Phone remains registered to the Home LTPS as a normal telephone, in case the PSAP calls back the originator of the emergency call.
	After the IP Phone is redirected to the Home Site, it cannot initiate a new operation for 5 minutes. This prevents the user from accidentally dialing the emergency DN and hanging up. In this case, the emergency response personnel might call back to confirm the accidental call (and thus confirm that no emergency exists). If the IP Phone immediately resumes a Virtual Office logon to another site, it cannot receive the call back.
	If the local TN has another IP Phone Virtual Office logged on when it comes back, the nonemergency IP Phone is pre-empted. If this occurs, ESAxxx messages are generated on the system TTY.

## **Emergency Services Access while logged off Virtual Office**

If an IP Phone user dials 911 while logged off Virtual Office, the LTPS redirects the 911 call to the local area 911 service (PSAP), not the remote Call Server 911 service. The Call Server is provisioned with Emergency Service Access Terminal Numbers (ESTN). The ESTN is used to

register the IP Phone with the Call Server. The logged out IP Phone can make ESA calls only. See Table 71: e911 process for IP Phone while logged out of Virtual Office on page 264.

Table 71: e911 process for IP Phone while logged out of Virtual Office

Step	Description			
1	The LTPS terminates the call on the remote Call Server.			
2	The LTPS displays Emergency Call Only on the IP Phone.			
3	The LTPS registers the IP Phone to the Call Server when the IP Phone goes off-hook, or when the Primary DN key, Handsfree key, or Headset key (IP Deskphone 1150E) are pressed. The Call Server allocates an ESTN and maps the ESTN key to the logged off IP Phone Primary DN.			
	A 60-second timer is created for the logged off IP Phone, which has an ESTN allocated. If the ESA number is not dialed before the time expires, the ESTN is released and the IP Phones returns to the original logged off state. The user must re-initiate the call.			
4	The LTPS starts the ESA call, thus reaching the correct PSAP.			
	The timer is reset to a preconfigured period of time (default 20 minutes) in case the PSAP calls back the originator of the emergency call.			
5	When the timer expires, the LTPS unregisters the IP Phone from the Call Server. The IP Phone returns to the original logged off state and the IP Phone ESTN becomes available for other ESA calls from any other logged off IP Phone.			

## Configuration

You must configure Emergency Services Access (ESA) on all nodes participating in Virtual Office logons. Enter the ESTN range in LD 24, and configure ESA in LD 11.

For more information, see *Emergency Services Access Fundamentals, NN43001-613* and *Branch Office Installation and Commissioning, NN43001-314* 

## 802.1Q

You can use the telephone user interface or DHCP to configure the 802.1Q support for IP Phones. Using DHCP eliminates the need to manually configure the VLAN ID as part of the installation. The configuration comprises two items: setting the p bits and setting the VLAN ID.

Element Manager has two fields for configuring 802.1Q support:

- 802.1Q Support: Select this check box to activate 802.1Q support. The priority bits value is specified in the 802.1Q Bits value box. If the check box is not selected, the IP Phone sends out the default priority of 6.
- 802.1Q Bits value (802.1p): Enter a value in the box. The range is 0 to 7.

For more information, see Configure Quality of Service on page 241.

# Password security

The following password security features should be configured to work with the IP Line application:

- SNMP community strings
- IPL> or oam> CLI Shell password
- Call Server Level 1 Password (PWD1)
- IP Phone Installer Password

The SNMP community strings are configured for the entire system. IPL> and oam> CLI Shell passwords and the Call Server Level 1 Password (PWD1) operate at the card level. The IP Phone Installer Password works at the node level.

- The SNMP community strings are configured on the Call Server and synchronized to all devices, including the Voice Gateway Media Cards.
- The IPL> and oam> CLI Shell password is synchronized with the PWD1.
- The Level 1 Passwords (PWD1) is set at the Call Server and is sent to all Voice Gateway Media Cards in the node.
- The IP Phone Installer Password is first applied to one Voice Gateway Media Card in the node and then is applied to all the Voice Gateway Media Cards in the node.

## **SNMP** community strings

SNMP community strings are required to access the Voice Gateway Media Card.

Element Manager is used to configure the community strings for CS 1000 systems.

# CLI Shell user name and password

The Command Line Interface (CLI) is password-protected to control Telnet access and access to the local maintenance port. The same user name and password also controls FTP access to the Voice Gateway Media Cards.

## Logon banner

The IP Line logon banner information includes the IP Line Voice Gateway Media Card loadware version, ELAN network interface IP address, card type, firmware version, current time and date, system name, system location, and system contact.

## Password guessing protection

Password guessing protection helps to block a hacker from attempting to log on to the Voice Gateway Media Card shell by repeatedly trying to guess the shell user ID and password.

The password guessing protection applies to either a tip session (direct maintenance portconnected TTY session) or a Telnet session.

The password guessing protection feature is described as follows:

- There is a logon failure threshold of three and a lockout period of 10 minutes. This is not userconfigurable.
- When the logon failure threshold is exceeded (by 3 consecutive failed logon attempts), the system raises an ITG1038 critical alarm. This alarm is sent to indicate the card logon has been locked due to too many incorrect password entries.

```
Alarm value = ITG alarm 38
perceivedSeverity = Critical
probableCause = Unauthorized maximum access attempts
Alarm text = IPL logon protection (logon locked)
```

When the 10 minute timer expires for the lockout period, the system raises an "ITG5038" cleared alarm. The clear message is sent after the lockout period expires.

```
perceivedSeverity = Cleared
probableCause = Unauthorized maximum access attempts
Alarm text = IPL logon protection (logon available)
```

- There is no online indication or warning during the failed logon attempt lockout state.
   Everything appears the same to the user trying to log on. The user is not informed that logon blocking was activated. The logon is ignored for 10 minutes.
  - Both the critical and cleared alarms are sent as SNMP traps to the system administrator. For security reasons, these two alarms do not call the syslog function as the other itgAlarms do, so no syslog message appears on the console or written in the syslog file.
- On the Voice Gateway Media Card, the faceplate displays GO38 (ITG1038) when the ITG1038 alarm is received because it is a critical alarm. The ITG5038 clears GO38 from the faceplate when the 10minute timer expires.

# Node password synchronization

The BOOTP.TAB and CONFIG.INI must be the same on all cards in the system. The cards that can be in the system are the Media Card 32-port line card, the MC 32S card, and the Signaling Server. To maintain a consistent configuration within the system, files are transferred from Leader 0 to the Follower cards using FTP.

For the FTP process to work correctly, all cards in a node must be synchronized with the same user ID and password. After the Voice Gateway Media Cards synchronize with the Call Server, the user logon synchronizes with the Call Server PWD1. The cards can then only be accessed by using the Call Server Level 1 Password (PWD1) user ID and password.

A card uses the user ID and password when it tries to access another card to send files using an FTP session. Sending data using an FTP session fails unless all the cards have the same user ID and password due to failed user authentication. Therefore, a unique user ID and password should be used within one system. Because most applications (except the NRS) communicate directly with

the Call Server, the Call Server Level 1 PWD1 user ID and password is the unique password among all platforms.

### Level 1 Password (PWD1)

The minimum password length on the Call Server is four characters. The minimum password on the Voice Gateway Media Card and the Signaling Server is eight characters.

For example, if the Call Server PWD1 is 0000, it is padded to the right with the four space characters to become 0000. You need not manually add the spaces.

### **Password Updates**

The Call Server PWD1 user ID and password is sent to all Voice Gateway Media Cards at the following times:

- when the Voice Gateway Media Cards initially establish a connection with the Call Server across the ELAN subnet
- when an EDD occurs on the Call Server

After the PWD1 information is downloaded from the Call Server, it is saved in the Voice Gateway Media Card NVRAM. If a Voice Gateway Media Card has not yet established a link with the ELAN subnet, the user ID and password that are currently stored in the card NVRAM are used to log on. The user ID and password might not match the PWD1 on the Call Server because the Call Server has not yet downloaded the current PWD1 to the Voice Gateway Media Card. After the ELAN subnet connection is established, the user ID and password are synchronized on all Voice Gateway Media Cards, and the new user ID and password are saved in the card NVRAM.

Because all Voice Gateway Media Cards automatically receive the user ID and password from the Call Server, the password can be changed in a single location, the Call Server CLI. This eliminates the need to change the password on every card in the node (change the password once on the Call Server). When the password changes at the Call Server, the password is automatically sent to all the Voice Gateway Media Cards.

If the PWD1 changes and an EDD operation does not occur, the cards can contain a mixture of old and new passwords. This can happen if a new card is plugged in, an existing card restarts or loses and reestablishes the ELAN subnet connection. Avaya recommends that you perform an EDD when the PWD1 password changes on the Call Server to ensure that all cards have the new PWD1 user ID and password.

For more information about the PWD1 Level 1 password, see the LD 17 Gate Opener PWD (Password) section in *Software Input Output — Administration, NN43001-611*.

#### IP Phone Installer Password

An IP Phone displays the node ID and Terminal Number (TN) of the IP Phone for five seconds as the IP Phone starts. Password protection controls who can change the TN on the IP Phone. The IP Phone Installer Password protection controls registration with a virtual line TN on the Call Server.

The IP Phone Installer Password can also be configured using the CLI commands in Element Manager. See Setting the IP Phone Installer Password on page 326.

For more information about password protection support on an IP Phone, see *Avaya IP Deskphone Fundamentals*, *NN43001-368*.

#### **Administrator IP Phone Installer Password**

The administrator password feature adds basic IP Phone Installer Password protection on the IP Phones to control registration with a virtual line TN on the Call Server. This feature does not provide a user password or a Station Control Password for IP Phones.

When the password is configured, the IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, Avaya 1165E IP Deskphone, or WLAN Handset 2210/2211/2212 and Avaya 6120/6140 WLAN Handsets screen shows the following information:

- The four-digit Node ID and a Password prompt instead of the Node ID and TN fields. For
  example, see <u>Figure 76: IP Phone registration with no password checking</u> on page 271 and
  Figure 77: IP Phone registration with password checking on page 272
- During password entry, an asterisk (\*) appears for each digit entered. The password does not appear.
- After the Node ID and Password are entered, the user presses OK. If the password passes the Connect Server authentication, a screen appears with the TN field. For example, see <u>Figure</u> 77: IP Phone registration with password checking on page 272

When the password is configured, the IP Phone 2001, IP Phone 2002, Avaya 2033 IP Conference Phone, Avaya 1110 IP Deskphone, Avaya 1210 IP Deskphone, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, and Avaya 1120E IP Deskphone screen shows:

- The four digit Node ID screen appears first. For example, see <u>Figure 75: IP Phone registration</u> with password checking on page 271.
- The user is then prompted with the Password screen instead of the TN field screen. For example, see <u>Figure 77: IP Phone registration with password checking</u> on page 272 and <u>Figure 74: IP Phone registration with no password checking</u> on page 270
- During password entry, an asterisk (\*) appears for each digit entered. The password does not appear.
- After the Password is entered, the user presses OK. If the password passes the Connect Server authentication, a screen appears with the TN field. For example, see <u>Figure 77: IP</u> <u>Phone registration with password checking on page 272.</u>

If the Node ID and Password are not entered, the registration continues after 5 seconds and the TN does not appear.

For an invalid Node ID password, the Node ID and Password screen appears again a maximum of two times to give the technician three chances to enter the password. After three failed attempts, the registration continues as if no password were entered. Restart the IP Phone and try again if more tries are needed.

If a zero length (null) password is entered, then the Node ID, TN, and Password screens do not appear on the IP Phone during the registration process. This provides maximum security by preventing entry of passwords or TN from the IP Phone.

## **Temporary IP Phone Installer Password**

A Temporary IP Phone Installer Password can be configured, which provides temporary user access to the TN for configuration.

A temporary password removes the need to distribute the Node password and then change the password afterwards. The temporary password is automatically deleted after it is used the defined number of times or when the duration expires, whichever comes first.

The following are examples of situations where the Temporary IP Phone Installer Password can be used:

- A department installs an Avaya 2050 IP Softphone. The technician creates a temporary
  password, configures an appropriate number of uses (such as allowing two logons for each IP
  Softphone 2050 in case a problem occurs the first time) and configures the duration to expire
  by the end of the weekend. The password access automatically ends before Monday morning
  (or sooner if the number of uses expires).
- A telecommuter must install an IP Phone. The technician provides the temporary password that expires the next day or after two uses. When the IP Phone Installer Password protection is enabled, the Set TN does not appear as part of the Set Info item on the Telephone Option menu. The IP Phone TN can be retrieved on the core CPU through the LD 20 PRT DNB and LD 32 IDU, or LD 80 TRAC, rlmShow.

### Registration screens with TN password feature

The IP Phone type and password protection determines the registration screen with the TN password feature.

For IP Phone 2001, IP Phone 2002, Avaya 2033 IP Conference Phone, Avaya 1210 IP Deskphone, Avaya 1220 IP Deskphone, Avaya 1230 IP Deskphone, Avaya 1120E IP Deskphone and Avaya 1110 IP Deskphone, see <a href="For IP Phones 2001/2002">For IP Phones 2001/2002</a>, and Avaya 2033/1210/1220/1230/1120E/1110 IP Deskphones on page 269

For IP Phone 2004, Avaya 2007 IP Deskphone, Avaya 1140E IP Deskphone, Avaya 1150E IP Deskphone, Avaya 1165E IP Deskphone, WLAN Handset 2210/2211/2212, and Avaya 6120/6140 WLAN Handsets, see IP Phone 2004, Avaya 2007/1140E/1150E/1165E IP Deskphones, WLAN Handset 2210/2211/2212, and Avaya 6120/6140 WLAN Handset on page 271

#### For IP Phones 2001/2002, and Avaya 2033/1210/1220/1230/1120E/1110 IP Deskphones

When you do not configure or enable password protection, the Password entry does not appear. The IP Phone displays the Node ID and TN. See <u>Figure 74: IP Phone registration with no password checking</u> on page 270.




Figure 74: IP Phone registration with no password checking

When you configure and enable password protection, the IP Phone displays the Node ID and password. The Password entry input field is blank (underscores do not appear). Therefore, the maximum length of the password is hidden. If you enter the correct password, the TN appears. See Figure 75: IP Phone registration with password checking on page 271.

Page 1:			
Node:			
ок	BKSpace	Clear	Cancel
Page 2:			
Password:			
ок	BKSpace	Clear	Cancel
Page 3:			
TN:			
ок	BKSpace	Clear	Cancel

Figure 75: IP Phone registration with password checking

# IP Phone 2004, Avaya 2007/1140E/1150E/1165E IP Deskphones, WLAN Handset 2210/2211/2212, and Avaya 6120/6140 WLAN Handset

When you do not configure or enable password protection, the Password entry does not appear. The IP Phone displays the Node ID and TN. See <u>Figure 76: IP Phone registration with no password checking</u> on page 271.

0	בי	a	Δ	1	
•	u	ч	•	•	٠

Node: TN:				
ок	BKSpace	Clear	Cancel	

Figure 76: IP Phone registration with no password checking

When you configure and enable password protection, the IP Phone displays the Node ID and password. The Password entry input field is blank (underscores are do not appear). Therefore, the maximum length of the password is hidden. If you enter the correct password, the TN appears. See Figure 77: IP Phone registration with password checking on page 272.




Figure 77: IP Phone registration with password checking

## **Configure the IP Phone Installer Passwords**

The IP Phone Installer Passwords are configured on a Signaling Server in the node. The passwords then apply to all Signaling Servers in the node.

If the IP Phone Installer Password is configured on the Signaling Server, the IP Phone Telephone Options, Diagnostics submenu is locked and the Set Info submenu does not display the Set IP Information or Ethernet Information options.

#### Administrative IP Phone Installer Password

The Administrative IP Phone Installer Password is used by the administrator to install a new IP Phone or change the configuration (node ID and TN) of an existing IP Phone.

To configure the Administrative IP Phone Installer Password, perform the steps in <u>Configuring the Administrative IP Phone Installer Password</u> on page 272.

#### Configuring the Administrative IP Phone Installer Password

- 1. Log on to a Signaling Server using the SecurityAdmin credentials.
- 2. In the Linux shell type the nodePwdShow command. This command displays the settings of the IP Phone Installer (node) password.

If in the default state, the IP Phone Installer Password was never assigned. The nodePwdShow command displays the following:

 NodeID – the IP Phone Installer Password configuration applies to all Signaling Servers on the same TLAN that belong to this Node ID.

- PwdEna by default the cards should be in disabled state (PwdEna=No). The PwdEna setting specifies the enabled (Yes) or disabled (No) state of the IP Phone Installer Password.
- Pwd this is the Administrator IP Phone Installer Password. In the default state, the Administrator password is null (zero-length).
- TmpPwd this is the temporary IP Phone Installer Password. In the default state, the temporary password is null.
- Uses the Uses parameter applies to the temporary IP Phone Installer Password. In the default state, this setting is null. If the card is not in the default state, the Uses parameter is a numeric value from 0 –1000. This number specifies the remaining number of uses for the temporary password. If zero is entered for the Uses parameter when setting the temporary password, the Time parameter is mandatory. When the Time parameter is in effect, the password expiration is based on time instead of the number of uses.
- Timeout the Timeout heading corresponds to the Time parameter of the temporary IP Phone Installer Password. In the default state, the Time is null. If the card is not in the default state, this setting specifies the duration in hours in which the temporary password is valid. The range is 0 – 240 hours (which is a maximum of 10 days). The number specified under Timeout indicates the remaining time to expire of the temporary password. The Time parameter is optional if the Uses parameter is non-zero. The Time parameter is mandatory if the Uses parameter is set to zero.

If both the Uses and Time parameters are entered, the password expires based on whichever happens first: the number of Uses becomes zero or the Time expires. If both the Uses and Time parameters are entered and are set to zero, it is the same as not configuring the temporary password.

Configure the Administrator IP Phone Installer Password.

The nodePwdSet <"password"> command enables and configures the administrator password. The <password> parameter can be null, or 6 to 14 digits in length. The valid characters are 0 to 9, asterisk (\*), and number sign (#). This command can be entered at any time. The new password overwrites the previous password.

Configure the password, first with a null password and then with a password specified.



#### 🛕 Warning:

By default, thenodePwdSet command with no parameter enables the administrator password and assigns a null (zero-length) password.

IP Phones cannot be installed if the administrator password is enabled and set to null.

Always specify the password parameter to install IPPhones.

4. Type nodePwdSet at the prompt to specify no password parameter.

Type nodePwdShow to see the following:

```
NodeID PwdEna Pwd
           TmpPwd Uses
====== 123 No
                       0d 0h 0m 0s
```

PwdEna: the password is now enabled (PwdEna=Yes).

Pwd: if you specify no <"password"> parameter, the administrator password is null. A null password causes the node ID and Password screen to be skipped during a restart.

5. Type nodePwdSet <"password"> at the prompt; the password parameter is 6 to 14 digits in length.

The valid character are 0 to 9, asterisk (\*), and number sign (#). For this example, use 1234567 as the password.

6. Type nodePwdShow to see the following:

NodeI	D PwdEna	Pwd	TmpPwd	Uses	Tin	neout
		=======	======	====	===	
123	No	1234567				od Oh Om Os

PwdEna: the administrator password is enabled (PwdEna=Yes).

Pwd: the administrator password, 1234567, appears.

Always specify the <password> parameter when you enter the nodePwdSet command.

The nodePwdEnable and nodePwdDisable commands enable and disable the administrative IP Phone Installer Password, respectively.

#### **Temporary IP Phone Installer Password**

A temporary IP Phone Installer Password can be configured. This enables temporary user access to the TN for configuration. A temporary password removes the need to distribute the administrative (node) password and the need to change it afterwards. If there is a null administrator password configured and a temporary password is created, the temporary password overrides the null administrative password.

The syntax for temporary IP Phone Installer Password specifies

- the password
- the number of times that the password can be entered
- · the time that the password is valid

To configure a temporary IP Phone Installer Password, perform the steps in Configuring the temporary IP Phone Installer Password on page 274.

#### Configuring the temporary IP Phone Installer Password

1. At the Linux shell, type nodeTempPwdSet <"password">, <uses>, <time>; password is the temporary password string 6 to 14 digits in length, uses is a value from 0 to 1000, and time is from 0 to 240 hours.

For example, nodeTempPwdSet 987654, 15, 3

2. Type nodePwdShow to see the following:

NodeID	PwdEna	Pwd	TmpPwd	Uses	Timeout	=====	======	=======	
======	======	========	= 123	No	12345	67 987	654 15	0d	
0h 0m 0s									

The temporary password is automatically deleted after it is used the defined number of times (Uses) or when the duration expires (Timeout), whichever comes first. To delete the temporary password before the number of uses or time expires, type the nodeTempPwdClear command at the prompt.

3. Type nodePwdShow to verify that the temporary password is deleted.

NodeID	PwdEna	Pwd	TmpPwd	Uses	Timeout	=====	 ======	
	======	========	= 123	No	12345	567	0d	
0h 0m 0s								

## Default user name and password

The IPL> CLI has a default user name of admin1 and a default password of 0000. The default user name and password will be changed as a preventative security measure to PWD1 after synchronization with the Call Server.

#### Reset the CLI Shell user name and password

If the authorized system management personnel do not have the current IPL> CLI Shell user name and password, reset the user name and password to the default (admin1 and 0000).

To reset the IPL> CLI shell user name and password, perform the steps in Resetting the user name and password to default on page 275. This procedure requires a connection to the local maintenance port on the Voice Gateway Media Card and requires restarting the card, which interrupts services.

#### Resetting the user name and password to default

- 1. Connect a terminal to the Maintenance port (labeled Maint) either directly or through a dialup modem. The terminal communication parameters must be as follows:
  - 9600 bps
  - 8 data bits
  - no parity
  - 1 stop bit
- 2. Press the Enter key on the keyboard.

The logon: prompt appears.



#### **Marning:**

Do not use a pencil to reset the Voice Gateway Media Card. The graphite carbon can create an electrical short circuit on the board.

- 3. Restart the card by pressing the RESET button on the faceplate of the card with a pointed object, such as a ball-point pen.
- 4. Start up messages are displayed on the terminal. Type jkl on the terminal keyboard when the prompt appears.
  - jk1 runs from BIOS or the boot ROM, which is printed early in the bootup process. You have 6 seconds to enter jkl at the prompt. If the prompt is missed, restart the card and repeat the above step.
- 5. After the card restarts from BIOS or boot ROM, a CLI prompt such as the BIOS> appears. Enter the following command:

shellPasswordNvramClear at the prompt.

- 6. Type reboot at the prompt to restart the card.
- 7. Wait for the card to completely restart into the IP Line application. The password synchronization feature automatically changes the password on the card.

# IP configuration commands

Table 72: IP configuration commands on page 276 describes the IP configuration commands.

**Table 72: IP configuration commands** 

IP configuration command	Function
setLeader	Performs all the necessary actions to configure a Leader. Sets IP address, gateway, subnet mask, boot method to static, and Leader bit in NVRAM.
clearLeader	Clears the Leader info in NVRAM and sets the boot method to use BOOTP, thus, making the card a Follower.
NVRIPShow	Prints the values of the IP parameters that reside in NVRAM.

For more information about commands, see *Software Input Output Reference — Maintenance*, *NN43001-711*.

# **TLAN** network interface configuration commands

Autonegotiate mode can be disabled if the ports on some data network switches, and routers are manually configured. For example, configuring a port for 100BaseT full-duplex can disable autonegotiation on the signaling link.

The IP Phones default to half-duplex mode when no autonegotiation signaling occurs. The result is that the IP Phones operate in half-duplex mode, while the switch is in full-duplex mode. Communication continues, but random packet loss can occur which affects the correct operation and voice quality.

## Important:

Configure ports for autonegotiation and autosense.

Configure the speed and duplex setting of the TLAN network interface using the following commands:

tLanSpeedSet speed: this command configures the speed of the TLAN network interface. By
default, the network interface autonegotiates to the highest speed supported by the switch. If
the switch is 10/100BaseT, the network interface negotiates to 100BaseT. Use this command

to debug Ethernet speed-related problems by forcing the network interface to 10BaseT operation immediately. The duplex mode setting is saved in NVRAM and read at startup. The parameter speed is set to the following:

- 10: disables autonegotiation and sets speed to 10 Mb/s 10100 enables autonegotiation
- tLanDuplexSet duplexMode: this command immediately configures the duplex mode of the TLAN network interface while operating when autonegotiate is disabled and the speed is fixed to 10 Mb/s (or 10BaseT mode). The duplex mode is saved in NVRAM and read at startup. The parameter duplexMode is set to the following:
  - 0: enables full-duplex mode 1: enables half-duplex mode

If the autonegotiation is disabled, and the speed and duplex mode are forced using the CLI commands, Avaya recommends that half-duplex mode be used to interoperate with the far end when the far end is set to autonegotiate.

If the duplex mode is configured as full-duplex, the far end must be configured as full-duplex and autonegotiate must be turned off.

Half-duplex mode works with either half-duplex or autonegotiate at the far end. However, full-duplex at the near end operates only with full-duplex at the far end.

# Display the number of DSPs

The DSPNumShow command displays the number of DSPs on the Voice Gateway Media Card.

At the IPL> or the oam> prompt, type: DSPNumShow.

# **Display IP Telephony node properties**

The IPInfoShow command displays information about an IP Telephony node.

At the prompt, type: IPInfoShow

The following IP Telephony node information appears on the TTY:

- IP addresses for the ELAN and TLAN subnets
- · default router for the ELAN and TLAN subnets
- subnet mask for the ELAN and TLAN subnets
- IP routing table
- IP configuration of the card (which is related to the IP configuration of the node)

The IPInfoShow command displays information similar to the following:

Maintenance Interface = lnIsa0

```
Maintenance IP address = 47.103.220.199

Maintenance subnet mask = 255.255.255.224

Voice Interface = lnPcil

Voice IP address = 47.103.247.221

Voice subnet mask = 255.255.255.0
```

#### **Table 73: ROUTE NET TABLE**

destination	gateway	flags	Refcnt	Use	Interface
0.0.0.0	47.103.247.1	3	7	5800883	lnPci1
47.103.220.192	47.103.220.199	101	0	0	lnIsa0
47.103.247.0	47.103.247.221	101	0	0	lnPci1
47.103.247.0	47.103.247.221	101	0	0	lnPci1

#### **Table 74: ROUTE HOST TABLE**

destination	gateway	flags	Refcnt	Use	Interface
127.0.0.1	127.0.0.1	5	0	0	100

value = 77 = 0x4d = M

# **Display Voice Gateway Media Card parameters**

The following commands provide information about a Voice Gateway Media Card:

- itgCardShow
- ifShow
- serialNumShow
- · firmwareVersionShow
- swVersionShow

#### itgCardShow

The itgCardShow command displays information about a Voice Gateway Media Card.

At the IPL> or oam> prompt, type: itgCardShow

The itgCardShow command displays information similar to the following:

Index: 1
Type : EXUT
Role : Leader
Node : 123

Leader IP: 47.103.247.220

```
Card IP: 47.103.247.221
Card TN: 44 0 10
Card State: ENBL
Uptime: 1 days, 19 hours, 43 mins, 11 secs (157391 secs)
Codecs: G711Ulaw(default), G711Alaw, G729AB
lnPci stat: 100 Mb/s (Carrier OK)
value = 1 = 0x1
```

#### **Registered Cards**

The following information appears for each card currently registered:

- platform
- TN
- ELAN network interface MAC
- TLAN network interface IP Address
- ELAN network interface IP Address
- · the length of time the card has been registered
- · the number of IP Phones registered to the card
- number of Time Outs

#### **Unregistered Cards**

The following information appears for each card currently not yet registered based on BOOTP.TAB:

- platform
- TN
- · ELAN network interface MAC
- TLAN network interface IP Address
- ELAN network interface IP Address

#### **Example**

The following is an example of the output on a Signaling Server:

```
electShow
Node ID: 678
Node Master : Yes
UpTime: 1 days, 3 hours, 1 mins, 58 secs
TN: 00 00
Host Type : ISP1100
IP TLAN : 47.11.215.55
IP ELAN: 47.11.216.139
Election Duration: 15
Wait for Result time : 35
Master Broadcast period: 30
=====master tps =====
Host Type TN TLAN IP Addr
ISP 1100 00 00 47.11.215.55
Next timeout : 3 sec
AutoAnnounce: 1
Timer duration: 60 (Next timeoutin 17 sec)
===== all tps ==
Num TN Host Type ELAN MAC TLAN IP
Addr ELAN IP Addr Up Time NumOfSets TimeOut
001 00 00 ISP 1100 00:02:B3:C5:50:C2 47.11.215.55 47.11.216.139 001 03:01:58 5 0
```

```
====== Cards in node configuration
that are not registered ======
Num TN Host Type ELAN MAC TLAN IP AddrELAN IP Addr
001 7 0 SMC 00:60:38:BD:C1:C1 47.11.215.54 47.11.216.49
value = 27886252 = 0x1a982ac
```

When all cards configured in a node are registered, the last part of the output displays the following:

```
===== All cards in node configuration are registered ======
```

### **Packet loss monitor**

Monitor audio packet loss using the following commands:

- vgwPLLog 0|1|2: enables the packet loss monitor. Packet loss is measured in the receive direction and the two halves of a call are monitored and logged independently. This command is not available on the MC 32S card.
  - A value of zero (0) disables packet loss logging.
  - A value of one (1, the default) logs a message if packet loss during the call exceeds the threshold set with the itgPLThreshold command.
  - A value of two (2) indicates that log messages are printed as packet loss is detected during the call. A message is printed each time packet loss is detected indicating how many packets were lost at that moment.
- itgPLThreshold xxx this command sets the packet loss logging and alarm threshold, where xxx is a number from 1 to 1000, and represents the threshold in 0.1percent increments. Packet loss that exceeds the threshold generates an SNMP trap and writes a message to the log file if logging is enabled. The default value is 10 (1percent).

# Transfer files using the CLI

A number of special file transfer commands are available to Put and Get files from the IPL> CLI or oam> CLI. These commands are normally used as part of an expert support procedure if Element Manager is not available.

The commands in <u>Table 75: File transfer</u> on page 281, are for the Voice Gateway Media Card. If Get is part of the command, the file is transferred from the server to the Voice Gateway Media Card. If Put is part of the command, the file is transferred from the Voice Gateway Media Card to the external FTP Server.

The commands in Table 76: File transfer for the MC 32S card on page 281 are for the MC 32S card.

Table 75: File transfer

Command	Parameters
swDownload	<hostname> <username> <password> <directory path=""> <file name=""></file></directory></password></username></hostname>
configFileGet	<hostname> <username> <password> <directory path=""> <file name=""></file></directory></password></username></hostname>
bootPFileGet	<hostname> <username> <password> <directory path=""> <file name=""></file></directory></password></username></hostname>
hostFileGet	<hostname> <username> <password> <directory path=""> <file name=""> <itgfile name=""> <listener></listener></itgfile></file></directory></password></username></hostname>
bootPFilePut	<hostname> <username> <password> <directory path=""> <file name=""></file></directory></password></username></hostname>
currOMFilePut	<hostname> <username> <password> <directory path=""> <file name=""></file></directory></password></username></hostname>
prevOMFilePut	<hostname> <username> <password> <directory path=""> <file name=""></file></directory></password></username></hostname>
logFilePut	<hostname> <username> <password> <directory path=""> <file name=""></file></directory></password></username></hostname>
configFilePut	<hostname> <username> <password> <directory path=""> <file name=""></file></directory></password></username></hostname>
hostFilePut	<hostname> <username> <password> <directory path=""> <file name=""> <itgfile name=""></itgfile></file></directory></password></username></hostname>

Table 76: File transfer for the MC 32S card

swDownload	swDownload [host user passwd dir file name]
configFileGet	spcPkgconfigFileGet [host user passwd hostDirPath hostfile name]
bootPFileGet	bootPFileGet [host user passwd hostDirPath hostfile name]
hostFileGet	hostFileGet [ftype listener host user passwd hostDirPath hostfile name loc alDirPath localfile name]
bootPFilePut	bootPFilePut [host user passwd hostDirPath hostfile name]
currOMFilePut	omFilePut [host user passwd hostDirPath hostfile name]
prevOMFilePut	prevOMFilePut [host user passwd hostDirPath hostfile name]
hostFilePut	hostFilePut [ftype listener host user passwd hostDirPath hostfile name loca IDirPath localfile name]

All commands are case-sensitive. The parameters after the command must each be enclosed in quotation marks, and between parameters must be a comma with no spaces.

Host name refers to any of the following:

- the IP address of the FTP host
- the Voice Gateway Media Card itself (use loopback address 127.0.0.1)
- · another Voice Gateway Media Card

# **Reset the Operational Measurements file**

Reset the Operational Measurements (OM) file if incorrect statistics are collected.

At the IPL> or oam> prompt, type: resetOM.

The resetOM command resets all operational measurement parameters that are collected since the last log dump. The statistics start from zero.

# Chapter 14: IP Line administration using Element Manager

## **Contents**

This section contains the following topics:

- Introduction on page 260
- <u>Element Manager administration procedures</u> on page 283
- Backup and restore data on page 313
- <u>Update IP Telephony node properties</u> on page 315
- Update other node properties on page 323
- Telnet to a Voice Gateway Media Card using Virtual Terminal on page 324
- Check the Voice Gateway Channels on page 326
- Setting the IP Phone Installer Password on page 326

## Introduction

This chapter explains how to administer IP Line and the Voice Gateway Media Card on Avaya Communication Server 1000 (Avaya CS 1000) systems using by Element Manager.

# **Element Manager administration procedures**

This section describes the administration procedures that can be performed by using Element Manager.

# Turn off browser caching

Internet Explorer caching interferes with the Element Manager application, in that users cannot see real-time changes as they occur. For this reason, Avaya recommends that you turn off Internet Explorer caching before you use Element Manager.

Perform the steps in <u>Configuring the Internet Explorer browser</u> on page 191 to turn of caching in the Internet Explorer browser.

# IP Line Operational Measurement report scheduling and generation

Operational Measurement (OM) reports provide important statistical and traffic information and feedback to the system administrator to better engineer the system. The information stored in the OM file applies only to the calls routed over the IP network by way of IP Line. OM reports give a quantitative view of system performance, such as jitter.

A single Voice Gateway Media Card Operational Measurements file can be viewed from Element Manager. This OM report is a view of the LTPS and Voice Gateway channel activity on the card. Use this procedure to view the card information for each Voice Gateway Media Card in the node.

The Voice Gateway Media Card OM file contains the following information:

- the number of incoming and outgoing calls
- · the number of call attempts
- the number of calls completed
- the total holding time for voice calls

To view a Voice Gateway Media Card OM file from Element Manager, perform the steps in Retrieving the current OM file from the Voice Gateway Media Card using Element Manager on page 284.

# Retrieving the current OM file from the Voice Gateway Media Card using Element Manager

- 1. In the Element Manager navigator, select IP Network > Maintenance and Reports.
  - The **Node Maintenance and Reports** window appears.
- 2. Expand the node containing the Voice Gateway Media Card by clicking the plus sign (+) to the left of the Node ID.
  - See Figure 78: Node Maintenance and Reports window on page 285.



Figure 78: Node Maintenance and Reports window

3. Click OM RPT associated with the Voice Gateway Media Card.

The View OM File window appears. See Figure 79: View OM File window on page 285.




Figure 79: View OM File window

The eight most recent OM Report files appear in chronological order for that Voice Gateway Media Card.

4. To view a OM file, select the file to view and then click View OM File.

The OM report data appears at the bottom of the window.

# **Collection period**

The file contains collection period information for each hour of the day that the card ran.

The collection periods start with the hour from midnight to 1:00 a.m. As each hour passes, a collection period is added to the OM file; therefore, a maximum of 24 collection periods are available each day.

# **Output**

The OM report output tracks the statistics for each IP Phone type.

Data is first written for the IP Phones followed by the data for the gateway channels.

# **Output example**

An example of a single-hour OM report is as follows:

```
collection time : 11/7/2006 2:00
2004Reg_Att: 0
2004Reg_Fail: 0
2004Unreg_Att: 0
2004Aud Setup: 0
2004Jitter Avg: 0.0
2004Jitter_Max: 0
2004Latency_Avg: 0.0
2004Latency_Max: 0
2004Pkt Lost: 0.00
2004Listen RFactor: 0.0
2004Voice Time: 0 mins 0 secs
2002Reg_Att: 0
2002Reg Fail: 0
2002Unreg_Att: 0
2002Aud Setup: 0
2002Jitter Avg: 0.0
2002Jitter_Max: 0
2002Latency_Avg: 0.0
2002Latency_Max: 0
2002Pkt Lost: 0.00
2002Listen RFactor: 0.0
2002Voice_Time: 0 mins 0 secs
2001Reg Att: 0
2001Reg_Fail: 0
2001Unreg_Att: 0
2001Aud Setup: 0
2001Jitter_Avg: 0.0
2001Jitter_Max: 0
2001Latency_Avg: 0.0
2001Latency Max: 0
2001Pkt_Lost: 0.00
2001Listen_RFactor: 0.0
2001Voice_Time: 0 mins 0 secs
1150Reg Att: 0
1150Unreg_Att: 0
1150Aud Setup: 0
1150Jitter_Avg: 0.0
1150Jitter_Max: 0
1150Latency_Avg: 0.0
1150Latency_Max: 0
1150Pkt Lost: 0.00
1150Listen RFactor: 0.0
1150Voice_Time: 0 mins 0 secs
1130Reg Att: 0
1130Reg Fail: 0
1130Unreg Att: 0
```

```
1130Aud Setup: 0
1130Jitter_Avg: 0.0
1130Jitter_Max: 0
1130Latency_Avg: 0.0
1130Latency_Max: 0
1130Pkt Lost: 0.00
1130Listen RFactor: 0.0
1130Voice_Time: 0 mins 0 secs 2004P2Reg_Att: 0
2004P2Reg Fail: 0
2004P2Unreg Att: 0
2004P2Aud_Setup: 0
2004P2Jitter_Avg: 0.0
2004P2Jitter Max: 0
2004P2Latency_Avg: 0.0
2004P2Latency Max: 0
2004P2Pkt Lost: 0.00
2004P2Listen RFactor: 0.0
2004P2Voice_Time: 0 mins 0 secs
2002P2Reg Att: 0
2002P2Reg Fail: 0
2002P2Unreg Att: 0
2002P2Aud_Setup: 0
2002P2Jitter Avg: 0.0
2002P2Jitter Max: 0
2002P2Latency_Avg: 0.0
2002P2Latency Max: 0
2002P2Pkt Lost: 0.00
2002P2Listen RFactor: 0.0
2002P2Voice Time: 0 mins 0 secs
2033Reg Att: 0
2033Reg Fail: 0
2033Unreg Att: 0
2033Aud Setup: 0
2033Jitter Avg: 0.0
2033Jitter Max: 0
2033Latency Avg: 0.0
2033Latency_Max: 0
2033Pkt Lost: 0.00
2033Listen RFactor: 0.0
2033Voice \overline{\text{T}}ime: 0 mins 0 secs
2050Reg_Att: 0
2050Reg_Fail: 0
2050Unreg_Att: 0
2050Aud Setup: 0
2050Jitter_Avg: 0.0
2050Jitter Max: 0
2050Latency Avg: 0.0
2050Latency_Max: 0
2050Pkt Lost: 0.00
2050Voice Time: 0 mins 0 secs
2210Reg Att: 0
2210Reg Fail: 0
2210Unreg_Att: 0
2210Aud Setup: 0
2210Jitter Avg: 0.0
2210Jitter Max: 0
2210Latency_Avg: 0.0
2210Latency_Max: 0
2210Pkt Lost: 0.00
2210Listen RFactor: 0.0
2210Voice \overline{\text{Time}}: 0 mins 0 secs
1120Reg Att: 0
1120Reg_Fail: 0
1120Unreg Att: 0
```

```
1120Aud Setup: 0
1120Jitter_Avg: 0.0
1120Jitter_Max: 0
1120Latency_Avg: 0.0
1120Latency_Max: 0
1120Pkt Lost: 0.00
1120Listen RFactor: 0.0
1120Voice_Time: 0 mins 0 secs
1110Reg Att: 0
1110Reg Fail: 0
1110Unreg Att: 0
1110Aud Setup: 0
1110Jitter_Avg: 0.0
1110Jitter Max: 0
1110Latency_Avg: 0.0
1110Latency Max: 0
1110Pkt Lost: 0.00
1110Listen RFactor: 0.0
1110Voice_Time: 0 mins 0 secs 2050MCReg_Att: 0
2050MCReg Fail: 0
2050MCUnreg_Att: 0
2050MCAud_Setup: 0
2050MCJitter Avg: 0.0
2050MCJitter Max: 0
2050MCLatency_Avg: 0.0
2050MCLatency Max: 0
2050MCPkt Lost: 0.00
2050MCVoice Time: 0 mins 0 secs
2211Reg_Att: 0
2211Reg_Fail: 0
2210Unreg Att: 0
2211Aud Setup: 0
2211Jitter_Avg: 0.0
2211Jitter Max: 0
2211Latency_Avg: 0.0
2211Latency Max: 0
2211Pkt Lost: 0.00
2211Listen RFactor: 0.0
2211Voice Time: 0 mins 0 secs
1160Reg Att: 0
1160Reg Fail: 0
1160Unreg Att: 0
1160Aud Setup: 0
1160Jitter Avg: 0.0
1160Jitter Max: 0
1160Latency_Avg: 0.0
1160Latency Max: 0
1160Pkt Lost: 0.00
1160Listen_RFactor: 0.0
1160Voice \overline{\text{T}}ime: 0 mins 0 secs
2212Reg Att: 0
2212Reg Fail: 0
2212Unreg_Att: 0
2212Aud Setup: 0
2212Jitter Avg: 0.0
2212Jitter Max: 0
2212Latency_Avg: 0.0
2212Latency Max: 0
2212Pkt Lost: 0.00
2212Listen RFactor: 0.0
2212Voice Time: 0 mins 0 secs
2007Reg Att: 0
2007Reg_Fail: 0
2007Unreg Att: 0
```

```
2007Aud Setup: 0
2007Jitter_Avg: 0.0
2007Jitter_Max: 0
2007Latency_Avg: 0.0
2007Latency_Max: 0
2007Pkt Lost: 0.00
2007Listen RFactor: 0.0
2007Voice_Time: 0 mins 0 secs
1140Reg Att: 0
1140Reg Fail: 0
1140Unreg Att: 0
1140Aud Setup: 0
1140Jitter_Avg: 0.0
1140Jitter_Max: 0
1140Latency_Avg: 0.0
1140Latency Max: 0
1140Pkt Lost: 0.00
1140Listen RFactor: 0.0
1140Voice_Time: 0 mins 0 secs
1145Reg Att: 0
1145Reg Fail: 0
1145Unreg Att: 0
1145Aud_Setup: 0
1145Jitter_Avg: 0.0
1145Jitter_Max: 0
1145Latency_Avg: 0.0
1145Latency Max: 0
1145Pkt Lost: 0.00
1145Listen RFactor: 0.0
1145Voice Time: 0 mins 0 secs
1210Reg_Att: 0
1210Reg Fail: 0
1210Unreg Att: 0
1210Aud_Setup: 0
1210Jitter Avg: 0.0
1210Latency_Avg: 0.0
1210Jitter Max: 0
1210Latency_Max: 0
1210Pkt_Lost: 0.00
1210Listen RFactor: 0.0
1210Voice \overline{\text{T}}ime: 0 mins 0 secs
1220Reg_Att: 0
1220Reg_Fail: 0
1220Unreg_Att: 0
1220Aud Setup: 0
1220Jitter_Avg: 0.0
1220Latency Avg: 0.0
1220Jitter \overline{M}ax: 0
1220Latency Max: 0
1220Pkt Lost: 0.00
1220Listen RFactor: 0.0
1220Voice Time: 0 mins 0 secs
1230Reg Att: 0
1230Reg_Fail: 0
1230Unreg Att: 0
1230Aud Setup: 0
1230Jitter Avg: 0.0
1230Latency_Avg: 0.0
1230Jitter_Max: 0
1230Latency_Max: 0
1230Pkt Lost: 0.00
1230Listen RFactor: 0.0
1230Voice Time: 0 mins 0 secs
ChanAud Setup: 0
ChanJitter_Avg: 0.0
```

```
ChanJitter Max: 0
ChanPkt Lost: 0.00
ChanVoice Time: 0 mins 0 secs
H323VtrkInVoCallAttempt: 0
H323VtrkInVoCallComp: 0
H323VtrkOutVoCallAttempt: 0
H323VtrkOutVoCallComp: 0
H323VtrkTotalVoiceTime: 0 mins 0 secs
H323VtrkInFaxCallAttempt: 0
H323VtrkInFaxCallComp: 0
H323VtrkOutFaxCallAttempt: 0
H323VtrkOutFaxCallComp: 0
H323VtrkFallBack: 0
H323VtrkQoSFallBack: 0
H323VtrkATPMFallBack: 0
H323VtrkRelCompFallBack: 0
SIPVtrkInVoCallAttempt: 0
SIPVtrkInVoCallComp: 0
SIPVtrkOutVoCallAttempt: 0
SIPVtrkOutVoCallComp: 0
SIPVtrkTotalVoiceTime: 0 mins 0 secs
SIPVtrkInFaxCallAttempt: 0
SIPVtrkInFaxCallComp: 0
SIPVtrkOutFaxCallAttempt: 0
SIPVtrkOutFaxCallComp: 0
SIPVtrkFallBack: 0
SIPVtrkQoSFallBack: 0
SIPVtrkATPMFallBack: 0
SIPVtrkRelCompFallBack: 0
SIPVtrkTLSAuthenticationFailure: 0
SIPVtrkTLSIncomingAttempt: 0
SIPVtrkTLSIncomingComp: 0
SIPVtrkTLSIncomingFailure: 0
SIPVtrkTLSOutgoingAttempt: 0
SIPVtrkTLSOutgoingComp: 0
SIPVtrkTLSOutgoingFailure: 0
OutTotalH323OvlCallCount: 0
OutSuccessH323OvlCallCount:0
OutOv12EnblocCallCount: 0
InTotalH323OvlCallCount:0
InSuccessH323OvlCallCount: 0
TotalARQGenerated:0
TotalARJRcvd: 0
TotalACFRcvd:0
H323NrsGatekeeperReq: 0
H323NrsGatekeeperConf: 0
H323NrsGatekeeperRej: 0
H323NrsRegistrationReg: 144
H323NrsRegistrationConf: 144
H323NrsRegistrationRej: 0
H323NrsUnregistrationReqRecd: 0
H323NrsUnregistrationConfSent: 0
H323NrsUnregistrationRejSent: 0
H323NrsAdmissionReq: 0
H323NrsAdmissionConf: 0
H323NrsAdmissionRej: 0
H323NrsLocationRegRecd: 0
H323NrsLocationConfSent: 0
H323NrsLocationRejSent: 0
H323NrsBandwidthRegRecd: 0
H323NrsBandwidthConfSent: 0
H323NrsBandwidthRejSent: 0
H323NrsDisengageReq: 0
H323NrsDisengageConf: 0
H323NrsDisengageRej: 0
```

```
SIPNrsRoutingAttempts: 0
SIPNrsRoutingSuccesses: 0
SIPNrsRoutingFailures: 0
SIPNrsRegistrationAttempts: 138
SIPNrsRegistrationSuccesses: 138
SIPNrsRegistrationFailures: 0
SIPCTITotalSoftClientlogonAttempts: 0
SIPCTITotalSoftClientlogonSuccesses: 0
SIPCTITotalAnswerCallRequests: 0
SIPCTITotalAnswerCallSuccesses: 0
SIPCTITotalClearConnectionRequests: 0
SIPCTITotalClearConnectionSuccesses: 0
SIPCTITotalConsultationCallRequests: 0
SIPCTITotalConsultationCallSuccesses: 0
SIPCTITotalDeflectCallRequests: 0
SIPCTITotalDeflectCallSuccesses: 0
SIPCTITotalHoldCallRequests: 0
SIPCTITotalHoldCallSuccesses: 0
SIPCTITotalMakeCallRequests: 0
SIPCTITotalMakeCallSuccesses: 0
SIPCTITotalRetrieveCallRequests: 0
SIPCTITotalRetrieveCallSuccesses: 0
SIPCTITotalSingleStepTransferRequests: 0
SIPCTITotalSingleStepTransferSuccesses: 0
SIPCTITotalTransferCallRequests: 0
SIPCTITotalTransferCallSuccesses: 0
SIPCTITotalMonitorStartRequests: 0
SIPCTITotalMonitorStartSuccesses: 0
SIPCTITotalMonitorStopRequests: 0
SIPCTITotalMonitorStopSuccesses: 0
SIPCTITotalConferenceCallRequests: 0
SIPCTITotalConferenceCallSuccesses: 0
SIPCTITotalSetForwardingRequests: 0
SIPCTITotalSetForwardingSuccesses: 0
SIPCTITotalGetForwardingRequests: 0
SIPCTITotalGetForwardingSuccesses: 0
SIPCTITotalSessionTerminated: 0
```

Each collection period provides the following information:

- The date and time for the collection hour.
- Voice Gateway channel information accumulated during the hour. The Voice Gateway data is prefixed by Chan.
- Notes indicating whether the equipment restarted during the hour.
- Virtual Trunk statistics display only for a Signaling Server that ran the VTRK H.323 Signaling Server in the last hour.

The OM file relates to the omreport.xxx file on the Voice Gateway Media Card, where xxx indicates the numbers of days since December 31.

# View Traffic reports

You can view system traffic and customer traffic reports in Element Manager.

# **System reports**

To view system traffic reports in the Element Manager navigator, click **Tools > Logs and Reports > Operational Measurements > System Traffic**.

#### **Networks report (TFS001)**

Click **Network** in the table to view the Networks report.




Figure 80: Networks report

#### Service loops report (TFS002)

Click **Service loops** in the table to view the page title, report description, and the parameters measured in the Service Loops report.

**Table 77: TFS002** 

Title	System xxx Service Loops Report
Description	System xxx Service Loops Report (TFS002) measures service loops and tone detectors.
Parameters Measured	
1	Service number.
2	Service type.

Title	System xxx Service Loops Report
3	Service FTM.
4	Service usage.
5	Service request peg count.

## Dial tone delay report (TFS003)

Click **Dial tone delay** in the table to view the page title, report description, and the parameters measured in the Dial tone delay report.

**Table 78: TFS003** 

Title	System xxx Dial Tone Delay Report
Description	Dial Tone Delay Report (TFS003) shows the number of times users waited for dial tone for longer than 1 second.
Parameters Measured	
1	Number of times a user waited longer than 1 second
2	Number of times a user waited longer than 10 second
3	Total time delay

#### **Processor load report**

Click **Processor load** in the table to view the Processor Load report.




Figure 81: Processor load report

#### **Selected terminals Report (TFS005)**

Click **Selected terminals** in the table to view the page title, report description, and the parameters measured in the Selected terminals report.

**Table 79: TFS005** 

Title	System xxx Selected Terminals Report
Description	Selected Terminals Report (TFS005) measures the output for individual terminals and terminal loops.
Parameters Measured	
1	Loop number
2	Line usage
3	Line peg count

#### **Junctor group report (TFS007)**

Click **Junctor group report** in the table to view the page title, report description, and the parameters measured in the Junctor group report.

**Table 80: TFS007** 

Title	System xxx Junctor Report
Description	Junctor Report (TFS007) displays measurements related to paths that connect network groups involving an intergroup junctor
Parameters Measured	
1	Junctor group
2	Failure to match
3	Total usage
4	Peg count

## Command status links and application module report (TFS008)

Click **Command status links and application module** links in the table to view the page title, report description, and the parameters measured in the Command status links and application module links group report.

**Table 81: TFS008** 

Title	System xxx Command Status Link and Application Module Link measurements Report
Description	Command Status Link (CSL) and Application Module Link (AML) measurements Report (TFS008) captures traffic data related to Command Status Links and Application Module Links.
Parameters Measured	
System	
1	Input queue overflow
2	Output queue overflow
3	System resource not available
4	Input queue size for system messages
5	Input queue size for call processing messages
5	Input queue size for administration messages
Command Status Link	
1	Port number
2	Value Added Server ID
3	CSL output failures
4	Number of link stops
5	Link down time
6	Average output queue size
7	Number of IOCHAR TTY buffer overflows
8	Packets with missing End of Block flag

9	Packets with premature End of Block flag
10	Packets with invalid priority
11	Packets with invalid length
Outgoing/Incoming message types	
1	Channel assignment request
2	Call connection
3	Present call
4	Call answered
5	Call disconnect
6	DN update
7	Dialed digits
8	Telset message
9	Telset status message
10	Message waiting indication change
11	Mpdate terminal status
12	TN maintenance mode
13	Confirmation
14	Administration data block
15	Software audit
16	Change terminal status
17	Device state information
18	Network layer data
19	Terminal status
20	Requests acquired
22	Responses acquired
23	Statistics messages
24	Incoming call indication messages
25	Call detail recording state requests
26	Call detail recording state responses
27	De-acquire request
28	De-acquire response
29	ATB on/off for acquire route
30	Error indications sent
31	Error indications received
32	Incoming calls accepted
33	System initialization indication messages

34	Acquired devices removed
35	Queue requests
36	Queue request response messages
37	Query request
38	Query request responses
39	Startup or shutdown indications
40	Startup or shutdown indication response messages
41	Statistics requests
42	Statistics response messages
43	Treatment completed messages
44	Treatment requests
45	Return to queue
46	Treatment response messages
47	Filter Bitmap request
48	Filter Bitmap response
49	Monitor make set busy
50	Make set in service
51	Message waiting indication change
52	Not ready
53	Off-hook
54	Operator revert
55	Override
56	Present call
57	Query
58	Ready
59	Call disconnect request
60	Request terminal status change
61	Set feature message
62	Set feature notification
63	Set feature
64	Timestamp
65	Unsolicited status message
66	Update terminal status
Message Priority	
1	Priority 1 messages
2	Priority 2 messages

3	Priority 3 messages
4	Priority 4 messages
Traffic	
1	Average incoming usage
2	Peak incoming usage
3	Average outgoing usage
4	Peak outgoing usage
5	Time since last query
Flow Control	
1	First flow control
2	Second flow control
3	Third flow control
4	Fourth flow control
5	Outgoing SSD failure count
6	AML reset count
Packets	
1	Incoming packets
2	Outgoing packets

# **D-channel report (TFS009)**

Click **D-channel report** in the table to view the page title, report description, and the parameters measured in the D-channel report group.

**Table 82: TFS009** 

Title	System xxx D-channel Report
Description	D-channel Report (TFS009) captures traffic activity on D-channels.
Parameters Measured	
System	
1	D-channel number
2	Incoming messages received
3	Outgoing messages sent
4	Input queue size for system messages
5	Input queue size for call processing messages
6	Input queue size for administration messages
7	Incoming call processing messages
8	Outgoing call processing messages
9	Incoming management messages

Title	System xxx D-channel Report
10	Outgoing management messages
11	Incoming maintenance messages
12	Outgoing maintenance messages
13	Average number of incoming bytes for each message
14	Average number of outgoing bytes for each message
15	Total transfer time for incoming messages
16	Total transfer time for outgoing messages
17	Requests in output message buffer
18	Output message buffer idle count
19	No End of Message mark message count
20	PRA Layer-3 protocol errors
21	D-channel down instances
22	Attempted anti-tromboning operations
23	Successful anti-tromboning operations
24	First flow control
25	Second flow control
26	Third flow control
27	Fourth flow control
MSDL data	
1	Average incoming link usage
2	Peak incoming link usage
3	Average outgoing link usage
4	Peak outgoing link usage
5	Number of connected calls
6	Time since MSDL D-channel traffic was cleared
Optimization data	
1	Optimization requests with the diversion trigger
2	Successful optimizations with the diversion trigger
3	Successful optimizations retaining the old path with the diversion trigger
4	Optimization requests with the congestion trigger
5	Successful optimizations with the congestion trigger
6	Successful optimizations retaining the old path with the congestion trigger
7	Optimization requests with the connected trigger
8	Successful optimizations with the connected trigger
9	Successful optimizations retaining the old path with the connected trigger

#### **ISDN GF transport report (TFS010)**

Click **ISDN GF transport** in the table to view the page title, report description, and the parameters measured in the ISDN GF transport report group.

**Table 83: TFS0010** 

Title	System xxx ISDN Generic Functional Report
Description	ISDN Generic Functional Report (TFS010) counts the number of times supplementary services or the ISDN transport cannot find an idle call register.
Parameters Measured	
1	GF/SS call register overflow peg count

#### Multi purpose ISDN signaling processor traffic report (TFS011)

Click **Multipurpose ISDN signaling processor traffic** in the table to view the report.

#### Multi-purpose ISDN signaling processor DCH management report (TFS012)

Click Multi-purpose ISDN signaling processor DCH management in the table to view the report.

**Table 84: TFS012** 

Title	System xxx Multipurpose ISDN Signaling Processor D-channel Report
Description	Multipurpose ISDN Signaling Processor D-channel Report (TFS012) displays the traffic management activity for each DSL based on the exchange of signaling messages between the MISP and the terminals over the D-channels.
Parameters Measured	
MISP information	
1	Loop number
2	1 to 10 bytes
3	11 to 20 bytes
4	More than 20 bytes
BRSC information	
1	D-channel D-channel
2	1 to 10 bytes
3	11 to 20 bytes
4	More than 20 bytes

#### Multi-purpose ISDN signaling processor messages report (TFS013)

Click Multipurpose ISDN signaling processor messages in the table to view the report.

**Table 85: TFS013** 

Title	System xxx Multipurpose ISDN Signaling Processor messages Report
Description	Multipurpose ISDN Signaling Processor messages Report (TFS013) shows the total number of call processing, maintenance, and management messages sent through each MISP in the system grouped by message size.
Parameters Measured	
MISP information	
1	MISP loop number
2	MISP link initializations
3	Terminal link initializations
4	MISP management messages
5	Terminal management messages
6	Incomplete calls Link errors
BRSC information	
1	D-channel
2	BRSC link initializations
3	Terminal link initializations
4	BRSC management messages
5	Terminal management messages
6	Incomplete calls Link errors

# ISDN BRI trunk DSL system report (TFS014)

Click ISDN BRI trunk DSL system in the table to view the report.

**Table 86: TFS014** 

Title	System xxx ISDN BRI Trunk DSL Report
Description	ISDN BRI Trunk DSL Report (TFS014) shows the total number of maintenance, administrative and protocol messages sent through each Digital Subscriber Loop in the system.
Parameters Measured	
MISP information	
1	MISP ID
2	Outgoing maintenance messages
3	Incoming maintenance messages
4	Outgoing administration messages
5	Incoming administration messages

Title	System xxx ISDN BRI Trunk DSL Report
6	Outgoing protocol messages
7	Layer 3 protocol messages
8	Layer 2 protocol messages
9	Layer 1 protocol messages
10	Connected calls

## Meridian packet handler report (TFS015)

Click **Meridian packet handler** in the table to view the page title, report description, and the parameters measured in the Meridian packet handler report group.

**Table 87: TFS015** 

Title	System xxx Meridian Packet Handler Report
Description	Meridian Packet Handler Report (TFS015) provides specific information about incoming and outgoing calls and data packets. This report is particularly useful for analyzing the flow of data over network links.
Parameters Measured	
1	MPH number
2	Link interface type
3	Link time slot number
4	Layer 2 link initializations
5	Attempted incoming calls
6	Completed incoming calls
7	Attempted outgoing calls
8	Duration of a data call
9	Incoming data packets
10	Outgoing data packets

## **QoS IP statistics (TFS016)**

Click **QoS IP statistics** in the table to view the report.




Figure 82: QoS IP statistics report

# **Customer traffic reports**

To view customer traffic reports in the Element Manager navigator, click **Tools**, **Logs and Reports**, **Operational Measurements**, **Customer Traffic**.

#### **Network report (TFC001)**

Click Networks in the table to view the page title, report description, and the parameters measured in the Networks report group.

**Table 88: TFC001** 

Title	System xxx Customer yy Networks Report
Description	Networks Report (TFC001) describes traffic details for each customer call.
Parameters Measured	
Incoming Traffic Data	
1	Failure to match
2	Usage

Title	System xxx Customer yy Networks Report
3	Peg count
1	Failure to match
2	Usage
3	Peg count
Outgoing Traffic Data	
1	Failure to match
2	Usage
3	Peg count
Intracustomer Traffic Data	
1	Failure to match
2	Usage
3	Peg count
Tandem Traffic Data	
1	Failure to match
2	Usage
3	Peg count
Miscellaneous	
1	Permanent signal
2	Abandon
3	Partial dial

# Trunks report (TFC002)

Click Trunks in the table to view the page title, report description, and the parameters measured in the Trunks report group.

**Table 89: TFC002** 

Title	System xxx Customer yy Trunks Report
Description	Trunks Report (TFC002) displays trunk usage. The report prints when the All Trunks Busy (ATB) condition occurs during the reporting period.
Parameters Measured	
1	Route number
2	Trunk type
3	Equipped trunks
4	Working trunks
5	Incoming usage
6	Incoming peg count

Title	System xxx Customer yy Trunks Report
7	Outgoing usage
8	Outgoing peg count
9	Outgoing overflow
10	All Trunks Busy
11	Toll peg count
12	All Trunks Busy for nonpriority users

#### Console queue report (TFC003)

Click Console queue in the table to view the page title, report description, and the parameters measured in the Console queue report group.

**Table 90: TFC003** 

Title	System xxx Customer yy Console Queue Report
Description	Console Queue Report (TFC003) examines the treatment of calls in customer queues.
Parameters Measured	
Attendant Response	
1	Average speed of answer
2	Average attendant response
3	Calls delayed peg count
4	Average time in queue
Abandoned Calls	
1	Abandoned calls peg count
2	Average wait time

#### Individual console measurement report (TFC004)

Click Individual console measurement in the table to view the page title, report description, and the parameters measured in the Console queue report group.

#### Feature key usage report (TFC005)

Click Feature key usage in the table to view the page title, report description, and the parameters measured in the Feature key usage report group.

**Table 91: TFC005** 

Title	System xxx Feature Key Usage Report
Description	Feature Key Usage Report (TFC005) looks at patterns of customer usage.
Parameters Measured	

Title	System xxx Feature Key Usage Report
1	Feature number
2	Peg count

## Radio paging report (TFC006)

Click Radio paging in the table to view the page title, report description, and the parameters measured in the Radio paging report group.

Table 92: TFC006

Title	System xxx Customer yy Radio Paging Report
Description	Radio Paging Report (TFC006) shows the number of calls processed by Radio Paging.
Parameters Measured:	
1	RPA system number
2	Request peg count
3	Blocked requests peg count
4	Requests abandoned by caller
Radio Paging	
1	Preselection peg count
2	Post selection peg count
3	Automatic mode peg count
4	Manual mode peg count
5	Diversion peg count
Paging Modes	
1	Mode 1 peg count
2	Mode 2 peg count
3	Mode 3 peg count
4	Mode 4 peg count
5	Mode 5 peg count
Average time	
1	Paging time out
2	Average answer time
3	Recall count
4	Average paging trunk use

## Call Park report (TFC007)

Click Call Park in the table to view the page title, report description, and the parameters measured in the Call Park report group.

**Table 93: TFC007** 

Title	System xxx Customer yy Call Park Report
Description	Call Park Report (TFC007) shows the call parking data across a System park and Station park DN.
Parameters Measured:	
1	System park peg count
2	System Park overflow peg count
3	Station Park peg count
4	Parked call access peg count
5	Parked call recall peg count
6	Average park wait time

## Messaging and auxiliary processor links report (TFC008)

Click Messaging and auxiliary processor links in the table to view the page title, report description, and the parameters measured in the Messaging and auxiliary processor links report group.

**Table 94: TFC008** 

Title	System xxx Customer yy Messaging and Auxiliary Processor Links Report
Description	Messaging and Auxiliary Processor Links Report (TFC008) provides data on Messaging and Auxiliary Processor links.
Parameters Measured:	
Auxiliary Processor Link	
1	APL number
2	Output queue overflow
3	Input queue overflow
4	Average output queue size
5	Average input queue size
6	Down time
7	Unavailable input message call register
8	Four second time out count
9	Negative acknowledgments
10	Input characters not synchronized
OMSG	
IMSG	
Packets	
1	Output packet messages

Title	System xxx Customer yy Messaging and Auxiliary Processor Links Report
Message Attendant Queue	
1	Automatic Call Distribution DN
2	Value Added Server ID
3	Auxiliary Processor Link number
4	Calls in message attendant queue
5	Direct calls to message attendant
6	Indirect calls
7	Time overflow calls
8	Abandoned calls
9	Average waiting time for abandoned calls
10	Average delay
11	Direct call processing time
12	Post call processing time
Telephone Status	
1	Automatic Call Distribution DN
2	Value Added Server ID
3	Auxiliary Processor Link number
4	Total calls
5	Special prefix access calls
6	Call forward access calls
7	User key access calls
8	Unsuccessful calls
Telephone Messaging	
1	Automatic Call Distribution DN
2	Value Added Server ID
3	Auxiliary Processor Link number
4	Total calls
5	Successful telephone messaging calls
6	Abandoned calls
7	Unsuccessful calls
8	Telephone messaging processing time
9	Calls requesting message attendant

# **Network attendant service report (TFC009)**

Click Network attendant service in the table to view the page title, report description, and the parameters measured in the Network attendant service report group.

**Table 95: TFC009** 

Title	System xxx Customer yy Network Attendant Service Report
Description	Network Attendant Service Report (TFC009) shows the attempts to route to NAS.
Parameters Measured:	
Alternate Routes	
1	Attempts to route to NAS across route 1
2	Attempts to route to NAS across route 2
3	Attempts to route to NAS across route 3
4	Attempts to route to NAS across route 4
Drop Backs	
1	Drop back busies over route 1
2	Drop back busies over route 2
3	Drop back busies over route 3
4	Drop back busies over route 4

## **DSP** peg count report (TFC012)

Click Call blocking due to lack of DSP resource in the table to view the page title, report description, and the parameters measured in the DSP peg count report group.

**Table 96: TFC0012** 

Title	System xxx Customer yy DSP Peg Count Report
Description	DSP Peg Count Report (TFC012) shows the number of times calls were blocked on an IP Media Gateway (IPMG) due to insufficient Digital Signal Processor (DSP) resources or a lack of bandwidth.
Parameters Measured:	
Alternate Routes	
1	IPMG loop number
2	Attempts to allocate DSP resources
3	Lack of DSP resources
4	Lack of bandwidth

## ISPC link establishment report (TFC105)

Click ISPC link establishment in the table to view the page title, report description, and the parameters measured in the ISPC link establishment report group.

**Table 97: TFC105** 

Title	System xxx Customer yy ISPC Link Establishment Report
Description	ISPC Link Establishment Report (TFC105) provides a peg count of the number of ISPC links established by an Australian Central office for each Phantom loop for each defined trunk.
Parameters Measured:	
Alternate Routes	
1	Loop Number
2	Peg Count

## **Broadcasting routes report (TFC111)**

Click Use of broadcasting routes set in the table to view the page title, report description, and the parameters measured in the Broadcasting routes report group.

**Table 98: TFC111** 

Title	System xxx Customer yy Broadcasting Routes Report
Description	Broadcasting Routes Report (TFC111) provides traffic data broadcasting route usage.
Parameters Measured:	
1	Route Number
2	Trunk Type
3	Successful connections
4	Average call duration
5	Average waiting duration
6	Maximum waiting time
7	Waiting time threshold peg count
8	Waiting parties threshold peg count
9	Lowest usage trunk connections
10	Next to lowest usage trunk connections
11	Next to next lowest usage trunk connections

#### **Route list measurement report (TFN001)**

Click Route list measurement in the table to view the page title, report description, and the parameters measured in the Route list measurement report group.

#### **Table 99: TFN001**

Title	System xxx Customer yy Route List Measurement Report
Description	Route List Measurement Report (TFN001) shows how often a route list was accessed, which list entries were used, and whether the call was successfully performed a selection or connection.
Parameters Measured:	
Route List	
1	Route list number
2	Number of requests
3	Requests served without delay
4	Expensive route acceptances
5	Requests blocked
6	VNS trunks reuse count
7	VNS trunks total idle time
Route List Entry	
1	Route list number
2	Number of calls
Off-hook Queuing	
1	Number of calls
2	Time elapsed in queue
3	Abandoned calls
Call Back Queuing	
1	Number of calls
2	Time elapsed in queue
3	Calls offered
4	User cancellations
Remote Virtual Queuing	
1	Number of calls
2	Time elapsed in queue
3	Calls offered
4	User cancellations

# **Network Class of Service Report (TFN002)**

Click Network Class of Service measurement in the table to view the page title, report description, and the parameters measured in the Network Class of Service report group.

**Table 100: TFN002** 

Title	System xxx Customer yy Network Class of Service Report
Description	Network Class of Service Report (TFN002) shows the grade of service in terms of blocking and queuing delay.
Parameters Measured:	
1	NCOS group number
2	Calls attempted
3	Expensive route acceptances
4	Requests served without delay
5	Requests blocked
6	Calls refusing expensive routes
Off-hook Queuing	
1	Number of calls
2	Time elapsed in queue
Call Back Queuing	
1	Number of calls
2	Time elapsed in queue
Remote Virtual Queuing	
1	Number of calls
2	Time elapsed in queue

# **Incoming trunk group report (TFN003)**

Click Incoming trunk group measurements in the table to view the page title, report description, and the parameters measured in the Incoming trunk group report group.

**Table 101: TFN003** 

Title	System xxx Customer yy Incoming Trunk Group Report
Description	Incoming Trunk Group Report (TFN003) shows incremental traffic that network queuing features impose on incoming trunk groups.
Parameters Measured:	
1	Incoming trunk group
2	Calls in off-hook queuing
3	Time elapsed in off-hook queuing
Call Back Queuing	
1	Calls offered
2	Calls accepted
3	Time elapsed in queue

Title	System xxx Customer yy Incoming Trunk Group Report
4	Calls blocked in call back
5	Unsuccessful call back attempts
Remote Virtual Queuing	
1	Calls offered
2	Calls accepted
3	Time elapsed in queue
4	Calls blocked in call back
5	Unsuccessful call back attempts

# Backup and restore data

All data is stored on the Call Server. Element Manager accesses the data for the elements being maintained. Element Manager does not store data.

You need to back up no Element Manager data. All data is retrieved from the Call Server and elements.

The c:/u/db/node directory is populated on the Call Server when you save node configuration data. The BOOTP.TAB and CONFIG.INI files are saved in this directory as c:/u/db/node/nodexxxx.btp and c:/u/db/node/nodexxxx.cfg; xxxx is the node ID:

- nodexxxx.btp is the BOOTP.TAB file
- nodexxxx.cfg is the CONFIG.INI.

If you remove a node, the associated files are also removed. For every node you create, a nodeyyyy.btp and nodeyyyy.cfg file are created in the C:/u/db/node directory.



#### **Marning:**

To prevent Element Manager corruption, do not manually edit or delete the node files.

# **Backup**

The Backup feature starts the Equipment Data Dump (EDD) on the Call Server to back up all Call Server data. Within Element Manager, the Call Server Backup feature starts a data dump and writes the Call Server data to the primary and internal backup drives.

The backup includes all Call Server data and the BOOTP.TAB and CONFIG.INI files for each node configured in the system. These files are stored on the Call Server for the IP Telephony nodes configured in the system.

You can also back up the Call Server by entering the EDD CLI command using LD 43.

During a backup, the BOOTP.TAB and CONFIG.INI files of all registered nodes are copied so you can restore them if the system fails.

Perform the steps in <u>Backing up the Call Server data</u> on page 314 to back up the Call Server.

#### **Backing up the Call Server data**

1. In the Element Manager navigator, select **Tools**, **Backup and Restore**, **Call Server Backup** and **Restore**. See Figure 83: Call Server Backup and Restore window on page 314.



Figure 83: Call Server Backup and Restore window

2. Click Backup.

The Call Server Backup window appears. See <u>Figure 84: Call Server Backup window</u> on page 314.



Figure 84: Call Server Backup window

- 3. Select **Backup** from the **Action** list.
- 4. Click **Submit** or click **Cancel** to cancel the backup.

The window displays the message "Backup in progress. Please wait..."

5. Click **OK** in the EDD complete dialog box.

The Backup function then displays information in a tabular form indicating the actions that occurred.

# Restore the backed up files

The Call Server Restore function restores the backup files from the internal backup device to the primary device. The Restore function performs the same task as the RIB CLI command in LD 43.

To restore the Call Server data, perform the steps in Restoring the Call Server data on page 315.

#### Restoring the Call Server data

- In the Element Manager navigator, select Tools, Backup and Restore, Call Server.
   The Call Server Backup and Restore window appears.
- 2. Click Restore.

The Call Server Restore window appears. See <u>Figure 85: Call Server Restore window</u> on page 315.



Figure 85: Call Server Restore window

- 3. Select Restore from Backup Data (RES) from the Action list.
- 4. Click Submit.

If the Restore is successful, the message "Restore was done successfully" appears.

# **Update IP Telephony node properties**

To update the node properties, perform the steps in <u>Updating the IP Telephony node properties</u> on page 315.

#### **Updating the IP Telephony node properties**

- 1. In the Element Manager navigator, select **IP Networks, Nodes: Servers, Media Cards**. The IP Telephony Nodes window appears.
- 2. Select the link for a Node ID.

The Node Details window appears.

- 3. Update the parameters in the appropriate sections as required. For more information, see Adding a card and configuring Voice Gateway Media Card properties on page 244.
- 4. Click Save.


# Add a Voice Gateway Media Card to the node

To add a Voice Gateway Media Card to the node, perform the steps in <u>Adding a Voice Gateway Media Card to the node</u> on page 316.

#### Adding a Voice Gateway Media Card to the node

- 1. Choose a card slot for the new card. Note the TN.
- 2. Configure IPTN in LD 14 at the Call Server.
- 3. Install the I/O cables for connection to the ELAN and TLAN network interfaces on the selected card slot.
- 4. In the Element Manager navigator, select **IP Network > Nodes: Servers, Media Cards**. The IP Telephony Nodes window appears.
- 5. Click the link for the Node ID where the card will be added.
  - The Node Details window appears.
- 6. Select Media Card from the Select to add menu.
- 7. Click Add.

The **New Media Card Details** window appears.



- 8. In the **Identification and Status** section of the window, enter the following information.
  - a. HostName: This is the host name.
  - b. Card TN: Enter the card slot number from 1 to 50.
  - c. **Server Type:** Select the server type.
    - Note:

DSP IPv6 address field is enabled only if you select the server type as MC32S card, and if IPv4 and IPv6 option is selected for TLAN address type of the corresponding node in Node Details page. If only IPv4 is selected for TLAN address type of the node, DSP IPv6 address field is displayed but the field is disabled during MC32S card configuration.

- d. MAC Address: This is the motherboard Ethernet address.
- 9. In the **Network** section of the window, enter the TLAN and ELAN network information.
  - a. **Telephony LAN (TLAN) IP address:** This is the TLAN network interface IP address for the card.
  - b. Embedded LAN (ELAN) IP address: This is the ELAN network interface IP address for the card. Element Manager and the system use this IP address to communicate with the card.
- 10. To add additional cards to the node, click **Add** again and enter the new card information. Repeat this step for each card that you add to the node.
- 11. Click **Save** after you add and configure a card.

- Click Save on the Node Details window to save the data to the Call Server.
- 13. Click **OK** to confirm.

If you click **Cancel** all configured information is discarded.

- 14. Click **Transfer/Status** associated with the node where the new card was added.
- Click **OK** to confirm the transfer.

The **Transfer Progress** window appears and displays each of the Voice Gateway Media Cards in the node.

The Voice Gateway Media Card retrieves the CONFIG.INI and BOOTP.TAB files from the Call Server. A check mark is added to each field as the card receives the CONFIG.INI and BOOTP.TAB files.

- 16. When the transfer is complete, click **OK** in the **Progress Check Complete** dialog box.
  - If the transfer is successful for a card, the Status column displays **Complete**.
  - If the transfer is unsuccessful, the Status column displays Fail.
- 17. Insert the new card.

The card starts and obtains the IP configuration from the node leader. This process takes several minutes.

The Maintenance faceplate shows an alarm of T:21 or S009.

- T:21 appears if the card is new and there is no CONFIG.INI file.
- S009 appears if the card was used before and has a CONFIG.INI file that contains an IP address for the Call Server that is no longer correct.
- 18. In the Element Manager navigator, select IP Network > Maintenance and Reports.

The Node Maintenance and Reports window appears.

- 19. Expand the node containing the Voice Gateway Media Card by clicking the plus sign (+) to the left of the Node ID.
- 20. Click **GEN CMD** associated with the Voice Gateway Media Card. See <u>Figure 86: Voice Gateway Media Card and GEN CMD button</u> on page 318.




Figure 86: Voice Gateway Media Card and GEN CMD button

The **General Commands** window appears.

- 21. From the Group list, select **Misc**.
- 22. In the Element Manager navigator, select **IP Network > Nodes: Servers, Media Cards**.
  - The **IP Telephony Nodes** window appears.
- 23. Click **Transfer/Status** to download the node information to the card.
- 24. In the Element Manager navigator, select IP Network > Maintenance and Reports.
  - The Node Maintenance and Reports window appears.
- 25. Expand the node containing the new card by clicking the plus sign (+) to the left of the Node ID.
- 26. Click **Status** for each Voice Gateway Media Card that was added.

The card status is Enabled or Disabled. If the status message "Web3003: Destination IP address cannot be reached; initial RPC failure" appears, then verify the network connection and the proper configuration of network equipment.

# Change the IP addresses of an IP Telephony node in Element Manager

Before you change any IP address understand <u>Codecs</u> on page 171, and consult with the system administrator.

To change the IP address of an IP Telephony node, perform the steps in <u>Changing the IP addresses</u> of an IP <u>Telephony node in Element Manager</u> on page 319.

#### Changing the IP addresses of an IP Telephony node in Element Manager

- 1. In the Element Manager navigator, select IP Network > Nodes: Servers, Media Cards.
  - The **IP Telephony Nodes** window appears.
- 2. Select the link for the Node ID.

The **Node Details** window appears.



The node IPv4 address mentioned in the above figure is just fro reference and is not valid.

- 3. Change the IP addresses as required.
  - a. **Node ID:** The Node ID appears but you cannot change it.
  - b. **Embedded LAN (ELAN) gateway IP address:** Enter the Embedded LAN (ELAN) gateway IP address in dotted decimal format. This is the IP address of the router interface on the ELAN subnet, if present. If the subnet does not have an Embedded LAN gateway, enter 0.0.0.0.
    - When an Embedded LAN gateway is added to the ELAN subnet, it must restrict access so that only authorized traffic is permitted on the ELAN subnet.
    - The router must disable the BootP relay agent for the ELAN network interface.

- The router must block all broadcast and multicast traffic from the ELAN subnet and enable only proper access (only authorized traffic and users coming through the ELAN gateway).
- c. **Embedded LAN (ELAN) subnet mask:** Enter the Embedded LAN subnet mask address in dotted decimal format. When you change these subnet masks, consider the possible conflict between the ELAN and TLAN network interface IP addresses. Consult with the network administrator before you change subnets.

When you change the Embedded LAN (ELAN) network interface IP address, coordinate it with the IP address on the Call Server (Active ELNK) network interface. Changes must also be coordinated with the following:

- Embedded LAN gateway and other IP devices on the ELAN subnet
- other devices on the ELAN subnet and customer enterprise network subnet that need to communicate with IP Line
- devices that receive SNMP traps
- 4. In the Element Manager navigator, click **System > Alarms > SNMP**.
  - a. In the **Trap Source** section, enter the following applicable parameters:
    - Navigation Site Name
    - Navigation System Name
  - b. In the MIB-2 System Group Parameters section, enter the following applicable parameters:
    - System Contact
    - · System Location
    - System Name
  - c. In the **Community** section, enter the following parameters for system management community strings for access to the Management Information Base (MIB) and trap generation, and to administrator community strings for access to the MIB views:
    - System Management Read
    - System Management Write
    - Trap Community
    - Administrator Group

The SNMP community strings control access to the IP Telephony node. Element Manager uses the community strings to control transmitting and retrieving configuration data files for database synchronization.

- d. In the **Trap Destinations** section, enter the IP address of the trap destinations. SNMP traps are sent to the entered IP address. A maximum of eight IP addresses can be configured.
- e. Click Save.

The parameters are automatically synchronized with the Call Server, Signaling Server, and Media Gateway Controller.

## **!** Important:

Perform an Equipment Data Dump (EDD) to permanently save the configured information.

After the parameters are synchronized, the associated host route entries are added to the routing table automatically. If a trap destination is removed, the corresponding routing table entry is removed as a result.

- 5. In the Element Manager navigator, select IP Network > Nodes: Servers, Media Cards.

  The IP Telephony Nodes window appears.
- 6. Select the link for the Node ID where the IP address is being changed.

The **Edit** window appears.

- 7. Enter the following **Embedded LAN (ELAN) configuration** settings:
  - a. **Call Server IP address:** This is the IP address of the Call Server on the ELAN subnet. Enter the Call Server ELAN network interface IP address (Active ELNK).

The Call Server ELAN network interface IP address must correspond to the Active ELNK IP address configured in LD 117. It must be on the same subnet as the ELAN IP address for the IP Line node.

- b. **Signaling port**: The default value is 15000. The range is 1024 to 65535.
- c. **Broadcast port**: The default value is 15001. The range is 1024 to 65535.
- 8. If entries must be made to the card routing table, click the **LAN** link on the **Node Details** window.

The LAN window appears as shown in the following figure.

# Managing:: 172.16.100.30 Username: admin System » IP Network » I<u>P Telephony Nodes</u> » <u>Node Details</u> » LAN

Node ID: 1100 - LAN




Figure 87: Node ID: xxx -LAN

9. Enter the IP address and Subnet mask for any host that is not on the ELAN subnet but requires access to the Voice Gateway Media Card across the ELAN subnet. Click Add.

A Telnet session for maintenance from a remote PC is an example of when this would be needed. The address of the remote PC would be added in the Route list.

The default route on the card causes packets for unknown subnets to be sent out the TLAN network interface. Packets from an external host arrive on the ELAN network interface. Responses are sent on the TLAN network interface. This process can cause one-way communication if the TLAN subnet is not routed to the ELAN subnet. It is necessary to add an entry in the Route list to correct the routing so that response packets are sent on the ELAN subnet. Each entry creates a route entry in the card route table that directs packets out the ELAN network interface.



#### Caution:

Use caution when you assign card routing table entries. Do not include the IP address of an IP Phone. Otherwise, voice traffic to these IP Phones is incorrectly routed through the ELAN subnet and ELAN gateway. To avoid including the wrong IP address, Avaya recommends that Host IDs be defined for the card routing table entries.

To add routes, click **Add** again and enter the route information. Repeat this step for each new route.

- 10. Click **Save**, and then click **OK**.
- 11. In the Node Configuration window, click Save associated with the node that had the IP address changes.

# Update other node properties

You can update the following node properties on the Node Details window.

- DSP Profile section: see Configuring DSP Profile data on page 238
- QoS section: see Configuring QoS on page 241

# Import or Export an IP Node Configuration File

Using Element Manager, import or export an XML file that contains the parameters for IP Telephony node data.


Using the Import feature, import a standard XML file from a local workstation. The file contains node properties data. Configuration parameters must be entered in the file in a standard template model. The template follows the same model as the config.ini file format. You can import, edit, and save the file to the Call Server. To import a file, perform the steps in Importing an IP Node Configuration File on page 323

#### Importing an IP Node Configuration File

In Element Manager, select System > IP Network > Nodes: Server, Media Cards.

#### The IP Telephony Nodes window appears.

2. Click Import.



- 3. To use an existing XML file that contains the configuration data for the IP Telephony node, click **Browse**. Search for the file on the local workstation, and click **Open** to add the file to the box.
- 4. To review and edit the configuration data, click **Preview**.
  - If the data in the imported file is invalid, an error message appears. The import fails.
  - If the data in the imported file is valid, the **Node Details** window appears.
- 5. Change the configuration data for the IP Node, if required.
- 6. Click **Save** to save the changes to the Call Server.

If the configuration data is invalid, an error message is displayed. The data is not updated to the Call Server.

# Telnet to a Voice Gateway Media Card using Virtual Terminal

To access the CLI on a Voice Gateway Media Card using Virtual Terminal from Element Manager, perform the steps in Accessing a Voice Gateway Media Card using Telnet on page 324.

#### Accessing a Voice Gateway Media Card using Telnet

- In the Element Manager navigator, select IP Network > Maintenance and Reports.
  - The **Node Maintenance and Reports** window appears.
- 2. Expand the node containing the Voice Gateway Media Card.
- 3. Click Virtual Terminal associated with the Voice Gateway Media Card.
  - See Figure 88: Virtual Terminal on page 325.




Figure 88: Virtual Terminal

The Virtual Terminal window appears and automatically connects to the Voice Gateway Media Card by using the TLAN or ELAN network interface IP address. See Figure 89: Virtual Terminal window on page 325.




Figure 89: Virtual Terminal window

- 4. Enter a user name and password to access the IPL> or oam> CLI.
  - The IPL > or oam > prompt appears if the logon is successful.
- 5. Type a question mark (?) or Help (for the MC 32S card) at the prompt to display a list of available IPL > or oam> CLI commands.
  - See IP Line CLI commands on page 399 for a list of commands.

# **Check the Voice Gateway Channels**

To check the Voice Gateway Channels on a Voice Gateway Media Card, perform the steps in Checking the Voice Gateway Channels on page 326.

### **Checking the Voice Gateway Channels**

1. In the navigation tree, select IP Network > Maintenance and Reports.

The **Node Maintenance and Reports** window appears.

- 2. Expand the node to show all its elements by clicking the plus sign (+) to the left of the Node ID.
- 3. Click **GEN CMD** associated with the Voice Gateway Media Card.

The **General Commands** window appears.

- 4. From the Group list, select Vgw.
- 5. From the Command list, select vgwShowAll.
- Click RUN.

The output of the vgwShowAll command appears in the text area at the bottom of the window.

7. To view the VGW Channel configuration, from the **Command** list, select **Print VGW**Channels and click **RUN**.

# Setting the IP Phone Installer Password

Element Manager includes the CLI commands to configure the administrative and temporary IP Phone Installer Password. For more information about the IP Phone Installer Password, see IP Phone Installer Password on page 267.

To configure the IP Phone Installer Password in Element Manager, perform the steps in <u>Setting the</u> <u>administrative and temporary IP Phone Installer Passwords</u> on page 326.

### Setting the administrative and temporary IP Phone Installer Passwords

1. Select IP Network > Maintenance and Reports.

The **Node Maintenance and Reports** window appears.

- 2. Expand the node to show all elements.
- 3. Click **GEN CMD** associated with the Voice Gateway Media Card.

The **General Commands** windows appears.

- 4. From the Group list, select NodePwd.
- 5. From the Command list, select nodePwdShow and click RUN.

The output from the nodePwdShow command appears in the text area at the bottom of the window. If in the default state, the IP Phone Installer Password was never assigned. The nodePwdShow output displays the following:

- NodeID the IP Phone Installer Password configuration applies to all Voice Gateway Media Cards on the same TLAN subnet that belong to this Node ID.
- PwdEna by default the cards should be in disabled state (PwdEna=No). The PwdEna setting specifies the enabled (Yes) or disabled (No) state of the IP Phone Installer Password.
- Pwd this is the administrator IP Phone Installer Password. In the default state, the administrator password is null.
- TmpPwd this is the temporary IP Phone Installer Password. In the default state, the temporary password is null.
- Uses the Uses parameter applies to the temporary IP Phone Installer Password. In the
  default state, this setting is null. If the card is not in the default state, the Uses parameter
  is a numeric value from 0 1000. This number specifies the remaining number of uses for
  the temporary password. If zero is entered for the Uses parameter when setting the
  temporary password, the Time parameter is mandatory. When the Time parameter is in
  effect, the password expiration is based on time instead of the number of uses.
- Timeout the Timeout heading corresponds to the Timeout parameter of the temporary IP Phone Installer Password. In the default state the Timeout is null. If the card is not in the default state, this setting specifies the duration in hours in which the temporary password is valid. The range is 0 240 hours (which is a maximum of 10 days). The number specified under Timeout indicates the remaining time to expire of the temporary password. The Timeout parameter is optional if the Uses parameter is non-zero. The Timeout parameter is mandatory if Uses is set to zero.

If both the Uses and Timeout parameters are entered, the password expires based on whichever happens first: the number of Uses becomes zero or the Timeout expires. If both the Uses and Timeout parameters are entered and are zero, it is the same as not setting the temporary password.

- 6. From the **Group** list, select **NodePwd**.
- 7. From the Command list, select **nodePwdSet** and click **RUN**.

The window refreshes and displays the blank **Node Password** field.

8. Enter the administrator IP Phone Installer Password in the **Node Password** field and click **RUN** .

This enables and configures the administrator password. The password parameter can be null or 6 to 14 digits in length. The valid characters are 0 to 9, asterisk (\*), and number sign (#). This command can be entered at any time. The new password entered overwrites the previous password.

The text area returns the message "Please run nodePwdShow to verify the result."

From the Command list, select nodePwdShow and click RUN.

The text area data output is similar to the following:

NodeID PwdEna	Pwd	TmpPwd	Uses	Timeout

=====	======		======	
123	Yes	1234567	0d 0h	0m 0s



### Warning:

If you click **RUN** in the Node Password field and no password is entered in the box, then the password is enabled but is null. In the above output, the PwdEna field displays Yes and the Pwd field is blank.

10. To configure a temporary password, from the Command list, select **nodeTempPwdSet**.

The window refreshes and blank fields are displayed for the following: Node Password, Uses, and Timeout.

11. Enter the temporary Node Password, the number of uses, and the Timeout, and click **RUN**.

The text area returns the message "Please run nodePwdShow to verify the result."

12. From the Command list, select nodePwdShow from the list box and click RUN.

The text area data output is similar to the following:

```
NodeID PwdEna Pwd
                    TmpPwd Uses
                                    Timeout
123 Yes 1234567 9876543 2 Od Oh Om Os
```

- 13. To clear the temporary IP Phone Installer password, select the nodeTempPwdClear command from the Command list and click RUN.
- 14. Confirm that the temporary password is cleared.

From the Command list, select nodePwdShow and click RUN.

The text area data output is similar to the following:

NodeII	PwdEna	Pwd	TmpPwd	Uses	Timeout
=====	======	=======	======	======	
123	Yes	1234567		(	Od Oh Om Os

# **Chapter 15: Numbering Groups**

A numbering group represents common numbering planning attributes which are shared by a group of subscriber telephony accounts. Each telephony account can belong to only one numbering group. If a telephony account does not belong to a specified numbering group, it is classified as a member of the default numbering group category. A member of the default numbering group category only uses a private numbering plan (private CDP and UDP dialing).

# Numbering group attributes

Numbering group attributes are summarized in <u>Table 102: Numbering group attributes</u> on page 329.

**Table 102: Numbering group attributes** 

Attribute Name	Rules and Comments
Name	Mandatory; Unique; Sortable in web UI; Maximum number of characters: 32 Allow: any character except comma
Element ID	Mandatory; Alphanumeric; Sortable in web UI; It is CS 1000 system serial number in LD143 (.ksho rec), printable in LD22 (reg tid) as well.
Target	Mandatory; Numeric (Range 0 – 99); Sortable in web UI It is CS 1000 customer number
Private Network ID (PNI)	Mandatory; Numeric; Maximum digit length: 5; Minimum digit value: 0; Maximum digit value: 16383 Sortable in web UI; It is CS 1000 system PNI number in LD15.
L0 Domain Name	Mandatory; Alphanumeric; Allowing dot Maximum # of characters: 30 Sortable in web UI; It is recommended to use the L0 domain name configured in the Network Routing Server
DN Range From	Mandatory; Numeric (Maximum 7 digits);
DN Range To	Mandatory; Numeric (Maximum 7 digits); It has to be >= DN Range From; The number of digits has to be the same for 'DN Range From' and 'DN Range To'

Table continues...

Attribute Name	Rules and Comments
Country Code	Optional; Numeric (Maximum 4 digits) Sortable in web UI If Country Code is not provisioned, subscriber telephony account E.164 international CLID/URI will not be generated.
Area Code / City Code	Optional; Numeric (Maximum 7 digits); Sortable in web UI If Area Code / City Code is not provisioned, subscriber telephony account E.164 international and national CLID/URIs will not be generated.
Exchange Code	Optional; Numeric (Maximum 7 digits) Sortable in web UI If Exchange Code is not provisioned, subscriber telephony account E.164 international, national and local CLID/URIs will not be generated.
AC1 (ESN Access Code)	Optional; Numeric (Maximum 7 digits); Sortable in web UI
AC2 (External Access Code)	Optional; Numeric (Maximum 7 digits); Sortable in web UI

# Numbering group validation rules

The numbering group validation rules are

- Maximum number of entries is 3000 numbering groups.
- No overlapping DN range within the same Element ID and Target combination is allowed.
- No overlapping DN range with same CountryCode + AreaCode + ExchangeCode is allowed.
- Can not use different AC1 values for the same target under an element.
- Can not use different AC2 values for the same target under an element.

# Calling Line Identification Uniform Resource Identifier Generation for Subscriber Telephony Account

There are five types of Calling Line Identification (CLID) Uniform Resource Identifiers (URI):

- 1. Private telephony L0 (CDP Steering Code)
- 2. Private telephony L1 (UDP location code)
- 3. Public E.164 Local (subscriber)
- 4. Public E.164 National
- 5. Public E.164 International

Data for up to five CLID/URIs are generated from each subscriber telephony account.

The rules for generating subscriber telephony account CLID/URIs are summarized in <u>Table 103:</u> Rules for generating subscriber telephony account <u>CLID/URIs</u> on page 331.

Table 103: Rules for generating subscriber telephony account CLID/URIs

Туре	Rule for generating the CLID/URI
Private telephony L0 (CDP Steering code)	The DN of the subscriber telephony account
Private telephony L1 (UDP location code)	Home location code + DN
PublicE.164 Local (subscriber)	Exchange code + DN
Public E.164 National	Area code + Exchange code + DN
Public E.164 International	'+' + Country code + Area code + Exchange code + DN

For an example of a subscriber telephony account, see <u>Table 104: Example of a subscriber telephony account</u> on page 331.

Table 104: Example of a subscriber telephony account

Subscriber Telephony Account Attribute	North America Type Value	Non-North America Type Value
DN	2222	3488
ESN	343-2222	633-3488

For an example of numbering group information, see <u>Table 105: Example of numbering group information</u> on page 331.

Table 105: Example of numbering group information

Numbering Group Attribute	North America Type Value	Non-North America Type Value
Country code	1	86
Area code/City code	613	10
Exchange code (E.164 prefix)	967	8288

For an example of each type of generated CLID/URI, see <u>Table 106</u>: <u>Example of generated CLID/URIs</u> on page 331.

Table 106: Example of generated CLID/URIs

CLID/URI Type	Subscriber Telephony Account CLID/URI (North America Type)	Subscriber Telephony Account CLID/URI (Non-North America Type)
Private telephony L0 (CDP Steering code)	2222	3488
Private telephony L1 (UDP location code)	343-2222	633-3488

Table continues...

CLID/URI Type	Subscriber Telephony Account CLID/URI (North America Type)	Subscriber Telephony Account CLID/URI (Non-North America Type)
Public E.164 Local (subscriber)	967-2222	8288-3488
Public E.164 National	613-967-2222	10-8288-3488
Public E.164 International	+1-613-967-2222	+86-10-8288-3488

### **CLID/URI Generator**

The CLID/URI Generator is a background process that runs periodically to generate telephone numbers for a TELEPHONY account in Subscriber Manager. The CLID generation provides telephone number information for public e164 local (External), national (National) and international (International) dialing. For an account that is published into the Subscriber details, these generated numbers are entered in the External, National and International fields of the subscriber. However, these values are not removed from the subscriber when the user publishes a different account which has no contact details, or when the current account no longer has the generated numbers. This data can be synchronized with the customer LDAP directory.

#### Note:

Only one account can be published into the subscriber data. Thus, if an employee has two telephones with different numbers for each telephone, only one of those telephones will be represented in the subscriber data.

Updates to these telephone number fields through the Subscriber Details page do not update accounts. The only way to update accounts is through the Avaya Communication Server 1000 (Avaya CS 1000) Element Manager account details page or through Flow Through Provisioning.

For more information about Subscriber Manager, see Subscriber Manager Fundamentals (NN43001-120).

# Manage numbering groups

The procedures in this section describe the functions available in UCM Common Services to manage numbering groups within your network. The Unicode Name Directory uses the numbering group functionality.

To access Numbering Groups a user must be mapped to the role All elements by type: Numbering Groups. Refer to *Unified Communications Management (NN43001-116*), for detailed information on assigning roles and permissions for access to Numbering Groups from the UCM Common Services.

Numbering Groups installs with a sample numbering Groups.csv file so that users can export the sample and use it as a template. Numbering Groups supports CSV files saved using OpenOffice.org 2.4.0 (or greater). Other CSV editors can be used. However, they have not been tested with Numbering Groups.

To modify numbering groups the user first exports the numbering groups file. The exported file is opened in a CSV editor and updated. The updated file is imported back into Numbering Groups using the import numbering groups functionality.

Validation is performed while importing the numbering groups. If a validation error occurs during the import process:

- proper validation error message is displayed
- · importing numbering group file is discarded
- · no data change occurs

Elements and targets are stored as name only. Hence, name changes in the element table of UCM Common Services requires the user to export the CSV file, update the data and then import the new file. The list of elements shown in the locations table is not validated against the UCM Common Services elements table until an account is added for a particular location and then only the particular location is validated.

# **Export numbering groups into a CSV file**

Use the steps in the following procedure to export one or more numbering groups into a CSV file.

### Exporting numbering groups into a CSV file

 From the UCM Common Services navigator, click Network > CS 1000 Services > Numbering Groups.

The Numbering Groups page opens.

2. Click Export.

The File Download dialog box opens.

3. Click Save.

The Save As dialog box opens.

4. Specify a path and filename for the CSV file and click **Save**.

The Download complete dialog box opens.

5. Click Close.

# Import numbering groups from a CSV file

Use the steps in the following procedure to import one or more numbering groups from a CSV file.

### Importing numbering groups from a CSV file

 From the UCM Common Services navigator, click Network > CS 1000 Services > Numbering Groups.

The Numbering Groups page opens.

#### 2. Click Import.

The Import Numbering Groups page opens.

#### Click Browse.

The Choose file dialog box opens.

4. Specify a path and filename for the CSV file and click **Open**.

The Import Numbering Groups page refreshes, and fills the path to the CSV file in the File name box.

#### 5. Click Import.

The Numbering Groups page opens.

# **Restore numbering groups**

Use the steps in the following procedure to restore previous numbering groups.

### Restoring numbering groups

 From the UCM Common Services navigator, click Network > CS 1000 Services > Numbering Groups.

The Numbering Groups page opens.

2. Click Restore.

A popup box is displayed. The popup box warns the user that: Current numbering groups will be discarded. Previous numbering groups will be restored.

3. Click OK.

# Invoke telephony account CLID/URI generation

Subscriber telephony account CLID/URI generation is based on a fixed schedule. Every 120 minutes (2 hours), the management application runs a scheduled CLID/URI generation job. Rather than waiting for the next fixed schedule to generate telephony account CLID/URIs, a user can invoke telephony account CLID/URI generation. CLID/URI generation may be time intensive, depending on the number of configured subscriber telephony accounts. The user can work on other administrative operations after invoking CLID/URI generation.

Use the steps in the following procedure to invoke telephony account CLID/URI generation.

#### Invoking telephony account CLID/URI generation

 From the UCM Common Services navigator, click Network > CS 1000 Services > Numbering Groups.

The Numbering Groups page opens.

2. Click Generate Now.

The **Numbering Groups** page displays the Generation Status. The Generation Status has three states:

- a. Never generated CLID/URI generation has never been triggered.
- b. Complete the last CLID/URI generation operation has completed.
- c. Running the current CLID/URI generation operation is running.

# View numbering groups report

To obtain CLID/URI generation status, use the steps in the following procedure to view the last numbering groups generation report.

### Viewing numbering groups report

 From the UCM Common Services navigator, click Network > CS 1000 Services > Numbering Groups.

The Numbering Groups page opens.

2. Click Report.

The Numbering Groups Report page opens.

# **Chapter 16: Corporate Directory**

The Avaya Communication Server 1000 (Avaya CS 1000) Corporate Directory allows Avaya 3900 Series Digital Deskphones and IP Phone sets to display and access a corporate-wide telephone directory. UCM Common Services provides a Corporate Directory application, that generates the corporate directory file and uploads it to Avaya CS 1000 systems.

Subscriber Manager and Corporate Directory are installed on the primary UCM server. The Subscriber Manager application manages the subscriber and accounts data for Corporate Directory.



In System Manager (SMGR) 6.2, Subscriber Manager is replaced with User Profile Manager (UPM). During upgrades from System Manager 6.1 to 6.2, user accounts must be exported from Subscriber Manager and imported to User Profile Manager. For information about migrating user accounts to UPM, see *Administering Avaya Aura System Manager*.

#### Related links

Forming Dialing Prefixes on page 336

Corporate Directory prerequisites on page 338

Manage Corporate Directory reports on page 338

Run the Corporate Directory report on page 339

**Export Corporate Directory report on page 341** 

Import the Corporate Directory report on page 342

View history of the Corporate Directory report on page 343

Viewing the history of the Corporate Directory report import on page 344

Schedule the Corporate Directory report on page 344

Blocking concurrent user operations in Corporate Directory on page 345

# **Forming Dialing Prefixes**

The numbers in the Corporate Directory should not be context or user sensitive because any user can dial from the directory and the results need to be consistent for all users. Therefore, the numbers must be plain internal or ESN numbers. These are numbers that do not need to be manipulated by pre-translation, zone based dialing, zone based prefixes (ZFDP), or other number manipulation features. The ESN numbers can be subject to post-translation, such as local termination or digit manipulation.

Dialing Prefixes are a combination of codes that are prefixed with a DN to construct a ready-to-dial number. Dialing prefixes can be created from the following codes:

- AC1
- Home Location Code (HLOC)
- AC2
- · International Code
- National Code
- · Area/City Code
- Exchange Code

For internal dialing, dialing prefixes will be formed using the AC1 and HLOC. For external dialing, dialing prefixes will be formed using the AC2, International Code, National Code, Area/City Code and Exchange Code. If any of the codes are unavailable, dialing prefixes are formed either without the code or by substituting zero, whichever is appropriate.

AC1 and AC2 Access Codes for a particular CS 1000 customer are configured using the Numbering Group application. The Home Location Code is available in the telephony account created using Subscriber Manager. The International Code, National Code, Area Code and Exchange Code are available only if CLID/URIs are generated for all telephony accounts. <u>Table 107: Data sources for codes used to form Dialing Prefixes</u> on page 337 summarizes the data sources used by the Corporate Directory application to create dialing prefixes.

Table 107: Data sources for codes used to form Dialing Prefixes

ESN (Internal)		External				
Access Code	Location	Access Code	International	National	Area Code	Exchange
(AC1)	Code (HLOC)	(AC2)	Code	Code		Code
Numbering	Telephony	Numbering	Account	Account	Account	Account
Group	Account	Group	CLID	CLID	CLID	CLID

Avaya recommends that the Access Codes be configured for each customer and that CLID/URIs are generated for all telephony accounts, so that appropriate dialing prefixes are formed. Note that the Access Codes must be configured and the CLID/URIs must be generated before any Corporate Directory operations are performed. For more information on configuring Access Codes and generating CLID/URIs, see <a href="Invoke telephony account CLID/URI generation">Invoke telephony account CLID/URI generation</a> on page 334.

The intermediate CSV report may contain DNs prefixed with HLOC or CLID. Based on the type of prefixes available in DNs and the type of Access Code(s) configured for the CS 1000 customer to which the report is to be uploaded, dialing prefixes are formed by applying the rules summarized in Table 108: Rules governing creation of Dialing Prefixes for a DN on page 338.

However, if the home customer (the customer on which the phone is configured) and the target customer (the customer to which the report is being uploaded) are the same, then, no prefixes are required. In this case, the DN will have no dialing prefixes.

Table 108: Rules governing creation of Dialing Prefixes for a DN

SI. No.	Access Code		DN Format	Output (Prefix + DN)
	AC1   AC2			
1	No	No	No CLID, No HLOC	DN
2	No	No	Valid HLOC	HLOC + DN
3	No	No	Valid CLID	CLID + DN
4	Yes	No	No CLID, No HLOC	DN
5	Yes	No	Valid HLOC	ESN Access Code + HLOC + DN
6	Yes	No	Valid CLID	CLID + DN
7	No	Yes	No CLID, No HLOC	DN
8	No	Yes	Valid HLOC	HLOC + DN
9	No	Yes	Valid CLID	External Access Code + CLID + DN
10	Yes	Yes	No CLID, No HLOC	DN
11	Yes	Yes	Valid HLOC	ESN Access Code + HLOC + DN
12	Yes	Yes	Valid CLID	External Access Code + CLID + DN

#### Related links

**Corporate Directory** on page 336

# **Corporate Directory prerequisites**

- The element containing target customers must be in the UCM security domain.
- Centralized Authentication must be enabled.

#### Related links

Corporate Directory on page 336

# **Manage Corporate Directory reports**

The procedures in this section describe the features available in UCM Common Services to manage Corporate Directory reports within your network.

#### Note that

- If a user attempts to launch the Corporate Directory when no valid telephony accounts are present, the message "No valid telephony accounts are available." is displayed on the page.
- To launch the Corporate Directory a user must be mapped to the role All elements by type: Numbering Groups.

• If a user attempts to launch the Corporate Directory when not mapped to the role All elements by type: Numbering Groups, the message "Role(s) assigned to user does not have permission enabled for allowing access to Corporate Directory. Please contact Network Administrator." is displayed on the page

Refer to *Unified Communications Management (NN43001-116)*, for detailed information on assigning roles and permissions for access to the Corporate Directory application from the UCM Common Services.

#### Related links

**Corporate Directory** on page 336

# **Run the Corporate Directory report**


### **Running the Corporate Directory report**

From the UCM Common Services navigator, click Network > CS 1000 Services > Corporate Directory.

The system opens the Corporate Directory page with the latest report status.

2. Click Configure.

The system displays the Properties page.



- 3. In the **Source Elements** section, select the check box beside the Elements to include in the report.
- 4. In the Target Elements section, select the check box beside one or more Target Element to which the Corporate Directory report is to be uploaded.
- 5. Click on the target element for which you configure source elements.

The system displays the Source Selection page.

- 6. Select the check box beside one or more Source Element from which you require the data.
- 7. Click Save.

The system displays the Properties page.

- 8. Select the Exclude unpublished Telephony Accounts check box.
- 9. Select the format of the **Name** field.
  - Use First and Last Name. The first name and last name correspond to the Subscriber First name and Last name.
  - Use Preferred Name. The first name is mapped with the corresponding Subscriber Preferred Name and the Last Name field is filled with empty string. If the Subscriber Preferred Name field is empty, then the First Name is mapped with the corresponding Subscriber First name and the Last Name field is mapped with corresponding Subscriber Last Name.
  - Use Display Name: When you use UCM on System Manager, a Use Display Name option is displayed instead of the Use Preferred Name option. The first name is mapped with the

corresponding User Localized Display Name and the Last Name field is mapped with the corresponding User Last Name.

Use CPND Name. If the CPND Name is not empty and contains comma (,) then first name
and last name for the Corporate Directory report are mapped to the corresponding CPND
Name field of the telephony account: the first name is mapped with all characters before
comma and the last name is mapped with all characters after the comma. If the CPND
Name is empty or does not contain comma, then the first name and last name correspond
to the Subscriber First name and Last name.

### Note:

Corporate Directory does not support comma (,) characters in any fields, such as first name, last name, department that are used for report generation. If a field contains comma, the system replaces comma by a space in the report.

- 10. Select the **CPND** name display format. This option is available only when you use UCM on System Manager. It is required to select the format of CPND Name used on the system to perform the mapping of Corporate Directory first and last name correctly. The following formats are available: "First, Last", "Last, First", "First Last", "Last First".
- 11. Click Save and Run.

The system displays the Report Execution Results page.

The system saves the selected parameters in the UCM Common Services server. When a user subsequently launch the Corporate Directory application, the saved report definition is used to find the source and target customers selected for the last report execution. The system selects the valid customers for running the report. Similarly, other report execution parameters, such as excluding unpublished accounts, name format, and scheduler parameters, are also enabled with the values used for the last report execution. Thus, a user can reuse the report definition created in the previous report generation.

You cannot automatically upload a Corporate Directory report when IPsec is configured when the Intra System Signaling Security (ISSS) level is set to **Full**. To upload the report, start a PDT shell and run the **UPDATE\_CORP\_DIR** command on each target Call Server. For information about the interaction between SNMP and ISSS/IPsec, see *Fault Management - SNMP*, NN43001-719.

#### Related links

Corporate Directory on page 336

# **Export Corporate Directory report**

The last generated Corporate Directory report can be exported to a client machine and edited offline prior to uploading it to a target element. The changes introduced in the exported CSV file will not be reflected in the data store. However, the changes will be propagated to the target elements.

### **Exporting Corporate Directory report**

From the UCM Common Services navigator, click Network > CS 1000 Services > Corporate Directory.

The system displays the Corporate Directory page.

#### 2. Click download report.

Note:

The download report link is unavailable if Corporate Directory reports have not been generated.

3. For Internet Explorer, click Save

The system displays the Save As dialog box.

Note:

For Mozilla Firefox, the system saves the report to the default directory that you earlier configured for Firefox. The system does not display the Save As dialog box.

4. Specify a path and filename for the CSV file and click **Save**.

The system displays the Download complete dialog box.

5. Click Close.

#### Related links

**Corporate Directory** on page 336

# **Import the Corporate Directory report**

Use the following procedure to import a Corporate Directory report from a client machine.

### **Importing Corporate Directory report**

From the UCM Common Services navigator, click Network > CS 1000 Services > Corporate Directory.

The system displays the Corporate Directory page.

2. Click Configure.

The system opens the Properties page.

3. Click From import file.

The system opens the Import page.

4. Click Browse.

The system displays the Choose file dialog box.

5. Specify a path and filename for the CSV file, and click **Open**.

The Import page refreshes, and populates the File name field with the path to the CSV file.

6. Click Upload.

The system refreshes the page and provides the last imported status.

7. Click download report... to export last imported report

The **download report...** option is unavailable if Corporate Directory reports have not been imported.

### Note:

The system imports the file only if the following criteria are satisfied:

- The file has a .csv or .CSV extension.
- The file is not empty.
- The file contains all mandatory columns exactly in the following order. The column names are case sensitive. FIRST\_NAME, LAST\_NAME, PRIMEDN, CUSTOMER, DEPARTMENT and SYSTEMID

#### Related links

**Corporate Directory** on page 336

# **View history of the Corporate Directory report**

Use the procedure to view the history of the last generated, last uploaded, or last imported Corporate Directory report.

### **Viewing history of Corporate Directory report**

From the UCM Common Services navigator, click Network > CS 1000 Services > Corporate Directory.

The system displays the Corporate Directory page.



If a report has not been generated, the system displays <code>Never Generated</code> next to <code>Last Generated</code>: in the <code>History</code> section of the page. Similarly, if a report has not been uploaded, the system displays <code>Never Uploaded</code> next to <code>Last Uploaded</code>. If a report has been generated or uploaded, the system displays the timestamp of the last generate or upload operation.

- 2. Perform one of the following actions:
  - To view history of the last generated report, click the Last Generated: time stamp link.
     The system displays the Last Generated Report Details page.
  - To view history of the last uploaded report, click on the Last Uploaded: time stamp link.
     The system displays the Last Uploaded Report Details page.

#### **Related links**

**Corporate Directory** on page 336

# Viewing the history of the Corporate Directory report import

1. From the UCM Common Services navigator, click Network > CS 1000 Services > **Corporate Directory.** 

The system displays the Corporate Directory page.

2. Click Configure.

The system displays the Properties page.

3. Click From import file.

The system opens the Import page.



#### Note:

If a report has not been imported, the system displays the message Never Imported next to Last Imported: in the History section of the page. If a report has been imported, the system displays the timestamp of the last import operation.

#### Related links

Corporate Directory on page 336

# Schedule the Corporate Directory report

Use the following procedure to schedule the Corporate Directory job.

#### **Scheduling Corporate Directory report**

1. From the UCM Common Services navigator, click Network > CS 1000 Services > Corporate Directory.

The system displays the Corporate Directory page.

2. Click Configure.

The system opens the Properties page.

3. Select the **Customize Scheduler** check box.

The system displays the Scheduler page.

- 4. In the **Frequency** field, select one of the following options:
  - Once, the default option.
  - Daily
  - Weekly
- 5. Select an appropriate options based on frequency you select.
- 6. Click Save.

The system displays the Corporate Directory status page.

#### Related links

**Corporate Directory** on page 336

# Blocking concurrent user operations in Corporate Directory

If a concurrent operation is not allowed, it is blocked for a second user. For all operations that have a status page, such as report generation, the second user is shown the status page of the first user and a message is displayed. For all other operations, a message is displayed on a pop-up box. In the following table it is assumed that the username of the first user is admin. If the username of the first user is not admin, the system displays similar error messages.

Table 109: Output as seen by a second user when concurrent operations are performed

Second User	First User		
Operation	Generate or Upload	Import	Export
Generate or Upload	Second user is not allowed to continue the Generate or Upload operation. Gives an error message Report Generation is already in progress by another user	Second user is not allowed to continue the Generate or Upload operation. Gives error message Report Import is already in progress by another user	Second user is not allowed to continue the Generate or Upload operation. Gives an error message Report Export is already in progress by another user
Import	Second user is not allowed to continue the Import operation. Gives an error message Report Generation is already in progress by another user	Second user is not allowed to continue the Import operation. Gives error message Report Import is already in progress by another user	Second user is not allowed to continue the Import operation. Gives an error message Report Export is already in progress by another user
Export	Second user is not allowed to continue the Export operation. Gives an error message Report Generation is already in progress by another user	Second user is not allowed to continue the Export operation. Gives error message Report Import is already in progress by another user	Second user is not allowed to continue the Export operation. Gives an error message Report Export is already in progress by another user

#### Related links

**Corporate Directory** on page 336

# **Chapter 17: IP Media Services**

IP Media Services is installed with the Signaling Server application and enabled using Element Manager. To configure the individual IP Media Services applications, package 422 must be unrestricted and configuration options must adhere to licensing limitations.



#### Note:

IP Media Services is only supported for CS 1000E systems. It is not supported on CS 1000M systems.

IP Media Services does not support Automatic Wake Up, as that feature does not use standard IP RAN or IP Music routes.

### **Contents**

This chapter contains the following topics:

- Introduction on page 346
- System architecture on page 347
- Network Media Services on page 350

### Introduction

In traditional TDM-based systems, TDM hardware cards (MIRAN and MGC) provide media services such as conference mixing and media playback. Delivering these services to IP endpoints requires many digital signaling processors (DSPs) to translate information between the TDM backplane and IP voice packets.

IP Media Services introduces IP versions of these services to the Avaya Communication Server 1000E (Avaya CS 1000E) by using the Avaya Aura® Media Server as the IP media service delivery platform.

Avaya Aura® MS supplies media services by using both secure and nonsecure Real-time Transport Protocol (sRTP and RTP) channels controlled by the Call Server and Signalling Server, which map the Avaya Aura® MS resources to existing virtual TNs. Avaya Aura® MS is an IP-based media server and therefore does not require DSPs to deliver IP media services to IP endpoints.

### Note:

The IP address for the IP Media Services controller must be in IPv4 format. If the Avaya Aura<sup>®</sup> MS is dual-stack, with both IPv4 and IPv6 formats, the signaling path between the IP Media Services applications and the Avaya Aura<sup>®</sup> MS is IPv4. Media paths between Avaya Aura<sup>®</sup> MS and IPv6-capable clients can be IPv6.

The Media Services software applications are included in the Signaling Server image and installed as part of Signaling Server applications. IP Media Services includes the following features and applications:

- IP Ad Hoc Conference
- IP Music Broadcast
- IP Recorded Announcements
- IP Tone Generation
- IP Attendant Console (3260)

### Note:

IP Media Services is supported only for Avaya CS 1000E systems.

For information about IP Media Services features and applications, see *Features and Services Fundamentals—Book 4, NN43001-106.* 

For information about deploying Signaling Server and associated applications, see *Linux Platform Base and Applications Installation and Commissioning, NN43001-315.* 

For information about Avaya Aura® MS, see *Media Application Server Platform Fundamentals*, *NN44471-101* and *Installing*, *Upgrading*, *and Patching Avaya Aura® Media Server*.

### Note:

IP Media Services is a specific implementation of Media Services 7.0. IP Media Services for CS 1000E does not support Avaya Aura® MS High Availability 1+1 (Primary and Backup Servers). IP Media Services uses a standard N+1 model (Primary, Secondary and Standard servers). Please keep this in mind when designing and deploying IP Media Services for the CS 1000E.


# System architecture

This section contains information on the following topics:

- Call Server on page 348
- Signaling Server on page 349
- Avaya Aura Media Servers on page 350

The main system components of IP Media Services are shown in the following diagram.

Figure 90: IP Media Services system components



### Note:

The Network Redirect Server (NRS) supports IP Media Services.

### **Call Server**

On the Call Server, the existing media service delivery standards are maintained. However, new IP-based media resource types emulate traditional TDM media resources and operate as virtual TNs, using software to replace former hardware functions. The virtual TN-based resources are IP Ad Hoc Conference and IP Tone loops, as well as IP Music and IP RAN routes and trunks.

In systems where both TDM and IP-based resources are active, the Call Server selects the appropriate resource based on the service target. Music and RAN services are selected based on the route type defined in the Customer and Route Data Blocks and Conference service is determined by the caller who presses the conference key. Whenever possible, the Call Server selects the same media resource type as the service target.

# Resource selection in mixed deployments

In systems with both IP and TDM endpoints, the Communication Server 1000E supports configuration of both TDM and IP media resources. In such deployments, the Call Server selects the media resource type according to the following criteria:

Conference—The preferred media resource type is the same as the phone that initiates the
conference. If no matching resource is available, the Call Server selects the other conference
resource type as an alternative.

- Tones—IP tone loops are selected for IP endpoints only. This includes IP Phones, IP
  Conference, IP Announcement, virtual trunks (SIP and H.323), and all devices connected using
  virtual trunks (such as SIP DECT and SIPL, and so on). If an IP Tone loop is not available, then
  a TDS loop is selected. However, if the preferred service is TDS and no TDS loops are
  available, an IP Tone loop is not used.
- Music and RAN—Music and RAN are chosen according to existing music and RAN route selection algorithms. Each music or RAN route on the system can consist of either TDM or IP trunks.

# Signaling Server

As with other virtual TN services, application software on the Signaling Server replaces the functions formerly provided by TDM hardware. IP Media Services introduces new Media Service Controller (MSC) applications to the Signaling Server that are the signaling bridge between the Call Server and the Avaya Aura® MS servers. These applications receive the traditional TDM-based signaling from the Call Server using the existing Signaling Server PBX Link and direct the Avaya Aura® MS signaling using SIP.

The Media Services Controller can be configured as a standalone Signaling Server application or as coresident with other Signaling Server applications, as determined by the capacity requirements for IP Media Services. For Communication Server 1000E capacity and engineering guidelines, see *Communication Server 1000E Planning and Engineering, NN43041-320.* 

IP Media Service Controller application is a collection of SIP clients. When the Call Server requests a media resource, the corresponding MSC application creates a new SIP client, which then makes a SIP request to the Avaya Aura® MS. After the SIP session is established, Avaya Aura® MS negotiates a media path with the target endpoint in response to speech path control messages received from the Call Server. Each IP Media service has its own unique MSC that is active.

IP Media Services supports both secure and non secure RTP and TLS signaling for the media path.

# **Resource registration**

IP Media Services applications use a resource registration process similar to that of the SIP Gateway. Each IP Media Service resource configured on the Call Server is assigned to an IP Telephony Node. At startup, the IP Media Services applications notify the Call Server that they are active using the Signaling Server's existing server online notification mechanism.

In response to this notification, the Call Server notifies the IP Media Services application of the resources that are available for it to manage. The IP Media Services application then creates the appropriate resources and registers them with the Call Server.

# Avaya Aura® Media Servers

The Avaya Aura® Media Server deliver RTP-based media services to the IP endpoints based on instructions received from the Call Server and Signaling Server. The Avaya Aura® MS servers are directed by SIP signaling from the IP Media Services controllers to deliver RTP service streams to IP endpoints and to subsequently tear down the streams upon completion of service delivery. IP Media Services supports both secure and non secure SIP signaling paths.

The relationship of Avaya Aura® MS servers to Communication Server 1000E resources is flexible; one Avaya Aura® MS can provide services to many Call Servers or several Avaya Aura® MS servers can provide service to one Call Server, depending on the number of subscribers supported by the Call Servers.

For information about Avaya Aura® MS, see Installing, Upgrading, and Patching Avaya Aura® Media Server and Implementing and Administering Avaya Aura® Media Server.



#### Note:

IP Media Services is a specific implementation of Media Services 7.0. IP Media Services for CS 1000E does not support Avaya Aura® MS High Availability 1+1 (Primary and Backup Servers). IP Media Services uses a standard N+1 model (Primary, Secondary and Standard servers). Please keep this in mind when designing and deploying IP Media Services for the CS 1000E.

### **Network Media Services**

The IP Media Services model is flexible and allows you to implement many network deployment models. It has the capability of supporting a simple dedicated model, such as a single Avaya Aura® MS associated with a single CS 1000E at the same location, to more complex models, such as multiple Avaya Aura<sup>®</sup> MSs servicing networks connecting several sites or bandwidth zones.

If a site needs more than one server due to capacity, Geographic Redundancy (survivability) or other redundancy requirements, you can combine those servers into a single cluster.



#### Note:

A cluster functions as a N+1 model. In this model, N servers are active and engineered to satisfy the required capacity, with one spare server. Thus, the failure of any one of the N servers does not impact customer capacity.

The following are examples where you can use a cluster:

- If you require 400 sessions and have one branch location in addition to the main site, you can use a single server at the main site and a single server at the branch. This provides the required capacity, Geographic Redundancy and redundancy.
- If you require 1,000 sessions and have a single site only, you can use a cluster at the main site.
- If you require 1,200 sessions, and have one branch location, you can use a cluster at the main site and a single server at the branch.

### Note:

Splitting an Avaya Aura® MS cluster across a WAN environment is not supported.

To facilitate the sharing of Avaya Aura<sup>®</sup> MS servers between sites or zones, you can use Network Routing Service or Aura<sup>®</sup> Session Manager as a proxy server to route media requests to the appropriate Avaya Aura<sup>®</sup> MS server. When the CS 1000E requires an IP media resource, it queries the proxy server to locate an Avaya Aura<sup>®</sup> MS server to fulfill the request.

# **Service routing**

The service routing model allows flexibility in how Avaya Aura® MS services are delivered by providing the following benefits:

- Several Communication Server 1000E systems can share Avaya Aura® MS servers.
- Alternate Avaya Aura<sup>®</sup> MS servers are selected in the event of network outage or resource exhaustion.
- Avaya Aura® MS servers are selected based on bandwidth zone criteria.

The Avaya Aura® MS servers are not statically bound to the Call Server media resources in the Call Server configuration. For example, when you configure an IP loop or route on the Call Server, no requirement exists for Avaya Aura® MS to fulfill requests for that loop or route.

Avaya Aura® MS querying occurs by using Media Service Routing Numbers (MSRN). You configure these routing numbers on the Call Server and the proxy server. On the Call Server, MSRNs are assigned to customer-zone-service combinations. On the proxy server, the MSRNs are assigned as routing entries against the Avaya Aura® MS servers.

Depending on the level of routing control desired, you can assign MSRNs on the Call Server with the following three levels:

#### **Customer level:**

This is a mandatory configuration item. The customer-level MSRN is used to locate Avaya Aura<sup>®</sup> MS servers for all zones that do not have a zone-specific MSRN assigned. When you only configure the customer MSRN, all media service requests for all zones follow the same Avaya Aura<sup>®</sup> MS selection policy.

#### Bandwidth zone level:

This is an optional configuration item. This level provides control over which Avaya Aura<sup>®</sup> MS is selected based on the bandwidth zone of the endpoint, which facilitates the delivery of services based on geographic location. Zone-level MSRNs also ensure that various zones have differing alternate Avaya Aura<sup>®</sup> MS selections.

#### Service level:

This is an optional configuration item. If a bandwidth zone has an MSRN assigned to it, then additional MSRNs can be assigned against specific media services within that zone. This ensures the separation of services to various Avaya Aura® MS servers or the application of alternate Avaya Aura® MS routing selections for different services.

Each MSRN represents a service delivery request in the form of a database record containing values for customer, zone, and service. When an IP Media Services Controller application on the Signaling Server attempts to locate an Avaya Aura® MS to provide service, it selects the MSRN used to query the NRS database according to the following criteria:

- 1. service-specific MSRN within the target bandwidth zone, if configured
- 2. MSRN of the target bandwidth zone, if configured
- 3. customer MSRN

If you use NRS as the proxy server, you configure each Avaya Aura® MS as a dynamically registering endpoint and configure the IP Media Services Controller as a static endpoint. You configure MSRNs as routing entries against the Avaya Aura® MS endpoints. This mapping, along with the associated routing entry costs, determines the primary and alternate Avaya Aura® MS used to fulfill requests associated with the MSRN customer-zone-service record.

If you use Avaya Aura® Session Manager as the proxy server, you configure each Avaya Aura® MS and IP Media Services Controller as a SIP entity.

You configure MSRNs as routing policy entries against the Avaya Aura<sup>®</sup> MS SIP entities. This mapping determines the Avaya Aura<sup>®</sup> MS used to fulfill requests associated with the MSRN customer-zone-service record.

You only require one static endpoint on the proxy server for IP Ad Hoc Conference, IP Music, IP Tone, and IP RAN applications. These applications use the TLAN IP of the Signaling Server. You do not need to configure a static endpoint for IP Attendant except in cases when there is no SIP Gateway configured. The IP Attendant application uses the Node IP of the Signaling Server.

### Note:

Avaya Aura® Session Manager does not support SIP registration.

Whenever an IP Media Services Controller application on the Signaling Server requires service from a Avaya Aura<sup>®</sup> MS, the Call Server selects the appropriate MSRN and passes it to the IP Media Services Controller.

The MSC uses the MSRN to query the proxy server database, which responds with a cost-sorted list of eligible Avaya Aura® MS servers. Starting with the lowest cost Avaya Aura® MS, the MSC locates a Avaya Aura® MS server to fulfill the request.

### Example of MRSN configuration when using NRS as the proxy server

After you configure the MSRN on the Call Server, use Network Routing Service Manager (NRSM) to add the service domain and Level 1 and Level 2 domains. Configure the IP Media Service controller as a static endpoint, as shown in the following figure.

### Note:

The MSC IP address must be in IPv4 format.




Figure 91: MSC as a static endpoint in NRSM

Configure the Avaya Aura® MS as a dynamic endpoint in NRSM by selecting Dynamic SIP endpoint from the SIP Support list menu. The following figure shows the Avaya Aura® MS configured as a dynamic endpoint in NRSM.




Figure 92: Avaya Aura® MS as a dynamic SIP endpoint in NRSM

After you configure the MSC and Avaya Aura® MS endpoints, add a routing entry for the Avaya Aura® MS endpoint. The following figure shows the routing entry page in NRSM.



Figure 93: Routing entry for Avaya Aura® MS endpoint in NRSM

### Note:

When configuring MSC and Avaya Aura® MS endpoints using NRS, you must configure the **SIP mode** as Proxy Mode. In Session Manager, all entities are Proxy Mode as Redirect Mode is not supported.

You can then continue to configure IP Media Services using the Element Manager Media Services Configuration Details page.

For information about configuring IP Media Services using Element Manager, see Configure IP Media Services using Element Manager on page 367.

For information about configuring MSRN using Element Manager, see <u>Configure Media Services</u> Routing Number using Element Manager on page 364.

For information about configuring NRSM, see *Network Routing Service Fundamentals*, *NN43001-130*.

# Avaya Aura® Session Manager

To enable media services routing for systems with Aura® Session Manager, you must configure the Avaya Aura® MS as a SIP Entity using Avaya System Manager. The Aura® Session Manager database can then be queried using a MSRN (Media Services Routing Number) to locate a specific server. You must configure media server routing numbers for both the Call Server and the Aura® Session Manager as the Dial Pattern for a Avaya Aura® MS SIP entity must partially match at each server.

If a MSRN is not configured on the Call Server, Aura<sup>®</sup>Session Manager (or a SIP Proxy Server) does not require any media server configuration and uses the local media server defined in Element Manager for all media services.

### Note:

For IP Attendant, the third party IP Attendant client must initially register with the IP Attendant MSC application on the CS 1000 Signaling Server. Then you can route it to a Media Server using Session Manager, NRS, or Local Media Server configuration.

# **Bandwidth management**

To facilitate proper bandwidth usage tracking, each Avaya Aura® MS endpoint (or Avaya Aura® MS SIP entity, if you are using Aura® Session Manager) is assigned a VPNI and bandwidth zone number that enables the Call Server to track bandwidth usage between the Avaya Aura® MS servers and other IP endpoints.

IP Media Services use a late-binding model to select a Avaya Aura® MS server for service requests. In this model, the Avaya Aura® MS selection does not occur until the Call Server determines the bandwidth zone of the Avaya Aura® MS by establishing the speech paths.

Because of the late-binding nature of the Avaya Aura® MS selection model, IP media sessions are not subject to bandwidth management call admission control. Bandwidth used by IP media sessions is accurately reported but IP media sessions are not blocked due to insufficient bandwidth. In this event, the Call Server raises a QOS0038 Insufficient Bandwidth alarm but the session remains established.

You can specify the zone and VPNI configuration for the Avaya Aura® MS SIP Entity when configuring the Location details in Avaya System Manager. This information is sent by Aura® Session Manager to the IP Media Services controller and is later used by the Call Server for bandwidth management. When viewing the SIP Entity details of the Avaya Aura® MS in Avaya System Manager, the Location field matches the zone and VPNI details entered in the Name field on the Location Details page in Avaya System Manager. For more information, see Configuring bandwidth management for a Avaya Aura MS SIP entity on page 377

For more information about bandwidth management, see Converging the Data Network with VoIP Fundamentals, NN43001-260.

# System resiliency

Avaya Aura® Session Manager allows up to two levels of Session Manager routing: Primary and Secondary ASMs.



#### Note:

If you are configuring Avaya Aura® Session Manager as the proxy server for the SIP Gateway in Element Manager, do not select the **Support registration** option. The SIP Proxy Server does not support registration.

The following sections describe the methods used by IP Media Services to provide system resiliency.

# Geographic redundancy

Multiple media servers can act as alternates if the primary media server fails. If you configure NRS as the proxy server. IP Media Services uses up to three levels of NRS routing. For small customer

deployments or survivable branches without an NRS, the local media server provides all media services.



#### Note:

The local media server configuration supports a single Avaya Aura® MS server only.

For systems using Aura® Session Manager as the proxy server, you can specify a Primary and Secondary Aura® Session Manager for two levels of alternate routing.

In High Scalability systems, the Survivable SIP Media Gateway (SSMG) consists of a Survivable Call Server (SCS) and SIP Media Gateway (SMG) that provide IP resources in the event of WAN outage. During a WAN outage, IP Phones register locally to the SCS.

To provide call progress tone (ring back tone only), tone service is requested from the SMG using the same method that the IP Media Services applications use to request tone service from the Avaya Aura® MS, provided that the SCS is running the IP Media Services application, the SMG IP address is configured as the local media server for IP Media Services, and the local media server role is configured as SIP Media Gateway. When the SMG receives the tone request, the SIP Gateway application translates the request to an ACD DN call. The Call Server places the call into an ACD queue and provides in-band ring back tone to the call originator.



#### Note:

Avaya Aura® MS clusters are not supported across a WAN environment.

# **Alternate NRS support**

If you configure the NRS as a proxy server, the MSC applications support the querying of up to three NRS servers and one local media server. The three-level hierarchy (primary, secondary, tertiary) for NRS selection allows for system resiliency and geographic redundancy if the network or NRS fails.

The local media server configuration allows for single site or zone deployments for which an NRS is not required. In a branch survivability scenario, an Avaya Aura® MS may be present in the branch but it cannot reach an NRS to locate it.

The following diagram shows an example of alternate NRS routing.




Figure 94: Alternate NRS routing

# **High Availability**

### Note:

The information in this section is in regards to IP Media Services Controller applications on the Signaling Server.

The High Availability model for the IP Media Services Controller applications is consistent with the model generally used for Signaling Server. The IP Media Services Controller applications are deployed on the IP telephony node in a 1+n Active/Standby model. On the current node master, IP Media Services Controller applications are active and registered to the Call Server. On the standby nodes, IP Media Services Controller applications are on standby and are not registered to the Call Server.

If the node master loses its mastership, an internal election process selects a new master. Media services running on the new node master become active and register to the Call Server. Media services on the previous master enter standby mode and are no longer registered to the Call Server.

### Note:

During the election process to select a new master node, media services are temporarily unavailable.

In conjunction with system resiliency and Geographic Redundancy, the High Availability model helps to ensure that there is no single point of failure for IP Media Services.

For more information about the election process, see Node election rules on page 226.

# **Security**

The following sections describe security features of IP Media Services.

# SIP security

Transport Layer Security (TLS) provides a SIP TLS signaling link between the IP Media Services controllers and Avaya Aura® MS that protects the integrity of SIP signaling and provides client-server authentication. A handshaking procedure establishes secure connections between TLS clients and Avaya Aura® MS.

No additional certificate configuration is required for IP Media Services. Mutual trust must be established between two SIP TLS endpoints that use certificates signed by different public CAs. To accomplish this trust, the TLS client must add the server signing CA certificate to the list of trusted CA certificates and the server must add the TLS client certificates, by using the Unified Communications Management (UCM) management console.

For more information about certificate management, see *Security Management Fundamentals*, *NN43001-604*.

# **Media Security**

IP Media Services applications provide Media Security capabilities for media exchanges between Communication Server 1000 devices and Avaya Aura® MS. Media Security allows endpoints using Secure Real-Time Transport Protocol (SRTP) to exchange secure media. Except for the IP Attendant application, which does not support it, SRTP is enabled by default for IP Media Services applications and cannot be disabled.

### Important:

If there are endpoints in the network that do not support SRTP, configure SIP Media Security as Best Effort to avoid speech path issues that can occur if the Avaya Aura® MS is configured with Media Security Enforced. If the Avaya Aura® MS is configured with Media Security Enforced, endpoints that do not support SRTP will not receive speech paths when added to an IP Ad Hoc Conference.

For more information about SRTP, see Security Management Fundamentals, NN43001-604.

For information about Avaya Aura<sup>®</sup> MS media security, see *Implementing and Administering Avaya Aura*<sup>®</sup> *Media Server*.

For information about signaling security for NRS, see *Network Routing Service Fundamentals*, *NN43001-130*.

# License requirements for IP Media Services

The following licenses are available for IP Media Services:

- IP Media Services Session license (System license)
  - This license is required for all IP Media Services and includes provisions for IP RAN, IP Music, IP Ad Hoc Conference, and IP Tone services.

### Note:

You require one IP Media Services Session for each individual caller receiving any form of Media Services treatment (i.e. there is no broadcasting over an IP Media Services Session).

- IP RAN sessions license (System license)
- IP MUSIC sessions license (System license)
- IP Attendant User license (User license)

### Note:

Each IP Attendant TN occupies three IP Media Session licenses.

Review the sections on IP RAN and IP Music for more details about the licensing implication of each, and their correlation with IP Media Services Session licenses.

Feature package 422 is required for IP Media Services and must be enabled on the keycode.

In addition, the following license is required for IP Media Services, on the Media Server:

RFC 4240 Services Sessions license



You require one RFC 4240 Services Session for each IP Media Services Session.

IP Media Services uses a floating license model to manage Avaya Aura® MS licensing. In a floating license model, authorized users receive licenses from a licensing server. The licensing server provides a limited number of licenses that are shared by multiple users and applications on a system or network. When the license expires or is no longer required by a user or application, the licensing server reclaims the license for distribution to other authorized users or applications.

There are two options for deploying the Avaya Aura® MS floating licensing model:

- Avaya Aura<sup>®</sup> MS deployed as a standalone server
- Avaya Aura<sup>®</sup> MS cluster deployment

In a Avaya Aura® MS standalone server or servers deployment, an individual license is generated and applied for each Avaya Aura® MS server. You must configure each Avaya Aura® MS server independently with a routing entry on NRS or Session Manager, as applicable.

In a Avaya Aura® MS cluster deployment, one license is generated and applied for the cluster. You must configure the Primary and Secondary servers with routing entries on NRS or Session Manager, as applicable.

For a Avaya Aura<sup>®</sup> MS cluster deployment:

IP Media Services does not support Avaya Aura® MS clusters across a WAN

 IP Media Services does not support High Availability 1+1 (Primary and Backup Servers) on the Avaya Aura<sup>®</sup> MS. N+1 (Primary, Secondary and Standard Servers) is the supported Avaya Aura<sup>®</sup> MS cluster deployment for IP Media Services.

Replication of content (for Music or Announcements) is supported in both standalone or cluster deployments.

For information on deploying Avaya Aura<sup>®</sup> MS licenses, see <u>Configure the license for a dedicated</u> <u>Avaya Aura MS</u> on page 360 and <u>Configure the license for an Avaya Aura MS cluster</u> on page 361

In addition, the Avaya Aura® MS Enablement license is required on each Avaya Aura® MS server, including servers provided for redundancy.

### Migrating Communication Server 1000 Release 7.6 licenses to MAS 7.0

For IP Media Services installed as part of Communication Server Release 7.6 systems, the KRS Authorization Code tool delivers the licensing.

# Configure the license for a dedicated Avaya Aura® MS

You can configure the license during the pre-deployment of Avaya Aura<sup>®</sup> MS or after Avaya Aura<sup>®</sup> MS has already been deployed. Choose the procedure as applicable to your installation.

### Configuring the pre-deployment license for a dedicated Avaya Aura® MS

Use this procedure to configure the pre-deployment licensing on a standalone Avaya Aura® MS server.

- 1. Configure a Communication Server 1000 Linux base server as a Primary security server.
- 2. Configure a Communication Server 1000 Linux base COTS2 server, Common Server or Common Server R2 as a Member security server.
- 3. Upload the Avaya Aura® MS installation media to the Primary security server.
- 4. Request a platform license key from the authorized person.

### Note:

You must know the MAC address of the Avaya Aura® MS server.

- 5. Log on to the Primary security server using the admin account.
- 6. Click Deployment > Deployment View.
- 7. From the View menu, select Network services.
- 8. Select MAS and click Add.
- 9. Enter a name for the service.
- 10. Choose the Member server for Avaya Aura® MS service.
- 11. Upload the license server key file and click **Validate**.
- 12. From the **View** menu, select **Servers**.
- Click Commit.
- 14. Choose the Member server.
- 15. From the **Deployment actions** menu, click **Deploy**.

For more information about deploying Avaya Aura® MS, see Linux Base Fundamentals, NN43001-315.

## Configuring the post-deployment license for a dedicated Avaya Aura® MS

Post-deployment licensing is configured on the Avaya Aura® MS using the Avaya Aura® MS Element Manager. For information on configuring the post-deployment licensing, refer to the Avaya Aura® MS documentation.

## Configure the license for an Avaya Aura® MS cluster

Avava Aura® MS cluster servers have three supported roles for IP Media Services on CS 1000E: Primary, Secondary and Standard server.



#### Note:

High Availability 1+1 (Primary and Backup server) is not supported for IP Media Services on CS 1000E.

For more information about Avaya Aura® MS, refer to Implementing and Administering Avaya Aura® Media Server.

## Configuring the pre-deployment license for a Primary Avaya Aura® MS

Use this procedure to configure the pre-deployment licensing for a Primary Avava Aura® MS server that is part of a cluster.

- 1. Configure a COTS2 server, Common Server, or Common Server R2 with Communication Server 1000 Linux base server as a Member security server and register it to the security domain.
- 2. Request a platform license key from the authorized person.

You must know the MAC address of the Avaya Aura® MS server.

- 3. Install Avaya Aura® MS on the Member server using the license server key specified during the Avaya Aura® MS pre-installation stage.
- 4. Configure the Member server as the Primary server in the Avaya Aura® MS cluster.

For information on Avaya Aura® MS clusters, see Implementing and Administering Avaya Aura® Media Server.

## Configuring the post-deployment license for a Primary Avaya Aura® MS

If you did not specify the license during the pre-deployment stage of the Primary (in the Avaya Aura® MS cluster) Avaya Aura® MS, you can apply it post-deployment using the Avaya Aura® MS Element Manager.

- 1. Using the Avaya Aura<sup>®</sup> MS Element Manager, navigate to **Licensing > General**.
- Select Use license server.
- 3. Copy the license text into the corresponding window.
- 4. Click Validate.

- 5. Click Save/Confirm.
- Restart the server.

## Configuring the license for a Secondary Avaya Aura® MS

Use this procedure to configure the licensing for a Secondary Avaya Aura® MS.

- 1. Configure a COTS2 server, Common Server, or Common Server R2 with Communication Server 1000 Linux base server as a Member security server and register it to the security domain.
- 2. Install Avaya Aura<sup>®</sup> MS on the Member server without the license server key specified during the Avaya Aura<sup>®</sup> MS pre-installation stage.
- 3. Configure the Member server as a Secondary server in the Avaya Aura® MS cluster, also specifying the Primary server of the cluster.
- 4. Restart Avaya Aura® MS on the Secondary server.

## Configuring the license for a Standard Avaya Aura® MS

Use this procedure to configure the licensing for a Standard Avaya Aura® MS.

- 1. Configure a COTS2 server, Common Server, or Common Server R2 with Communication Server 1000 Linux base server as a Member security server and register it to the security domain.
- 2. Install Avaya Aura® MS on the Member server without the license server key specified during the Avaya Aura® MS pre-installation stage.
- 3. Configure the Member server as a Standard server in the Avaya Aura® MS cluster, also specifying the Primary server of the cluster.
- 4. Restart Avaya Aura® MS on the Standard server.

## IP Media Services feature restrictions and limitations

The following restrictions and limitations apply to IP Media Services:

- IP Media Services on CS 1000E does not support Avaya Aura® MS clusters across a WAN
- IP Media Services on CS 1000E does not support High Availability 1+1 (Primary and Backup server)
- You can only deploy IP Media Services on CS 1000E as a Member UCM server; you cannot deploy it as a Primary or Backup UCM server.
- IP Music may not be provided to an Avaya Aura Communication Manager user if Direct Audio connections are enabled. As a workaround, Avaya recommends you configure Direct IP-IP Audio Connections to N in signaling-group form for all SIP trunks towards CS 1000 on Communication Manager.

#### Note:

When Direct IP-IP Audio Connections is configured to N for all SIP trunks towards CS 1000, any IP to IP calls from Communication Manager to CS 1000 use TDM resources.

For more information about Direct Audio connections, see *Administering Avaya Aura Communication Manager*, 03-300509.

- When Session Timer is enabled on the 1100 and 1200 Series IP Deskphones, the phone may stop playing IP Music when the Session Timer expires. Avaya recommends you disable the Session Timer on 1100 and 1200 Series IP Deskphones when using IP Media Services.
  - For more information about disabling the Session Timer, see the entry for Session Timer Service in SIP Software for Avaya 1100 Series IP Deskphones Administration, NN43170-600, and SIP Software for Avaya 1200 Series IP Deskphones Administration, NN43170-601.
- IP Media Services feature does not support media renegotiation. For example, when IP Music
  is playing it is impossible to transfer the call. Specifically, the following scenarios are not
  supported:
  - If User A listens to IP Music or IP RAN and performs a transfer to another User B, User B does not hear IP Music or IP RAN.
  - If User A talks to User B and User B transfers the call to an ACD, the ACD plays IP Music or IP RAN to User B in a consultation call. When User B presses the **Transfer Complete** button, User A does not hear this IP Music or IP RAN.

This limitation applies to IP Music, IP RAN and IP Tone.

# Chapter 18: IP Media Services configuration

IP Media Services is installed with the Signaling Server application and enabled using Element Manager. To configure the individual IP Media Services applications, package 422 must be unrestricted and configuration options must adhere to licensing limitations.

## **Contents**

This section contains information about the following topics:

- Configure Media Services Routing Number using Element Manager on page 364
- Configure IP Media Services using Element Manager on page 367
- Configuring the Avaya Aura MS SIP Domain, Trusted Nodes and Routes for IP Media Services on page 379
- Configure the Avaya Aura MS media source using Element Manager on page 382
- Configure Zone and VPNI information using Network Routing Service Manager on page 385
- Configure support for MAS clusters on page 387
- Configure survivable IP Tones on page 388
- Configure the FTC table for IP Tones on page 389
- Configure Music on Hold based on phone type on page 390

# **Configure Media Services Routing Number using Element Manager**

You can configure the Media Services Routing Number (MSRN) at the service level or customer level using Element Manager.

 Configuring the Media Services Routing Number at the service level using Element Manager on page 365 • Configuring the Media Services Routing Number at the customer level using Element Manager on page 366

# Configuring the Media Services Routing Number at the service level using Element Manager

- 1. In the Element Manager navigation tree, click **System > IP Network**, and then click **Zones**. The **Bandwidth Zones** page appears.
- 2. Select the zone to edit and click **Edit**.

The **Edit Bandwidth Zone** page appears.



Figure 95: Edit Bandwidth Zone page

3. Click the Media Services Zone Properties link.

The Media Services Zone Properties (Zone) page appears.

4. Click Add.

The **Add Media Services Zone Properties** page appears.




Figure 96: Add Media Services Zone Properties page

Required values are marked with an asterix (\*).

- 5. From the **Customer number** list menu, select the customer number.
- 6. In the Media Services routing DN text box, type the media services routing DN.
- 7. (Optional) Enter the DNs for the IP Media Services applications.
- 8. Click Save.

The **Media Services Zone Properties** page appears and displays the configured DN values

# Configuring the Media Services Routing Number at the customer level using Element Manager

- 1. In the Element Manager navigation tree, click **Customers**.
- 2. Click the Media Services Properties link.

The **Feature Packages** page appears.

3. Expand the IP Media Services fields by clicking the plus (+) sign.




Figure 97: Element Manager Customers page

- 4. Enter the Media services routing number.
- 5. From the **Numbering plan identifier (NPI)** list menu, choose the Numbering plan identifier.
- 6. From the **Type of number (TON)** list menu, choose the Type of number.
- 7. Click Save.

## Configure IP Media Services using Element Manager

Use the procedures in this section to configure IP Media Services using Element Manager.

This section contains the following procedures:

- Enable IP Media Services using Element Manager on page 367
- Configure a proxy server using Element Manager on page 368
- Configure a local media server using Element Manager on page 369
- Configure the SIP URI Map using Element Manager on page 370
- Configure the Port Settings using Element Manager on page 371
- Configure IP Attendant Gateway using Element Manager on page 372

## **Enable IP Media Services using Element Manager**

Use this procedure to enable the IP Media Services applications using Element Manager.

#### **Enabling IP Media Services using Element Manager**

 In the Element Manager navigation tree, click System > IP Network > Nodes, Servers, Media Cards.

The **IP Telephony Node**s Web page appears.

2. Click Add.

The **New IP Telephony Node** page appears.

3. Enter the information for the node.

For information on configuring an IP Telephony Node, see <u>Configuration of IP Telephony</u> <u>nodes using Element Manager</u> on page 227.

- 4. In the Applications section, select the IP Media Services check box.
- 5. Click Next.

The IP Media Services Configuration Details Web page appears.



Figure 98: IP Media Services Configuration Details Web page

- 6. In the **Services** section, select the check boxes for the IP Media Services you want to enable.
- 7. Click Save.

You can continue to configure the rest of the IP Media services settings by following the procedures in this section.

## Configure a proxy server using Element Manager

You can use NRS or Aura® Session Manager as a proxy server with IP Media Services. Use this procedure to configure the proxy server details using Element Manager.

#### **Configuring a proxy server using Element Manager**

1. In the Element Manager navigation tree, click **System > IP Network > Nodes, Servers, Media Cards**.

The **IP Telephony Nodes** Web page appears.

- 2. Click the link for the Node ID to be changed.
- 3. Select Node Details > IP Media Services Configuration.

The IP Media Services Configuration Details Web page appears.




Figure 99: Proxy server section of the IP Media Services Configuration Details Web page

- 4. Click the MS Settings link.
- 5. In the **Proxy or Redirect Server** section, enter the IP media service domain name, Application ID, NRS or Aura®Session Manager IP addresses, as well as any applicable port and protocol details.

OR

You can choose to import the configuration settings from the SIP gateway session by selecting the **Import SIP gateway settings** check box.

6. Click Save.

## Configure a local media server using Element Manager

Use this procedure to configure a local media server using Element Manager. You can use this configuration when there is no NRS or Session Manager available or for local survivability if the NRS or Session Manager cannot be reached. You can use the local media server configuration to point to one Avaya Aura® MS server only.

#### Configuring a local media server using Element Manager

1. In the Element Manager navigation tree, click **System > IP Network > Nodes, Servers, Media Cards**.

The **IP Telephony Nodes** Web page appears.

- 2. Click the link for the Node ID to be changed.
- 3. Select Node Details > IP Media Services Configuration.

The IP Media Services Configuration Details Web page appears.

- 4. Click the MS Settings link.
- In the Local Media Server section, select the local media server Role, enter the FQDN/IP address of the local media server, as well as any applicable Port or Transport protocol details.




Figure 100: Local Media Server section of the IP Media Services Configuration Web page

6. Click Save.

## Configure the SIP URI Map using Element Manager

Use this procedure to configure the SIP URI Map for IP Media Services using Element Manager.

### **Configuring the SIP URI Map using Element Manager**

 In the Element Manager navigation tree, click System > IP Network > Nodes, Servers, Media Cards.

The **IP Telephony Nodes** Web page appears.

- 2. Click the link for the Node ID to be changed.
- 3. Select Node Details > IP Media Services Configuration.

The **Media Services Configuration Details** Web page appears.

#### 4. Click the SIP URI Map link.




Figure 101: SIP URI Map section of the IP Media Services Configuration page

- 5. Enter the Public E.164 domain names and Private domain names, as applicable.
- 6. Click Save.

## **Configure the Port Settings using Element Manager**

Use this procedure to configure the Port Settings for IP Media Services using Element Manager.

#### **Configuring the Port Settings using Element Manager**

 In the Element Manager navigation tree, click System > IP Network > Nodes, Servers, Media Cards.

The **IP Telephony Nodes** Web page appears.

- 2. Click the link for the Node ID to be changed.
- 3. Select Node Details > IP Media Services Configuration.

The IP Media Services Configuration Web page appears.

4. Click the **Port Settings** link.




Figure 102: Port Settings section of the IP Media Services Configuration page

- 5. Enter the port settings for each application.
- 6. Click Save.

## Configure IP Attendant Gateway using Element Manager

Use this procedure to configure IP Attendant Gateway using Element Manager.

#### **Configuring IP Attendant Gateway using Element Manager**

 In the Element Manager navigation tree, click System > IP Network > Nodes: Servers, Media Cards.

The IP Telephony Nodes Web page appears.

- 2. Click the link for the Node ID to be changed.
- 3. Select Node Details > IP Media Services Configuration.

The IP Media Services Configuration Web page appears.

- 4. Click the Port Settings link.
- 5. Scroll down to the IP Attendant section.
- In the IP Attendant section, enter the ports for the TCM TCP, SIP UDP, SIP TCP, and SIP TLS.




Figure 103: IP Attendant section of the IP Media Services Configuration Details page

The recommended port values are as follows:

- TCM TCP = 3500 (this port value must match the port value configured for the IP Attendant client)
- SIP UDP = 5090
- SIP TCP = 5090 (this port value must match the port value configured for the IP Attendant client)
- SIP TLS = 5091
- Note:

Only TCP is supported. UDP is not supported. TLS is not supported for the IP Attendant.

7. Click Save.

# Configure IP Media Services using Avaya Aura ® System Manager

Use the procedures in this section to configure IP Media Services (i.e. Media Services Controller) on the Signaling Server using Avaya Aura® System Manager. Only one IP Media Services SIP entity is required on the Avaya Aura® Session Manager for all IP Media Services Controller applications on one CS 1000 node.

## Configuring IP Media Services as a SIP entity

Before you can configure IP Media Services as a SIP entity, you must configure an Adaptation module and link the entity to Avaya Session Manager. Otherwise, the SIP Invite is not routed properly to the Avaya Aura® MS. Use this procedure to configure a SIP entity for IP Media Services.

 In the Avaya System Manager navigation tree, navigate to Elements > Routing > Adaptations and click New.

The Adaptation Details page appears.

- 2. In the **Adaptation name** text box, type CS1000Adapter. As noted above, call routing fails (404 Not Found) if you do not configure the relevant Adaptation Module.
- From the Module name list menu, select the CS1000Adapter module name and click Commit.
- In the Avaya System Manager navigation tree, click SIP Entities.
   The SIP entity list appears.
- 5. Click New.

The SIP Entity Details page appears.




Figure 104: SIP Entity Details page

- 6. In the **Name** field, enter the name for the SIP entity.
- 7. In the **FQDN or IP Address** field, enter the FQDN or IP address of the TLAN interface of the IP Media Services Controller application on the Signaling Server.
- 8. From the **Adaptation** list, select CS1000 Adapter.
- 9. From the **Type** list, select Other.

- 10. From the SIP Link Monitoring list menu, select Link Monitoring Disabled.
- 11. Click Commit.

## Configuring the SIP entity link for IP Media Services

In the Avaya System Manager navigation tree, click Routing > Entity Links.
 The Entity Links page appears.



- 2. Under the Name column, enter a name for the Entity Link.
- 3. Under the SIP Element 1 column, select the Avaya System Manager SIP entity from the list.
- 4. Under the **Protocol** column, select the appropriate protocol.
- 5. Under the **Port** column, enter the port number.
- 6. Under the SIP Element 2 column, select the IP Media Services SIP entity from the list.
- 7. Click Commit.

## Configuring Avaya Aura® MS as a SIP entity

Use this procedure to configure a Avaya Aura® MS SIP entity in Avaya System Manager and link it to Aura® Session Manager.

- In the Avaya System Manager navigation tree, click Elements > SIP Entities.
   The list of SIP entities appears.
- 2. Click New.

The SIP Entity Details page appears.




Figure 105: SIP Entity Details page

- 3. In the **Name** field, enter a name for the Avaya Aura<sup>®</sup> MS SIP Entity. Example: mas233.
- 4. In the **FQDN or IP Address** field, enter the Avaya Aura® MS FQDN or IP address.
- 5. From the **Type** list, select Other.
- 6. From the **Location** list, select the location containing the VPNI and Zone information configured for the Aura® Session Manager SIP entity.
- 7. Click Commit.

## Configuring the SIP entity link for Avaya Aura® MS

In the Avaya System Manager navigation tree, click Routing > Entity Links.
 The Entity Links page appears.



- 2. Under the **Name** column, enter a name for the Entity Link.
- 3. Under the SIP Element 1 column, select the Avaya System Manager SIP entity from the list.

- 4. Under the **Protocol** column, select the appropriate protocol.
- 5. Under the **Port** column, enter the port number.
- 6. Under the SIP Element 2 column, select the Avaya Aura® MS SIP entity from the list.
- 7. Click Commit.

# Configuring bandwidth management for a Avaya Aura® MS SIP entity

In the Avaya System Manager navigation tree, click Elements > Locations.
 The Location Details page appears.



Figure 106: Location Details page

2. In the **Name** field, enter the values for zone and VPNI using the following format:

x-vpni=<value>; x-zone=<value>



The zone and VPNI configuration entered during the configuration of the Avaya Aura<sup>®</sup> MS SIP entity is sent by Aura<sup>®</sup> Session Manager to the IP Media Services controller. This information is later used by the Call Server for bandwidth management. When viewing the SIP Entity details of the Avaya Aura<sup>®</sup> MS in Avaya System Manager, the **Location** field matches the **Name** you enter during this step.

3. Click Commit.

# Configuring the Routing Policy and Dial Pattern for Avaya Aura® MS

In Aura<sup>®</sup>Session Manager, you must configure a Routing Policy to assign the appropriate Routing Destination and Time of Day. You must also configure a Dial Pattern so that the MSRN can assign the appropriate Policy to the Dial Pattern. You must define the Dial Pattern on both the Avaya Aura<sup>®</sup>

MS and Call Server so that the Aura<sup>®</sup> Session Manager can assign a Avaya Aura<sup>®</sup> MS to the Call Server for providing IP Media Services.

Use this procedure to configure the Policy and Dial Pattern for Avaya Aura® MS.

1. In the Avaya System Manager navigation tree, click **Elements > Routing > Routing Policies**.

The Routing Policy Details page appears.




Figure 107: Routing Policy Details page

- 2. In the **Name** field, enter the name for the Routing Policy.
- Click the Select button under Select SIP entity as destination and select a Avaya Aura®
  MS SIP entity.
- Click Commit.
- In the Avaya System Manager navigation tree, click **Dial Patterns**.
   The Dial Pattern Details page appears.




Figure 108: Dial Pattern Details page

- 6. Enter the Dial Pattern details. Mandatory fields are marked with an asterix (\*). In the above example, dial pattern 4000 corresponds to a Media Service Routing Number (MSRN) as configured on the Call Server side.
- 7. Click the Add button under Originating Locations and Routing policies to select the originator location names and routing policy names for the configured Dial Pattern.
- 8. Click Commit.

## Configuring the Avaya Aura® MS SIP Domain, Trusted **Nodes and Routes for IP Media Services**

You must add Aura® Session Manager as a SIP Trusted Node on the Avaya Aura® MS using the Avava Aura® MS Element Manager. This is required because Aura® Session Manager is a proxy server for all SIP signaling received by the Avaya Aura® MS.

If you are using a local Avaya Aura® MS, you must also add the IP Media Services Controller on the Signaling Server as a SIP Trusted Node. This is required for resiliency in the event Aura® Session Manager is not responding.



#### Warning:

To avoid the alarm "All configured SIP routes are down", do the following:

- 1. In the Avaya Aura® MS Element Manager navigation tree, click System Configuration > Signaling Protocols > SIP > General Settings.
  - The General Settings page appears.
- 2. In the Routing section, uncheck Enforce SIP Route Configuration, which is checked by default.

#### 3. Click Save.

Depending on whether or not the proxy server is NRS or Aura® Session Manager, certain conditions might apply. Use the procedure that applies to your configuration.

## Configuring for Aura® Session Manager

Use this procedure if your system uses Aura® Session Manager as the proxy server.

 In the Avaya Aura® MS Element Manager navigation tree, click System Configuration > Signaling Protocols > SIP > Domains and Accounts.

The **Domains and Accounts** page appears.

2. Click Add.

The Add SIP Domain page appears.



Figure 109: Add SIP Domain page

- 3. Enter the domain name and click **Save**.
- 4. Using the Avaya Aura® MS Element Manager, navigate to **System Configuration > Signaling Protocols > SIP > Nodes and Routes**.

The SIP Nodes and Routes page appears.

In the Trusted Nodes section, click Add.

The **Add SIP Trusted Node** page appears.

6. Enter the IP address of the Signaling Server where IP Media Services is installed and click **Save**.



All IP Media Services applications except IP Attendant use the TLAN IP address of the Signaling Server. IP Attendant uses the node IP of the Signaling Server.

The **Nodes and Routes** page appears.

7. In the **Trusted Nodes** section, click **Add**.

The **Add SIP Trusted Node** page appears.

8. Enter the IP address of the SIP Proxy Server (SPS) and click Save.

The **Nodes and Routes** page appears.

 Navigate to System Configuration > Signaling Protocols > SIP > Domains and Accounts.

The Domains and Accounts page appears.

10. Click Add.

The Add SIP Account page appears.

11. Click Save.

#### **Configuring for NRS**

Use this procedure if your system uses NRS as the proxy server.

 In the Avaya Aura® MS Element Manager navigation tree, click System Configuration > Signaling Protocols > SIP > Domains and Accounts.

The **Domains and Accounts** page appears.

2. Click Add.

The **Add SIP Domain** page appears.



Figure 110: Add SIP Domain page

- 3. Enter the domain name and click Save.
- 4. Using the Avaya Aura® MS Element Manager, navigate to **System Configuration > Signaling Protocols > SIP > Nodes and Routes**.

The SIP Nodes and Routes page appears.

In the Trusted Nodes section, click Add.

The Add SIP Trusted Node page appears.

6. Enter the IP address of the Signaling Server where IP Media Services is installed and click **Save**.



All IP Media Services applications except IP Attendant use the TLAN IP address of the Signaling Server. IP Attendant uses the node IP of the Signaling Server.

The **Nodes and Routes** page appears.

7. In the **Trusted Nodes** section, click **Add**.

The Add SIP Trusted Node page appears.

8. Enter the IP address of the SIP Proxy Server (SPS) and click Save.

The **Nodes and Routes** page appears.

9. Navigate to System Configuration > Signaling Protocols > SIP > Domains and Accounts.

The **Domains and Accounts** page appears.

10. Click Add.

The **Add SIP Account** page appears.

- 11. Enter the new account information, ensuring that the following conditions are met:
  - The account name must match the name used for the Avaya Aura® MS endpoint on NRS.
  - The password must match the password used for the endpoint authentication in NRSM.
- 12. Click Save.

# Configure the Avaya Aura® MS media source using Element Manager

Use this procedure to configure the media source using Element Manager on the Avaya Aura® MS. Ensure that the media file conforms to the following properties:

· Audio Format: Pulse-Code Modulation (PCM)

Sample Rate: 8.00 kHzAudio Sample Size: 16 bitAudio Bit Rate: 128kbps

· Channels: 1 mono




Figure 111: Audio Properties

### Configuring the Avaya Aura® MS media source using Element Manager

- In the Avaya Aura® MS Element Manager navigation tree, click Home > Tools > Media Management > Provision Media.
- 2. Select an item in the Content Namespace Name list and click **Browse**.

The Provision Media (CS 1000) page appears.




Figure 112: Provision Media (CS 1000) page

From this page you can add content groups, add media, and delete media.

Media content for IP Media Services is managed using the following hierarchy:

CS1000 / sip.domain.com / CallServerHostName / CustomerNumber / RouteNumber, where:

- CallServerHostName = for VxWorks systems, this value is the LD 117 hostname. For Linux systems, this value is the hostname configured on the system layer during installation of the operating system.
- Customer number = 2 digits, including leading 0s (zeros).
- Route number = 3 digits, including leading 0s (zeros).

The media file name indicates the route number and route type. For example, media files for RAN routes are prefixed by ran and media files for Music routes are prefixed by mus.

#### Example

CS1000/sip.domain.com/csbvw02/00/mus012.wav

3. Click the **More Actions** list for additional options.

### Note:

An Avaya Aura® MS can act as a master media source for other Avaya Aura® MS servers in the network without requiring the servers to belong to a cluster. By configuring the Active Cluster Primary Node Address for each Avaya Aura® MS to point to the master Avaya Aura® MS (the primary server in the network with the master copy of the content), content stores can be synchronized between the servers using the cluster replication process. This provides a local media source in the event the master Avaya Aura® MS is unreachable. The other Avaya Aura® MS servers will automatically audit and resynchronize their content stores with the master Avaya Aura® MS once connectivity is restored.

For more information about Avaya Aura® MS, see *Implementing and Administering Avaya Aura® Media Server*.

#### Note:

Avaya recommends that you configure the default Avaya Aura® MS codec package to be the same as the CS 1000 codec package. Otherwise, the system might experience speech path issues.

### Note:

Avaya recommends that you configure the Media Security crypto attributes (authentication algorithm, MKI length) the same across all CS 1000 elements, such as Avaya Aura® MS, SIP IP Phones, and so on. Otherwise, the system might experience speech path issues.

## **Content Store replication**

Content Store replication is a one-way data copy from a master cluster to a replica cluster. Content Store replication is supported between servers in a cluster, as well as between clusters. The master cluster can have up to four directly-connected replica clusters. You can create chains of replica clusters, thereby creating hierarchies that scale to greater than four replica clusters in the network. In these cascading hierarchies, intermediate replica clusters act as master clusters for replica clusters further down the hierarchy.

No changes are required on the master to enable replication. Replica clusters connect to the master cluster using the Replication Account for authentication and are configured to use the master as the source for media content updates.

#### **Content replication features**

Content Store replication between clusters provides the following capabilities:

- Single point provisioning: Many clusters with common data, for example, announcement recordings, can be provisioned from a single designated master cluster. Replication ensures the data is copied from the master cluster to the replica clusters.
- Geographic-redundancy: A duplicate cluster at an alternate location can be maintained as a
  contingency cluster to receive traffic when the primary location becomes unavailable. The
  contingency cluster is a replica of the master cluster and receives all the Content Store
  application data in real-time so that it is ready to take over with the latest content. A
  contingency cluster must not receive traffic or provisioning changes when in standby.

## **Enabling replication of Content Store data between clusters**

#### **Procedure**

- 1. Gain access to Element Manager for the Primary server in the replica cluster and navigate to **EM > Cluster Configuration > Replication Settings**.
- 2. Enter the address of the Primary server of the master cluster in the **Master Cluster Primary Node Address** field.
- Click Save.

If the system raises any critical mirror connection alarms, ensure that you have used the correct address and that the Replication Account username and password are the same for all the clusters. If you have not enabled Configuration Replication within the cluster, repeat Step 1 to Step 3 for each node in the replica cluster.

#### Result

The system activates Content Store replication immediately. All of the content data on the master cluster is copied to the replica cluster.

# Disabling replication of Content Store data between clusters Procedure

- 1. Gain access to EM for the Primary server in the replica cluster and navigate to EM > Cluster Configuration > Replication Settings.
- 2. Clear the Master Cluster Primary Node Address field.
- Click Save.

If you have not enabled Configuration Replication within the cluster, repeat Step 1 to Step 3 for each node in the replica cluster. If required, use the EM Media Management tool to remove content data.

#### Result

The system disables replication immediately. The system does not delete the content on the replica. The replica can use the local content the replica has, but will no longer receive updates from the master cluster.

# **Configure Zone and VPNI information using Network Routing Service Manager**

The Avaya Aura® MS is defined as a dynamic SIP gateway endpoint on the NRS. The NRS can detect if an Avaya Aura® MS is out of service by using its registration details. You can configure Zone and VPNI details using the Network Routing Service Manager (NRSM) SIP endpoint page. The Zone and VPNI details are added to the SIP 3XX message sent back to the Call Server.

Use this procedure to configure the Zone and VPNI details for IP Media Services bandwidth management.

## Configuring IP Media Services Zone and VPNI details using Network Routing Service Manager

 In the Network Routing Service Manager navigation tree, click Numbering Plans > Endpoints > Gateway Endpoint.

The **Edit Gateway Endpoint** Web page appears.




Figure 113: Edit Gateway Endpoint Web page

2. Enter the required values and click Save.

## Note:

When configuring MSC and Avaya Aura® MS endpoints using NRS, you must configure the SIP mode as Proxy Mode. In Session Manager, all entities are Proxy Mode as Redirect Mode is not supported.

For information about NRSM, see Network Routing Service Fundamentals, NN43001-130.

## Configure support for Avaya Aura® MS clusters

## Configuring NRS to support Avaya Aura® MS clusters

If you configured NRS as the SIP Proxy Server, you must add each Avaya Aura® MS server within a Avaya Aura® MS cluster as a Gateway Endpoint using Network Routing Server Manager. You only need to configure the primary and secondary Avaya Aura® MS servers as routing entries for the Media Service Routing Number.

The following figure shows two Avaya Aura® MS cluster servers as Gateway Endpoints:




Figure 114: Avaya Aura® MS cluster servers as Gateway Endpoints

The following figure shows the primary Avaya Aura® MS server within the cluster with a routing entry for the MSRN:




Figure 115: Primary Avaya Aura® MS server with MSRN routing entry

## Configuring Aura® Session Manager to support Avaya Aura® MS clusters

If you configured Aura<sup>®</sup> Session Manager as a SIP Proxy Server, you must use Aura<sup>®</sup> System Manager to add each Avaya Aura<sup>®</sup> MS within the cluster as a SIP Entity and link it to Aura<sup>®</sup> Session Manager. You only need to configure a Routing Policy and Dial Pattern for the Media Services Routing Number for the Primary and Secondary Avaya Aura<sup>®</sup> MS.

## **Configure survivable IP Tones**

In High Scalability systems, the SIP Survivable Media Gateway (SSMG) consists of a Survivable Call Server (SCS) and SIP Media Gateway (SMG) that provide IP resources in the event of WAN outage. During a WAN outage, IP Phones register locally to the SCS.

To provide call progress tone (ring back tone only), tone service is requested from the SMG using the same method that the IP Media Services applications use to request tone service from the Avaya Aura® MS, provided that the SCS is running the IP Media Services application, the SMG IP address is configured as the local media server for IP Media Services, and the local media server role is configured as SIP Media Gateway.

When the SMG receives the tone request, the SIP Gateway application translates the request to an ACD DN call. The Call Server places the call into an ACD queue and provides in-band ring back tone to the call originator.

To configure survivable IP Tones for High Scalability systems, perform the following steps.

## Note:

These steps assume that you have enabled IP Media Services Package 422, configured the Media Services Routing Number, and that IP Media Services is running on the SCS.

- 1. On the SCS, set the Node IP of the SIP Gateway as the IP of the local media server in Node configuration. Ensure that the Proxy or Redirect Server settings are empty.
- 2. Select IP tone option in the SCS Node configuration. The mscTone application should be running on the SCS SS, and the IP TONE loop should be created and active.
- 3. On the SCS, system has MSRN configuration which will route to SIP Gateway system in NRS. This configuration makes it possible to resolve the CDN number at termination from the IP TONE number. Ensure that the number used for MSRN configuration can be routed through SIP from the SCS to SIP Gateway.
- 4. On SIP Gateway, dummy ACD queue is created without agents. CDN, which is the same as MSRN created in step 2 on SCS system, has this dummy ACD DN as default. Ensure that CNTL value is configured as No in CDN block.

### Note:

Regardless of the tone requested, only the survivable IP tones are provided when the Local Media Server entry is in use.

## Configure the FTC table for IP Tones

The IP Tone application uses the Firmware Cadence (FCAD) table on the Call Server to request tones from the Avaya Aura® MS, but some feature tones do not contain any FCAD entries in the default Flexible Tone and Cadence (FTC) table.

To provide IP Tones for those features, configure the FCAD and FTC tables using LD 56.

Table 110: LD 56 - Create a new FCAD entry

Prompt	Response	Description
REQ	NEW	Create a new entry.
TYPE	FCAD	Type of data block = FCAD (Firmware Cadence)
WCAD	0-225	Cadence number (0 is reserved for continuous tone
		and cannot be changed).
CDNC	xxxx xxxx xxxx	Cadence value
END	aa	End treatment for cadence (aa = REPT, ON, or OFF)
- CYCS	xxxx	Cycles
- WTON	(NO) YES	Define tones associated with the cadence

After creating the new entry for the FCAD table, associate it with the XCAD parameter of the tone feature in the FTC table.

Table 111: LD 56 - Specify the FCAD entry in the FTC table

Prompt	Response	Description
REQ	CHG	Change
TYPE	FTC	Flexible Tone and Cadence
TABL	0-31	FTC Table number
SSCT	(NO) YES	Software Controlled Cadences and Tones
	aa	Feature to modify.
- XCAD	0-(2)-255	FCAD cadence number entry

For more information about prompts and responses for LD 56, see *Software Input Output Reference* — *Administration*, *NN43001–611*.

#### **Example: Configure FCAD for Agent Observe Tone**

The following is an example of configuring the FCAD and FTC for the Agent Observe Tone (AOBT) feature:

1. Specify the FCAD entry for Agent Observe Tone in the FTC Table using LD 56:

```
new FCAD
WCAD 32 (any new value)
CDNC 00205 03072 00051 03072 00000 00000 00000 00000 00000
END REPT
CYCS 2
WTON NO
```

2. Modify the FTC table to specify the new FCAD entry for the AOPT feature using LD 56:

```
REQ chg
TYPE ftc
TABL 0
...
SCCT yes
CAMP
...
AOBT
-XTON
-XCAD 32 (new FCAD entry from step 1)
```

## Configure Music on Hold based on phone type

In previous releases, it was possible to offer different music to callers on hold only when the call was internal or external. IP Media Services extends this functionality by providing the option to configure different music for callers placed on hold based on the type of phone involved in the call.

When configuring a phone, use the Music Route number (MRT) prompt in LD 11 to configure standard or IP-based music Route Data Blocks. You can apply the same MRT number to multiple phones. You can configure the IP Music route at both the customer and route levels.

Use the Class of Service prompts SBMA (Set-Based Music Allowed) and SBMD (Set-Based Music Denied) to allow or deny the feature.

Table 112: LD 11 - Assign Music Route number to a phone

Prompt	Response	Description
REQ	aaa	NEW or CHG
TYPE	bbb	Terminal type. It can be any BCS or PBX phone.
CUST	xx	Customer ID
MRT	n	Music Route number. Route type is MUS or IMUS. By default, MRT value is empty.

Table 113: LD 11 - Enable Music on Hold for a phone

Prompt	Response	Description
REQ	aaa	NEW or CHG
TYPE	bbb	Terminal type. It can be any BCS or PBX phone.
CUST	xx	Customer ID
CAC_MFC		
CLS	(SBMD)/SBMA	Set Based Music Denied/Allowed

## **Chapter 19: Maintenance**

## **Contents**

This chapter contains the following topics:

- Introduction on page 392
- IP Line and IP Phone maintenance and diagnostics on page 392
- IP Line CLI commands on page 399
- IP Media Services CLI commands on page 401
- Lamp Audit function on page 403
- Troubleshoot an IP Phone installation on page 403
- Maintenance telephone on page 403
- <u>Faceplate maintenance display codes</u> on page 404
- System error messages on page 406
- Voice Gateway Media Card self-tests on page 410
- Replace the Media Card CompactFlash on page 410

## Introduction

This chapter describes maintenance functions for the Voice Gateway Media Card, IP Line and IP Phones.

Check the Avaya Web site for information about the most recent software, firmware, and application releases.

## IP Line and IP Phone maintenance and diagnostics

This section describes the commands in LD 32 and LD 117.

## **LD 32**

<u>Table 114: LD 32 Maintenance commands for the Voice Gateway Media Card</u> on page 393 summarizes the system maintenance commands available in LD 32.

The following ECNT commands are available in LD 117 and LD 32:

- ECNT CARD
- ECNT NODE
- ECNT SS
- ECNT ZONE

The following ECNT commands are available in LD 117:

- ECNT FW
- ECNT MODL
- ECNT PEC

For more information about the ECNT commands, see <u>Counting IP Phones</u> on page 132 and <u>LD</u> <u>117</u> on page 394.

Table 114: LD 32 Maintenance commands for the Voice Gateway Media Card

Command	Description
_	Table continues
DISC 1 s c	Disables the specified card, I = loop, s = shelf, c = card.
DISI 1 s c	Disables the specified card when idle, I = loop, s = shelf, c = card
	Use the DISI command to disable the Voice Gateway Media Card instead of the DISC command. The NPR0011 message indicates the disabled state of the Voice Gateway Media Card.
DISU 1 s c u	Disables the specified unit; I = loop, s = shelf, c = card, u = unit
ECNT CARD L S	Counts and prints the number of IP Phones registered for the specified card.
C <customer></customer>	If the <customer> parameter is specified, the count is specific to that customer. A card must be specified to enter a customer; otherwise, the count is across all customers.</customer>
	If no parameters are entered, the count is printed for all zones. A partial TN can be entered for the card (L or L S) which then prints the count according to that parameter. A customer cannot be specified in this case.
	Example:
	ECNT CARD 81 << Card 81 >> Number of Registered Ethersets: 5 Number of Unregistered Ethersets: 27

Command	Description
ECNT ZONE	Counts and prints the number of IP Phones registered for the specified zone.
zoneNum   <customer></customer>	If <customer> parameter is specified, the count is specific to that customer. A zone must be specified to enter a customer; otherwise, the count is across all customers.</customer>
	If no parameters are entered, the count is printed for all zones.
	If an IP Phone is logged on to Virtual Office and the parameter entered for Current Zone (CUR_ZONE) is different from the parameter entered for Configured Zone (CFG_ZONE), registered and unregistered Ethersets are counted for both zones.
	Example:
	ECNT ZONE 0 0 << Zone 0 Customer 0 >> Number of Registered Ethersets: 4 Number of Unregistered Ethersets: 17
ECNT NODE	Counts and prints the number of IP Phones registered for the specified node.
nodeNum	If the nodeNum parameter is not entered, the count is printed for all nodes.
	Example:
	ECNT NODE 8765 << Zone 8765 >> Number of Registered Ethersets: 3
ECNT SS <hostname></hostname>	Counts and prints the number of IP Phones registered for the specified Signaling Server.
	If hostName parameter is not entered, the count is printed for all Signaling Servers.
	Example:
	ECNT SS << Signaling Server: BVWAlphaFox IP 10.10.10.242>> Number of Register Ethersets: 1000
	If the hostName variable contains an underscore (_), then an NPR001 error message is returned, as an underscore is considered to be an invalid character.
ENLC 1 s c	Enable the specified card; I = loop, s = shelf, c = card
ENLU 1 s c u	Enable the specified unit; I = loop, s = shelf, c = card, u = unit
IDC 1 s c	Print the Card ID information for the specified card, I = loop, s = shelf, c = card
	This command displays the PEC (Product Engineering Code) and serial number for the card. The IP Line PEC is NTZC80AA.
STAT 1 s c	Print the CS 1000 software status of the specified card, I = loop, s = shelf, c = card
STAT 1 s c u	Print the CS 1000 software status of the specified unit, I = loop, s = shelf, c = card, u = unit

## LD 117

<u>Table 115: LD 117 Count registered IP Phones</u> on page 395 summarizes the system maintenance commands available in LD 117.

The following ECNT commands are also maintained in LD 32:

- ECNT CARD <Loop> <Shelf> <Card> <CustomerNumber>
- ECNT NODE <NodeNumber>
- ECNT SS <HostName>
- ECNT ZONE <ZoneNumber> <CustomerNumber>

For more information about the ECNT commands, see <a href="Counting IP Phones">Counting IP Phones</a> on page 132.

Table 115: LD 117 Count registered IP Phones

Command	Description
ECNT ZONE zoneNum <customer></customer>	Counts and prints the number of IP Phones registered for the specified zone.
	<ul> <li>If <customer> parameter is specified, the count is specific to that customer. A zone must be specified to enter a customer; otherwise, the count is across all customers.</customer></li> </ul>
	If no parameters are entered, the count is printed for all zones.
	Example:
	ECNT ZONE 0 0 << Zone 0 Customer 0 >> Number of Registered Ethersets: 4 Number of Unregistered Ethersets: 17
ECNT NODE nodeNum	Counts and prints the number of IP Phones registered for the specified node.
	If the nodeNum parameter is not entered, the count is printed for all nodes.
	Example:
	ECNT NODE 8765 << Zone 8765 >> Number of Registered Ethersets: 3
ECNT SS <hostname></hostname>	Counts and prints the number of IP Phones registered for the specified Signaling Server.
	If hostName parameter is not entered, the count is printed for all Signaling Servers.
	Example:
	ECNT SS << Signaling Server: BVWAlphaFox IP 10.10.10.242>> Number of Register Ethersets: 1000
	If the hostName variable contains an underscore (_), then an NPR001 error message appears, as an underscore is an invalid character.
ECNT FW <xx> <a> <bb> <ff></ff></bb></a></xx>	Prints the number of IP Phones with specified firmware ID and running specified firmware version.
	<xx>: firmware ID</xx>
	<a>: major version designator</a>

Table continues...

Command	Description
	<bb>: minor version designator</bb>
	<ff>: filter to apply on firmware version; can be one of the following:</ff>
	=: equal to
	~: not equal to
	<: less than
	>: greater than
	Only the XX parameter is mandatory.
	ECNT FW <xx> <a> <bb> defaults to ECNT FW <xx> <a> <bb> =</bb></a></xx></bb></a></xx>
	ECNT FW <xx> <a> counts all registered IP Phones with firmware ID equal to <xx> and major version designator equal to <a>.</a></xx></a></xx>
	ECNT FW <xx> counts all registered IP Phones with firmware ID equal to <xx>.</xx></xx>
	ECNT FW is equivalent to ECNT FW ALL; that is, the list containing firmware IDs and the quantity of IP Phones with this firmware ID is printed.
ECNT MODL <mmmm></mmmm>	Prints the number of IP Phones of specified model.
	<mmmm> – specifies model name.</mmmm>
	If this parameter is omitted, then a list of the model names and associated mnemonics is printed.
ECNT PEC <pec></pec>	Prints the number of IP Phones with specified PEC, where:
	<pec> – Product Engineering Code</pec>
	ECNT PEC is equivalent to ECNT PEC ALL; that is, the list containing the PECs and the quantity of IP Phones with this PEC is printed.

## TN

For Avaya IP Phones, consider two kinds of TN:

- physical TN: represents a physical unit of the Voice Gateway Media Card
- virtual TN: configured on a virtual superloop and represents an IP Phone

## **Physical TN**

Physical TN, that are seen as trunk units, are managed using existing LD32 commands.

#### Virtual TN

Because virtual TN are configured on a virtual superloop, virtual TN maintenance has no meaning; that is, what is already provided by the Avaya Communication Server 1000 (Avaya CS 1000) for phantom loops.

In LD 32, any command affecting a phantom loop leads to an NTP665 message because the loop does not physically exist. LD 32 supports **STAT**, **DISU**, **ENLU**, and **IDU** commands on an IP Phone Virtual TN. All other commands generate the NPR047 message.

#### Maintenance commands for the IP Phone

<u>Table 116: LD 32 maintenance commands for IP Phones</u> on page 397 contains the maintenance commands in LD 32 for the IP Phone. For more information about commands, see *Software Input Output Reference — Maintenance, NN43001-711*.

Table 116: LD 32 maintenance commands for IP Phones

Command	Description	
STAT 1 s c u	Displays the IP Phone state.	
	UNEQ, IDLE, BUSY, and DSBL have the usual meaning.	
	IDLE and DSBL state are precise by the following information:	
	UNREGISTERED identifies an IP Phone configured in the system but not yet registered.	
	REGISTERED identifies a registered IP Phone.	
DISU 1 s c u	Change the IP Phone state to DSBL.	
	UNREGISTERED or REGISTERED state is not modified.	
ENLU 1 s c u	Change the IP Phone state to IDLE.	
	UNREGISTERED or REGISTERED state is not modified.	
IDU 1 s c u	Displays selected IP Phone information.	
	Displays the TN number, MAC address, device code, NT code, color code, release code, software code, serial number, IP Phone IP address, and LTPS IP address.	
STAT VTRK <cust#> <route#> <start_mb#> <number members="" of=""></number></start_mb#></route#></cust#>	Displays the status of the virtual trunks for a customer route starting from a specified starting member for the number of members specified.	

#### **IDU** command

Because the system must request the information from the IP Phone, the IDU is effectively a PING command that you can use to test the end-to-end IP connectivity of the IP Phone.

See Figure 116: IDU command output on page 398 for an example of IDU command output.

>LD 32 .idu 61 0

12004 TN: 061 0 00 00 V TN ID CODE: i2004

ISET MAC ADR: 00:60:38:76:C7:9D ISET IP ADR: 30.1.1.10:5200 LTPS IP ADR: 47.11.216.49

MANUFACTURER CODE: [NAME]

MODEL:

NT CODE: NT2K00GI COLOR CODE: 66 RLS CODE: 0 SER NUM: 76C79D

FW/SW VERSION: 0602B59

.idu 61 1

I2004 TN: 061 0 00 01 V TN ID CODE: i2004

ISET MAC ADR: 00:60:38:76:38:E0

ISET IP ADR: 30.1.1.100:1250 (192.168.1.13)

LTPS IP ADR: 47.11.216.50

MANUFACTURER CODE: [NAME]

MODEL:

NT CODE: NT2K00GI COLOR CODE: 66 RLS CODE:

SER NUM: 7638E0

FW/SW VERSION: 0602B59

#### Figure 116: IDU command output

Any information about attached IP Phone KEMs, or the Avaya 1100 Series Expansion Module also appears.

In the example in <u>Figure 116: IDU command output</u> on page 398, the first IP Phone is not behind a NAT device; the second IP Phone is behind a NAT device. The ISET IP ADR field displays the IP Phone signaling IP address as seen by the LTPS. If the IP Phone is behind a NAT device, the ISET IP ADR field displays the public address (the address seen by the LTPS) followed by the private IP address (the address configured at the IP Phone) in parentheses.

This format applies only for IP Phone Virtual TNs.

If the IP Phone is not registered with the Call Server, an NPR0048 message is generated. If the IP Phone is registered but idle, the system prints the IP Phone IP address and generates an NPR0053 message. If the IP Phone is registered, but the Call Server is not responding, an NPR0503 message is generated.

#### **IP Line CLI commands**

IP Line CLI commands supplement Overlay commands and introduce features specific to the Signaling Server platform.

For more information about commands, see *Software Input Output Reference — Maintenance, NN43001-711*.

Note:

VxWorks-based deplist CLI commands are not supported.

Note:

Use the appinstall command only if you are directed by Avaya support.

Use SSH to access the CLI. These IP Line CLI commands are entered at the command prompt.

## Protocol trace tool commands for the Network Connection Service

#### Important:

A system warm start causes all tracing to cease. Traces must be reentered after the system restarts.

<u>Table 117: Protocol trace tool CLI commands for the NCS</u> on page 400 includes the protocol trace tool commands for the Network Connection Service (NCS). You must be assigned to the OAM role to run these commands.

For more information, see Software Input Output Reference — Maintenance, NN43001-711.

Table 117: Protocol trace tool CLI commands for the NCS

CLI Command	Description	Signaling Server	
<pre>tpsARTrace IP <ip address=""></ip></pre>	Traces the tpsAR protocol, which is used to determine where an IP Phone registers.	Х	
ID <user id=""></user>	IP Address: a string containing the IP Phone IP address		
ALL	user UID: the ID of the IP Phone to trace (the DN used to log on) or the H323_Alias of where the IP Phone tries to register		
	ALL: all IP Phones are to be monitored		
tpsARTraceOff	Removes the specified endpoint from the list of	Х	
IP <ip address=""></ip>	endpoints to be traced.		
ID <user id=""></user>			
ALL			
tpsAROutput	Sets the output for all tpsAR protocol traces.	Х	
<pre><output_destination> &lt;"File Pathname"&gt;</output_destination></pre>	Output_Destination specifies where all the trace messages for the tpsARTraceSet are to be directed.		
	If the command runs from the Voice Gateway Media Card or the Linux shell prompt:		
	The values are as follows:		
	1 = TTY		
	2 = RPTLOG		
	3 = File		
	4 =TTY + File		
	If the command runs from the OAM prompt or Linux prompt on the Signaling Server:		
	The values are the actual word, not a number:		
	TTY		
	RPTLOG		
	FILE		
	TTY+FILE		
	File Pathname is a string enclosed in quotation marks. It specifies the file to write to if you select option 3 or 4.		

CLI Command	Description	Signaling Server
tpsARTraceSettings	Displays the trace tool settings, which endpoints are traced, and where the trace output is directed.	X
tpsARTraceHelp	Displays a list of all CLIs used for tracing tpsAR protocol messages, including usage and parameters.	X

#### **IP Media Services CLI commands**

#### **Syslog commands**

IP Media Service applications use the existing logging facility available on the Signaling Server. Linux Base syslog commands can be used to view or configure the syslog configuration for each type of media service, as shown in the following table.

Table 118: Syslog commands for IP Media Services

Command	Description	
syslogShow	Displays the IP Media Services syslog configuration.	
<pre>syslogFacilitySet <pre><pre>cprocess&gt;<facility></facility></pre></pre></pre>	Configures the IP Media Services applications syslog facility.	
syslogLevelSet <pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	Configures the IP Media Services applications syslog level, where:	
	<pre><pre><pre><pre><pre><pre><pre><pre></pre></pre></pre></pre></pre></pre></pre></pre>	
	mscConf = IP Ad Hoc Conference	
	mscMusc = IP Music	
	mscAnnc = IP Recorded Announcements	
	mscAttn = IP Attendant Console	
	mscTone = IP Tone	
	<task> =</task>	
	tMSC = IP Media Services tasks	
	<level> =</level>	
	INFO (Default)	
	• NONE	
	• EMERG	

Command	Description	
	• ALERT	
	• CRIT	
	• ERROR	
	• WARNING	
	• NOTICE	
	• DEBUG	

#### Example

To enable the debugging log:

==> syslogLevelSet mscConf tMSC DEBUG

All log messages are saved in the common Signaling Server log file /var/log/cs1000/ss\_common.log.

For more information about syslog commands, see *Linux Platform Base and Applications Installation and Commissioning, NN43001-315.* 

For information about syslog facility and level details, see *Software Input Output Reference* — *Administration, NN43001-611* and *Software Input Output Reference* — *Maintenance, NN43001-711*.

#### **Maintenance commands**

You can use LD 117 to display the status of IP Media Services applications.

Table 119: LD 117 - Display status of IP Media Services applications

Command	Description
STAT SERV APP IPCONF	Print the status of servers that have IP Ad Hoc Conference listed as an application.
STAT IP TYPE 3260	Print IP Attendant Console 3260 status
PRT IPDN <ip_address></ip_address>	Print IP Attendant Console 3260 information for the specified IP address
STAT SERV APP IPATTN	Print the status of servers hosting the IP Attendant Console 3260
STAT SERV APP IPMUS	Print the status of servers that have IP Music listed as an application.
STAT SERV APP IPANN	Print the status of servers that have IP Announcement listed as an application.
STAT SERV APP IPTONE	Print the status of servers that have IP Tone listed as an application.

For information about maintenance commands, see *Software Input Output Reference — Maintenance, NN43001-711*.

#### **Lamp Audit function**

The Lamp Audit function provides a continuous source of heartbeat messages to ensure the IP Phone is powered and the IP connection is alive. Because a reliable UDP connection exists from the core through to the IP Phones, any failure of the IP Phone or the IP connection is detected.

#### **Network Signaling Diagnostics**

Network Signaling Diagnostics can be run as part of the midnight routines defined in LD 30. For more information, see *Software Input Output Reference — Maintenance, NN43001-711*.

#### Troubleshoot an IP Phone installation

If an IP Phone cannot be installed because the prompt for the node ID or TN does not appear, perform the steps in <u>Troubleshooting an IP Phone installation</u> on page 403.

#### Troubleshooting an IP Phone installation

- 1. Log on to a Signaling Server in the node.
- 2. Type the nodePwdShow command at the prompt.
- 3. Use the nodePwdSet "password" command to configure the administrative password and to enable IP Phone installation. Ensure the password parameter is included.

#### Maintenance telephone

An IP Phone functions as a maintenance telephone when the CoS is defined as MTA (Maintenance Telephone Allowed) in the Multiline Telephone Administration program (LD 11). A maintenance telephone enables commands to be sent to the system; however, you can enter only a subset of commands from a system terminal. To access the system using the maintenance telephone, a Special Service Prefix (SPRE) code (defined in the Customer Data Block) is entered and followed by 91. To enter commands, press the keys that correspond to the letters and numbers of the command (for example, to enter LD 43 return, press 53#42##).

The following overlays (LDs) are accessible from an IP Phone operating as a maintenance telephone: 30, 32, 33, 34, 36, 37, 38, 41, 43, 45, 46 and 60.

The previous maintenance overlay operations are supported on IP Phones except for the Tone and Digit Switch (TDS) commands of LD 34 and TONE command of LD 46.

#### Faceplate maintenance display codes

The Voice Gateway Media Card maintenance display provides the diagnostic status of the card during powerup, the operational state when in service, and error information about the functional state of the card.

- <u>Table 120: Media Card 32-port card faceplate maintenance display codes</u> on page 404 lists the normal and fault display codes for the Media Card 32-port line card.
- <u>Table 122: Media Card 32 card diagnostic information</u> on page 405 and <u>Table 123: Messages</u> displayed on the LED during <u>Media Card 32S card normal operation</u> on page 406 lists the messages on the faceplate for the Media Card 32S card.

Table 120: Media Card 32-port card faceplate maintenance display codes

Normal code	Fault code	Message	
T:00	F:00	Initialization	
T:01	F:01	Testing Internal RAM	
T:02	F:02	Testing ALU	
T:03	F:03	Testing address modes	
T:04	F:04	Testing watchdog	
T:05	F:05	Testing 8051 coprocessor	
T:06	F:06	Testing timers	
T:07	F:07	Testing external RAM	
T:08	F:08	Testing dongle	
T:09	F:09	Programming timeswitch FPGA	
T:10	F:10	Programming ISPDI FPGA	
T:11	F:11	Testing host dual port RAM	
T:12	F:12	Testing DS-30 dual port RAM	
T:13	F:13	Testing SEEPROM	
T:14	F:14	Booting Host processor, waiting for response with self-test information	
T:15	F:15	Not used	
T:16	F:16	Not used	
T:17	F:17	Not used	
T:18	F:18	Not used	
T:19	F:19	Not used	
T:20	F:20	Waiting for application startup message from Host processor	

Normal code	Fault code	Message	
T:21	F:21	CardLAN enabled, waiting for request configuration message	
T:22	F:22	CardLAN operational, A07 enabled, display now under host control	

Table 121: List of error codes for the Media Card 32-port card

Code	Description	
H:00	Host Processor not booting	
H:01	SDRAM test failure	
H:02	SRAM test failure	
H:04	PC Card device failure	
H:08	Network interface failure	
H:20	DSP interface failure	
H:40	NVRAM or EEPROM interface failure	
H:80	PCM connector failure	

Table 122: Media Card 32 card diagnostic information

Message	Description		
BOOT	Appears when the display becomes active.		
POST	Power On Self Test (POST)		
	Displays while the Media Card 32S card performs hardware system tests during system powerup.		
PASS	Appears when POST passes.		
EXXX	Appears if a serious system error is detected.		
	Error code where XXX is a numeric value.		
LOAD	Appears when application software loads.		

During powerup, the card performs multiple self-tests, including an internal RAM test, a ALU test, address mode test, a boot ROM test, a timer test, and an external RAM test. If a test test fails, the card enters a maintenance loop, and no further processing is possible. A failure message appears to indicate which test failed.

If the other tests fail (up to and including the EEPROM test), a message appears for three seconds. If more than one test fails, the message indicates the first failure. If you select verbose mode (by the test input pin on the backplane), the 3-second failure message does not appear.

If a test fails on the Media Card, F:XX appears on the hexidecimal display for 3 seconds after the T: 13 message (Testing SEEPROM). For example, if the 8051 coprocessor test fails, F:05 appears on the Media Card faceplate. If more that one test fails, the message indicates the first failure.

If the IXP encounters failures during initialization, an H:XX error code appears. <u>Table 121: List of error codes</u> for the Media Card 32-port card on page 405 shows the list of error codes.

When the Media Card 32S card starts, diagnostic information, such as boot status, appears on the faceplate.

In normal operation, the messages appear in the following order:

- BOOT
- POST
- PASS
- LOAD

If a self-test error occurs, an error code appears.

Table 123: Messages displayed on the LED during Media Card 32S card normal operation

Message	Description
Exxx	E indicates an error code when a serious system error is detected, and xxx is a numeric value.
Sxxx	S indicates a system link error code, and xxx is a numeric value.

#### System error messages

When an error or specific event occurs, SNMP agent on the Voice Gateway Media Card sends an alarm trap to any SNMP manager that is configured in the SNMP Manager list in the ITG Card properties. System error message are also written to an error log file.

View the log file in any text browser after you upload it to an FTP host using the LogFilePut command.

ITG and ITS messages incorporate the severity category of the message in the first digit of the four-digit number. Message numbers beginning with 0 do not follow this format.

1 = Critical 2 = Major 3 = Minor 4 = Warning 5 = Cleared (Info) 6 = Indeterminate (Info)

Error messages with a severity category of Critical are displayed on the Voice Gateway Media Card maintenance faceplate display in the form: Gxxx or Sxxx; xxx is the last three digits of the ITG or ITS message. The Signaling Server has no display. Alarms appear in the Signaling Server report log or by way of SNMP on an Alarm browser.

<u>Table 124: Critical ITG Error messages</u> on page 407 lists the critical ITG messages and <u>Table 125:</u> <u>Critical ITS Error messages</u> on page 409 lists the critical ITS messages.

A Voice Gateway Media Card can send all listed alarms. Any alarm that can be sent by the Signaling Server has an X in the Signaling Server column.

For a complete list of other error messages, see *Software Input Output Reference—System Messages, NN43001-712*.

**Table 124: Critical ITG Error messages** 

Maintenance display	Corresponding critical error message	Signaling Server	Description
G000	ITG1000	Х	Card (re)started.
G001	ITG1001	Х	Task spawn failure <name>.</name>
G002	ITG1002	Х	Memory allocation failure.
G003	ITG1003	Х	File IO error <operation> <object> <errno> <errtext>.</errtext></errno></object></operation>
G004	ITG1004	Х	Network IO error <operation> <object> <errno> <errtext>.</errtext></errno></object></operation>
G005	ITG1005	Х	Message queue error <operation> <object> <errno> <errtext>.</errtext></errno></object></operation>
G006	ITG1006	Х	Unexpected state encountered <file> <li><e state="">.</e></li></file>
G007	ITG1007	Х	Unexpected message type <file> <li><msg>.</msg></li></file>
G008	ITG1008	Х	Null pointer encountered <file> <li>Name of pointer.</li></file>
G009	ITG1009	Х	Invalid block <file> <li>Type of block.</li></file>
G010	ITG1010	Х	Unable to locate data block <file> <li>Type of block.</li></file>
G011	ITG1011	Х	File transfer error: <operation> <file> <host></host></file></operation>
G012	ITG1012	Х	Module initialization failure: <modulename></modulename>
G013	ITG1013	_	Ethernet receiver buffer unavailable, packet discarded.
G014	ITG1014	Х	Ethernet carrier: <ifname> <state></state></ifname>
G015	ITG1015		Ethernet device failure: <ifname></ifname>
G017	ITG1017	Х	Invalid or unknown SSD message: <ssdtype> <tn> <msg></msg></tn></ssdtype>
G018	ITG1018	_	Invalid or unknown X12 SSD message <tn> <msg></msg></tn>
G019	ITG1019	_	DSP channel open failure <channel>.</channel>
G020	ITG1020	Х	Configuration error <param/> <value> <reason>.</reason></value>

Maintenance display	Corresponding critical error message	Signaling Server	Description
G021	ITG1021	_	DSP successfully reset <dsp>.</dsp>
G022	ITG1022	_	DSP channel not responding, channel disabled <channel>.</channel>
G023	ITG1023	_	DSP device failure: <dsp> <errnum> <errtext></errtext></errnum></dsp>
G024	ITG1024	_	DSP failure <dsp> <errno> <errtext></errtext></errno></dsp>
G025	ITG1025	_	DSP download: <dsp> <reason></reason></dsp>
G026	ITG1026	_	DSP download retry succeeded <dsp></dsp>
G027	ITG1027	_	DSP memory test: <dsp> <reason></reason></dsp>
G028	ITG1028	Х	Voice packet loss: <channel> &lt; %packetLoss&gt; <direction> <dstaddr></dstaddr></direction></channel>
G029	ITG1029	_	Error in DSP task <file> <li><errno> <errtext>.</errtext></errno></li></file>
G030	ITG1030	_	Allocation failure in DSP memory pool.
G031	ITG1031	Х	Invalid codec number: <codec></codec>
G032	ITG1032	_	Attempt to open a DSP that is already open: <channel></channel>
G033	ITG1033	_	Failed to send data to DSP channel: <channel></channel>
G034	ITG1034	_	DSP channel unexpectedly closed: <channel></channel>
G035	ITG1035	_	Encountered and unexpected open DSP channel, closed it: <channel></channel>
G036	ITG1036	_	Call server communication link: <call ip="" server=""> <up down=""></up></call>
G037	ITG1037	_	Wrong image downloaded. Binary was created for <cardtype> card.</cardtype>
G038	ITG1038	_	IPL logon protection (logon available or locked)
G039	ITG1039	_	Bad DSP channel <channel id=""></channel>
G040	ITG1040	_	Last reset reason for card: <reasonstring> where the reason String can be: Reboot command issued (by software or through CLI); Watchdog Timer Expired; Manual reset; Internal XA problem; or unknown</reasonstring>
G041	ITG1041	X	perceivedSeverity = alarmSeverityWarning

Maintenance display	Corresponding critical error message	Signaling Server	Description
			probableCause = alarmCauseRemoteTransmissionError
G042	ITG1042	_	perceivedSeverity = alarmSeverityWarning probableCause = alarmCauseOutOfMemory

Table 125: Critical ITS Error messages

Maintenance Display	Corresponding Critical Error Message	Signaling Server	Description
S000	ITS1000	Х	VTI function call time-out.
S001	ITS1001	Х	User terminal registration failed. <ip> <hwid> <errno> <errtext>.</errtext></errno></hwid></ip>
S002	ITS1002	Х	Connect service activation error <reason>.</reason>
S003	ITS1003	Х	Duplicate master <node> <ip1> <ip2>.</ip2></ip1></node>
S004	ITS1004	Х	Invalid node ID <ip> <hwid>.</hwid></ip>
S005	ITS1005	Х	Corrupt node ID/TN field <ip> <hwid>.</hwid></ip>
S006	ITS1006	Х	Received corrupt UNIStim message <message dump="">.</message>
S007	ITS1007	Х	Received unknown UNIStim message <message dump="">.</message>
S008	ITS1008	Х	Terminal connection status: <ip> <status>.</status></ip>
S009	ITS1009	Х	Call Server communication link: <state>.</state>
S010	ITS1010	Х	Terminal doesn't support codec: <ip><codec>.</codec></ip>
S011	ITS1011	Х	<pre><ip address="">: Last reset reason for IP Phone:</ip></pre>
S012	ITS1012	Х	User entered the wrong IP Phone Installer Password three times during Branch User Config. The IP Phone is locked out from User Configuration for one hour.
			Action: Wait for the IP Phone to unlock in 1 hour, or use the IPL CLI command clearLockout to unlock the IP Phone.
S013	ITS1013	Х	User entered the wrong Craftsperson Node Level TN Entry Password three times.The IP Phone is locked out.

Maintenance Display	Corresponding Critical Error Message	Signaling Server	Description
			Action: To remove the lock, use LD 32 to disable, and then enable the IP Phone.

#### **Voice Gateway Media Card self-tests**

During powerup, the Voice Gateway Media Card performs diagnostic tests to ensure correct operation. The faceplate RS-232 port on the Voice Gateway Media Card can be used to monitor the progress of these tests. When the processor responds correctly, the controller switches the serial port to provide Card LAN communication and connects the processor with the external RS-232 port.

#### Replace the Media Card CompactFlash

The Media Card must have the CompactFlash card installed in order to be used as a Voice Gateway Media Card. If the CompactFlash card is removed from the Media Card, another CompactFlash card must be installed before you use the Media Card.

If you must remove the CompactFlash card, perform the steps in <u>Removing the CompactFlash</u> on page 410. To reinstall a CompactFlash card, see <u>Installing the CompactFlash card on the Media Card</u> on page 207.

#### Removing the CompactFlash

- Lift the metal clip that holds the CompactFlash card in the socket on the Voice Gateway Media Card.
- 2. Slide the card from the socket and carefully remove the CompactFlash card.
- 3. Return the CompactFlash card to an antistatic package.

# Chapter 20: Voice Gateway Media Card maintenance using Element Manager

#### **Contents**

This chapter contains the following topics:

- Introduction on page 411
- Replace a Voice Gateway Media Card on page 411
- Add another Voice Gateway Media Card on page 412
- Access CLI commands from Element Manager on page 413

#### Introduction

This chapter provides information about the maintenance functions for the Voice Gateway Media Card that you perform in Element Manager.

#### Replace a Voice Gateway Media Card

Replace the Voice Gateway Media Card when the card is removed or when the following conditions occur:

- The Voice Gateway Media Card displays a code of the form F:xx on the faceplate LED following a restart. This code indicates an unrecoverable hardware failure. The card cannot register with the system. The exception is the F:10 code, which indicates that the Security Device is missing from the card.
- The Management (ELAN) network interface or the Voice (TLAN) network interface on the Voice Gateway Media Card failed. This is indicated by failing to show a link pulse on the voice IP interface status LED or on the switch. The maintenance port can also continuously print "InIsa0 Carrier Failure" messages after determining that the hub or switch port and ELAN cable are valid.

A voice channel on the Voice Gateway Media Card has a consistent voice quality fault, such as
persistent noise or lack of voice path, even after resetting the card and retransmitting the card
properties.

#### **Verify Voice Gateway Media Card loadware**

Perform the following steps to verify and upgrade the card loadware.

- 1. Verify the version of the loadware currently installed on the Voice Gateway Media Card. See <a href="Determine Voice Gateway Media Card software version">Determine Voice Gateway Media Card software version</a> on page 249.
- 2. Obtain the latest files from the Avaya Web site. See <u>Software delivery</u> on page 25.
- 3. Upload the loadware files using the File Upload system utility in Element Manager. See <u>Uploading loadware and firmware files</u> on page 250.
- 4. Upgrade the Voice Gateway Media Card software. See <u>Upgrading the card loadware</u> on page 251.
- 5. Restart the Voice Gateway Media Card. See <u>Restarting the Voice Gateway Media Card</u> on page 252.

#### **Add another Voice Gateway Media Card**

Perform the steps in <u>Add another Voice Gateway Media Card to the system</u> on page 412 to add another Voice Gateway Media Card to the system.

#### Add another Voice Gateway Media Card to the system

- 1. Install and cable the Voice Gateway Media Card, as described in <u>Install the hardware components</u> on page 205.
- 2. In the Element Manager navigator, select IP Network > Nodes: Servers, Media Cards.

  The IP Telephony Nodes window appears.
- 3. Select the link for a Node ID.
  - The **Node Details** window appears.
- 4. Select Media Card from the Select to add menu and then click Add .
  - The **New Media Card** window appears.
- 5. Enter the card information.
  - a. Hostname: This is the host name.
  - b. Card TN: Enter the card slot number from 1 to 50.
  - c. **MAC Address:** The MAC address is the Motherboard Ethernet address labeled on the faceplate of the Voice Gateway Media Card.

- d. Embedded LAN (ELAN) IP address: This is the ELAN network interface IP address for the card. Element Manager and the system use this address to communicate with the card.
- e. **Telephony LAN (TLAN) IP address:** This is the TLAN network interface IP address for the card.
- f. Telephony LAN (TLAN) DSP IP address
  - Note:

The DSP daughterboard is a device that is fixed on the main board of the MC32S card. The device requires a TLAN IP address.

6. Click Save.

The **Node Details** window appears.

- 7. Click **Save** on the Node Details window.
- 8. On the **IP Telephony Nodes** window, click the **Status** link associated with the node containing the Voice Gateway Media Card.
- 9. After the transfer is complete, restart the new card.
  - Restart the card to obtain the BOOTP parameters from the Leader and to establish ELAN and TLAN subnet connectivity.
- 10. Perform the steps in <u>Upgrading the card loadware</u> on page 251 to download the most recent software to the Voice Gateway Media Card.
- 11. Perform the steps in Restarting the Voice Gateway Media Card on page 252 to restart the card and run the new software.
- 12. Perform the steps in <u>Upgrading the IP Phone firmware</u> on page 254 to update the card firmware.

#### **Access CLI commands from Element Manager**

To access CLI commands in Element Manager, perform the steps in Access CLI commands from Element Manager.

Avaya Communication Server 1000 (Avaya CS 1000) supports the following command groups for the Media Card 32S:

- General
- System
- Voice Gateway
- Special
- Security

#### Accessing CLI commands for the Media Card 32S

1. In the Element Manager navigator, select IP Network > Maintenance and Reports.

The Node Maintenance and Reports window appears.

- 2. Expand the node containing the Voice Gateway Media Card by clicking the plus sign (+) to the left of the Node ID.
- 3. Click **GEN CMD** associated with the MC32S card.

The **General Commands** window appears.

The line shown on the top of the General Commands window, under **General Commands**, displays the IP address of the MC 32S card.

- 4. Select one of the following CLI command groups from the **Group** list box:
  - General
  - System
  - · Voice Gateway
  - Special
  - Security
- 5. Select the CLI command from the Command list, and click RUN.

The output of the command appears in the text area at the bottom of the General Commands window.

For information about the CLI commands, see *Software Input Output Reference — Maintenance*. NN43001-711.

## Appendix A: NAT router requirements for NAT Traversal feature

#### **Contents**

This section contains the following topics:

- Description on page 415
- Requirements on page 416
- Natcheck output on page 418

#### **Description**

This appendix describes the requirements of a Network Address Translation (NAT) router to enable it to support the NAT Traversal feature.

For a NAT device to work correctly between an IP Phone and the Avaya Communication Server 1000 (Avaya CS 1000) system, the following requirements must be met:

- Use a cone NAT.
- Configure a long time-out period for the Private-to-Public mapping.
- If multiple IP Phones are behind the same NAT router, support hairpinning.
- Keep alive the Private-to-Public mapping created by a NAT router by packets in only one direction (standard in most NAT routers).
- The IP Phone run the correct minimum firmware version (not a NAT device requirement, but still important).

You can confirm most of the issues encountered by using either an IP Phone behind the NAT device or a PC running the third-party natcheck tool.

#### Important:

Avaya is not affiliated in any manner with the natcheck tool, and, therefore is not liable or responsible for problems that you might encounter.

The natcheck tool can be downloaded at no cost from //midcom-p2p.sourceforge.net/. The natcheck tool runs in Windows on a PC connected to the internet through a NAT router.

#### Requirements

#### **Cone NAT**

The NAT Traversal feature cannot work unless the NAT device has a cone NAT implemented.

#### Confirm using natcheck

Run the natcheck program. Look for the following message:

```
UDP consistent translation: YES (GOOD for peer-to-peer)
```

If Yes appears, then the NAT router uses a cone NAT.

#### **Confirm using IP Phone**

The NAT router uses a cone NAT if no error message appears when the IP Phone registers to the system. The NAT device does not use a cone NAT if the IP Phone behind it displays the following error message:

```
NAT Error! ITG3053
Please try upgrading firmware on the NAT device or replacing it with a different NAT device that has a cone NAT implemented.
```

#### **Time-out configuration**

#### Confirm using natcheck

Time-out configuration cannot be performed using natcheck.

#### **Confirm using IP Phone**

If the IP Phone connection times out and the IP Phone restarts, use LD 117 to lower the NAT Keep Alive Timer value on the Call Server. The restarts can indicate that the NAT device address or port mapping is cleared because no message traffic arrives from the IP Phone. By lowering the NAT Keep Alive Timer value in the Call Server, keepalive messages are sent more frequently to keep the mapping alive.

```
>ld 117
->chg nkt 20
```

If lowering the NAT Keep Alive Timer value to the minimum value of 20seconds does not stop the time-outs, try replacing the NAT device.

#### Hairpinning

Hairpinning occurs when an IP Phone behind a NAT router can send packets to the Public IP address and Port of another IP Phone connected to the same NAT router. Determine if hairpinning is supported on the NAT router.

#### Confirm using natcheck

Run the natcheck program. Look for the message:

```
UDP loopback translation: YES (GOOD for peer-to-peer)
```

If this messages prints, then a two-way speech path should be available between two IP Phones behind the NAT device. See Figure 117: Speech path on page 417.




Figure 117: Speech path

#### **Confirm using IP Phone**

Connect two IP Phones to the same NAT device and call from one phone to the other. Confirm that a two-way speech path is achieved during the call.

#### Unidirectional packet flow

#### Confirm using natcheck

The natcheck tool cannot be used to determine if the private-to-public mapping created by the NAT device is being kept alive by a unidirectional packet flow.

#### **Confirm using IP Phone**

If an IP Phone behind a NAT device has a two-way speech path immediately after registration, and continues to have a two-way speech path 2 to 30 minutes later, then the NAT device address or port mapping is kept alive by the packets. If a one-way speech path occurs after this time period, ensure

that the IP Phone has the latest firmware version. If the IP Phone has the most recent firmware, then the problem lies with the NAT device. Try replacing the NAT device with a different model.

If the one-way speech path problem is fixed after restarting the IP Phone, it is likely that the NAT device does not meet the requirement of unidirectional packet flow. As well, ensure that the firmware on the IPPhone has the most recent firmware version (previous firmware versions can be a possible source of problems for the one-way speech path).

#### Firmware versions

The IP Phone must have the correct minimum firmware version.

#### Confirm using natcheck

The natcheck tool cannot be used to determine the IP Phone firmware version.

#### **Confirm using IP Phone**

On the IP Phone, go to the Services, Telephone Options, Set Info menu and scroll down to the FW Version menu item. The minimum firmware versions (based on the vintage of the IP Phone) that support the NAT Traversal feature are as follows:

- IP Phone 2002 and IP Phone 2004: xxxxB64
- Phase II IP Phone 2002 and IP Phone 2004: xxxxD41
- Avaya 2050 IP Softphone: xxxx375

Previous firmware versions do not correctly support the NAT Traversal feature.

#### **Natcheck output**

A NAT router using CONE NAT produces output similar to the following.

```
D: \\natcheck>natcheck -v
server 1: pdos.lcs.mit.edu at 18.26.4.9:9856
server 2: tears.lcs.mit.edu at 18.26.4.77:9856
server 3: sure.lcs.mit.edu at 18.26.4.29:9856
Local TCP port: 1400
Local UDP port: 1401
Request 1 of 20...
Connection to server 2 complete
Server 1 reports my UDP address as 69.156.96.28:57283
Server 2 reports my UDP address as 69.156.96.28:57283
Server 3 reports my UDP address as 69.156.96.28:57283
Connection to server 1 complete
Server 1 reports my TCP address as 69.156.96.28:57281
Connection from 18.26.4.29:9856
Server 3 reports my TCP address as 69.156.96.28:57281
Request 2 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 3 of 20...
```

```
Loopback packet from 69.156.96.28 port 57285
Request 4 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 5 of 20...
Loopback packet from 69.156.96.28 port 57285
Server 2 reports my TCP address as 69.156.96.28:57281
Initiated TCP server 3 connection
Initiated TCP loopback connection
Connection from 69.156.96.28:57289
Loopback received
Request 6 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 7 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 8 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 9 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 10 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 11 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 12 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 13 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 14 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 15 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 16 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 17 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 18 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 19 of 20...
Loopback packet from 69.156.96.28 port 57285
Request 20 of 20...
Loopback packet from 69.156.96.28 port 57285
TCP RESULTS:
TCP consistent translation: YES (GOOD for peer-to-peer)
TCP simultaneous open: YES (GOOD for peer-to-peer)
TCP loopback translation: YES (GOOD for peer-to-peer)
TCP unsolicited connections filtered: NO (BAD for security)
UDP RESULTS:
UDP consistent translation: YES (GOOD for peer-to-peer UDP loopback translation: YES (GOOD for peer-to-peer)
                                   YES (GOOD for peer-to-peer)
UDP unsolicited messages filtered: NO (BAD for security)
```

For the NAT router to support the NAT Traversal feature, natcheck must display the following:

```
UDP consistent translation: YES (GOOD for peer-to-peer)
```

Ye indicates that Cone NAT is used. No indicates that Symmetric NAT is present. Symmetric NAT is not supported.

Near the beginning of the output, the PUBLIC port seen by various servers appears. In this case, all three servers receive the packets from the same PUBLIC port of 57283. <u>Figure 118: Private-to-Public port mapping</u> on page 420shows this Private-to-Public port mapping.




Figure 118: Private-to-Public port mapping

Because all three servers see the same PUBLIC port, the NAT router uses Cone NAT.

# Appendix B: I/O, maintenance, and extender cable description

#### **Contents**

This section contains the following topics:

- Introduction on page 421
- NTMF94EA I/O cable on page 421
- Connector pin assignments on page 422
- NTAG81CA maintenance cable description on page 425
- NTAG81BA maintenance extender cable on page 425
- Replace the NT8D81BA cable on page 426

#### Introduction

This appendix describes the NTMF94EA, NTAG81CA, and NTAG81BA cables and explains how to replace the NT8D81BA backplane ribbon cable, if required.

#### NTMF94EA I/O cable

The NTMF94EA cable provides the ELAN and TLAN network interfaces from the Voice Gateway Media Card to the customer network equipment. This cable has one DB9 serial port that provides serial connection between the card and the customer PC or TTY. See <a href="Figure 119: NTMF94EA">Figure 119: NTMF94EA</a> <a href="ELAN">ELAN</a>, TLAN and RS-232 serial maintenance I/O cable on page 422.

You must use the mounting screw to secure the top of the NTMF94EA cable 25-pair Amphenol connector to the system. The screw ties the LAN cable shield to the Avaya Communication Server 1000 (Avaya CS 1000) frame ground for EMC compliance.

The NTMF94EA cable provides a factory-installed, shielded, RJ-45-to-RJ-45 coupler at the end of both the ELAN and the TLAN network interfaces. An unshielded coupler prevents ground loops (if required). See <u>Prevent ground loops on connection to external customer LAN equipment</u> on

page 424to determine if you use the unshielded coupler. Both ends of the RJ-45 ports of the cables are labeled to distinguish the TLAN network interface and the ELAN network interface. The ports provide the connection point to the customer ELAN and TLAN equipment. Use shielded CAT5 cable to connect to the customer equipment.

To improve EMC performance, use standard cable ties to bundle all LAN cables as they route from the system.

#### Important:

To avoid damage to CAT5 cable, do not overtighten cable ties.




Figure 119: NTMF94EA ELAN, TLAN and RS-232 serial maintenance I/O cable

#### **Connector pin assignments**

<u>Table 126: Voice Gateway Media Card I/O Panel Pinout</u> on page 422 shows the I/O connector pin designations for the Voice Gateway Media Card.

Table 126: Voice Gateway Media Card I/O Panel Pinout

Pin	Normal Assignment	ITG Assignment	Pin	Normal Assignment	ITG Assignment
2	R1	Not Used	26	T0	Not Used
3	R2	Not Used	27	T1	Not Used
4	R3	Not Used	28	T2	Not Used
5	R4	Not Used	29	T3	Not Used
6	R5	AGND	30	T4	AGND

Pin	Normal Assignment	ITG Assignment	Pin	Normal Assignment	ITG Assignment
7	R6	Not Used	31	T5	Not Used
8	R7	Not Used	32	T6	Not Used
9	R8	Not Used	33	T7	Not Used
10	R9	AGND	34	Т8	AGND
11	R10	PGT0	35	Т9	PGT1
12	R11	PGT2	36	T10	PGT3
13	R12	PGT4	37	T11	PGT5
14	R13	PGT6	38	T12	PGT7
15	R14	PGT8	39	T13	PGT9
16	R15	PGT10	40	T14	PGT11
17	R16	SGNDA	41	T15	BDCDA-
18	R17	BSINA-	42	T16	BSOUTA-
19	R18	BDTRA-	43	T17	SGND
20	R19	BDSRA-	44	T18	BRTSA-
21	R20	BCTSA-	45	T19	BSINB-
22	R21	BSOUTB-	46	T20	BDCDB-
23	R22	BDTRB-	47	T21	BDSRB-
24	R23	DI+	48	T22	DI-
25	no connect	DO+	49	T23	DO-
2	R1	no connect	50	no connect	no connect

Table 127: NTMF94EA cable pin description

I/O Panel: P1	Signal Name	P2, P3, P4	Color
P1-21	BSOUTB-	P2-2	Red
P1-22	BDTRB-	P2-4	Green
	SGRND	P2-5	Brown
P1-45	BSINB-	P2-3	Blue
P1-46	BDCDB-	P2-1	Orange
P1-47	BDSRB-	P2-6	Yellow
P1-25	SHLD GRND	_	_
P1-50	SHLD GRND	_	_
P1-18	RXDB+	P4-3	Green/White
P1-19	TXDB+	P4-1	Orange/White
P1-43	RXDB-	P4-6	White/Green

P1-44	TXDB-	P4-2	White/Orange
P1-23	RX+	P3-3	Green/White
P1-24	TX+	P3-1	Orange/White
P1-48	RX-	P3-6	White/Green
P1-49	TX-	P3-2	White/Orange
P1-25	SHLD GRND	_	Bare
P1-50	SHLD GRND	_	Bare

#### Prevent ground loops on connection to external customer LAN equipment

The shielded RJ-45 coupler is the connection point for the customer shielded CAT5 LAN cable to the hub, switch, or router supporting the TLAN and ELAN subnets. Use shielded CAT5 RJ-45 cable to connect to the customer TLAN/ELAN equipment. Perform the steps in Preventing ground loops on page 424 to prevent ground loops when you connect to external customer LAN equipment.

Follow the steps in Preventing ground loops on page 424 to prevent ground loops.

#### **Preventing ground loops**

- 1. Connect the customer-provided shielded CAT5 LAN cable to the external LAN equipment. Ensure that the external LAN equipment is powered up.
- 2. Use an ohmmeter to measure resistance to ground between the free end of the shielded RJ-45 cable and the building ground.

The ohmmeter must measure Open to ground before you plug it into the shielded RJ-45 coupler on the end of the NTMF94EA.

If the ohmmeter does not measure Open, install the unshielded RJ-45 coupler (provided) on the end of the NTMF94EA to prevent ground loops to external LAN equipment.



#### 🔼 Warning:

The serial maintenance ports on the faceplate connector and the DB-9 female connector of the NTMF9DA cable assembly are identical. Do not connect a serial device to both access points simultaneously. This results in incorrect and unpredictable operation of the Voice Gateway Media Card.

#### NTAG81CA maintenance cable description

The NTAG81CA maintenance cable is connected between the nine-pin D-type RS-232 input on a standard PC and the MAINT connector on the NT8R17AB faceplate or through the I/O cable serial port. See Figure 120: NTAG81CA Maintenance cable on page 425.



Figure 120: NTAG81CA Maintenance cable

<u>Table 128: NTAG81CA maintenance cable pin description</u> on page 425describes the NTAG91CA cable pin description.

Table 128: NTAG81CA maintenance cable pin description

Signals (MIX Side)	Eight-pin Mini-DIN (MIX Side) Male	Nine-pin D-Sub (PC Side) Female	Signals (PC Side)
DTRB-	1	6	DSR-
SOUTB-	2	2	SIN-
SINB-	3	3	SOUT-
GND	4	5	GND
SINA-	5	nc	nc
CTSA-	6	nc	nc
SOUTA-	7	nc	nc
DTRA-	8	nc	nc

#### NTAG81BA maintenance extender cable

The NTAG81BA maintenance extender (3 m) cable connects the NTAG81CA cable to a PC or terminal. It has a nine-pin D-type connector at both ends; one male and one female. See <u>Table 129: NTAG81BA Maintenance cable pin description</u> on page 426. The cable can also extend the serial port presented by the NTMF94EA I/O panel cable. The extender cable is shown in <u>Figure 121: NTAG81BA Maintenance Extender cable</u> on page 426.

Table 129: NTAG81BA Maintenance cable pin description

Nine-pin D-Sub (Male)	Nine-pin D-Sub (Female)
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9



Figure 121: NTAG81BA Maintenance Extender cable

#### Replace the NT8D81BA cable

This procedure explains how to replace the NT8D81BA cable with the NT8D81AA cable.

Cables are designated by the letter of the I/O panel cutout, such as A, B, and C, where the 50-pin cable connector is attached. Each cable has three 20-pin connectors (16 positions are used), designated 1, 2, and 3, that attach to the backplane. Using the designations described, the backplane ends of the first cable are referred to as A-1, A-2, and A-3. The locations of the cable connectors on the backplane are designated by the slot number (L0 through L9 for NT8D11, L0 through L15 for NT8D37) and the shroud row (1, 2, and 3). Using these designations, the slot positions in the first slot are referred to as L0-1, L0-2, and L0-3.

In NT8D37BA and NT8D37EC (and later) IPE Modules, all 16 IPE card slots support 24-pair cable connections. <u>Table 130: NT8D37 cable connections</u> on page 426 shows the cable connections from the backplane to the inside of the I/O panel.

Table 130: NT8D37 cable connections

Backplane slots – shroud rows	I/O panel/cable designation
L0-1, 2, 3 L1-1, 2, 3 L2-1, 2, 3 L3-1, 2, 3 L4-1, 2, 3 L5-1, 2, 3 L6-1, 2, 3 L7-1, 2, 3 L8-1, 2, 3 L9-1, 2, 3 L10-1, 2, 3 L11-1, 2, 3 L12-1, 2, 3 L13-1, 2, 3 L14-	
1, 2, 3 L15–1, 2, 3	

<u>Figure 122: Backplane slot designations</u> on page 427 shows the designations for the backplane end of the cables, the backplane slot designations for the cable connections, and the associated network segments for the backplane slots.




Figure 122: Backplane slot designations

#### **Tools list**

The following tools are required to perform this procedure.

- · Ty-wrap cutter
- Ty-wraps
- · Needle nose pliers
- · Slotted screwdriver

#### Remove the NT8D81BA cable

Perform the steps in Removing an NT8D81BA cable on page 427 to remove the NT8D81BA cable.

#### Removing an NT8D81BA cable

- 1. Identify the I/O panel and backplane designation that corresponds to the left slot of the pair of card slots, viewed from the front, in which the ITG ISL Trunk card is installed.
- 2. Disconnect the filter from the I/O panel using a screwdriver and needle nose pliers. Retain the fasteners.
- 3. Power down the IPE shelf.
- 4. Remove the IPE module I/O safety panel.

- 5. To remove the ribbon cables from the IPE backplane, apply gentle pressure on the tab on the right side of the shroud while you pull the connector from the shroud.
- 6. Remove connector 1 first, then remove connectors 2 and 3.
- 7. Discard the NT8D81BA cable.

#### Install the NT8D81AA cable

Perform the steps in <u>Installing an NT8D81AA cable</u> on page 428 to install the NT8D81AA cable.

#### Installing an NT8D81AA cable

- Install the NT8D81AA ribbon cable connectors in the IPE module backplane shroud. Be sure
  you install the connector so the label faces right with the arrow pointing up and the connector
  fully engaged into the shroud:
  - a. Install connector 1, (labeled UP1^) into backplane shroud 1.
  - b. Install connector 2, (labeled UP2<sup>^</sup>) into backplane shroud 2.
  - c. Install connector 3, (labeled UP3<sup>^</sup>) into backplane shroud 3.
- 2. Dress the ribbon cables back individually inside the rear of IPE module and restore the original arrangement. Start with the cables to be underneath.
- 3. Restore power to the IPE module.
- 4. Replace the I/O safety panel.

### **Appendix C: Product integrity**

#### **Contents**

This section contains the following topics:

- Introduction on page 429
- Reliability on page 429
- Environmental specifications on page 430

#### Introduction

This chapter presents information about the Voice Gateway Media Card reliability, environmental specifications, and electrical regulatory standards.

For more information about servers, see *Linux Platform Base and Applications Installation and Commissioning, NN43001-315.* 

#### Reliability

Reliability is measured by the Mean Time Between Failures (MTBF).

#### Mean Time Between Failures (MTBF)

The Mean Time Between Failure (MTBF) is 46 years for Voice Gateway Media Cards. Failures for every 106 hours of operation are 2.483, based on 40 degrees Celcius (140 degrees Fahrenheit).

#### Voice Gateway Media Card power consumption

<u>Table 131: Voice Gateway Media Card power consumption</u> on page 430 shows the worst case current drawn by the Voice Gateway Media Cards from each Backplane voltage supply.

Table 131: Voice Gateway Media Card power consumption

Card Type	Power Consumption
Media Card	+ 15 volt = 6 watts => 0.2 amps
	+5 volt = 7.25 watts => 1.45amps

#### **Environmental specifications**

<u>Table 132: Environmental specifications (maximum)</u> on page 430 shows the environmental specifications of the Voice Gateway Media Card. The Voice Gateway Media Card provides external interface protection to –52 V DC, but does not provide lightning or hazardous voltage protection.

**Table 132: Environmental specifications (maximum)** 

Parameter	Specifications
Operating temperature	0° to +45°C (+32 to +113°F), ambient
Operating humidity	5 to 95% RH (non condensing)
Storage temperature	-20° to +60°C (-4° to +140°F)

Measurements of performance regarding temperature and shock were made under test conditions. <u>Table 133: Environmental specifications (recommended)</u> on page 430 shows recommended temperature and humidity ranges for the Voice Gateway Media Card based on results from this test.

Table 133: Environmental specifications (recommended)

Specification	Minimum	Maximum	
Normal Operation			
Recommended	15°C	30°C	
Relative humidity	20%	55% (non condensing)	
Absolute	10°C	45°C	
Relative humidity	20%	80% (non condensing)	
Short Term (less than 72 hr)	-40°C	70°C	
Rate of change	Less than 1°C for every 3 minutes		

Specification	Minimum	Maximum	
Storage			
Recommended	–20°C	60°C	
Relative humidity	5%	95% (non condensing)	
	-40	-40° C to 70°C, non condensing	
Temperature Shock			
In 3 minutes	-40°C	25°C	
In 3 minutes	70°C	25°C	
	-4	–40° to 70° C, non condensing	

# Appendix D: Subnet Mask Conversion from CIDR to Dotted Decimal Format

#### Introduction

Subnet masks are expressed in Classless InterDomain Routing (CIDR) format, appended to the IP address, such as 10.1.1.1/20. You must convert the subnet mask from CIDR format to dotted decimal format to configure IP addresses.

The CIDR format expresses the subnet mask as the number of bits counting from the most significant bit of the first IP address field. A complete IP address consists of 32 bits. Therefore, a typical CIDR format subnet mask is in the range /9 to /30. Each decimal number field in the dotted decimal format has a value from 0 to 255, where decimal 255 represents binary 1111 1111.

Perform the steps in <u>Converting a subnet mask from CIDR format to dotted decimal format</u> on page 432 to convert a subnet mask from CIDR format to dotted decimal format.

#### Converting a subnet mask from CIDR format to dotted decimal format

- 1. Divide the CIDR format value by 8. The quotient (the number of times that 8 divides into the CIDR format value) equals the number of dotted decimal fields containing 255.
  - In the example 10.1.1.1/20, the subnet mask is expressed as /20. A value of 20 divided by 8 equals a quotient of 2, with a remainder of 4. Therefore, the first two fields of the subnet mask in dotted decimal format are 255.255.
- 2. If a remainder exists, see <u>Table 134: CIDR format remainders</u> on page 432 to obtain the dotted decimal value for the field following the last field containing 255. In the example of /20 above, the remainder is 4. In <u>Table 134: CIDR format remainders</u> on page 432, a remainder of 4 equals a binary value of 1111 0000 and the dotted decimal value of the next and last field is 240. Therefore the first three fields of the subnet mask are 255.255.240.
- 3. If remaining fields exist in the dotted decimal format, they have a value of 0. Therefore, the complete subnet mask in dotted decimal format is 255.255.240.0.

#### Table 134: CIDR format remainders

Remainder of CIDR format value divided by eight	Binary value	Dotted decimal value
1	1000 0000	128

Remainder of CIDR format value divided by eight	Binary value	Dotted decimal value
2	1100 0000	192
3	1110 0000	224
4	1111 0000	240
5	1111 1000	248
6	1111 1100	252
7	1111 1110	254

### Index

Numerics	Digital Signaling Processor (DSP)	
	Digital Signaling Processor daughterboards	29
802.1Q Support <u>1</u>		
911 <u>2</u>	replication of Content Store data between clusters 38	<u>85</u>
	DN Generator33	<u>32</u>
A	DSP daughterboards	<u> 29</u>
A		
add additional cards to the node244, 3	<u>16</u> <b>E</b>	
Automatic IP Phone TN conversion		
Avaya 6120 WLAN Handset		คร
Avaya 6140 WLAN Handset		_
Twaya o 140 WE Ta Tianaset	echoServerShow	
_	echoServerShow 99	
В	EDD	
	Element Manager	
backplanes		
connectors4		
I/O panel connections4	<u>-</u>	<u> </u>
backup <u>3</u>	10	0 =
Back up an IP Phone Application Server database 1		
bandwidth used <u>1</u>		
Basic IP User License		44
blocked calls1	<u>32</u>	
BOOTP parameters4		
Branch Office1	<u>44</u>	
Browser	F	
Internet Explorer1	91 10 code <u>4</u>	<u>11</u>
Mozilla Firefox1	<u>92</u> xx <u>4</u>	<u>11</u>
	FIBN <u>2</u>	<u> 15</u>
С	FIBN, Package 3652	<u> 15</u>
	Firmware	
call attempts and completions1	32 IP Phone <u>1</u> 4	<u>46</u>
Call Statistics		
Card TN		
CHG ES11		
CHG ES2		13
CHG NKT1		
CLI commands, informational4		10
Codec	47	
community string2		
CompactFlash2	ne.	
Configuring a virtual Superloop in Element Manager 2	16 Haldware	
	1 laraware vvatorioog Timer	
Configuring Internet Explorer1		
Configuring Mozilla Firefox	<u>92</u> Hostname	<u>16</u>
connector pin assignments	20	
NT8D02 Digital Line Card4		
connectors 4		
Corporate Directory	. I/O paneis	
CRPA/CRPD <u>2</u>	backplane connections42	26
	informational CLI commands available from Element	
D	Manager4	13
	Internet Explorer 205, 227, 22	
Data Path Capture tool1	Internet Options dialog box	

Internet Telephone Firmware		Network Address Translation	<u>106</u>
IP Ad Hoc Conference		NT8D02 Digital Line Card	
IP Attendant Console (3260)		connector pin assignments	
IP client cookies	<u>55</u>	NT8D37BA IPE Modules	
IPE modules		NT8D37EC IPE Modules	<u>426</u>
cable connections		NT8D37 IPE Modules	
IP Media Services		cable connections	
configuration	<u>364</u>	NT8D81BA cable	
description	<u>346</u>	Numbering Groups	<u>329</u>
licensing	<u>359</u>		
security		0	
IP Music Broadcast		•	
IP Phone configuration data summary sheet	<u>182</u>	operational parameters	281
IP Phone Types	<u>56</u>	operational report	
IP Recorded Announcements	<u>346</u>		
IP Tone Generation	<u>346</u>	_	
IP User License	<u>43</u>	P	
isetGet	<u>115</u>	D. J 005	045
isetReset	<u>114</u>	Package 365	
isetScpwModify	114	port 5200	
isetScpwQuery	114	Private Zone	
isetScpwVerify		PRT ES1	
,		PRT ES2	
17		PRT ESS	
K		PRT ZONE	
Koon Alivo Time out actting	110	PRT ZONE ALL	
Keep Alive Time-out setting	<u>112</u>	PUBLIC RTCP port number PWD1	
Language synchronization		Q	400
License		QoS	
Live Dialpad		Quality of Service	<u>132</u>
InIsa0 Carrier Failure			
illisad Carrier i allure	<u>411</u>	R	
M		reliability	429
Marcal ID Division TN and a	==	replication of Content Store data	
Manual IP Phone TN conversion		enabling	<u>385</u>
Mapping	<u>107</u>	replication of Content Store data between clusters	
MAS servers		disabling	<u>385</u>
Content Store replication	<u>384</u>	Restore the IP Phone Application Server database	<u>197</u>
mean time between failures			
Media Card 32 card		e	
Media Card 32S card	<u>38</u>	S	
Media Services Routing Number		Security Device is missing	411
description		Software Deployment Packages	
Mozilla Firefox		superloop	
Mute		заропоор	······ <u>42</u>
MVC 205048, <u>131</u> , <u>141</u> , <u>225</u>	5, <u>238</u> , <u>262</u>	т	
N			
14		temperature specifications	
NAT	107. 108	Temporary IP User License	
NAT Keep Alive timeout setting		Traffic printouts	<u>132</u>
NAT Mapping Keep Alive			
NAT Mapping Keep Alive Time-out setting			

#### Index

#### U

Unicode support	<u>411</u>
V	
Virtual Office	42, 215 216 215 110 110
w	
WLAN Handset 2210	<u>141</u> <u>43</u> , <u>48</u> <u>43</u> , <u>48</u>
WLAN Handset 6140	